

3D SYNTHETIC  
VISION EFIS

HIGHWAY-  
IN-THE-SKY  
NAVIGATION

GRAPHICAL  
FLIGHT  
MANAGEMENT  
SYSTEM

INTEGRATED  
AUDIO/RADIO  
MANAGEMENT



# IDU-680 Version 8.0D Pilot Guide (Fixed Wing)

# Pilot Operating Guide and Reference

Document 64-000099-080D

(Fixed Wing)

Software Version 8.0D

© 2016

Genesys Aerosystems

All Rights Reserved

No part of this document may be reproduced in any form, or by any means, without prior written consent of Genesys Aerosystems.

FlightLogic and Virtual VFR are trademarks of Genesys Aerosystems.

All other brand names and trademarks are the property of their respective holders.

One S-TEC Way, Municipal Airport, Mineral Wells TX. 76067

Phone: (800) 872-7832 Fax: (940) 325-3904

*[www.genesys-aerosystems.com](http://www.genesys-aerosystems.com)*



## Table of Contents

Section 1	Introduction .....	1-1
1.1.	Introduction .....	1-5
1.2.	EFIS/FMS Description .....	1-6
1.3.	Run Demonstrator/Training Application .....	1-9
1.4.	EFIS Training Tool.....	1-11
1.5.	About This Guide .....	1-11
Section 2	System Overview .....	2-1
2.1.	Abbreviations and Acronyms.....	2-4
2.2.	System Overview.....	2-15
2.2.1.	IDU Initialization .....	2-15
2.2.2.	Application Software Air Mode and Ground Mode .... .....	2-19
2.3.	General Arrangement .....	2-19
2.4.	EICAS Display .....	2-20
2.4.1.	PFD with EICAS .....	2-22
2.5.	HSI with MAP .....	2-23
2.6.	Color Conventions .....	2-23
2.7.	Warning/Caution/Advisory System .....	2-25
2.8.	Database and Software Updates .....	2-54
2.8.1.	Navigation and Obstruction Databases .....	2-54
2.8.2.	Update Requirements.....	2-55
2.8.3.	Terrain Database Update .....	2-58
Section 3	Display Symbology .....	3-1
3.1.	Introduction .....	3-12
3.2.	Application Software Air Mode and Ground Mode .....	3-12

3.3.	IDU-680 PFD Display (Normal Mode).....	3-13
3.3.1.	IDU-680 PFD Display (Essential Mode).....	3-14
3.3.2.	IDU-680 PFD Display (Basic Mode).....	3-15
3.3.3.	IDU-680 MFD Display (Normal Mode) .....	3-16
3.3.4.	IDU-680 MFD Display (Essential Mode) .....	3-17
3.3.5.	IDU-680 MFD Display (Normal Mode) with EICAS ... .....	3-18
3.4.	Menu Functions.....	3-18
3.4.1.	Selecting BARO .....	3-19
3.4.2.	Selected Altitude Sub-Mode (Target Altitude)....	3-21
3.4.3.	VNAV Sub-Mode .....	3-22
3.4.4.	Altitude Display (VNAV Tile) .....	3-23
3.4.5.	Altitude Display (Metric Units) .....	3-24
3.5.	PFD Symbology .....	3-24
3.5.1.	Minimum Altitude.....	3-25
3.5.2.	Vertical Speed Indicator .....	3-26
3.5.3.	Normal AGL Indication .....	3-28
3.5.4.	Analog AGL Indication.....	3-29
3.5.5.	Decision Height .....	3-30
3.5.6.	Airspeed Display .....	3-31
3.5.7.	Airspeed Display (With EFIS-Coupled).....	3-36
3.5.8.	Heading Display .....	3-36
3.5.9.	Pitch Scale .....	3-38
3.5.10.	Pitch Limit Indicator .....	3-39
3.5.11.	G-Force and Fast/Slow Indicator .....	3-40
3.5.12.	Basic Mode.....	3-41

3.5.13.	Unusual Attitude Mode .....	3-42
3.5.14.	PFD Background .....	3-43
3.5.15.	Flight Path Marker (Velocity Vector).....	3-48
3.5.16.	Bank Angle Scale .....	3-50
3.5.17.	Turn Indication .....	3-50
3.5.18.	Timer Indication .....	3-51
3.5.19.	Marker Beacon Symbology .....	3-51
3.5.20.	Flight Director Symbology (FD1 Single Cue) .....	3-51
3.5.21.	Flight Director Symbology (FD2 Dual Cue) .....	3-52
3.5.22.	Course Deviation Indicator .....	3-53
3.5.23.	OBS Setting of CDI.....	3-55
3.5.24.	Heading/Roll-Steering Sub-Mode.....	3-55
3.5.25.	Vertical Deviation Indicator.....	3-55
3.5.26.	Vertical Deviation Indicator (EFIS Coupled) .....	3-58
3.5.27.	Highway in the Sky/Skyway.....	3-59
3.5.28.	Active Waypoint and Waypoint Identifier .....	3-59
3.5.29.	Mini Map .....	3-60
3.5.30.	Runways.....	3-62
3.5.31.	Traffic Thumbnail .....	3-63
3.5.32.	Traffic Display Definitions .....	3-64
3.5.33.	Traffic Rendering Rules.....	3-64
3.6.	Fully Integrated Autopilot Annunciations .....	3-66
3.7.	Navigation Display Symbology .....	3-70
3.7.1.	Basic Moving Map .....	3-71
3.7.2.	Ownship Symbology.....	3-71
3.7.3.	Moving Map with Instrument Approach .....	3-72

3.7.4.	North-Up Arc Mode .....	3-72
3.7.5.	North-Up Centered Mode .....	3-73
3.7.6.	Heading-Up Centered Mode .....	3-73
3.8.	Conventional HSI/PTR Format.....	3-74
3.8.1.	Compass Rose Symbols .....	3-75
3.8.2.	Fuel Totalizer/Waypoint Bearing and Distance Functions .....	3-76
3.8.3.	Clock/Timers/Options .....	3-78
3.9.	Navigation Log .....	3-80
3.9.1.	Clock and Groundspeed .....	3-80
3.9.2.	Fuel Remaining and Fuel Flow Data .....	3-80
3.9.3.	Waypoint Identifier Column .....	3-80
3.9.4.	VNAV and VNAV Offset Column.....	3-82
3.9.5.	Path Column.....	3-82
3.9.6.	Distance Column .....	3-83
3.9.7.	Estimated Time Enroute Column .....	3-83
3.9.8.	Estimated Time of Arrival Column.....	3-83
3.9.9.	Fuel Remaining Column.....	3-84
3.10.	Start Point.....	3-84
3.11.	Altitude Capture Predictor .....	3-84
3.11.1.	Top of Descent .....	3-84
3.12.	Projected Path.....	3-85
3.13.	Active Flight Plan Path/Manual Course/Runways.....	3-86
3.14.	FOV Indication.....	3-87
3.15.	Range.....	3-87
3.16.	Navigation Data.....	3-88



- 3.16.1. Air Data and Groundspeed .....3-90
- 3.16.2. Analog Navigation Symbology .....3-91
- 3.16.3. Borders .....3-92
- 3.16.4. Terrain/Obstructions .....3-92
- 3.17. Pan Mode .....3-95
- 3.18. HSI Screen .....3-96
  - 3.18.1. HSI Screen VDI .....3-96
  - 3.18.2. Analog Navigation Symbology .....3-97
  - 3.18.3. Air Data and Groundspeed .....3-99
  - 3.18.4. Clock/Timers/Options .....3-100
  - 3.18.5. Fuel Totalizer/Waypoint Bearing and Distance Functions .....3-101
- 3.19. WX-500 Data .....3-101
  - 3.19.1. Strike Screen Range .....3-102
  - 3.19.2. Active Flight Plan Path/Manual Course/Runways .....3-103
- 3.20. Dedicated Traffic Screen .....3-104
  - 3.20.1. Ownship Symbol .....3-104
  - 3.20.2. Traffic Screen Range .....3-105
  - 3.20.3. Compass Rose Symbols .....3-105
  - 3.20.4. Active Flight Plan Path/Manual Course/Runways .....3-106
- 3.21. Datalink Symbology .....3-107
  - 3.21.1. Datalink Screen Legend .....3-112
  - 3.21.2. Air Data and Groundspeed .....3-112
  - 3.21.3. Clock/Timers/Options .....3-112
  - 3.21.4. Datalink Screen Orientation .....3-117

3.21.5.	Datalink Screen Range .....	3-118
3.21.6.	Boundary Circle Symbols .....	3-118
3.21.7.	Active Flight Plan Path/Manual Course/Runways..... .....	3-119
3.21.8.	Borders .....	3-119
3.21.9.	Pan Mode .....	3-120
3.22.	Weather Radar .....	3-120
3.22.1.	Weather Screen Format .....	3-121
3.22.2.	Weather Screen Range .....	3-122
3.22.3.	Track Line .....	3-123
3.22.4.	Active Flight Plan Path/Manual Course/Runways..... .....	3-123
3.22.5.	Weather Radar Return Data .....	3-124
3.22.6.	Air Data and Groundspeed .....	3-126
3.22.7.	Clock/Timers/Options .....	3-126
3.22.8.	Fuel Totalizer/Waypoint Bearing and Distance Functions .....	3-129
3.23.	Video Input Screen.....	3-129
3.23.1.	ZOOM Level .....	3-130
3.23.2.	Pan Mode .....	3-130
3.23.3.	Video Input Status Display .....	3-131
Section 4	Reversionary Modes .....	4-1
4.1.	Reversionary Modes .....	4-7
4.2.	System Operation in Reversionary Modes .....	4-8
4.2.1.	OAT Sensor Failure Mode .....	4-11
4.2.2.	Heading Failure Mode .....	4-11
4.2.3.	PFD Screen Auto Reversion .....	4-11

- 4.2.4. EICAS Screen Single-Action Reversion .....4-12
- 4.2.5. GPS Failure .....4-12
- 4.3. PFD Failure Mode 0 (Normal Mode) .....4-15
  - 4.3.1. MFD Failure Mode 0 (Normal Mode).....4-17
- 4.4. PFD Failure Mode 1 (Normal Mode) .....4-19
  - 4.4.1. PFD Failure Mode 1 (Essential Mode) .....4-21
  - 4.4.2. MFD Failure Mode 1 (Normal Mode).....4-23
- 4.5. PFD Failure Mode 2 (Normal Mode) .....4-25
  - 4.5.1. MFD Failure Mode 2 (Normal Mode).....4-27
  - 4.5.2. MFD Failure Mode 2 (Essential Mode).....4-29
- 4.6. PFD Failure Mode 3 (Normal Mode) .....4-31
  - 4.6.1. MFD Failure Mode 3 (Normal Mode).....4-33
- 4.7. PFD Failure Mode 4 (Normal Mode) .....4-35
  - 4.7.1. MFD Failure Mode 4 (Normal Mode).....4-37
  - 4.7.2. MFD Failure Mode 4 (Essential Mode).....4-39
- 4.8. PFD Failure Mode 5 (Normal Mode) .....4-41
  - 4.8.1. MFD Failure Mode 5 (Normal Mode).....4-43
  - 4.8.2. MFD Failure Mode 5 (Essential Mode).....4-45
- 4.9. PFD Failure Mode 6 (Normal Mode) .....4-47
  - 4.9.1. MFD Failure Mode 6 (Normal Mode).....4-49
  - 4.9.2. MFD Failure Mode 6 (Essential Mode).....4-51
- 4.10. PFD Failure Mode 7 (Normal Mode) .....4-53
  - 4.10.1. MFD Failure Mode 7 (Normal Mode).....4-55
  - 4.10.2. MFD Failure Mode 7 (Essential Mode).....4-57
- Section 5 Menu Functions and Step-By-Step Procedures .....5-1
  - 5.1. Menu Functions .....5-10

5.2.	Menu Synchronization.....	5-10
5.3.	Menu Function Types.....	5-13
5.4.	Top-Level Menu .....	5-14
5.4.1.	IDU-680 PFD Normal Mode Top-Level Menu....	5-14
5.5.	IDU-680 MFD Normal Mode Top-Level Menu .....	5-15
5.6.	IDU-680 PFD or MFD Essential Mode Top-Level Menu... .....	5-16
5.6.1.	Top-Level Menu Option Descriptions.....	5-16
5.6.2.	#1 Encoder (●) .....	5-18
5.6.3.	Top-Level Menu Automatic Pop-up Function Descriptions .....	5-19
5.7.	First Page (PFD) .....	5-27
5.7.1.	PFD Page First-Level Option Descriptions .....	5-28
5.7.2.	First Level (MFD).....	5-29
5.7.3.	First Level (PFD IDU#1) Normal Mode .....	5-30
5.7.4.	First Level (MFD IDU other than #1) Normal Mode .. .....	5-31
5.7.5.	MFD Page First-Level Option Descriptions.....	5-32
5.7.6.	IDU-680 EICAS Page First-Level in Essential Mode .....	5-33
5.7.7.	PFD Page in Top Area and Essential Mode EICAS Page in Bottom Area.....	5-34
5.7.8.	First-Level Menu of an MFD (IDU Other Than #1) in Normal Mode .....	5-35
5.7.9.	EICAS Page First-Level Option Descriptions.....	5-35
5.8.	EICAS Exceedance Menu.....	5-36
5.9.	Expand CAS Menu.....	5-36
5.9.1.	Expand CAS Menu (Step-By-Step).....	5-37

- 5.10. Lower-Level Menus (Below First-Level) .....5-38
- 5.11. Flight Plan (FPL) Menu.....5-39
  - 5.11.1. Flight Planner Page .....5-39
  - 5.11.2. PFD Page Shown on IDU .....5-40
  - 5.11.3. No PFD Page Shown on IDU .....5-40
  - 5.11.4. To Create an Overfly User Waypoint.....5-41
  - 5.11.5. Flight Plan (FPL) Menu Selecting (Step-By-Step).....5-41
  - 5.11.6. Flight Plan (FPL) Menu Create-Edit (Step-By-Step) . .....5-42
  - 5.11.7. Activate Flight Plan (Step-By-Step) .....5-45
  - 5.11.8. Edit Flight Plan (Step-By-Step).....5-46
  - 5.11.9. Reverse Flight Plan (Step-By-Step) .....5-47
  - 5.11.10. Delete Flight Plan (Step-By-Step) .....5-48
  - 5.11.11. Create User Waypoint (LAT-LON) (Step-By-Step) .....5-49
  - 5.11.12. Create User Waypoint (RAD-DST) (Step-By-Step) .....5-52
  - 5.11.13. Delete User Waypoint (Step-By-Step).....5-54
  - 5.11.14. RAIM Prediction.....5-56
- 5.12. Active Flight Plan (ACTV) Menu .....5-58
  - 5.12.1. Main Menu .....5-58
  - 5.12.2. Active Flight Plan (ACTV) Menu Options .....5-63
- 5.13. Active Flight Plan (ACTV) Menu Options .....5-68
  - 5.13.1. Active Flight Plan (ACTV) Menu (Step-By-Step)5-69
  - 5.13.2. Active Flight Plan (ACTV) Options NRST Menu Option (Step-By-Step).....5-70
- 5.14. Information (INFO) Menu.....5-71

5.14.1.	Information (INFO) Menu (Step-By-Step) .....	5-74
5.15.	Omnibearing Selector (OBS) Menu .....	5-75
5.15.1.	Omnibearing Selector (OBS) Menu (Step-By-Step) . .....	5-76
5.16.	Heading Bug (HDG) Menu .....	5-77
5.16.1.	Heading Bug (HDG) Menu (Step-By-Step) .....	5-77
5.17.	Nearest (NRST) Menu .....	5-78
5.17.1.	Nearest (NRST) Menu (Step-By-Step).....	5-81
5.17.2.	Nearest (NRST) Menu ILS .....	5-82
5.18.	Direct Menu .....	5-82
5.18.1.	Direct Menu (Step-By-Step) .....	5-84
5.19.	Timer (TIMER) Menu.....	5-85
5.19.1.	Timer (TIMER) Menu (Step-By-Step).....	5-86
5.20.	PFD Source (SOURCE) Menu .....	5-87
5.21.	PFD Bug (BUGS) Menu .....	5-88
5.21.1.	PFD Bug (BUGS) Menu (Step-By-Step) .....	5-91
5.22.	Remote Bugs Panel .....	5-93
5.23.	PFD Declutter (DCLTR) Menu .....	5-97
5.23.1.	PFD Declutter (DCLTR) Menu (Step-By-Step)	5-100
5.24.	PFD Altimeter Menu .....	5-101
5.24.1.	PFD Altimeter Menu (Step-By-Step) .....	5-102
5.25.	MFD Fault Display (FAULTS) Menu .....	5-103
5.25.1.	MFD Fault Display (FAULTS) Menu (Step-By-Step) .....	5-106
5.26.	MFD FUEL Totalizer Quantity Setting (SET FUEL) Menu .....	5-107
5.27.	MFD Page (PAGE) Menu.....	5-108

- 5.27.1. MFD Page (PAGE) Menu (Step-By-Step) .....5-109
- 5.27.2. MFD MAP ND Page .....5-110
- 5.27.3. MFD HSI Page.....5-110
- 5.27.4. MFD NAV Log Page .....5-111
- 5.27.5. MFD ND Page Format (FORMAT) Menu .....5-112
- 5.27.6. MFD HSI Pointer (PTRS) Menu .....5-115
- 5.27.7. MFD Traffic Format (FORMAT) Menu.....5-116
- 5.27.8. MFD Datalink Format (FORMAT) Menu.....5-117
- 5.27.9. MFD Video Input Format (FORMAT) Menu ....5-119
- 5.27.10. MFD Video Input Format (FORMAT) Menu Center Rotary Encoder Controls .....5-121
- 5.27.11. MFD ND Page Format Menu .....5-122
- 5.27.12. MFD ND Page Format (FORMAT) Menu (Step-By-Step) .....5-125
- 5.28. MFD HSI Pointer (PTRS) Menu .....5-125
  - 5.28.1. MFD HSI Pointer (PTRS) Menu (Step-By-Step) .....5-126
  - 5.28.2. MFD Strike Format (FORMAT) Menu.....5-126
- 5.29. Audio/Radio (AR) Page Menu .....5-127
  - 5.29.1. AR Tune.....5-127
  - 5.29.2. AR Expand Page .....5-130
  - 5.29.3. AR Expand Page First-Level Options.....5-130
  - 5.29.4. AR Expand Page Second-Level Options .....5-131
- 5.30. Audio/Radio Controls.....5-134
  - 5.30.1. Audio/Radio Controls (Step-By-Step).....5-134
- Section 6 Quick Start Tutorial .....6-1
- Section 7 IFR Procedures.....7-1

7.1.	IFR Procedures .....	7-6
7.2.	Overview of Approaches .....	7-6
7.2.1.	Vertical Deviation Indicator Linear Limits .....	7-8
7.2.2.	Highway in the Sky (Skyway) .....	7-8
7.2.3.	Waypoint Sequencing .....	7-14
7.2.4.	Fly-Over Waypoints .....	7-15
7.2.5.	Fly-By Waypoints .....	7-17
7.2.6.	Direct-To .....	7-21
7.3.	Magnetic Course .....	7-22
7.3.1.	AHRS Modes for Heading Source .....	7-22
7.3.2.	GPS Altitude .....	7-23
7.3.3.	Dead Reckoning .....	7-23
7.3.4.	Geodesic Path Computation Accuracy .....	7-23
7.3.5.	Parallel Offsets .....	7-23
7.4.	Default GPS/SBAS Navigation Modes .....	7-25
7.5.	GPS/SBAS CDI Scale .....	7-28
7.6.	Approach Type Selection .....	7-29
7.6.1.	Approach Path Definition .....	7-31
7.7.	VTF IFR Approach .....	7-32
7.8.	VTF VFR Approach .....	7-32
7.9.	Missed Approach and Departure Path Definition .....	7-33
7.10.	Loss of Navigation Monitoring .....	7-34
7.11.	Discontinuities .....	7-34
7.12.	Selection of an Instrument Procedure .....	7-35
7.12.1.	Standard Terminal Arrival Route (STAR) .....	7-36
7.12.2.	ILS Instrument Approach .....	7-39



- 7.12.3. LOC Back Course Instrument Approach .....7-43
- 7.12.4. RNAV (GPS) Instrument Approach to LPV Minima...  
.....7-47
- 7.12.5. NRST ILS Instrument Approach .....7-50
- 7.12.6. VOR/DME Instrument Approach .....7-53
- Section 8 Terrain Awareness Warning System .....8-1
  - 8.1. TAWS (Terrain Awareness and Warning System) Functions.....8-5
    - 8.1.1. Terrain Display.....8-6
  - 8.2. Forward Looking Terrain Alert Function .....8-7
    - 8.2.1. FLTA Modes .....8-8
    - 8.2.2. GPS/SBAS Navigation Mode Slaving.....8-8
    - 8.2.3. Default FLTA Mode .....8-8
  - 8.3. FLTA Search Envelope .....8-10
    - 8.3.1. FLTA Search Volume .....8-12
    - 8.3.2. FLTA Alerts and Automatic Popup .....8-12
  - 8.4. Premature Descent Alert Function .....8-14
  - 8.5. Excessive Rate of Descent (GPWS Mode 1) .....8-15
  - 8.6. Excessive Closure Rate to Terrain (GPWS Mode 2) .8-17
  - 8.7. Sink Rate after Takeoff or Missed Approach (GPWS Mode 3) .....8-19
  - 8.8. Flight into Terrain When Not in Landing Configuration (GPWS Mode 4).....8-20
  - 8.9. Excessive Downward Deviation from an ILS Glideslope (GPWS Mode 5).....8-22
  - 8.10. 500-Foot Wake-Up Call .....8-24
  - 8.11. External Sensors and Switches .....8-24
  - 8.12. TAWS System Basic Parameter Determination .....8-25

8.13.	TAWS Automatic Inhibit Functions (Normal Operation)....	8-31
8.13.1.	TAWS Automatic Inhibit Functions (Abnormal Operation).....	8-31
8.13.2.	TAWS Manual Inhibit Functions.....	8-34
8.14.	TAWS Selections on PFD.....	8-34
Section 9	Appendix.....	9-1
9.1.	Appendix.....	9-5
9.2.	Operating Tips.....	9-5
9.3.	Domestic or International Flight Planning.....	9-5
9.3.1.	Descent Planning.....	9-5
9.3.2.	Terrain Clearance.....	9-5
9.3.3.	Departure Airport Information.....	9-6
9.3.4.	Unique Names for Flight Plans.....	9-6
9.3.5.	Altimeter Settings.....	9-6
9.3.6.	Warnings, Cautions, and Advisories.....	9-6
9.4.	Magnetic vs. True North Modes of Operation.....	9-7
9.5.	Altitude Miscompare Threshold.....	9-8
9.6.	Airspeed Miscompare Threshold.....	9-9
9.7.	Jeppesen NavData Chart Compatibility.....	9-11
9.8.	ARINC 424 Path-Terminator Leg Types.....	9-12
9.9.	Data Logging and Retrieval.....	9-17
9.10.	Log Files.....	9-18
9.10.1.	Delete LOG Files.....	9-18
9.11.	Routes and Waypoints.....	9-18
9.11.1.	VFR Flight Planning.....	9-18
9.11.2.	Download Routes and User Waypoints.....	9-19

- 9.12. EFIS Training Tool (ETT) .....9-19
- 9.13. Upload Routes and User Waypoints .....9-19
  - 9.13.1. Delete Routes .....9-19
  - 9.13.2. Upload Routes and User Waypoints .....9-19
  - 9.13.3. Delete Routes .....9-20
- 9.14. USB External Drive Memory Limitations .....9-20
- 9.15. Service Difficulty Report .....9-21
- 9.16. Certification Basis .....9-22
- 9.17. Environmental Requirements .....9-24

INDEX

GLOSSARY

# Section 1 Introduction

## Revision Record

Rev	Notes	Date	Author

## Table of Contents

SECTION 1	INTRODUCTION .....	1-1
1.1.	INTRODUCTION .....	1-5
1.2.	EFIS/FMS DESCRIPTION.....	1-6
1.3.	RUN DEMONSTRATOR/TRAINING APPLICATION .....	1-9
1.4.	EFIS TRAINING TOOL .....	1-11
1.5.	ABOUT THIS GUIDE.....	1-11

## List of Figures

FIGURE 1-1: IDU-680 INPUT IDENTIFICATION .....	1-6
FIGURE 1-2: IDU-680 PRIMARY FLIGHT DISPLAY (PFD).....	1-8
FIGURE 1-3: IDU-680 MULTIFUNCTION DISPLAY (MFD) .....	1-9
FIGURE 1-4: RUN DEMONSTRATOR/TRAINING APPLICATION.....	1-10

## 1.1. Introduction

In the last two decades, aviation has become more and more complex; as a result, cockpit resources have followed the commercial carriers' trend toward "automation centered" systems. These sophisticated systems minimize pilot involvement and automate control of the aircraft and its systems to the greatest extent possible, thereby relegating the pilot to the role of manager and emergency backup. Examples are flight directors and fly-by-wire systems where the pilot is removed from the information loop.

The Genesys Aerosystems EFIS installed in this airplane was conceived and designed as a "pilot-centered" system. While still highly automated, this type of system, common in other military tactical applications, presents the pilot with information necessary to make decisions about the flight and take the appropriate actions. A good example is the Highway-In-The-Sky (HITS), which allows for highly automated approaches, but its predictive nature provides the pilot unprecedented awareness of upcoming maneuvers. Contrary to the traditional idea of overloading the pilot with information and options, this Genesys Aerosystems EFIS clearly and concisely presents only necessary information. This reduces pilot workload while greatly decreasing task complexity as it minimizes confusion. The result is safer flying with less stress and fatigue.

The Genesys Aerosystems EFIS Flight Logic goal is IFR-VFR equivalence, and the basic concept of the FlightLogic EFIS is proven HUD symbology overlaying a real-time 3-D virtual reality view of the outside world. The resulting "synthetic vision" provides the pilot in IMC with the same simple visual clues for navigation and aircraft control as those used in VFR conditions. This "virtual VFR" eliminates the need to scan multiple instruments for aircraft control or mentally interpret complicated enroute and approach procedures. As experience is gained with this complex integrated system, each pilot will fly with more precision, awareness, and confidence.



## 1.2. EFIS/FMS Description



**Figure 1-1: IDU-680 Input Identification**

The IDU (Integrated Display Unit) is manufactured from machined, anodized aluminum and has 16 pushbuttons along the vertical sides numbered L1 through L8 starting at the top left corner of the display moving down from a pilot's perspective and R1 through R8 from the top right corner moving down the display.

There are four encoders along the bottom with the left encoder only controlling the backlighting intensity. This encoder has a unique set of messages interpreted by the backlight controller for setting the backlight intensity.

The remaining three encoders from right to left across the bottom of the bezel are designated encoder **1**, **2**, and **3**. References in Section 5 Menu Functions and Step-By-Step Procedures refer to these as which encoder to push and/or scroll for desired outcomes. Between the two center encoders on the bezel, a USB port with provisions for a slip indicator or blank housing act as a movable door. When this door is lifted, an optical switch initiates the Ground Maintenance Mode necessary for gaining access to the maintenance program once a USB memory device is inserted.

The IDU bezel includes an ambient light sensor located on the front face to measure ambient light levels. This is used only to set backlight illumination levels. The brightness control independently controls the panel lighting brightness and display lighting brightness. Panel lighting refers to the illumination of legends, encoders, and buttons (push and scroll clockwise to increase and counter clockwise to decrease). Display lighting refers to the illumination of the LCD display (without pushing and as described with panel lighting). This lighting may be controlled locally or remotely with a default state being with the local control.

**NOTE:**

If attempting to enter the Ground Maintenance mode with bright light shining directly on the display, shield the light sensor if necessary.



Figure 1-2: IDU-680 Primary Flight Display (PFD)





Figure 1-3: IDU-680 Multifunction Display (MFD)

### 1.3. Run Demonstrator/Training Application

Using the built in Demonstration Application, the EFIS may be used to fly anywhere in the world while performing any procedure (except takeoff and landing) based on the current Jeppesen navigation database. To use this feature:

- 1) With power off, lift the USB Memory Flash Door. Insert a USB flash memory storage device in the IDU lower bezel.
- 2) Power the system on and use encoder **1** (scroll and push to enter) to select the **RUN DEMONSTRATION/TRAINING APPLICATION** option.



**Figure 1-4: Run Demonstrator/Training Application**

The demonstrator allows the pilot to gain familiarity of the EFIS menu structure and location of button tiles for each operation. Load an instrument procedure prior to take off to view the sequence of events to be expected with the aircraft flying the same speeds normally flown as read from the preset limits.

The demonstrator program automatically begins flying over Reno, Nevada, USA. The altitude begins at approximately 7900' MSL and may be changed with the use of the menu and target altitude control. The airspeed remains relatively constant but may be controlled through the use of the Airspeed IAS bug in the BUGS menu. The simulated aircraft may be positioned anywhere in the world due to the worldwide terrain database loaded in the system by activating a flight plan stored in the memory. However, the Jeppesen navigation database must be updated to match the area of the world navigation as anticipated since worldwide terrain is loaded.

All appropriate navigation signals are simulated, allowing for precision and non-precision instrument approaches found within the current navigation database. All obstructions in the latest Obstruction database and all Caution, Warning, and Advisory System aural and flag annunciations are presented as appropriate during the simulated demonstration flights. During operation in this mode, each IDU operates independently of all sensors, Remote Bugs panel, and other displays.

In addition to the demonstrator program, a training tool is available to load on a personal computer for purposes of flying like the aircraft.

## 1.4. EFIS Training Tool

The EFIS Training Tool (ETT) is an application entirely based on the EFIS code and is compatible with 32- or 64-bit versions of Microsoft Windows®. It serves as a multi-purpose tool for training pilots and provides features to record and capture images. This tool may be used to create routes and user waypoints for saving and uploading into the aircraft mounted IDUs. The ETT has a bezel with simulated buttons and encoders responsive to mouse and external keyboard messages. Bezel graphics are derived from actual bezel design data, and the ETT presents an active display with 1:1 pixel correspondence to an actual IDU display. The audio output capability for the ETT matches the audio functionality in the actual IDU. This Training Tool simulates the functionalities of the IDU-680, which begins flight in Reno, Nevada at approximately 7900' MSL. An alternate method of Training Tool initialization is available at any altitude, speed, and wind conditions anywhere in the world through the simulate.ini program loaded into the computer root directory. See User manual distributed with the ETT install files as described in the Appendix Section 9 for further details.

Flight plans may be created on either PFD or MFD, stored, and activated in the same manner as on the EFIS displays installed in the aircraft. This allows for moving the start point to anywhere in the world where loaded NavData is present for practicing published procedures. As with the Demonstrator program, the aircraft begins flying at approximately 7900' MSL (unless the simulate.ini program is loaded) intercepting the first leg at a 45° angle.

## 1.5. About This Guide

The operation of the Genesys Aerosystems EFIS and FMS is described in great detail and divided into nine sections as follows:

### **TABLE OF CONTENTS**

*Use this section to locate areas by topic...*

### **INTRODUCTION (Section 1)**

*Use this section to gain basic understanding of how this pilot guide is constructed and where to begin...*

## **SYSTEM OVERVIEW (Section 2)**

This section provides a basic system description and block diagram; operational warnings; acronyms, and abbreviations; coloring conventions; and detailed descriptions of the EFIS hardware. This section contains the Warnings, Cautions, and Advisories table describing annunciations for each category, where the flag appears, and on which position of each display under identified conditions.

*Use this section to gain better understanding of the system and learn terminology, abbreviations, acronyms, and what the warnings, cautions, and advisories mean. This is where a basic description of all encoder and button functions and coloring conventions are introduced with menu tile definitions, as well as, database updating procedures and how the IDU behaves during initialization...*

## **DISPLAY SYMBOLOGY (Section 3)**

This section provides identification of each screen element of the PFD and MFD. For each separate screen, every element of the symbology is identified on a sample screen. Immediately following the sample screens, all elements for that screen are listed.

*Use this section to gain familiarity and understand what symbology to anticipate and define after viewing for every possible PFD and ND presentation...*

## **REVERSIONARY MODES (Section 4)**

This section provides views of the IDU-680 displays with various sensor failed conditions and resulting symbology as well as examples of various configurations and display formats used with specific tables showing affected functions.

*Use this section to understand what to expect when a particular sensor fails and what changes on the display immediately or after a specified amount of time...*

## **MENU FUNCTIONS AND STEP-BY-STEP PROCEDURES (Section 5)**

This section shows a flow diagram and selection options with step-by-step procedures for each configured possibility with this

EFIS system. The basis for this section has been the Systems Requirement Documentation for this operating system software.

*Use this section to understand the menu structure of each feature and how to go step-by-step during operation of each specific task...*

### **QUICK START TUTORIAL (Section 6)**

This section provides the basics necessary for flying a familiarization flight with this system. With a few simple steps, an active waypoint may be created and the view may be controlled to manage the displays for the existing flight conditions.

*Use this section to quickly gain familiarity with where to locate controls to manipulate the system for each operation...*

### **IFR PROCEDURES (Section 7)**

This section provides detailed information and instruction about selecting and flying instrument procedures found within the Jeppesen navigation database.

*Use this section to gain familiarity with selection of departure, published instrument approach, and standard terminal arrival procedures. This section describes how ATC clearances may often change and how the active flight plan quickly reflects these changes. Additionally, this section defines every example of the most popular of all published procedures with views of referenced published procedures...*

### **TERRAIN AWARENESS WARNING SYSTEM (Section 8)**

This section contains a description of the TSO-C151b TAWS (all classes) functionality for this fixed wing aircraft with all configurations.

*Use this section for understanding the TAWS functions provided for the various phases of flight in addition to the call-outs for each GPWS Mode as described in detail for all possible configurations. This section defines the various parameters which automatically apply to each mode of flight...*



## APPENDIX (Section 9)

This section contains support material and other useful information about system operation, ancillary guidance from Jeppesen, and supplemental information.

*Use this section for understanding Domestic flight planning; Magnetic vs. True North modes of operation; Airspeed/Altitude Miscompare thresholds; EFIS Training Tool accessibility; naming conventions used by the navigation database provider; flight data recorded information format; downloading routes and user waypoints; and sourcing a copy of the Service Difficulty Report form...*

## INDEX

The Index provides an alphabetical listing of terms used in the pilot guide with corresponding page numbers.

*Use this index to look up key words and locate where at least one or several instances it is used in the text.*

## GLOSSARY

The Glossary provides an alphabetical listing of definitions for terms used in the pilot guide.

*Use this index to look up definitions for key words and terms.*

**Genesys Aerosystems is committed to producing the highest quality product possible, and we welcome comments and suggestions concerning this publication. Please e-mail comments and suggestions to:**

**[genesys-support@genesys-aerosystems.com](mailto:genesys-support@genesys-aerosystems.com)**

or

**[genesys-support@s-tec.com](mailto:genesys-support@s-tec.com)**

If you encounter problems with the operation of your Genesys Aerosystems EFIS, please complete and return the Service Difficulty Report in the Appendix section directly to:

Genesys Aerosystems  
One S-Tec Way  
Mineral Wells Municipal Airport  
Mineral Wells, Texas 76067 or Fax: (940) 325-3904

# Section 2      System Overview

## Table of Contents

SECTION 2	SYSTEM OVERVIEW .....	2-1
2.1.	ABBREVIATIONS AND ACRONYMS .....	2-4
2.2.	SYSTEM OVERVIEW .....	2-15
2.2.1.	<i>IDU Initialization</i> .....	2-15
2.2.2.	<i>Application Software Air Mode and Ground Mode..</i> .....	2-19
2.3.	GENERAL ARRANGEMENT .....	2-19
2.4.	EICAS DISPLAY .....	2-20
2.4.1.	<i>PFD with EICAS</i> .....	2-22
2.5.	HSI WITH MAP .....	2-23
2.6.	COLOR CONVENTIONS .....	2-23
2.7.	WARNING/CAUTION/ADVISORY SYSTEM .....	2-25
2.8.	DATABASE AND SOFTWARE UPDATES .....	2-54
2.8.1.	<i>Navigation and Obstruction Databases</i> .....	2-54
2.8.2.	<i>Update Requirements</i> .....	2-55
2.8.3.	<i>Terrain Database Update</i> .....	2-58

## List of Figures and Tables

FIGURE 2-1: SYSTEM DIAGRAM .....	2-15
TABLE 2-1: IDU INITIALIZATION SOFTWARE VERSION AND PART NUMBERS.....	2-16
FIGURE 2-2: PRIMARY IDU-680 PFI ON TOP HALF AND ND ON BOTTOM HALF.....	2-20
FIGURE 2-3: EICAS.....	2-21
FIGURE 2-4: PFD WITH EICAS .....	2-22
FIGURE 2-5: MFD WITH HSI AND MAP .....	2-23
TABLE 2-2: WARNINGS, CAUTIONS, AND ADVISORIES .....	2-26
TABLE 2-3: ANNUNCIATIONS PRIORITY .....	2-53
TABLE 2-4: LOG FILE VALUES.....	2-54
FIGURE 2-6: GROUND MAINTENANCE PAGE .....	2-54
FIGURE 2-7: IDU-680 STARTUP SCREEN.....	2-56

## 2.1. Abbreviations and Acronyms

AC	Advisory Circular
AD	Airworthiness Directive
A-D	Analog to Digital (converter)
ADAHRS	Air Data Attitude Heading Reference System
ADC	Air Data Computer
ADF	Automatic Direction Finder
ADS-B	Automatic Dependent Surveillance-Broadcast
AFCS	Automatic Flight Control System
AFM	Aircraft Flight Manual
AGL	Above Ground Level
AHRS	Attitude Heading Reference System
AIRAC	Aeronautical Information Regulation and Control
AIRMET	Airmen's Meteorological Information
ALTA	Equal to "Selected Altitude Submode" (AW 109SP)
AMLCD	Active Matrix Liquid Crystal Display
ANSI	American National Standards Institute
APV	Approach with Vertical Guidance
ARINC	Aeronautical Radio, Inc.
ARP	SAE Aerospace Recommended Practice
AS	SAE Aerospace Standard
ASEL	Aircraft Selected Altitude
ATA	AT Attachment (hard disk storage interface)
ATC	Air Traffic Control
CA	Course to Altitude
CD	Course to DME Distance

CDI	Course Deviation Indicator
CDR	Critical Design Review
CDTI	Cockpit Display of Traffic Information
CM	Configuration Management
CNS	Communications/Navigation/Surveillance
COM	Communication
CPM	Company Project Manager
CPM	Computer Processor Module
CPU	Central Processing Unit
CR	Change Request
CR	Course to Radial Termination
CRC	Cyclic Redundancy Check
CSA	Conflict Situation Awareness (ADS-B)
DA	Decision Altitude
D-A	Digital to Analog (converter)
DAICD	Digital Aeronautical Information CD
DAR	Designated Airworthiness Representative
DCN	Document Change Notice
DEM	Digital Elevation Model
DER	Designated Engineer Representative
DH	Decision Height
DL	Data Link
DME	Distance Measuring Equipment
DMIR	Designated Manufacturing Inspection Representative
DO	RTCA Document
DOD	Department of Defense

DOF	Digital Obstruction File
DP	Departure Procedure
DR	Dead Reckoning or Defect Report
DSP	Digital Signal Processing
EFIS	Electronic Flight Instrument System
EGNOS	European Geostationary Navigation Overlay Service
EGPWS	Enhanced Ground Proximity Warning System
EIA	Electronics Industry Association
EICAS	Engine Indicating and Crew Alerting System
ETA	Estimated Time of Arrival
ETE	Estimated Time Enroute
ETT	EFIS Training Tool
FA	Course from a Fix to Altitude
FAA	Federal Aviation Administration
FAF	Final Approach Fix
FAR	Federal Aviation Regulation
FAWP	Final Approach Waypoint (same as FAF)
FD	Course from a Fix to DME Distance
FDE	Fault Detection and Exclusion
FHA	Functional Hazard Analysis
FIFO	"First in, First out"
FIS	Flight Information Service
FIS-B	Flight Information Service-Broadcast
FL	Flight Level
FLTA	Forward Looking Terrain Awareness
FMEA	Fault Mode and Effects Analysis

FMS	Flight Management System
FPE	Floating Point Emulation
FPM	Feet per Minute
FPM	Flight Path Marker
FSD	Full Scale Deflection
FTE	Flight Technical Error
FTP	Fictitious Threshold Point
GAGAN	India's GPS and GEO-Augmented Navigation System
GBAS	Australia's Ground Based Augmentation System
GLONASS	Russian Global Navigation Satellite System
GLS	GNSS Landing System
GMF	Ground Maintenance Function
GND	Ground (potential)
GNSS	Global Navigation Satellite System
GPH	Gallons Per Hour
GPI	Glidepath Intercept
GPIP	Glide Path Intercept Point
GPS	Global Positioning System
GPWS	Ground Proximity Warning System
HAL	Horizontal Alert Limit
HAT	Height Above Threshold
HFOM	Horizontal Figure of Merit
hPa	Hectopascal
HPL	Horizontal Protection Level
HSI	Horizontal Situation Indicator
HUD	Head Up Display



HUL	Horizontal Uncertainty Limit
IAP	Instrument Approach Procedure; Initial Approach Point
IAS	Indicated Airspeed
IAWP	Initial Approach Waypoint (same as IAP)
IC	Integrated Circuit
ICAO	International Civil Aviation Organization
ICD	Interface Control Document
ID	Identity or Identification
IDS	Integrated Display System (AW-109SP)
IDU	Integrated Display Unit
IFR	Instrument Flight Rules
ILS	Instrument Landing System
IM	Inner Marker
IO	Input/Output
IPV	Instrument Procedure with Vertical Guidance
ISR	Interrupt Service Routine
IVSI	Instantaneous Vertical Speed Indicator
JAD	Jeppesen Aviation Database
JTAG	Joint Test Action Group (IEEE 1149.1 Standard)
K	Kilo=1000
KB	Kilobyte
KIAS	Knots Indicated Airspeed
KT	Knot - Nautical Mile per Hour
KTAS	Knots True Airspeed
LDA	Localizer-type Directional Aid
LED	Light Emitting Diode

LNAV	Lateral Navigation
LOC	Localizer
LOI	Loss of Integrity
LON	Loss of Navigation
LP	Localizer Performance
LPV	Localizer Performance with Vertical Guidance
LRU	Line Replaceable Unit
LSB	Least Significant Bit or Byte
LTP	Landing Threshold Point
MAHP	Missed Approach Holding Point
MAHWP	Missed Approach Holding Waypoint (same as MAHP)
MAP	Missed Approach Point; Missed Approach Procedure
MASPS	Minimum Aviation System Performance Standard
MAWP	Missed Approach Waypoint (same as MAP)
MB	Megabyte
MDA	Minimum Descent Altitude
MEMS	Micro Electro Mechanical System
MFD	Multifunction Display (IDU with software for showing multiple display screens)
MM	Middle Marker
MOPS	Minimum Operational Performance Standard
MOT	Mark On Target
MSAS	Japan's MTSAT-based Satellite Augmentation System
MSB	Most Significant Bit or Byte
MSL	Mean Sea Level
MSU	Magnetic Sensor Unit
MTBF	Mean Time Between Failures

NACO	National Aeronautical Charting Office
NAS	U.S. National Airspace System
NASA	National Aeronautics and Space Administration
ND	Navigation Display
NDB	Nondirectional Beacon
NED	National Elevation Dataset
NI	Navigational Information
NIMA	National Imagery and Mapping Agency
NM	Nautical Mile
NPA	Non-Precision Approach
OASIS	Open Architecture Systems Integration Symbology
OAT	Outside Air Temperature
OBS	Omnibearing Selector
ODP	Obstacle Departure Procedure
OM	Outer Marker
OT	Other Traffic (Traffic Function)
PA	Proximate Advisory (Traffic Function)
PDA	Premature Descent Alert
PDR	Preliminary Design Review
PFD	Primary Flight Display (display screen showing primary instrumentation -- also refers to the primary IDU with software that only shows primary instrumentation)
PFDE	Predictive Fault Detection and Exclusion
PFI	Primary Flight Information
PIC	Peripheral Interface Controller
PLI	Pitch Limit Indicator
PM	Personality Module

PN	Part Number
PRAIM	Predictive Receiver Autonomous Integrity Monitoring
PSAC	Plan for Software Aspects of Certification
PSCP	Project Specific Certification Plan
PSP	Partnership for Safety Plan
PTN	Problem Tracking Number
QA	Quality Assurance
QFE	Altimeter setting provides height above reference point
QM	Quality Management
QNE	Altimeter setting provides pressure altitude readout
QNH	Altimeter setting provides MSL altitude at a reporting point
RA	Resolution Advisory (Traffic Function)
RAIM	Receiver Autonomous Integrity Monitoring
RAM	Random Access Memory
RBP	Remote Bug Panel
RCP	Radar Control Panel
RHT	Radar Height
RMI	Radio Magnetic Indicator
RNAV	Area Navigation
RNP	Required Navigation Performance
RS	EIA Recommended Standard
RTC	Real Time Computing
RTCA	Radio Telephone Commission for Aeronautics
RTD	Resistive Thermal Detector
RTL	Run Time Library
Rx	Receive

---

SA	Selective Availability
SAE	Society of Automotive Engineers
SAS	Software Accomplishment Summary
SBAS	Satellite Based Augmentation System
SCI	Software Configuration Index
SCMP	Software Configuration Management Plan
SCR	Software Conformity Review
SCS	Software Coding Standards
SDCM	System of Differential Correction and Monitoring
SDD	Software Design Document
SDP	Software Development Plan
SDS	Software Design Standards
SECI	Software Environment Configuration Index
SIGMET	Significant Meteorological Advisory
SMA	Sub-Miniature version A connector
SN	Serial Number
SNI	Serial Number Information
SOI	Stage of Involvement (FAA software audit)
SPR	Software Problem Report
SQA	Software Quality Assurance
SQAP	Software Quality Assurance Plan
SQAR	Software Quality Assurance Representative
SRD	Software Requirements Document
SRS	Software Requirements Standards
SRTM	Shuttle Radar Topographical Mission
SSA	System Safety Assessment


SSM	Sign Status Matrix
STAR	Standard Terminal Arrival Routes
STC	Supplemental Type Certificate
STP	Software Test Protocol
STS	Software Test Specification
SUA	Special Use Airspace
SV	Service Vehicle
SVCP	Software Verification Cases and Procedures
SVP	Software Verification Plan
SVR	Software Verification Results
SVS	Synthetic Vision System
SYRD	System Requirements Document
TA	Traffic Advisory (Traffic Function)
TACAN	Ultra-High Frequency Tactical Air Navigational Aid
TAFs	Terminal Aerodrome Forecasts
TAS	Traffic Advisory System
TAS	True Airspeed
TAWS	Terrain Awareness and Warning System
TCAD	Traffic Collision Alert Device
TCAS	Traffic Collision Alert System
TCH	Threshold Crossing Height
TD	Traffic Display
TERPS	Terminal Instrument Procedures
TFR	Temporary Flight Restriction
TIS	Traffic Information Service
TIS-B	Traffic information Service-Broadcast

TMS	Texas Instruments family of DSP processors
TQP	Tool Qualification Plan
TSO	Technical Standard Order
TTA	Time to Alert
Tx	Transmit
UART	Universal Asynchronous Receiver-Transmitter
UIM	User Interface Module
USGS	United States Geological Survey
UTC	Universal Time Coordinated
VA	Heading to Altitude
VAL	Vertical Alert Limit
VD	Heading to DME Distance
VFOM	Vertical Figure of Merit
VFR	Visual Flight Rules
VHF	Very High Frequency
VNAV	Vertical Navigation
VOR	VHF Omnidirectional Radio
VORTAC	Collocated VOR and TACAN
VPL	Vertical Protection Level
VR	Heading to Radial Termination
VSI	Vertical Speed Indicator
VTF	Vectors to Final
VUL	Vertical Uncertainty Limit
WAAS	Wide Area Augmentation System
WGS84	World Geodetic System 1984

## 2.2. System Overview

The IDU-680 EFIS System is a complete flight and navigation instrumentation system that intuitively provides information to a pilot via computer generated screen displays. The screen displays include three-dimensional, enhanced situational awareness Primary Flight Displays (PFD) and Multi-Function Displays (MFD). The Multi-Function Display may be configured to show a moving map, an HSI, terrain, traffic, datalink weather, radar, video or a dedicated Engine Indicating and Crew Alerting System (EICAS) displays.

At any given time, each system has only one IDU transmit enabled to send RS-232 and RS-422 system transmissions. By default the PFD is “Transmit Enabled” and, if it subsequently fails, the respective MFD becomes transmit enabled.



**Figure 2-1: System Diagram**

### 2.2.1. IDU Initialization

The hardware, including file system, IO, and graphics, are initialized. Immediately after graphics initialization, a logo screen with the text “INITIALIZING” is displayed and includes the Genesys Aerosystems



logo, software version number, and software part number. The software version number delineates: (1) major revision number (i.e., “8.0”) and (2) minor revision letter (e.g., “D”). The software version number and software part number display as follows.

**Table 2-1: IDU Initialization Software Version and Part Numbers**

<b>Version Number</b>	<b>Part Number</b>
Rev 8.0D	25-EFIS80D-SW-0003

Aircraft configurations are initially read from flash drive storage. This provides the IDUs with a default configuration setup in the event of personality module failure. The Pilot System #0 or #1 IDU reads aircraft configuration from its personality module and, in the case of a multi-screen installation with a #1 IDU, transmits this configuration to the other IDUs, including all Co-Pilot System IDUs. Upon reception of the configurations transmission from the Pilot System #0 or #1 IDU, the other IDUs save the transmitted configurations to flash drive storage.

Aircraft parameters (latitude, longitude, altitude), as they existed prior to the last system shutdown, are read to initialize the system, which allows for a good initialization, even if system sensors are failed or not yet initialized. For a future application update (i.e., updating software version 8.0A to 8.0X), all aircraft settings re-initialize to default values. Otherwise, aircraft settings as they existed prior to the last system shutdown are used to initialize the system with the exception of the following default values:

- 1) Active flight plan structure and associated values are cleared.
- 2) Timers are turned off.
- 3) Minimum altitude setting is turned off.
- 4) FMS OBS setting is set to automatic.
- 5) VOR/LOC 1 OBS setting is set to 360°.
- 6) VOR/LOC 2 OBS setting is set to 360°.
- 7) Parallel offset is set to 0 NM.
- 8) Airspeed bug is turned off.

- 9) Target altitude bug is turned off.
- 10) Vertical speed bug is turned off.
- 11) HSI navigation source is set to FMS.
- 12) Heading bug is turned off.
- 13) Datalink and map panning modes are set to off.
- 14) PFD zoom mode is set to off.
- 15) Manual RNP is set to off.
- 16) PFD skyway is set to on.
- 17) V-speeds are cleared.
- 18) RDR-2000/2100 scale is initialized to 80NM
- 19) Crosslink is initialized to on.
- 20) G-Force telltales are automatically reset unless they exceed G-Limits.

Based upon the air/ground mode parameter value from the last system shutdown, the IDU decides whether it is booting on the ground or in flight.

If booting on the ground, the following actions happen:

- 1) A logo screen with the words “TESTING” is displayed.
- 2) CRC-32 values for application executable, limitations files, NavData files, obstruction files, and terrain header files is checked.
- 3) If the CRC-32 check fails, the program exits with an error message and creates a bit result file indicating failure.
- 4) If the CRC-32 check passes, the program continues to initialize and creates a bit result file indicating passage.
- 5) If the “Baro Auto-Setting on Startup Flag” is enabled, the application will autoset the altimeter based upon the terrain elevation at the startup point.
- 6) The application auto-sets the altimeter based upon the terrain elevation at the startup point.

- 7) A logo screen displaying database versions and validity dates is displayed with the message “PRESS ANY KEY TO CONTINUE”.
- 8) If all critical sensors (GPS, ADC, and AHRS) are in normal condition, display screens are shown immediately. The #1 IDU initializes to the PFD screen. Other IDUs initialize to the MFD.
- 9) If any critical sensor is not in normal condition, a logo screen with a two-minute countdown timer is shown.
- 10) The display screen is shown at the earliest of:
  - a) When two minutes have elapsed;
  - b) When the pilot presses any button to escape the startup countdown;
  - c) When all critical sensors are in normal condition. The #1 IDU initializes to the PFD screen Normal Mode (PFD on top, MFD on bottom);
  - d) Other IDUs: If EICAS is configured, IDU #2 initializes to EICAS on top and MFD on bottom. All other IDUs initialize to MFD on top and MFD on bottom.
- 11) On the IDU #0 or #2 with fuel totalizer functions enabled, the fuel set menu is activated to remind the pilot to set the fuel totalizer quantity.

If booting in the air, the following actions happen:

- 1) A logo screen with the words “QUICK START” is displayed.
- 2) The bit result file created during the last ground boot is checked. If the bit result file indicates a failure, the program exits with an error message. If the bit result file indicates passage, the program continues.
- 3) The display screens initialize as follows:
  - a) IDU #1 : PFD Normal Mode (PFD on top, MFD on bottom)
  - b) Other IDUs: If EICAS is configured, IDU #2 initializes to Primary EICAS on top and MFD on bottom. If EICAS is not configured, IDU #2 initializes to MFD on top and MFD on bottom. All other IDUs initialize to MFD on top and MFD on bottom.

## 2.2.2. Application Software Air Mode and Ground Mode

Numerous symbology elements change behavior depending upon whether the aircraft is on the ground or in flight. These are referred to as Air Mode and Ground Mode. This determination is separate from the system initialization modes.

This parameter is continuously calculated as follows:

- 1) If a Weight on Wheels/Weight on Ground discrete input is configured, the Air or Ground Modes are determined solely from the discrete input position.
- 2) Otherwise, Mode is determined as follows:
  - a) If airspeed is valid and AGL altitude is valid, Ground Mode is set when indicated airspeed is 40 knots and AGL altitude is less than 75 feet.
  - b) If airspeed is invalid but AGL altitude is valid, Ground Mode is set when AGL altitude is less than 75 feet.
  - c) Under any other circumstance, Air Mode is set by default.

## 2.3. General Arrangement

The IDU-680 is 7.500"W x 10.250"H x 4.750"D and weighs less than 9.5 lbs. The IDU-680 is composed of two major sub-assemblies mechanically connected by through-bolts, the User Interface Module (UIM) and the Computer Processor Module (CPM). The IDU-680 has the capacity to accommodate integrated peripherals mechanically attached to the CPU but have electrical isolation and redundancy. These modules may include:

- 1) Integrated ADAHRS Sensor Module
- 2) Integrated GPS/SBAS Sensor Module
- 3) Serial Protocol Converters
- 4) Video Format Converters

Data storage consists of up to two compact flash cards sufficiently sized to hold world terrain, navigation, and obstruction databases. Because the receive ports of the IDU-680s are connected to the digital sensor modules in parallel, each IDU-680 is independent from all other IDU-680s. In an IFR installation, the software of the primary

IDU-680 is configured so only the primary screen Primary Flight Information (PFI) display top half plus Multi-Function Display (MFD) bottom half is displayed as seen in Figure 2-2.



**Figure 2-2: Primary IDU-680 PFI on Top Half and ND on Bottom Half**

## 2.4. EICAS Display

The software of all other IDU-680s are configured so any screen display is shown at any time. The only limitation to this rule is that since these IDU-680s can be configured as a primary display of engine information, at least one of the MFD areas must show the engine display. Shown below is an IDU-680 MFD with the top display area showing the EICAS and bottom area configured to the MAP page. See section § 4.2.4 for EICAS Screen Single-Action Reversion.




Figure 2-3: EICAS

2.4.1. PFD with EICAS




Figure 2-4: PFD with EICAS

## 2.5. HSI with MAP




Figure 2-5: MFD with HSI and MAP

## 2.6. Color Conventions

The Genesys Aerosystems EFIS uses a consistent set of colors for displaying information detailed as follows. (Any color representation may not be exactly identical as it appears on the IDU.)



**WHITE** is used for scales, associated labels and figures, pilot action, or data entry. Examples:

- Scales markings (airspeed, altitude, heading, VSI, pitch, map ranges, etc.).
- Pilot-selected values (airspeed, heading, altitude)



- Secondary flight data (TAS, wind, OAT, timers, etc.).



**CYAN** is used for IFR navigation dataset items (airports with instrument approach procedures, VORs, intersections, and Advisory text on black background).



**MAGENTA** is used to indicate certain navigation database items and electronically calculated or derived data. Examples:

- Active waypoint related symbols
- Course data (desired track, CDI)
- VFR airports, NDBs
- VNAV altitudes



**GRAY** is used for conformal runway depiction (light gray for usable portion of the active runway, dark gray for other runway surfaces) and as a figure background for airspeed and altitude readout.



**GREEN** is used to indicate normal or valid operation (airspeed, altitude tape coloring, status indication, etc.). Examples:

- Aircraft ground track
- Skyway symbology
- Airspeeds in green arc
- Autopilot annunciations



**DARK GREEN** is used for the terrain indication on the moving map. The slope between adjacent terrain pixels in an increasing longitude direction determines the shade used.



**AMBER (YELLOW)** is used to identify conditions requiring immediate pilot awareness and may require subsequent pilot action. Examples:

- Caution indications
- Altitude or heading alert

- Component failure indication
- Minimum altitude
- Airspeeds in amber (yellow) arc



**OLIVE** is used in various shades to show terrain within 2000' and below aircraft altitude.



**BROWN** is used in a variety of shades to indicate earth/terrain portion of the primary flight display. Shades of brown are used when terrain is at or above the aircraft altitude on the MFD.



**BLUE** is used in a variety of shades to indicate the sky portion of the PFD and bodies of water on the moving map.



**RED** is used to indicate aircraft limitations or conditions which require immediate pilot action. Examples:

- Warnings (airframe operation limits, terrain awareness)
- Pitch limit indicator (low speed awareness)
- Airspeeds in red arc



**BLACK** is used for the field of view angle lines on the moving map, for figures on a gray background, and for outlining borders and certain figures/elements on backgrounds where contrast is minimal, e.g., airspeed, altitude, and menu tiles on the PFD/MFD.

## 2.7. Warning/Caution/Advisory System

The IDU's integrated audio/visual warning system monitoring a wide variety of parameters and providing annunciations for conditions demanding pilot awareness. There are three categories of annunciations: warnings, cautions, and advisories. Where time delay is referenced, it is the programmed delay in seconds prior to the annunciation appearing. The following table lists the annunciations provided by the IDU:

**WARNING** Displayed with red flag and an aural annunciation that repeats until the condition goes away or is acknowledged by the pilot.

**CAUTION** Displayed with amber (yellow) flag and a single aural annunciation.

**ADVISORY** Displayed with black flag and blue letters with a single aural annunciation.

**Table 2-2: Warnings, Cautions, and Advisories**

Display Flag "..." indicates no flag	Aural Annunciation	Condition
<b>GLIDESLOPE</b>	"Glideslope, Glideslope"	Within GPWS Mode 5 warning envelope. Half second time delay.
<b>LOW FUEL</b>	"Fuel Low, Fuel Low"	One of the following conditions is true: <ol style="list-style-type: none"> <li>1) One of the Low Fuel Warning discrete inputs is active</li> <li>2) One of the sensed fuel tank quantities is below its low fuel warning threshold</li> <li>3) Total aircraft fuel is below the pilot-set emergency fuel threshold.</li> </ol> 1-minute time delay.
<b>OBSTRUCTION</b>	"Warning Obstruction, Warning Obstruction"	Obstruction within TAWS FLTA warning envelope. Half second time delay.
<b>OVERSPEED</b>	"Overspeed, Overspeed"	Indicated airspeed exceeds redline ( $V_{NE}/V_{MO}/M_{MO}$ as appropriate) plus instrument error. No time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>PULL UP</b>	"Terrain, Terrain, Pull Up, Pull Up"	Terrain cell within TAWS FLTA warning envelope. Half second time delay.
		Within GPWS Mode 2 warning envelope. Half second time delay.
	"Pull Up, Pull Up"	Within GPWS Mode 1 warning envelope. Half second time delay.
<b>STALL</b>	"Stall, Stall"	Activated above 100' AGL if indicated airspeed is below the higher of $V_{S1}$ or $V_{S1}$ corrected for G-load +5 KIAS. Deactivated if stall warning flag is set to 0. No time delay.
<b>TRAFFIC</b>	"Traffic, Traffic"	Resolution Advisory. Not given if own aircraft below 400' AGL nor if target is below 200' AGL (ground target). Audio not generated with TCAS-II system. No time delay.
<b>CAUTIONS</b>		
<b>ADC1 FAIL</b>	Alert Tone	Only active in dual-ADC installation. Indicates no valid indicated airspeed, pressure altitude, or VSI received from ADC #1 for more than 1 second. No time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>ADC2 FAIL</b>	Alert Tone	Only active in dual-ADC installation. Indicates no valid indicated airspeed, pressure altitude, or VSI received from ADC #2 for more than 1 second. No time delay.
<b>ADS-B FAIL</b>	Alert Tone	Enabled by ADS-B Out Fail Warning Limits setting. Mode-S Transponder indicates bad ADS-B Out Status. 2-second time delay.
<b>AHRS1 FAIL</b>	Alert Tone	Only active in dual-AHRS installation. Indicates no valid bank, pitch, or heading received from AHRS #1 for more than 1 second. No time delay.
<b>AHRS2 FAIL</b>	Alert Tone	Only active in dual-AHRS installation. Indicates no valid bank, pitch, or heading received from AHRS #2 for more than 1 second. No time delay.
<b>ALT MISCOMP</b>	Alert Tone	Only active in dual-ADC installation with neither ADC in failure condition. Indicates pressure altitude difference between ADCs is beyond limits. 10-second time delay. Inhibit for 5 minutes after startup.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>ATT MISCOMP</b>	Alert Tone	Only active in dual-AHRS installation with neither AHRS in failure condition. Indicates pitch or roll difference between AHRS is beyond limits (6°). 10-second time delay. Inhibit for 5 minutes after startup.
<b>AUX SENSOR</b>	"Auxiliary Sensor Failure, Auxiliary Sensor Failure"	No valid message or bad status received from installed optional sensors. Sensor status displayed in FAULTS menu. Applies to the following optional sensors: <ol style="list-style-type: none"> <li>1) RS-232 TAS System</li> <li>2) ADS-B System</li> <li>3) WSI Datalink System</li> <li>4) WX-500 Lightning System</li> <li>5) Analog Interface System</li> <li>6) Weather Radar</li> <li>7) Weather Radar Control Panel</li> </ol> 5-second time delay.
<b>CHECK GEAR</b>	"Check Gear, Check Gear"	Activated if RG flag is set to 1, aircraft is below 150' AGL, aircraft is descending, and any landing gear is not down. 2-second time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
CHECK IDU 1 CHECK IDU 2 CHECK IDU 3 CHECK IDU 4	Alert Tone	<p>When armed (i.e., at least one intra-system monitor message has been received from the transmitting display), checks intra-system monitor messages. Indicates either:</p> <ol style="list-style-type: none"> <li>1) screen counter value has not changed in the last 1 second <math>\pm</math> 0.1 seconds; or</li> <li>2) intra-system monitor message is not fresh (i.e., no message received for longer than 1 second <math>\pm</math> 0.1 second).</li> </ol> <p>"#" indicates which IDU is failing the check, either IDU 1, IDU 2, IDU 3, or IDU 4.</p> <p>No time delay.</p>

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>CHECK RANGE</b>	"Check Range, Check Range"	<p>Less than 30 minutes buffer (at current groundspeed) between calculated range and distance to:</p> <ol style="list-style-type: none"> <li>1) The last waypoint if it is active; or</li> <li>2) The airport if on a missed approach; or</li> <li>3) Along-route distance to destination.</li> </ol> <p>Not activated in climbing flight. Not activated if below 60 knots groundspeed.</p> <p>5-minute time delay.</p>
CHECK TRIM ▼	"Check Pitch Trim"	Only active with Intelliflight 1950. Pitch is mistrimmed for more than 3 continuous seconds (i.e., trim is not responding). DOWN trim is needed.
CHECK TRIM ▲	"Check Pitch Trim"	Only active with Intelliflight 1950. Pitch is mistrimmed for more than 3 continuous seconds (i.e., trim is not responding). UP trim is needed.



**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>COOLING FAN</b>	Alert Tone	Triggered when external cooling fan is commanded on by the cooling fan discrete output and the cooling fan status discrete input indicates the cooling fan is not rotating. 1-minute time delay.
<b>FUEL SPLIT</b>	Alert Tone	Compares the volume of fuel designated left wing tank fuel vs. volume of fuel designated right wing tank fuel to the Fuel Split Caution Threshold. Issues a caution if the difference exceeds the Fuel Split Caution Threshold. Only performed if the Fuel Split Caution Threshold is non-zero and both left and right wing tank fuel are monitored and valid. 1-minute time delay.
<b>GLIDESLOPE</b>	"Glideslope, Glideslope"	Within GPWS Mode 5 caution envelope. Half second time delay.
<b>GPS LOI</b>	Alert Tone	GPS/SBAS loss of integrity caution. No time delay.
<b>GPS LON</b>	Alert Tone	GPS/SBAS loss of navigation caution. No time delay.

Table 2-2: Warnings, Cautions, and Advisories

Display Flag "--" indicates no flag	Aural Annunciation	Condition
<p><b>GPS MISCMP</b></p>	Alert Tone	<p>Only active in dual-GPS/SBAS installation with neither GPS/SBAS in failure condition. Indicates position, track, or groundspeed difference between GPS/SBAS units is beyond limits as follows:</p> <p><b>Position:</b> Enroute Mode 4NM Terminal Mode 2NM Departure Mode .6NM IFR Approach Mode .6NM VFR Approach Mode .6NM</p> <p><b>Track:</b> If groundspeed is greater than 30 kts, miscompare if difference is more than 4°.</p> <p><b>Groundspeed:</b> If difference between GPS#1 and GPS#2 miscompare is more than 10 kts.</p> <p>10-second time delay.</p>
<p><b>GPS1 FAIL</b></p>	Alert Tone	<p>Only active in dual-GPS/SBAS installation. Indicates no valid message received from GPS/SBAS #1 for more than 5 seconds.</p> <p>No time delay.</p>

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>GPS2 FAIL</b>	Alert Tone	Only active in dual-GPS/SBAS installation. Indicates no valid message received from GPS/SBAS #2 for more than 5 seconds. No time delay.
<b>GS MISCOMP</b>	Alert Tone	Only active when two valid glideslopes are being received. Indicates at least one glideslope is receiving a signal within 1 dot of center and difference between glideslope signals is beyond limits (0.25 Dots). 10-second time delay.
<b>HDG MISCOMP</b>	Alert Tone	Only active in dual-AHRS installation with neither AHRS in failure condition. Indicates heading difference between AHRS is beyond limits (6°). 1-minute time delay. Inhibit for 5 minutes after startup. 10 second time delay otherwise 60 second time delay. Inhibit for 5 minutes after startup.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>IAS MISCOMP</b>	Alert Tone	<p>Only active in dual-ADC installation with neither ADC in failure condition. Indicates indicated airspeed difference between ADCs is beyond limits.</p> <p>10-second time delay.</p> <p>10-second time delay. Inhibit for 5 minutes after startup.</p>
<b>LOC MISCOMP</b>	Alert Tone	<p>Only active when two valid localizers are being received. Indicates at least one localizer is receiving a signal within 1 dot of center and difference between localizer signals is beyond limits (0.25 Dots).</p> <p>10-second time delay.</p>

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>LOW FUEL</b>	"Fuel Low, Fuel Low"	A Low Fuel Warning is not active and one of the following conditions is true: <ol style="list-style-type: none"> <li>1) One of the Low Fuel Caution discrete inputs is active.</li> <li>2) One of the sensed fuel tank quantities is below its low fuel caution threshold.</li> <li>3) Total aircraft fuel is below the pilot-set minimum fuel threshold.</li> </ol> 1-minute time delay.
<b>NO HEADING</b>	Alert Tone	No valid heading received from selected AHRS for more than 1 second. No time delay. Disabled if in MFD-only operation. Not shown if PFD heading scale is red-X'd.
<b>NO POSITION</b>	Alert Tone	No valid position data available from selected GPS/SBAS for more than 5 seconds and Dead Reckoning not available. No time delay.

Table 2-2: Warnings, Cautions, and Advisories

Display Flag "--" indicates no flag	Aural Annunciation	Condition
NO TAWS	Alert Tone	Indicates aircraft is currently beyond extent of terrain database or a failure condition exists preventing the TAWS FLTA function from operating. Half second time delay.
OAT SENSOR OAT1 SENSOR OAT2 SENSOR	Alert Tone	Indicates OAT sensor has failed. "OAT SENSOR" applicable to single ADC installation. "OAT# SENSOR" applicable to dual ADC installation. Indicates OAT indication is invalid, but other air data parameters are normal (i.e., air data is not Red-X'd). Half second time delay.
OBSTRUCTION	"Caution Obstruction, Caution Obstruction"	Obstruction within TAWS FLTA caution envelope. Half second time delay.
PLT MISCOMP CPLT MISCOMP	Alert Tone	Only active when fresh intra-system monitor messages are being received. Indicates a critical parameter being used by another display exceeds the miscompare thresholds when compared to the monitoring display. Compares the following critical parameters:

**Table 2-2: Warnings, Cautions, and Advisories**




<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
		1) Attitude (Pitch and Roll) (use Attitude Miscompare logic) 2) Heading (use Heading Miscompare logic) 3) Pressure Altitude (use Altitude Miscompare logic) 4) Indicated Airspeed (use Airspeed Miscompare logic) 5) Localizer (both inputs) (use Localizer Miscompare logic) 6) Glideslope (both inputs) (use Glideslope Miscompare logic) 7) Radar Altitude (use Radar Altitude Miscompare logic) 8) Latitude (Use GPS/SBAS Miscompare logic) 9) Longitude (Use GPS/SBAS Miscompare logic) 10) Track (Use GPS/SBAS Miscompare logic)

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
		11) Groundspeed (Use GPS/SBAS Mis-compare logic)  1-second time delay.
PLT1 OVRTMP PLT2 OVRTMP PLT3 OVRTMP PLT4 OVRTMP CPLT1 OVRTMP CPLT2 OVRTMP CPLT3 OVRTMP CPLT4 OVRTMP	Alert Tone	IDU core temperature greater than 95°C. 2-second time delay.
PLT1 SCC PLT2 SCC PLT3 SCC PLT4 SCC CPLT1 SCC CPLT2 SCC CPLT3 SCC CPLT4 SCC	Alert Tone	Indicates SCC card (Personality Module) could not be read upon power-up. This means limits internal to the IDU are being used by the system. Only active on the ground.
RADALT FAIL	Caution	Only active in single-Radar Altimeter installation. For analog radar altimeter, indicates below 2000'AGL in Air Mode without a valid radar altimeter reading. 2-second time delay.
RADALT1 FAIL	Alert Tone	Only active in dual-Radar Altimeter installation. Indicates no radar altimeter reading received from Radar Altimeter #1 for more than 1 second. Annunciation is also displayed in Ground Mode. 2-second time delay.



**Table 2-2: Warnings, Cautions, and Advisories**

Display Flag "--" indicates no flag	Aural Annunciation	Condition
	Alert Tone	Only active in dual-Radar Altimeter installation. Indicates no radar altimeter reading received from Radar Altimeter #2 for more than 1 second. Annunciation is also displayed in Ground Mode. 2-second time delay.
	Alert Tone	Only active in dual-radar altimeter installation with neither radar altimeter in failure condition. Indicates radar altitude difference between radar altimeters is beyond limits as follows.  $\geq 500' \text{AGL} \quad \Delta 14\%$ $100 - 500' \text{AGL} \quad \Delta 10\%$ $< 100' \text{AGL} \quad \Delta 10'$  10-second time delay.
	Alert Tone	Only active in dual-system (pilot and co-pilot), dual-ADC installation with good inter-system communications, and neither ADC in failure condition. Indicates both systems are operating from same ADC source.  No time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>SAME AHRS</b>	Alert Tone	Only active in dual-system (pilot and co-pilot), dual-AHRS installation with good inter-system communications, and neither AHRS in failure condition. Indicates both systems are operating from same AHRS source.  No time delay.
<b>SAME EICAS</b>	Alert Tone	Only active in dual-system (pilot and co-pilot), installation with good inter-system communications. Indicates both systems are operating from the same EICAS data source for labels where dual sources are setup in the OASIS configuration file.  No time delay.
<b>SAME GPS</b>	Alert Tone	Only active in dual-system (pilot and co-pilot), dual-GPS/SBAS installation with good inter-system communications, and neither GPS/SBAS in failure condition. Indicates both systems are operating from same GPS/SBAS source.  No time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>SAME NAV</b>	Alert Tone	Only active in dual-system (pilot and co-pilot) with good inter-system communications. Indicates both systems are operating from same navigation source. Alert inhibited if both Systems are operating from GPS/SBAS in a single-GPS/SBAS installation.  No time delay.
<b>SAME RADALT</b>	Alert Tone	Only active dual-system (pilot and co-pilot), dual-radar altimeter installation with good inter-system communications, and neither radar altimeter in failure condition. Indicates both systems are operating from same radar altimeter source.  No time delay.
<b>SINK RATE</b>	"Sink Rate, Sink Rate"	Within GPWS Mode 1 caution envelope. Half second time delay.
<b>TCAS FAIL</b>	Alert Tone	Only active with ARINC735A-1 TCAS-II, TCAS-I, or TAS system. Indicates lack of communications with system or failure indication from system.  No time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>TERRAIN</b>	"Caution Terrain" Caution Terrain"	Terrain cell within TAWS FLTA caution envelope. Half second time delay.
		Within GPWS Mode 2 caution envelope. Half second time delay.
<b>TOO LOW</b>	"Too Low Terrain, Too Low Terrain"	Within GPWS Mode 3 envelope. Half second time delay.
		Within GPWS Mode 4 "Too Low Terrain" envelope. Half second time delay.
	"Too Low Gear, Too Low Gear"	Within GPWS Mode 4-2 "Too Low Gear" envelope. Half second time delay.
	"Too Low Flaps, Too Low Flaps"	Within GPWS Mode 4-3 "Too Low Flaps" envelope. Half second time delay.
	"Too Low Terrain, Too Low Terrain"	Within TAWS PDA envelope. Half second time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>TOTALZR QTY</b>	Alert Tone	Compares the volume of sensed fuel to the fuel totalizer calculation. Issues a caution if the difference exceeds the Totalizer Mismatch Caution Threshold. Only performed if: <ol style="list-style-type: none"> <li>1) Totalizer Mismatch Caution Threshold is non-zero;</li> <li>2) Fuel totalizer is enabled;</li> <li>3) Unmonitored Fuel Flag is false;</li> <li>4) Fuel totalizer has a valid value; and</li> <li>5) Fuel levels are valid.</li> </ol> 1-minute time delay.
<b>TRAFFIC</b>	"Traffic, Traffic"	Traffic Advisory. Not given if own aircraft below 400' AGL nor if target is below 200'AGL (ground target). Audio not generated with TCAS-II system. No time delay.
TRIM MOTION ▼	"Trim in Motion, Trim in Motion"	Only active with Intelliflight 1950. Pitch trim running for more than a preset amount of time in the DOWN direction. The amount of time is part of the aircraft limits.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
TRIM MOTION ▲	"Trim in Motion, Trim in Motion"	Only active with Intelliflight 1950. Pitch trim running for more than a preset amount of time in the UP direction. The amount of time is part of the aircraft limits.
VERT LON	Alert Tone	Loss of vertical navigation caution. No time delay.
XFILL FAIL	Alert Tone	Only active in dual-system (pilot and co-pilot). Indicates lack of inter-system communications. 2-second time delay. Inhibit for 30 seconds after startup.
--	"Minimums, Minimums"	Deviation from above to below minimum altitude bug. Causes minimum altitude readout to turn amber (yellow) and flash. No time delay.
--	"Altitude, Altitude"	Deviation greater than 150' from selected altitude after capture. Altitude capture defined as being within 100' of altitude. 2-second time delay.
--	"Altitude, Altitude"	If not on a descending VNAV profile, deviation greater than 150' from altitude of the current or prior VNAV waypoint after capture. Altitude capture defined as being within 100' of altitude. 2-second time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
--	"Decision Height"	Deviation from above to below decision height bug. Causes decision height readout to turn amber (yellow) and flash. No time delay.
<b>ADVISORIES</b>		
<b>ADC INIT</b>	Chime	ADC not at full accuracy during warm-up. No time delay.
<b>AHRS DG</b>	Chime	Activated DG mode if available.
<b>ANP: 0.01</b> <b>ANP: 15.0</b>	Chime	GPS/SBAS Actual Navigation Performance based upon current GPS/SBAS HPL.
<b>BARO MISCOMP</b>	Chime	Only active in dual-system (pilot and co-pilot) installation. Indicates mismatch of altimeter settings or altimeter modes between systems. 10-second time delay.
<b>CHK BARO</b>	Chime	Ascending through transition level: Altimeter not set to 29.92 inHg or 1013 mbar.  Descending through transition level: Altimeter set to 29.92 inHg or 1013 mbar. Descent warning times out in 10 seconds.  2-second time delay.  Disabled during QFE operation.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>DR 00:00</b> <b>DR 01:23</b>	Chime	GPS/SBAS in dead reckoning mode with valid ADC and AHRS data. Timer shows time since loss of position to indicate quality of DR solution. No time delay.
<b>FLTA INHBT</b>	Chime	Shown when the FLTA function is automatically inhibited during normal operation. "NO TAWS" caution and "TAWS INHBT" advisory have priority over this message. No time delay.
<b>FPM INHBT</b>	Chime	Flight Path Marker inhibit function activated through use of momentary discrete input. No time delay.
<b>LNAV APPR</b>	Chime	GPS/SBAS in LNAV Approach Mode. No time delay.
<b>LNU/UNU APPR</b>	Chime	GPS/SBAS in LNAV/VNAV Approach Mode. No time delay.
<b>LP APPR</b>	Chime	GPS/SBAS in LP Approach Mode. No time delay.
<b>LPV APPR</b>	Chime	GPS/SBAS in LPV Approach Mode. No time delay.



**Table 2-2: Warnings, Cautions, and Advisories**

Display Flag "--" indicates no flag	Aural Annunciation	Condition
MORE-PRS MENU	None	Number of active messages exceeds 11. This advisory appears to guide the pilot in accessing the EXPAND CAS menu. No time delay.
PLT1 PWR PLT2 PWR PLT3 PWR PLT4 PWR CPLT1 PWR CPLT2 PWR CPLT3 PWR CPLT4 PWR	Chime	Indicates one of the dual redundant power supplies within an IDU is not functioning correctly. Only active on the ground. 1-minute time delay.
PTK = L 1NM PTK = L 20NM PTK = R 1NM PTK = R 20NM PTK ENDING	Chime	GPS/SBAS Parallel Offset path advisory. ## is nautical miles left (L) or right (R) of main path. No time delay. Text changes to "PTK ENDING" if within the parallel offset distance from a parallel offset exit waypoint. No time delay.
RNP X.XXA RNP XX.XA	Chime	GPS/SBAS Automatic Required Navigation Performance as acquired from navigation database
RNP X.XXM RNP XX.XM	Chime	GPS/SBAS Manual Required Navigation Performance as set by pilot.

Table 2-2: Warnings, Cautions, and Advisories

Display Flag "--" indicates no flag	Aural Annunciation	Condition
<b>SUSPEND</b>	Chime	GPS/SBAS automatic waypoint sequencing is suspended. Caused by being on final approach segment prior to arming missed approach, selecting manual GPS/SBAS OBS, or being in holding prior to activating the <b>CONTINUE</b> tile. No time delay.
<b>TA ONLY</b>	Chime	Only active with TCAS-II system. Indicates TCAS-II system is unable to display resolution advisories. No time delay.
<b>TAS INHBT</b>	Chime	TAS aural inhibited through activation of TCAS/TAS Audio Inhibit discrete input. No time delay.
<b>TAWS GS CNX</b>	Chime	TAWS glideslope cancel (GPWS Mode 5) activated through use of discrete input. No time delay. GS Cancel annunciation feature is for Class A TAWS only.
<b>TAWS INHBT</b>	Chime	TAWS inhibited (audio only) through use of discrete input. No time delay.
<b>TAWS LOW ALT</b>	Chime	TAWS low altitude mode activated through use of discrete input. No time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>TCAS STBY</b>	Chime	Only active with TCAS-II system. Indicates system is either: (1) in standby or (2) executing functional test in flight. No time delay.
<b>TCAS TEST</b>	Chime	Only active with TCAS-II system. Indicates system is in functional test on ground. No time delay.
<b>TERMINAL</b>	Chime	GPS/SBAS in Terminal mode. No time delay.
<b>TRUE NORTH</b>	Chime	True North mode input discrete is asserted and system is operating in True North mode. No time delay.
<b>VECTORS</b>	Chime	GPS/SBAS in Vectors to Final Approach mode prior to sequencing FAWP. No time delay.
<b>VFR APPR</b>	Chime	GPS/SBAS in VFR approach mode. No time delay.
<b>VNAV AVAIL</b>	Chime	Only active with Intelliflight 1950. Indicates VNAV guidance is available but not currently in use by the autopilot. Press the "VNV" button on the Mode Control Panel to engage VNAV mode.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
<b>XFILL ARM</b>	Chime	Only active in dual-system (pilot and co-pilot) with good inter-system communications and crossfill not inhibited. Indicates systems are not synchronized and synchronization function is available. No time delay.
<b>XFILL INHBT</b>	Chime	Only active in dual-system (pilot and co-pilot) with good inter-system communications. Indicates crossfill is manually inhibited through use of discrete input. No time delay.
--	Chime	Sounds chime when countdown timer reaches 00:00:00. No time delay.
--	Altitude Alert Tone	Tone given when within the greater of 1000' or 50% of VSI from uncaptured selected or VNAV waypoint altitude. Inhibited in approach procedures. No time delay.
--	"Five Hundred"	Descending through 500' AGL advisory. Armed upon climbing through deadband value above 500' AGL. Half second time delay.

**Table 2-2: Warnings, Cautions, and Advisories**

<b>Display Flag</b> "--" indicates no flag	<b>Aural Annunciation</b>	<b>Condition</b>
--	"Autopilot Disconnect"	Only active with Intelliflight 1950. Aural message given when the autopilot servos disengage for any reason.
--	"Autopilot Failure"	Only active with Intelliflight 1950. Aural message given when an autopilot failure is detected.

The volume of aural annunciations is adjusted according to severity as follows:

**WARNING**

= Full volume set into aircraft limits

**CAUTION**

= 80% of volume set into aircraft limits

**ADVISORY**

= 60% of volume set into aircraft limits

Press the audio mute switch to mute the active aural annunciation.

Flags are visually prioritized so active warning flags are displayed above active caution flags, which are displayed above active advisory flags. Within categories, active flags are stacked in chronological order with the most recent annunciation on top. Warning flags flash at 2Hz until acknowledged by pressing the audio mute switch. Caution flags flash at 1Hz until acknowledged by pressing the audio mute switch. Only the highest priority (in criticality and recency), unacknowledged aural annunciation is played at any given time. In addition, to further minimize cockpit confusion, the above annunciations are grouped and prioritized so only one annunciation is active. Annunciations are prioritized in this manner as follows (higher in list = higher priority).

**Table 2-3: Annunciations Priority**

1) GPWS Mode 1 Warning
2) GPWS Mode 2 Warning
3) TAWS FLTA Warning
4) Obstruction Warning
5) Stall
6) Overspeed
7) TAWS FLTA Caution
8) Obstruction Caution
9) GPWS Mode 4-1
10) TAWS PDA
11) GPWS Mode 4-2
12) GPWS Mode 4-3
13) GPWS Mode 1 Caution
14) GPWS Mode 2 Caution
15) GPWS Mode 3
16) GPWS Mode 5 Warning
17) GPWS Mode 5 Caution
18) Check Gear
19) Traffic Warning (Resolution Advisory)
20) Traffic Caution (Traffic Advisory)
21) Low Fuel Warning
22) Low Fuel Caution
23) Fuel Split Caution
24) Fuel Totalizer Mismatch Caution
25) Check Range

In addition, flags are decluttered from all IDUs which are not “transmit enabled”. Flags only appear on non-talker IDUs, if they are IDU-specific and cannot reasonably be shown on the talker (i.e., CHECK IDU #).

Flags and custom CAS messages are logged in non-volatile memory at 1Hz in ASCII, comma delimited format. Active logging is to a file named “caslog00.csv” (with the \*.csv file extension, this file may be directly opened by Microsoft Excel or similar spreadsheet software). In addition, data from the previous four flights are kept in files “caslog01.csv” through “caslog04.csv.” Upon system start, the existing “caslog00.csv” through “caslog03.csv” files are renamed “caslog01.csv” through “caslog04.csv”, and “caslog00.csv” is opened for active logging.

The first line of the log files contains column headings related to the flag's text (for standard warning functions) or the "CAS Log File Text" parameter (for custom CAS messages). All standard warning functions are logged. Only custom CAS messages with valid "CAS Log File Text" parameters (i.e., not an empty string) are logged. This allows logging of custom CAS messages to be controlled by the EICAS configuration file.

Within the data fields of the log file, values are written as follows.

<b>Table 2-4: Log File Values</b>	
<b>Category</b>	<b>Value</b>
NORMAL	0
ADVISORY	1
CAUTION	2
WARNING	3

## 2.8. Database and Software Updates

### 2.8.1. Navigation and Obstruction Databases

The EFIS uses Jeppesen NavData® for the navigation database and Jeppesen data for the obstruction database, which are secured directly through the Jeppesen Company.

The EFIS is updated through the Ground Maintenance Function (GMF). To gain access to the GMF, prior to applying power, slide the slip indicator or non-slip blank door cover at the bottom-center of the IDU bezel upward to the first detent position to expose the USB port.



**Figure 2-6: Ground Maintenance Page**

## 2.8.2. Update Requirements

When an update is performed, the procedures must be performed on every IDU in the EFIS system separately. Scheduled updates are as follows:

Navigation Database Every 28 days

Obstruction Database Every 28 days

The EFIS Software and Terrain Database are unscheduled and on-condition and covered under a Service Bulletin.

**The Jeppesen Navigation and Obstruction database may be accessed through [www.jeppesen.com](http://www.jeppesen.com) to place the order for the correct database.**

There are three types of navigation databases that may be used on this EFIS.

**Americas** - Containing major airports and navigation for Alaska, Canada, Continental U.S., Hawaii, Puerto Rico, Bahamas, Bermuda, Mexico, Central, and South America.

**International** - Containing all available coverage except North and South America.

**World** - Containing major airports and navigation with the Americas.

The Navigation database is loaded on each IDU by placing the program **navdata.exe** on a USB Memory card.

### **CAUTION:**

**Failure to update the EFIS with the correct navigation database causes the IDU to remain in continual reboot mode and does not allow any display page to appear.**

### **CAUTION:**

**Always install a valid USB Memory Device in the IDU prior to activating any Ground Maintenance Function. Operation of the Ground Maintenance Function without a valid USB memory device installed may cause erroneous failure indications or corruption of the IDU.**




The obstruction database is distributed by a government agency in each country. Not all countries have obstruction databases available.

Once the NavData database (navdata.exe) and obstruction database (obst.exe) are loaded on the USB memory device, insert the USB device into USB port with the power off. Turn power on to gain access to the GMF page. Scroll **1** to **“Update Databases”** and push to enter. Once each database is loaded, the pilot is prompted to press any button to continue to complete the process. Once both databases have successfully been uploaded, power down the IDU, remove the USB memory device, and lower the USB door. Repeat this process for each IDU installed in the aircraft.

### NOTE:

During a NavData update and a stored flight plan contains a waypoint which has been changed, it is either updated, or the flight plan is deleted during the update process.



**Figure 2-7: IDU-680 Startup Screen**

Once each IDU has been updated, power up the entire EFIS system in normal flight mode and verify each IDU successfully updated with the latest database by noting the new NavData cycle expiration dates before acknowledging the startup screen. There is no expiration for the obstruction database.

Cyclic Redundancy Check (CRC) self-test at every step of the process verifies all data loaded into the IDU and ensures the data installed into the system was not corrupted at any point during the process.

The IDU provides an updateable navigation database containing at least the following location and path information, referenced to WGS-84, with a resolution of 0.01 minute (latitude/longitude) and 0.1° (for course information) or better at all of the following for the area(s) in which IFR operations are intended:

- 1) Airports;
- 2) VORs, DMEs (including DMEs collocated with localizers), collocated VOR/DMEs, VORTACs and NDBs (including NDBs used as locator outer marker);
- 3) All named waypoints and intersections shown on enroute and terminal area charts;
- 4) All airways shown on enroute charts, including all waypoints, intersections, and associated RNP values (if applicable). Airways are retrievable as a group of waypoints (select the airway by name to load the appropriate waypoints and legs between the desired entry and exit points into the flight plan).
- 5) RNAV DPs and STARs, including all waypoints, intersections, and associated RNP values if applicable. DPs and STARs are retrievable as a procedure (select the procedure by name to load the appropriate waypoints and legs into the flight plan).
- 6) LNAV approach procedures in the area(s) in which IFR operation is intended consist of:
  - a) Runway number and label (required for approach identification);
  - b) Initial Approach Waypoint (IAWP);
  - c) Intermediate Approach Waypoint(s) (IWP) (when applicable);
  - d) Final Approach Waypoint (FAWP);
  - e) Missed Approach Waypoint (MAWP);
  - f) Additional missed approach waypoints (when applicable); and
  - g) Missed Approach Holding Waypoint (MAHWP).

The complete sequence of waypoints and associated RNP values (if applicable), in the correct order for each approach,

is retrievable as a procedure (select the procedure by name to load the appropriate waypoints and legs into the flight plan). Waypoints utilized as a final approach waypoint (FAWP) or missed approach waypoint (MAWP) in an LNAV approach procedure are uniquely identified as such (when appropriate) to provide proper approach mode operation.

- 7) LNAV/VNAV procedures in the area(s) where IFR operation is intended. LPV, LP, and/or LNAV/VNAV published procedures are available.

Select a procedure by name to load the appropriate waypoints and legs into the active flight plan. Waypoints used as a Final Approach Waypoint (FAWP) and LTP/FTP/MAWP in an LNAV/VNAV procedure are uniquely identified as such to provide proper approach mode operation.

### **2.8.3. Terrain Database Update**

The IDU-680 contains the entire World Terrain Database, which is updated on an as-needed basis as described in a service bulletin.

# **Section 3      Display Symbology**

## Table of Contents

SECTION 3	DISPLAY SYMBOLOGY .....	3-1
3.1.	INTRODUCTION.....	3-12
3.2.	APPLICATION SOFTWARE AIR MODE AND GROUND MODE .... .....	3-12
3.3.	IDU-680 PFD DISPLAY (NORMAL MODE).....	3-13
3.3.1.	<i>IDU-680 PFD Display (Essential Mode)</i> .....	3-14
3.3.2.	<i>IDU-680 PFD Display (Basic Mode)</i> .....	3-15
3.3.3.	<i>IDU-680 MFD Display (Normal Mode)</i> .....	3-16
3.3.4.	<i>IDU-680 MFD Display (Essential Mode)</i> .....	3-17
3.3.5.	<i>IDU-680 MFD Display (Normal Mode) with EICAS.</i> .....	3-18
3.4.	MENU FUNCTIONS.....	3-18
3.4.1.	<i>Selecting BARO</i> .....	3-19
3.4.2.	<i>Selected Altitude Sub-Mode (Target Altitude)</i> .	3-21
3.4.3.	<i>VNAV Sub-Mode</i> .....	3-22
3.4.4.	<i>Altitude Display (VNAV Tile)</i> .....	3-23
3.4.5.	<i>Altitude Display (Metric Units)</i> .....	3-24
3.5.	PFD SYMBOLOGY .....	3-24
3.5.1.	<i>Minimum Altitude</i> .....	3-25
3.5.2.	<i>Vertical Speed Indicator</i> .....	3-26
3.5.3.	<i>Normal AGL Indication</i> .....	3-28
3.5.4.	<i>Analog AGL Indication</i> .....	3-29
3.5.5.	<i>Decision Height</i> .....	3-30
3.5.6.	<i>Airspeed Display</i> .....	3-31
3.5.7.	<i>Airspeed Display (With EFIS-Coupled)</i> .....	3-36
3.5.8.	<i>Heading Display</i> .....	3-36

3.5.9.	<i>Pitch Scale</i> .....	3-38
3.5.10.	<i>Pitch Limit Indicator</i> .....	3-39
3.5.11.	<i>G-Force and Fast/Slow Indicator</i> .....	3-40
3.5.12.	<i>Basic Mode</i> .....	3-41
3.5.13.	<i>Unusual Attitude Mode</i> .....	3-42
3.5.14.	<i>PFD Background</i> .....	3-43
3.5.15.	<i>Flight Path Marker (Velocity Vector)</i> .....	3-48
3.5.16.	<i>Bank Angle Scale</i> .....	3-50
3.5.17.	<i>Turn Indication</i> .....	3-50
3.5.18.	<i>Timer Indication</i> .....	3-51
3.5.19.	<i>Marker Beacon Symbology</i> .....	3-51
3.5.20.	<i>Flight Director Symbology (FD1 Single Cue)</i> ...	3-51
3.5.21.	<i>Flight Director Symbology (FD2 Dual Cue)</i> .....	3-52
3.5.22.	<i>Course Deviation Indicator</i> .....	3-53
3.5.23.	<i>OBS Setting of CDI</i> .....	3-55
3.5.24.	<i>Heading/Roll-Steering Sub-Mode</i> .....	3-55
3.5.25.	<i>Vertical Deviation Indicator</i> .....	3-55
3.5.26.	<i>Vertical Deviation Indicator (EFIS Coupled)</i> .....	3-58
3.5.27.	<i>Highway in the Sky/Skyway</i> .....	3-59
3.5.28.	<i>Active Waypoint and Waypoint Identifier</i> .....	3-59
3.5.29.	<i>Mini Map</i> .....	3-60
3.5.30.	<i>Runways</i> .....	3-62
3.5.31.	<i>Traffic Thumbnail</i> .....	3-63
3.5.32.	<i>Traffic Display Definitions</i> .....	3-64
3.5.33.	<i>Traffic Rendering Rules</i> .....	3-64
3.6.	<b>FULLY INTEGRATED AUTOPILOT ANNUNCIATIONS</b> .....	3-66

3.7.	NAVIGATION DISPLAY SYMBOLOGY .....	3-70
3.7.1.	<i>Basic Moving Map</i> .....	3-71
3.7.2.	<i>Ownship Symbology</i> .....	3-71
3.7.3.	<i>Moving Map with Instrument Approach</i> .....	3-72
3.7.4.	<i>North-Up Arc Mode</i> .....	3-72
3.7.5.	<i>North-Up Centered Mode</i> .....	3-73
3.7.6.	<i>Heading-Up Centered Mode</i> .....	3-73
3.8.	CONVENTIONAL HSI/PTR FORMAT .....	3-74
3.8.1.	<i>Compass Rose Symbols</i> .....	3-75
3.8.2.	<i>Fuel Totalizer/Waypoint Bearing and Distance Functions</i> .....	3-76
3.8.3.	<i>Clock/Timers/Options</i> .....	3-78
3.9.	NAVIGATION LOG .....	3-80
3.9.1.	<i>Clock and Groundspeed</i> .....	3-80
3.9.2.	<i>Fuel Remaining and Fuel Flow Data</i> .....	3-80
3.9.3.	<i>Waypoint Identifier Column</i> .....	3-80
3.9.4.	<i>VNAV and VNAV Offset Column</i> .....	3-82
3.9.5.	<i>Path Column</i> .....	3-82
3.9.6.	<i>Distance Column</i> .....	3-83
3.9.7.	<i>Estimated Time Enroute Column</i> .....	3-83
3.9.8.	<i>Estimated Time of Arrival Column</i> .....	3-83
3.9.9.	<i>Fuel Remaining Column</i> .....	3-84
3.10.	START POINT .....	3-84
3.11.	ALTITUDE CAPTURE PREDICTOR .....	3-84
3.11.1.	<i>Top of Descent</i> .....	3-84
3.12.	PROJECTED PATH .....	3-85

3.13.	ACTIVE FLIGHT PLAN PATH/MANUAL COURSE/RUNWAYS .....	3-86
3.14.	FOV INDICATION .....	3-87
3.15.	RANGE.....	3-87
3.16.	NAVIGATION DATA .....	3-88
3.16.1.	<i>Air Data and Groundspeed</i> .....	3-90
3.16.2.	<i>Analog Navigation Symbology</i> .....	3-91
3.16.3.	<i>Borders</i> .....	3-92
3.16.4.	<i>Terrain/Obstructions</i> .....	3-92
3.17.	PAN MODE.....	3-95
3.18.	HSI SCREEN .....	3-96
3.18.1.	<i>HSI Screen VDI</i> .....	3-96
3.18.2.	<i>Analog Navigation Symbology</i> .....	3-97
3.18.3.	<i>Air Data and Groundspeed</i> .....	3-99
3.18.4.	<i>Clock/Timers/Options</i> .....	3-100
3.18.5.	<i>Fuel Totalizer/Waypoint Bearing and Distance Functions</i> .....	3-101
3.19.	WX-500 DATA .....	3-101
3.19.1.	<i>Strike Screen Range</i> .....	3-102
3.19.2.	<i>Active Flight Plan Path/Manual Course/Runways</i> ... .....	3-103
3.20.	DEDICATED TRAFFIC SCREEN .....	3-104
3.20.1.	<i>Ownship Symbol</i> .....	3-104
3.20.2.	<i>Traffic Screen Range</i> .....	3-105
3.20.3.	<i>Compass Rose Symbols</i> .....	3-105
3.20.4.	<i>Active Flight Plan Path/Manual Course/Runways</i> ... .....	3-106
3.21.	DATALINK SYMBOLOGY .....	3-107



3.21.1.	<i>Datalink Screen Legend</i> .....	3-112
3.21.2.	<i>Air Data and Groundspeed</i> .....	3-112
3.21.3.	<i>Clock/Timers/Options</i> .....	3-112
3.21.4.	<i>Datalink Screen Orientation</i> .....	3-117
3.21.5.	<i>Datalink Screen Range</i> .....	3-118
3.21.6.	<i>Boundary Circle Symbols</i> .....	3-118
3.21.7.	<i>Active Flight Plan Path/Manual Course/Runways</i> .. .....	3-119
3.21.8.	<i>Borders</i> .....	3-119
3.21.9.	<i>Pan Mode</i> .....	3-120
3.22.	WEATHER RADAR .....	3-120
3.22.1.	<i>Weather Screen Format</i> .....	3-121
3.22.2.	<i>Weather Screen Range</i> .....	3-122
3.22.3.	<i>Track Line</i> .....	3-123
3.22.4.	<i>Active Flight Plan Path/Manual Course/Runways</i> .. .....	3-123
3.22.5.	<i>Weather Radar Return Data</i> .....	3-124
3.22.6.	<i>Air Data and Groundspeed</i> .....	3-126
3.22.7.	<i>Clock/Timers/Options</i> .....	3-126
3.22.8.	<i>Fuel Totalizer/Waypoint Bearing and Distance Functions</i> .....	3-129
3.23.	VIDEO INPUT SCREEN.....	3-129
3.23.1.	<i>ZOOM Level</i> .....	3-130
3.23.2.	<i>Pan Mode</i> .....	3-130
3.23.3.	<i>Video Input Status Display</i> .....	3-131

## List of Figures and Tables

FIGURE 3-1: PFD IN NORMAL MODE.....	3-13
FIGURE 3-2: PFD IN ESSENTIAL MODE WITH EICAS CONFIGURED..	3-14
FIGURE 3-3: PFD IN BASIC MODE.....	3-15
FIGURE 3-4: MFD IN NORMAL MODE WITH MAP PAGE DISPLAYED ON TOP AND BOTTOM.....	3-16
FIGURE 3-5: MFD IN ESSENTIAL MODE WITH EICAS CONFIGURED ..	3-17
FIGURE 3-6: MFD IN NORMAL MODE WITH EICAS ON TOP AND MAP ON BOTTOM.....	3-18
FIGURE 3-7: MENU FUNCTIONS .....	3-19
FIGURE 3-8: ENCODER FUNCTIONS .....	3-19
FIGURE 3-9: SELECTING BARO.....	3-20
FIGURE 3-10: ALTIMETER SETTING .....	3-20
FIGURE 3-11: ALTIMETER QFE.....	3-21
FIGURE 3-12: TARGET ALTITUDE BUG (VERTICALLY INTEGRATED) ..	3-21
FIGURE 3-13: TARGET ALTITUDE BUG (NOT VERTICALLY INTEGRATED) .....	3-22
FIGURE 3-14: VNAV SUB-MODE (NOT VERTICALLY INTEGRATED) ..	3-22
FIGURE 3-15: VNAV SUB-MODE (VERTICALLY INTEGRATED).....	3-23
FIGURE 3-16: ALTITUDE DISPLAY (VNAV TILE) .....	3-23
FIGURE 3-17: ALTITUDE DISPLAY (METRIC UNITS).....	3-24
FIGURE 3-18: PFD SYMBOLOGY.....	3-25
FIGURE 3-19: MINIMUM ALTITUDE.....	3-26
FIGURE 3-20: VSI.....	3-26
TABLE 3-1: SCALE GRADUATIONS AND DISPLAY .....	3-27
FIGURE 3-21: VSI BUG .....	3-27
FIGURE 3-22: VSI BUG (VERTICALLY INTEGRATED).....	3-28
FIGURE 3-23: NORMAL AGL INDICATION.....	3-28
TABLE 3-2: AGL INDICATION TO AVOID JUMPINESS .....	3-29
FIGURE 3-24: ANALOG AGL INDICATION .....	3-29
TABLE 3-3: ANALOG AGL INDICATOR.....	3-29
TABLE 3-4: ANALOG AGL INDICATOR MARKINGS .....	3-30
FIGURE 3-25: DECISION HEIGHT .....	3-31
FIGURE 3-26: AIRSPEED DISPLAY .....	3-31
FIGURE 3-27: AIRSPEED TREND .....	3-32
TABLE 3-5: AIRSPEED BUG LIMITS .....	3-32
TABLE 3-6: AIRSPEED BUG SETTING ANNUNCIATION AND BUG COLORS .....	3-32
FIGURE 3-28: AIRSPEED SCALE FAR PART 23.....	3-34
FIGURE 3-29: AIRSPEED SCALE FAR PART 25.....	3-36
FIGURE 3-30: AIRSPEED DISPLAY (WITH EFIS-COUPLED).....	3-36
FIGURE 3-31: HEADING DISPLAY .....	3-37
FIGURE 3-32: SLIP/SKID INDICATOR.....	3-37

FIGURE 3-33: HEADING BUG DISPLACED .....	3-38
FIGURE 3-34: PITCH SCALE .....	3-39
FIGURE 3-35: PITCH LIMIT INDICATOR .....	3-39
TABLE 3-7: AMBER (YELLOW) PITCH LIMIT INDICATOR APPEARANCE LIMITS.....	3-39
FIGURE 3-36: G-FORCE INDICATOR.....	3-40
FIGURE 3-37: G-FORCE INDICATOR TELLTALE INDICATIONS.....	3-40
FIGURE 3-38: FAST SLOW INDICATOR.....	3-41
FIGURE 3-39: BASIC MODE .....	3-41
FIGURE 3-40: LANDING GEAR INDICATION.....	3-41
FIGURE 3-41: UNUSUAL ATTITUDE MODE .....	3-42
FIGURE 3-42: AIRPLANE PFD TERRAIN AND OBSTRUCTIONS .....	3-44
TABLE 3-8: LAT-LON RESOLUTION BOUNDARIES .....	3-45
TABLE 3-9: TERRAIN AND OBSTRUCTION RENDERING LEVELS.....	3-46
FIGURE 3-43: PFD WITH TERRAIN Deselected ON PFD .....	3-47
FIGURE 3-44: FLIGHT PATH MARKER.....	3-48
TABLE 3-10: FLIGHT PATH MARKER BEHAVIOR .....	3-49
FIGURE 3-45: FLIGHT PATH MARKER GHOST .....	3-49
FIGURE 3-46: BANK ANGLE .....	3-50
FIGURE 3-47: TURN INDICATION .....	3-50
FIGURE 3-48: TIMER.....	3-51
FIGURE 3-49: MARKER BEACONS.....	3-51
FIGURE 3-50: FLIGHT DIRECTOR FD1 (SINGLE CUE).....	3-52
FIGURE 3-51: FLIGHT DIRECTOR FD1 (BASIC MODE).....	3-52
FIGURE 3-52: FLIGHT DIRECTOR FD2 (NORMAL MODE) .....	3-52
FIGURE 3-53: FLIGHT DIRECTOR FD2 (BASIC MODE).....	3-53
FIGURE 3-54: COURSE DEVIATION INDICATOR .....	3-53
TABLE 3-11: CDI BEHAVIOR AND COLOR.....	3-54
TABLE 3-12: VERTICAL DEVIATION INDICATOR BEHAVIOR .....	3-55
FIGURE 3-55: VERTICAL DEVIATION INDICATOR.....	3-57
FIGURE 3-56: VERTICAL DEVIATION INDICATOR COLOR DURING GPS/SBAS LON OR VLON .....	3-58
FIGURE 3-57: EFIS COUPLED VERTICALLY WITH GLIDESLOPE MODE ENGAGED .....	3-58
FIGURE 3-58: HIGHWAY IN THE SKY .....	3-59
FIGURE 3-59: ACTIVE WAYPOINT .....	3-59
FIGURE 3-60: MINI MAP.....	3-60
TABLE 3-13: MINI-MAP BEHAVIOR (WHEN NOT DECLUTTERED) .....	3-61
FIGURE 3-61: MINI MAP VOR SYMBOLOGY .....	3-61
FIGURE 3-62: RUNWAYS.....	3-62
TABLE 3-14: RUNWAY DRAWING CRITERIA .....	3-63
FIGURE 3-63: TRAFFIC THUMBNAIL.....	3-63
TABLE 3-15: TRAFFIC RENDERING RULES.....	3-64

TABLE 3-16: PILOT SELECTED OT AND PA TRAFFIC ALTITUDE-FILTER ...	3-65
TABLE 3-17: TRAFFIC SYMBOLGY .....	3-65
FIGURE 3-64: TRAFFIC SYMBOLGY .....	3-66
FIGURE 3-65: AUTOPILOT ANNUNCIATION .....	3-66
FIGURE 3-66: AUTOPILOT INITIALIZING IN ROLL AND PITCH MODES..	3-67
FIGURE 3-67: AUTOPILOT READY (ABSENCE OF FAIL OR INIT).....	3-67
FIGURE 3-68: AUTOPILOT ROLL AND PITCH MODES.....	3-67
FIGURE 3-69: FD DISPLAYED ON PFD WITH ROLL AND PITCH MODES....	3-67
FIGURE 3-70: AUTOPILOT HDG AND ALT MODES ENGAGED.....	3-67
FIGURE 3-71: AUTOPILOT WITH HDG, NAV:VOR, AND ALT MODES ENGAGED.....	3-68
FIGURE 3-72: AUTOPILOT WITH HDG, APR:LOC, AND ALT MODES ENGAGED.....	3-68
FIGURE 3-73: AUTOPILOT WITH HDG, APR:LOC, ALT, AND APR: GS.....	3-68
FIGURE 3-74: AUTOPILOT WITH HDG AND VS MODES ENGAGED ...	3-68
FIGURE 3-75: AUTOPILOT WITH HDG AND IAS MODES ENGAGED ...	3-68
FIGURE 3-76: AUTOPILOT WITH HDG AND PITCH MODES ENGAGED	3-69
FIGURE 3-77: AUTOPILOT WITH HDG, NAV:BC, AND PITCH MODES ENGAGED.....	3-69
FIGURE 3-78: AUTOPILOT WITH APR:LOC AND APR:GS MODES ENGAGED.....	3-69
FIGURE 3-79: AUTOPILOT WITH APR:FMS AND APR:GS MODES ENGAGED.....	3-69
FIGURE 3-80: AUTOPILOT WITH NAV:FMS AND ALT MODES ENGAGED.....	3-69
FIGURE 3-81: AUTOPILOT WITH NAV:LOC AND ALT MODES ENGAGED.....	3-70
FIGURE 3-82: AUTOPILOT WITH APR:BC AND ALT MODES ENGAGED....	3-70
FIGURE 3-83: AUTOPILOT WITH CWS MODE ENGAGED .....	3-70
FIGURE 3-84: AUTOPILOT WITH G/A (GO-AROUND) ENGAGED IN ROLL AND PITCH MODES.....	3-70
FIGURE 3-85: BASIC MOVING MAP.....	3-71
FIGURE 3-86: OWNSHIP SYMBOLGY .....	3-71
FIGURE 3-87: MOVING MAP WITH INSTRUMENT APPROACH.....	3-72
FIGURE 3-88: NORTH-UP ARC MODE .....	3-72
FIGURE 3-89: NORTH-UP CENTERED MODE.....	3-73
FIGURE 3-90: HEADING-UP CENTERED MODE.....	3-73
FIGURE 3-91: CONVENTIONAL HSI/PTR FORMAT.....	3-74
FIGURE 3-92: HSI OWNSHIP SYMBOLS (CENTERED ON THE HSI AND POINTING STRAIGHT UP).....	3-74

FIGURE 3-93: COMPASS ROSE.....	3-75
FIGURE 3-94: FUEL TOTALIZER/WAYPOINT BEARING AND DISTANCE FUNCTIONS .....	3-76
TABLE 3-18: FUEL TOTALIZER/WAYPOINT BEARING AND DISTANCE FUNCTIONS .....	3-76
FIGURE 3-95: CLOCK AND TIMERS.....	3-78
TABLE 3-19: CLOCK/TIMERS/OPTIONS .....	3-78
FIGURE 3-96: NAVIGATION LOG .....	3-80
TABLE 3-20: GRAPHICAL METAR SYMBOLS .....	3-81
FIGURE 3-97: START POINT .....	3-84
FIGURE 3-98: TOP-OF-DESCENT OR TOP-OF-CLIMB.....	3-85
FIGURE 3-99: PROJECTED PATH .....	3-85
FIGURE 3-100: FIELD OF VIEW .....	3-87
FIGURE 3-101: RANGE .....	3-88
FIGURE 3-102: NAVIGATION DATA AND AIRSPACE DEPICTION.....	3-88
TABLE 3-21: AIRSPACE DEPICTION.....	3-89
FIGURE 3-103: AIR DATA AND GROUNDSPEED.....	3-90
FIGURE 3-104: ANALOG NAVIGATION SYMBOLOGY.....	3-91
FIGURE 3-105: BORDERS .....	3-92
TABLE 3-22: TERRAIN DISPLAY ON NAVIGATION DISPLAY COLOR RELATIONSHIP TO AIRCRAFT ALTITUDE.....	3-92
FIGURE 3-106: TERRAIN/OBSTRUCTIONS .....	3-93
FIGURE 3-107: OBSTRUCTIONS.....	3-94
TABLE 3-23: OBSTRUCTIONS .....	3-94
FIGURE 3-108: PAN MODE.....	3-95
FIGURE 3-109: HSI POINTER COLOR .....	3-96
FIGURE 3-110: ANALOG NAVIGATION DISPLAY VOR1 AND VOR2...	3-97
FIGURE 3-111: HSI BEARING DISTANCE READOUT WITH DME IN HOLD .....	3-97
FIGURE 3-112: HSI BEARING DISTANCE READOUT WITHOUT DME IN HOLD .....	3-98
FIGURE 3-113: HSI BEARING DISTANCE READOUT WITH DME IN HOLD .....	3-98
FIGURE 3-114: HSI WITH MARKER BEACON DISPLAYED .....	3-99
FIGURE 3-115: HSI DISPLAY AIR DATA AND GROUNDSPEED .....	3-99
FIGURE 3-116: HSI CLOCK/TIMERS .....	3-100
FIGURE 3-117: HSI FUEL TOTALIZER/WAYPOINT BEARING.....	3-101
TABLE 3-24: LIGHTNING STRIKES .....	3-101
FIGURE 3-118: LIGHTNING SYMBOLS.....	3-102
FIGURE 3-119: ACTIVE FLIGHT PLAN PATH/MANUAL COURSE/RUNWAYS .....	3-103
TABLE 3-25: WX-500 STATUS .....	3-104
FIGURE 3-120: DEDICATED TRAFFIC SCREEN OWNERSHIP SYMBOLS	3-104
FIGURE 3-121: TRAFFIC DISPLAY FORMAT .....	3-105

FIGURE 3-122: TRAFFIC SCREEN RANGE COMPASS ROSE SYMBOLS .....	3-105
FIGURE 3-123: DATALINK SYMBOLOGY .....	3-107
TABLE 3-26: WSI INFLIGHT™ DATA PRODUCTS .....	3-107
TABLE 3-27: DATALINK NEXRAD RADAR DATA .....	3-108
TABLE 3-28: DATALINK NEXRAD ECHO TOPS .....	3-109
TABLE 3-29: DATALINK GRAPHICAL METARS .....	3-109
TABLE 3-30: GRAPHICAL METARS (GMETARS) SCREEN RANGE .....	3-109
FIGURE 3-124: NRST AIRPORT INFO .....	3-110
TABLE 3-31: DATALINK GRAPHICAL METAR PRECIPITATION.....	3-110
FIGURE 3-125: DATALINK WINDS AND TEMPERATURE ALOFT .....	3-111
FIGURE 3-126: DATALINK SCREEN LEGEND .....	3-112
FIGURE 3-127: CLOCK/TIMERS/OPTIONS .....	3-112
TABLE 3-32: DATALINK NEXRAD RADAR STATUS.....	3-113
FIGURE 3-128: DATALINK.....	3-117
TABLE 3-33: DATALINK SCREEN RANGE VALUES .....	3-118
FIGURE 3-129: BOUNDARY CIRCLE SYMBOL .....	3-118
TABLE 3-34: WEATHER RADAR INHIBITED CONDITIONS .....	3-120
FIGURE 3-130: WEATHER RADAR ON ND.....	3-121
FIGURE 3-131: RADAR IN ARCED FORMAT .....	3-121
FIGURE 3-132: RADAR IN PROFILE DEPICTION .....	3-122
FIGURE 3-133: RADAR TRACK LINE .....	3-123
FIGURE 3-134: RADAR ACTIVE FLIGHT PLAN.....	3-124
FIGURE 3-135: RADAR RETURN DATA .....	3-124
TABLE 3-35: WEATHER RADAR RETURN DATA .....	3-125
FIGURE 3-136: RADAR CLOCK/TIMER/OPTIONS .....	3-126
TABLE 3-36: RDR 2100 APPLICABILITY .....	3-127
TABLE 3-37: RDR 2100 MODE ANNUNCIATION .....	3-127
FIGURE 3-137: VIDEO PAN VIEW .....	3-130
FIGURE 3-138: VIDEO STATUS .....	3-131

### 3.1. Introduction

In an IFR installation, the software of the primary IDU-680 is configured so only the primary screen (Primary Flight Information display top half and Multifunction Display bottom half) is displayed. The software is configured on all other IDU-680 displays so any screen display is shown at any time. The only limitation to this rule is where IDU-680 displays are configured as a primary display of engine information; at least one of the Multi-Function display areas must show the engine display.

The following sections detail the symbology used on the PFD IDU-680 in Normal and Essential modes and the MFD IDU-680 in Normal and Essential modes. Not all combinations of possible views are represented.

### 3.2. Application Software Air Mode and Ground Mode

Numerous symbology elements change behavior depending upon whether the aircraft is on the ground or in flight. This is referred to as Air Mode and Ground Mode. This determination is separate from the system initialization modes described in Section 2 System Overview. This parameter is continuously calculated as follows:

- 1) If a Weight on Wheels/Weight on Ground discrete input is configured, the Air or Ground Modes are determined solely from the discrete input position.
- 2) Otherwise, Mode is determined as follows:
  - a) If airspeed is valid and AGL altitude is valid, Ground Mode is set when indicated airspeed is less than 40 knots, and AGL altitude is less than 75 feet.
  - b) If airspeed is invalid but AGL altitude is valid, Ground Mode is set when AGL altitude is less than 75 feet.
  - c) Under any other circumstance, Air Mode is set by default.

### 3.3. IDU-680 PFD Display (Normal Mode)



Figure 3-1: PFD in Normal Mode



### 3.3.1. IDU-680 PFD Display (Essential Mode)





Figure 3-2: PFD in Essential Mode with EICAS Configured

### 3.3.2. IDU-680 PFD Display (Basic Mode)




**Figure 3-3: PFD in Basic Mode**

When enabled through mode selection, Basic Mode is a traditional attitude display with the airspeed, altitude, and heading scales appearing in blacked-out areas in a “Basic-T” arrangement but is disabled while Unusual Attitude Mode is active. The following list of features is no longer present when the Basic mode is displayed:

- 1) Atmospheric perspective
- 2) Terrain rendering
- 3) Obstructions rendering
- 4) Flight Path Marker
- 5) Availability of Bank Scale option
- 6) Airport runways

### 3.3.3. IDU-680 MFD Display (Normal Mode)



**Figure 3-4: MFD in Normal Mode with MAP Page Displayed on Top and Bottom**

### 3.3.4. IDU-680 MFD Display (Essential Mode)





Figure 3-5: MFD in Essential Mode with EICAS Configured

### 3.3.5. IDU-680 MFD Display (Normal Mode) with EICAS



**Figure 3-6: MFD in Normal Mode with EICAS on Top and Map on Bottom**

### 3.4. Menu Functions

On the IDU-680, soft menu functions are used at both levels and displayed in a dedicated, blacked-out area in the screen margins. Soft menu function tiles indicate further menu levels with a filled triangle (with further levels) or hollow triangle (without further levels) pointing to the associated peripheral button. Soft menu function tiles appear next to the appropriate IDU button or adjacent to one of the encoders when appropriate.



**Figure 3-7: Menu Functions**



**Figure 3-8: Encoder Functions**

Selection lists too long to be presented in the available space indicate the location within the list. When the menu system is beyond the top-level, **EXIT** appears adjacent to the top right pushbutton (**R1**) to provide one touch escape to the top-level. When a soft menu level is deeper than the first-level, **BACK** appears adjacent to the top left pushbutton (**L1**) to provide a method of regressing through the menu system by one level.

### 3.4.1. Selecting BARO

Press the **BARO** button to enter the BARO mode and view the inches of mercury (inHg) or millibars (mbar) value in the lower right corner. Scroll **1** clockwise to increase QNH and counter clockwise to decrease QNH. Push **1** to enter the new value.



**Figure 3-9: Selecting BARO**

The altimeter setting is shown immediately below the altitude readout box and digitally displays the altimeter setting in either inches of mercury (inHg) or millibars (mbar) according to the pilot-selected units. Immediately below the altimeter setting, the mode is identified as QFE operations, otherwise no mode is indicated.

**QFE:** Barometric setting resulting in the altimeter displaying height above a reference elevation (i.e., airport or runway threshold).

**QNE:** Standard barometric setting (29.92 inHg or 1013 mbar) used to display pressure altitude for flight above the transition altitude.

**QNH:** Barometric setting resulting in the altimeter displaying altitude above mean sea level at the reporting station.



**Figure 3-10: Altimeter Setting**



**Figure 3-11: Altimeter QFE**

### 3.4.2. Selected Altitude Sub-Mode (Target Altitude)

When in selected altitude sub-mode, the altitude scale has a pilot-settable target altitude bug geometrically interacting with the altitude box pointer. The target altitude bug setting is limited to -1000 feet at the low end and 50,000 at the high end, and is annunciated above the altitude scale as seen above with a resolution of 100 feet.

When in altitude hold mode, the target altitude bug setting annunciation is green, while the target altitude bug is filled-white.



When in a climb or descent mode, the target altitude bug setting annunciation is white, and the target altitude bug is hollow-white.

During altitude hold capture, the target altitude bug setting annunciation is green and flashes, while the target altitude bug is filled-white.



**Figure 3-12: Target Altitude Bug (Vertically Integrated)**



When not vertically integrated with an autopilot, the target altitude bug setting annunciation is white, and the target altitude bug is filled-white at all times.



**Figure 3-13: Target Altitude Bug (Not Vertically Integrated)**

### 3.4.3. VNAV Sub-Mode

When in VNAV sub-mode, the altitude scale shows the active waypoint VNAV altitude (if it exists) with a bug symbol geometrically interacting with the altitude box pointer. The VNAV altitude bug setting is annunciated above the altitude scale with a resolution of 100 feet.

When not vertically integrated with a fully-integrated digital autopilot, the VNAV altitude bug setting annunciation includes a legend with the abbreviation “VNAV” indicating the VNAV altitude sub-mode.

When vertically integrated with a fully-integrated digital autopilot, this legend is not needed because an equivalent indication appears in the autopilot mode annunciation area. The VNAV altitude bug is used either as a visual reference or, when vertically integrated with an autopilot either fully or partially integrated through use of the vertical mode discrete input, as a control parameter for climbs or descents.



**Figure 3-14: VNAV Sub-Mode (Not Vertically Integrated)**

When vertically integrated with an autopilot:

When in altitude hold mode, the VNAV altitude bug setting annunciation is green, and the VNAV altitude bug is filled-magenta.

The VNAV altitude bug setting annunciation is green and flashes, while the VNAV altitude bug is filled-magenta during altitude hold capture.

When in a climb or descent mode, the VNAV altitude bug setting annunciation is white, and the VNAV altitude bug is hollow-magenta.




**Figure 3-15: VNAV Sub-Mode (Vertically Integrated)**

When the VNAV altitude or target altitude differs from aircraft altitude to the extent the associated bug is off-scale, the associated bug is “parked” in the direction of the difference with half of the associated bug visible as seen in Figure 3-15.

#### 3.4.4. Altitude Display (VNAV Tile)

When enabled for performing VNAV with a manually selected altitude entered, **VNAV** tile appears for “one-touch” engagement of VNAV.



**Figure 3-16: Altitude Display (VNAV Tile)**

### 3.4.5. Altitude Display (Metric Units)

Pilot-selectable altitude values may be presented in metric units with a resolution of 10 meters as depicted.



**Figure 3-17: Altitude Display (Metric Units)**

### 3.5. PFD Symbology

The PFD combines pitot-static information, heading, attitude, 3-D navigation data, and more overlaid on a virtual background of the outside world. Other objects in the background, including terrain, obstructions, traffic, and runways are presented conformally as if seen directly in front of the aircraft while looking outside.



**Figure 3-18: PFD Symbolology**

### 3.5.1. Minimum Altitude

When a minimum altitude is selected (in 10-foot increments), a bug in the form of a bold amber (yellow) bar is displayed in the appropriate position on the altitude tape and below in amber (yellow).

The minimum altitude setting is indicated above the altitude tape with a line drawn below. In Figure 3-19, 760' MSL is set.

Minimum and target altitude/VNAV altitude bugs may be used simultaneously.



**Figure 3-19: Minimum Altitude**



**Audible Annunciation**

When a minimum altitude is set, descending from above to below causes an aural annunciation of “Minimums, Minimums” and the minimum altitude turns amber (yellow) and flashes.

**3.5.2. Vertical Speed Indicator**




A vertical speed indicator (VSI) is located to the right of the altitude box. The VSI is depicted as a "worm" format and provides an analog and digital representation of VSI in feet per minute.

**Figure 3-20: VSI**

**Table 3-1: Scale Graduations and Display**

Type Traffic Installed	Scale Limit	Scale Graduations and Display
With TCAS-II	±6,000 FPM	±500, ±1,000, ±2,000, ±4,000, and ±6,000 FPM The background of the VSI functions as an RA display with green and red colored regions to provide RA maneuver guidance.
Without TCAS-II	±3,000 FPM	±500, ±1,000, ±2,000, and ±3,000 FPM



The VSI worm grows in proportion to the square root of the vertical speed so a change near 0 feet per minute displaces the worm to a much greater degree than an equivalent change at a larger feet per minute value. Readouts of vertical speed rounded to the nearest 100 feet per minute appear above the VSI scale (for climbs) or below the VSI scale (for descents).

The pilot-selectable VSI bug setting in this example is set to 1000 FPM climb rate and has a resolution of 100 FPM.

**Figure 3-21: VSI Bug**

The vertical speed bug is used either as a visual reference or, when vertically integrated with an autopilot (either fully integrated or partially integrated through use of the vertical mode discrete input), as a control parameter for climbs or descents. It is mutually exclusive with the airspeed bug.




When vertically integrated with an autopilot, the VSI bug setting annunciation is green with the speed bug filled-white when in VSI climb or descent mode. Otherwise, the VSI bug setting is white, and VSI bug becomes hollow-white.

When not vertically integrated with an autopilot, the vertical speed bug setting annunciation is white, and the vertical speed bug is filled-white at all times.

**Figure 3-22: VSI Bug (Vertically Integrated)**

### 3.5.3. Normal AGL Indication



Normal AGL indication with DH 200 displayed below.

**Figure 3-23: Normal AGL Indication**

AGL altitude is displayed in two formats; one at the bottom-center of the display above the Course Deviation Indicator (Normal) and as the (Analog) AGL Indicator described below. These are mutually exclusive of each other and driven by whichever AGL altitude source is used for a TAWS system but not displayed when the source is invalid. A source indication appears to designate the source for either format as follows:

- 1) R = Radar altitude.
- 2) G = GPS/SBAS geodetic height less database ground elevation.
- 3) B = Barometric altitude less database ground elevation.

AGL indication designed behavior to avoid jumpiness.

**Table 3-2: AGL Indication to Avoid Jumpiness**

Altitude	300 Feet	≥100Feet < 300Feet	<100 Feet
AGL Indication resolution	10 Feet	5 Feet	1 Foot

AGL altitude is not displayed in either format when it is greater than the radar altimeter maximum valid altitude but not displayed when it is invalid. Additionally, AGL indication includes a display of the currently set decision height. This is accompanied by “Decision Height” aural annunciation, and the decision height display and readout turn amber (yellow) and flash.

#### 3.5.4. Analog AGL Indication



A pilot-selected analog AGL indication is displayed in the lower right corner of the PFD above the active waypoint identifier with a green circular tape and digital readout in the center. The circular tape has a radial line at its end and disappears above 1000' AGL.

**Figure 3-24: Analog AGL Indication****Table 3-3: Analog AGL Indicator**

Analog AGL Indicator Markings 0-1000 Feet		AGL	Scaling (at clock position)
0-100 Feet	100 Feet-1000 Feet	0' AGL	6:00
Linear	Logarithmic	50' AGL	9:00
		100' AGL	12:00
		200' AGL	1:30
		500' AGL	3:00



	<b>Major Tick Marks</b>	<b>Minor Tick Marks</b>
<b>0'</b>	✓	
<b>10'</b>		✓
<b>20'</b>		✓
<b>30'</b>		✓
<b>40'</b>		✓
<b>50'</b>	✓	
<b>60'</b>		✓
<b>70'</b>		✓
<b>80'</b>		✓
<b>90'</b>		✓
<b>100'</b>	✓	
<b>200'</b>		✓
<b>300'</b>		✓
<b>400'</b>		✓
<b>500'</b>	✓	
<b>1000'</b>	✓	

The Analog AGL indicator disappears in Unusual Attitude mode and is mutually exclusive with the Mini-Map and Traffic Thumbnail. Likewise, when the Analog AGL altitude display is shown, the normal AGL display is removed.

### **3.5.5. Decision Height**

Analog AGL indication includes a display of the currently set decision height to the left of the indication along with an amber (yellow) radial line on the circular tape.

The decision height turns amber (yellow) and flashes when the aircraft descends below decision height from above. When below decision height, the circular tape and digital readout are amber (yellow). This is accompanied by a “Decision Height” aural annunciation, and decision height readout turns amber (yellow) and flashes.



**Figure 3-25: Decision Height**

### 3.5.6. Airspeed Display



Airspeed is digitally displayed in the same color as airspeed scale in knots, miles per hour, or kilometers per hour with interactive pointer. The airspeed scale is commensurate with the certification category of the aircraft.


The airspeed box pointer interacts with the airspeed scale and has graduations every 10 measurement units with labels every 20 measurement units with high numbers at the top.

The airspeed scale range is 80-130 measurement units.

During an ADC failure, a red “X” is displayed in place of the airspeed scale.

**Figure 3-26: Airspeed Display**

An airspeed trend vector is calculated along the aircraft longitudinal axis and displayed in a “worm” format to provide an analog representation of the indicated airspeed achieved in ten seconds, assuming the instantaneous longitudinal acceleration rate is maintained along the velocity vector.



The pilot-settable airspeed bug geometrically interacts with the airspeed box pointer and is colored as per the following tables.

When the bug setting differs from aircraft speed to the extent the bug would be off scale, the bug appears to be “parked” as in this example.

**Figure 3-27: Airspeed Trend**

**Table 3-5: Airspeed Bug Limits**


Table 3-5: Airspeed Bug Limits	
Low end	High end
Higher of 1.2 x $V_s$ or 60KIAS	Red-line ( $V_{NE}$ , $V_{MO}$ , or $M_{MO}$ )

**Table 3-6: Airspeed Bug Setting Annunciation and Bug Colors**

	Without vertically integrated autopilot	With vertically integrated autopilot
<b>Airspeed bug setting annunciation color</b>	White at all times	Green when in airspeed climb or descent mode otherwise white.
<b>Airspeed Bug</b>	Filled-white at all times	Filled-white when in airspeed climb or descent mode otherwise hollow-white.

The airspeed scale background and readout for Part 23 airplanes has coloration as follows:

- 1) If in Air Mode, a red low-speed awareness area from the bottom of the scale to  $V_{S0}$ . The airspeed readout is red in this area.
- 2) If in Ground Mode, a gray area from the bottom of the scale to  $V_{S0}$ . The airspeed readout is gray at 0 (indicating “dead” airspeed) but otherwise white in this area.
- 3) If a valid  $V_{FE}$  exists, a white flap-operating area from  $V_{S0}$  to  $V_{FE}$ . The airspeed readout is white in this area.
- 4) For aircraft without a  $V_{MO}/M_{MO}$ :
  - a) A green safe-operating area from  $V_{S1}$  to  $V_{NO}$ . The airspeed readout is green in this area.
  - b) An amber (yellow) caution area from  $V_{NO}$  to  $V_{NE}$ . The airspeed readout is amber (yellow) in this area.
  - c) A red high-speed awareness area from  $V_{NE}$  to the top of the scale. The airspeed readout is red in this area.
- 5) For aircraft with a  $V_{MO}/M_{MO}$ :
  - a) A gray safe-operating area from  $V_{FE}$  (if it exists) or  $V_{S0}$  to  $V_{MO}/M_{MO}$ . The airspeed readout is green in this area.
  - b) A red high-speed awareness area from the lower of  $V_{MO}$  or  $M_{MO}$  to the top of the scale. The airspeed readout is red in this area.



**Figure 3-28: Airspeed Scale FAR Part 23**


The airspeed scale background and readout for Part 25 airplanes (Part 25 “Airspeed Scale Type”) has colored regions as follows:

- 1) If in Air Mode with a pilot-input  $V_{REF}$  value:
  - a) A red low-speed awareness area from the bottom of the scale to G-compensated  $1.1 \times V_{S0}$ .  $V_{S0}$  is calculated by dividing the pilot-input  $V_{REF}$  by 1.23. The airspeed readout is red in this area.
  - b) An amber (yellow) low-speed awareness area from G-compensated  $1.1 \times V_{S0}$  to G-compensated  $1.2 \times V_{S0}$ . The airspeed readout is amber (yellow) in this area.
  - c) If a valid  $V_{FE}$  exists, a white flap-operating area from G-compensated  $1.2 \times V_{S0}$  to  $V_{FE}$  and a gray normal-operating area from  $V_{FE}$  to the lower of  $V_{MO}$  or  $M_{MO}$ . The airspeed readout is white in the flap-operating area and green in the normal-operating area.

- d) If a valid  $V_{FE}$  does not exist, a gray normal-operating area from G-compensated  $1.2 \times V_{S0}$  to the lower of  $V_{MO}$  or  $M_{MO}$ . The airspeed readout is green in this area.
- 2) If in Ground Mode or without a pilot-input  $V_{REF}$  value:
    - a) If a valid  $V_{FE}$  exists, a white flap-operating area from the bottom of the scale to  $V_{FE}$  and a gray normal-operating area from  $V_{FE}$  to the lower of  $V_{MO}$  or  $M_{MO}$ . The airspeed readout is gray at 0 (indicating “dead” airspeed) but otherwise white in the flap-operating area and green in the normal-operating area.
    - b) If a valid  $V_{FE}$  does not exist, a gray normal-operating area from the bottom of the scale to the lower of  $V_{MO}$  or  $M_{MO}$ . The airspeed readout is gray at 0 (indicating “dead” airspeed) otherwise white below 60 and green at or above 60 in this area.
  - 3) A red high-speed awareness area from the lower of  $V_{MO}$  or  $M_{MO}$  to the top of the scale. The airspeed readout is red in this area.


The airspeed scale for Part 25 airplanes have additional specific airspeed markings as follows:

- 1) If pilot-input  $V_{REF}$  is valid, a white  $V_S$  marking at the aircraft's 1-G  $V_{S0}$  or an amber (yellow)  $V_S$  marking at  $V_{S0}$  corrected for G-loading, whichever is higher.  $V_{S0}$  is calculated by dividing the pilot-input  $V_{REF}$  by 1.23
- 2) If enabled ( $V_{GL}$  not 0), a “green dot” best glide speed marker at  $V_{GL}$ .
- 3) If enabled ( $V_X$  not 0), a  $V_X$  marking at  $V_X$ .
- 4) If enabled ( $V_Y$  not 0), a  $V_Y$  marking at  $V_Y$ .
- 5) If enabled ( $V_A$  not 0), a  $V_A$  marking at  $V_A$ .
- 6) If enabled ( $V_{MFE}$  not 0), a “white triangle” maximum flap extension speed marker at  $V_{MFE}$ .



**Figure 3-29: Airspeed Scale FAR Part 25**

### 3.5.7. Airspeed Display (With EFIS-Coupled)



Airspeed descent to 7,500' with green color and filled airspeed

**Figure 3-30: Airspeed Display (with EFIS-Coupled)**

### 3.5.8. Heading Display


The PFD heading scale across the top of the display is aligned with magnetic north with graduations every  $5^\circ$  with major graduations and heading labels every  $10^\circ$ . These graduations and digits of the heading scale are equally spaced so, at an aircraft roll angle of zero,

they approximately conform to the three-dimensional PFD background. The heading scale includes a triangular white heading pointer aligned with the longitudinal axis of the aircraft with a slip indicator.



**Figure 3-31: Heading Display**

An integral slip indicator is provided and may replace the mechanical slip indicator mounted in the bezel. The slip indicator is a rectangle just below the heading pointer that moves left and right to indicate the lateral acceleration sensed by the AHRS in the same manner as the ball in a mechanical slip indicator. The integral slip indicator is responsive to lateral (Y-axis) G-force (the slip indicator is the white rectangular part of the heading pointer) and is damped, so it approximately matches a conventional glass vial indicator.



**Figure 3-32: Slip/Skid Indicator**

The heading scale has a green, diamond-shaped track pointer aligned with the aircraft's track across the earth. When the aircraft's track is displaced from aircraft heading beyond the boundaries of the PFD screen, the track pointer is drawn at the limit of the heading scale in the direction of the displacement, and the aircraft track value is displayed in a solid green box above the track pointer. The track pointer is not displayed when indicated airspeed is in the noise range (when indicated airspeed or groundspeed is less than 30 KIAS).

The heading scale has a pilot-settable heading bug symbol designed to geometrically interact with the heading pointer. When the heading bug is set, the value is displayed in a white bordered black box above the heading bug symbol for a period of five



seconds. When the heading bug value is displaced from aircraft heading beyond the boundaries of the PFD screen, the heading bug symbol is drawn halved at the limit of the heading scale in the direction of the displacement, and the heading bug value is displayed in a white bordered black box above the heading bug symbol as seen in Figure 3-33.




**Figure 3-33: Heading Bug Displaced**

When an active waypoint exists, the heading scale includes a magenta, star-shaped waypoint pointer at a point corresponding with the active waypoint. When the waypoint pointer is displaced from aircraft heading beyond the boundaries of the PFD screen, the waypoint pointer is replaced by a magenta, triangular arrow at either the far-right or far-left limit of the heading scale to indicate the shortest (not necessarily the safest) direction of turn to the active waypoint as seen above. The waypoint pointer and shortest direction of turn indications turn amber (yellow) in the event of GPS Loss of Navigation caution.

### 3.5.9. Pitch Scale


Rotation of the background, pitch scale, and background oriented display elements occur relative to the location of the waterline symbol or Large Aircraft Reference Marks.

The pitch scale has increments every 5° with major increments and pitch scale labels every 10° and increments equally spaced to approximately conform to the three dimensional PFD background. Pointer bars at the ends of each major increment indicate the direction to the horizon. Pitch scale increments automatically declutter to present the fewest possible increments needed to unambiguously display pitch attitude. The pitch scale terminates with a zenith symbol (small white circle) at +90° and a nadir symbol (small white circle with “+”) at -90°.



**Figure 3-34: Pitch Scale**

**3.5.10. Pitch Limit Indicator**



**Figure 3-35: Pitch Limit Indicator**

An amber (yellow) feathered pitch limit indicator symbol appears at 20 knots indicated airspeed above stall speed defined as follows:

<b>Table 3-7: Amber (Yellow) Pitch Limit Indicator Appearance Limits</b>	
FAR Part 23 airplanes- 1-G $V_{S1}$ or $V_{S1}$ corrected for G-loading	Part 25 airplanes: If pilot-input $V_{REF}$ is valid, the higher of the aircraft's 1-G $V_{S0}$ or $V_{S0}$ corrected for G-loading where $V_{S0}$ is calculated by dividing the pilot-input $V_{REF}$ by 1.23.

The pitch limit indicator is a “feathered” symbol modified to work with either the Flight Path Marker or the Large Aircraft Symbol Reference Marks (Basic Mode or Unusual Attitude Mode). The pitch limit indicator first appears above the applicable reference symbol (either the Flight Path Marker or the Large Aircraft Symbol Reference Marks) and converges upon the applicable reference symbol as


indicated airspeed decreases. At five knots indicated airspeed above stall speed, the pitch limit indicator becomes red and merges with the applicable reference symbol at stall speed and continue moving downward as indicated airspeed further decreases.

### 3.5.11. G-Force and Fast/Slow Indicator



**Figure 3-36: G-Force Indicator**

A G-Force indicator appears in the normal mode as depicted or next to the Large Aircraft Symbol Reference Marks (Basic Mode or Unusual Attitude mode) when difference between G-Force and 1-G is greater than 0.3 Gs.



**Figure 3-37: G-Force Indicator Telltale Indications**

Positive telltales appear whenever G-force exceeds 2.5G

Negative telltales appear whenever negative G-force is less than -0.5G.


Telltales appear full-time within G-indication area and are removed when AOA Fast/Slow replaces G-indicator.

#### **NOTE:**

When **RESET G** option in the PFD declutter menu is pressed, the telltales reset to 0 unless the aircraft G-limits have been exceeded. If the G-limits have been exceeded, Ground Maintenance Function option is available to reset exceedance on the ground only.

When the landing gear is down and the EFIS is receiving a valid Flight Director Fast/Slow label, the G-Force indicator is replaced by

a Fast/Slow indicator which has a “worm” format providing an analog representation of deviation from a target angle of attack.




The Fast/Slow indicator worm grows in the “F” direction with angles of attack lower than the target and grows in the “S” direction with angles of attack higher than the target and is decluttered when on the ground.

**Figure 3-38: Fast Slow Indicator**


**3.5.12. Basic Mode**



**Figure 3-39: Basic Mode**



**Normal Mode**



**Basic Mode**

**Figure 3-40: Landing Gear Indication**

In the Normal and Basic modes, the PFD displays landing gear as shown in Figure 3-40. The following features are no longer present when Basic Mode is displayed:

- |                            |                        |
|----------------------------|------------------------|
| 1) Atmospheric perspective | 5) Roll Pointer option |
| 2) Terrain rendering       | 6) Bank Scale option   |
| 3) Obstructions rendering  | 7) Airport runways     |
| 4) Flight Path Marker      |                        |

### 3.5.13. Unusual Attitude Mode



**Figure 3-41: Unusual Attitude Mode**

Unusual Attitude Mode is enabled when pitch attitude exceeds  $+30^\circ$  or  $-30^\circ$  or bank angle exceeds  $65^\circ$ . Once enabled, the Unusual Attitude Mode remains engaged until pitch attitude returns to within  $5^\circ$  of the horizon and bank attitude returns to within  $10^\circ$  of the horizon. Recovery chevrons, tied to the  $30^\circ$  and higher pitch scale indications (both positive and negative), appear to aid in unusual attitude recovery.

#### **NOTE:**

The recovery chevrons are a normal part of the pitch scale but are not necessarily tied to unusual attitude mode.

The following features are disabled in the Unusual Attitude mode:

- 1) Terrain and Obstruction rendering
- 2) CDI
- 3) VDI
- 4) Flight Path Marker
- 5) Highway in the Sky boxes
- 6) Atmospheric perspective
- 7) Analog and Digital AGL indication
- 8) Active Waypoint symbology
- 9) Mini Map
- 10) Traffic thumbnail
- 11) If in the Basic Mode, the PFD reverts to the Normal Mode
- 12) If in Zoom mode FOV, the PFD reverts to normal FOV
- 13) Runways

### 3.5.14. PFD Background

The PFD has a three-dimensional background generated from terrain elevation and obstruction elevation data stored in electronic memory. The “actual horizon” displayed on the PFD is based upon the higher of terrain within 90NM or a horizon calculated using a visible horizon equation (i.e., horizon [NM] = 1.17 x sq. root alt in feet). Thus, the relative elevation of terrain and obstructions with respect to aircraft altitude and performance is observed by reference to the primary flight information pitch ladder and flight path marker.

The background has two pilot-selectable field-of-view (FOV) modes, wide FOV mode (approximately 70°) and narrow FOV mode (approximately 35°). In Unusual Attitude Mode, wide FOV mode is automatically selected.

The terrain and obstruction rendering uses hidden surface removal techniques while terrain/sky rendering uses atmospheric perspective techniques. Terrain with obstruction rendering is collectively pilot-selectable to declutter the display (*independent declutter of obstructions is not possible*). Terrain and obstruction rendering is disabled in Basic Mode, Unusual Attitude Mode, and during any reversionary mode. In Unusual Attitude Mode, the blue-brown boundary line of the background decouples from the pitch scale at high pitch angles so a sliver of the blue-brown boundary line always remains visible to give guidance to the horizon.



**Figure 3-42: Airplane PFD Terrain and Obstructions**

The terrain ahead of the aircraft is shown conformally with the artificial horizon in the correct scale and perspective for the aircraft's current position and altitude. Worldwide terrain coverage is provided in each IDU and is shown with a resolution as shown in Table 3-8.

Terrain is displayed ahead of the aircraft using a grid and simulates "atmospheric perspective" (the terrain lines fade into the background "ground" color as they recede into the distance). This enhances the three-dimensional effect, improves distance judging, and eliminates foreground occlusion (object in the foreground cannot be seen against a similar background). Furthermore, an actual horizon is depicted based upon an aircraft altitude like the real horizon. Distance varies to create a realistic depiction of the horizon.

A blended-tone sky is displayed in conjunction with terrain. The sky fades from light blue at the horizon to dark blue at the top of the display to simulate atmospheric perspective and enhance the three-dimensional presentation. Additionally, the blended sky increases contrast of the directional scale, emphasizes the horizon, and provides a compelling visual cue to a nose-high attitude.

At latitudes greater than 75°, no grid lines are shown. To keep the grid spacing relatively consistent, at latitudes between 45° and 75°, the longitude spacing is increased according as follows.

**Table 3-8: LAT-LON Resolution Boundaries**

Latitude Range	Longitude Grid Spacing	Heading Boundary	
		Pole	Equator
0° to 46°	24 arc-seconds		
46° to 62°	48 arc-seconds	46°	45°
62° to 70°	72 arc-seconds	62°	61°
70° to 74°	96 arc-seconds	70°	69°
74° to 75°	120 arc-seconds	74°	73°

**NOTE:**

There is a one degree dead band to prevent grid flicker while flying along one of the boundary latitudes. The grid space switching changes at one degree less latitude when flying towards the Equator than it does when flying toward the Poles.

A blended-tone sky is displayed in conjunction with terrain. The sky fades from light blue at the horizon to dark blue at the top of the display to simulate atmospheric perspective and enhance the 3-D presentation. Additionally, the blended sky increases contrast of the directional scale, emphasizes the horizon, and provides a compelling visual cue to a nose-high attitude.



**Table 3-9: Terrain and Obstruction Rendering Levels**

Feature	Terrain Rendering Coloring	Notes
<b>SVS BASIC</b>	Shades of brown for non-water terrain. Deep blue denotes areas of water and takes precedence over the shades of brown.	Amber and red colors not used for normal display of terrain.
<b>SVS TAWS</b>	Shades of olive when at or below 100 feet less than aircraft altitude.  Shades of brown when above 100 feet than aircraft altitude.  Deep blue denotes areas of water and takes precedence over other colors.  TAWS coloring of FLTA alert or warning cells.	Amber and red colors used for normal display of terrain.  Amber and red colors used to show terrain areas causing FLTA alerts.
<b>None</b>	No terrain or obstructions are shown. Neither, <b>SVS BASIC</b> or <b>SVS TAWS</b> is selected.	


***WARNING:***

***DO NOT USE THIS EFIS FOR TERRAIN-FOLLOWING FLIGHT. DO NOT ATTEMPT TO NAVIGATE USING THE TERRAIN DEPICTION. ALWAYS ADHERE TO PUBLISHED NAVIGATIONAL INSTRUMENT PROCEDURES AND NAVIGATIONAL CHARTS IN ALL FLIGHT CONDITIONS.***

When terrain and obstruction rendering is deselected or disabled, the PFD screen background is a conventional blue over brown attitude display presentation without atmospheric perspective. Additionally, terrain may be deselected on the PFD and retained on the ND MAP display as seen in Figure 3-43.

***WARNING:***

***MANY TOWERS, ANTENNAS, STRUCTURES, AND OBSTRUCTIONS ARE NOT IN THE DATABASE.***



**Figure 3-43: PFD with Terrain Deselected on PFD**

Towers, antennas, and other obstructions such as buildings and manmade structures are shown on the PFD display as vertical amber (yellow) lines. Obstructions are conformal in both location and size and only shown in conjunction with terrain regardless of altitude. Obstructions which represent a collision hazard are annunciated aurally and with a caution or warning flag.



**Audible Annunciation**

Towers, antennas, and obstructions representing a collision hazard cause an annunciation of “Obstruction” and aural annunciation of “Caution Obstruction” or “Warning Obstruction”.

**NOTE:**

The obstruction data is provided by Jeppesen and must be updated each 28 days to maintain current database information.

**3.5.15. Flight Path Marker (Velocity Vector)**


**Figure 3-44: Flight Path Marker**


At low speed and in flight (indicated airspeed <45 KIAS), the flight path marker is removed and replaced with Large Aircraft Symbol Reference Marks. This is due to the difficulty of generating a useable flight path marker at extremely low speeds.

The PFD flight path marker appears at a location on the background to coincide with the aircraft's actual flight path as projected upon the outside world. The flight path marker is laterally displaced parallel to the horizon with respect to the center of the display to account for the difference between aircraft track and heading, and is vertically displaced perpendicular to the horizon to account for aircraft climb or descent angle. Because the flight path marker is used in conjunction with a three-dimensional background, the flight path marker utility normally associated with a HUD is achieved.

**Table 3-10: Flight Path Marker Behavior**

	<b>Crab Angle</b>
<b>Cage</b> (Become laterally centered on the display)	When exceeding 15° (wide FOV) or 7.5° (narrow FOV mode)
<b>Uncage</b> (Resume lateral floating)	When returning below 13° (wide FOV mode) or 6.5° (narrow FOV mode)
Flight path marker movement is dampened by reference to aircraft pitch and heading so as not to deviate from pitch or heading at a rate greater than 1°/sec.	

When caged, a flight path marker “ghost” is displayed at the flight path marker’s proper lateral location. When the location of the ghost is displaced to the extent it would interfere with heading, altitude, or airspeed indications, the ghost is removed from the display. The flight path marker is not shown in Basic Mode, and in the Unusual Attitude Mode, it disappears to allow the pilot to concentrate on the Large Aircraft Symbol Reference Marks for unusual attitude recovery. In reversionary mode 1 (GPS failure), the flight path marker changes to a light gray color after one minute to indicate degraded performance. Flight path marker at low speed (indicated airspeed < 45 KIAS) behavior further depends upon whether the aircraft is in flight or on the ground.

**Figure 3-45: Flight Path Marker Ghost**

### 3.5.16. Bank Angle Scale




The Bank Scale and Roll Pointer are centered upon the Large Aircraft Symbol Reference Marks in Basic or Unusual Attitude Modes.

**Figure 3-46: Bank Angle**

When bank angle scale decluttering is selected, a bank angle scale and sky pointer are displayed when the magnitude of bank angle exceeds  $2.8^{\circ}$ . With decluttering selected, appearance of the bank angle scale and roll pointer are dampened based upon magnitude and time to prevent nuisance appearances. When decluttering is not selected, the bank angle scale and sky pointer appear full time with level,  $10^{\circ}$ ,  $20^{\circ}$ ,  $30^{\circ}$ ,  $45^{\circ}$ , and  $60^{\circ}$  marks on left and right sides.

### 3.5.17. Turn Indication



Rate of turn is available as an option in the PFD Declutter menu to show a worm in the direction of turn with full scale deflection indicating a standard rate of turn and half standard rate indicated at the mid-scale marking.

**Figure 3-47: Turn Indication**

### 3.5.18. Timer Indication




When selected by the pilot, countdown or count-up timer is displayed above the Fight Path Marker or Large Aircraft Symbol Reference Marks. The format of the time is **hh:mm:ss** (hours, minutes, seconds).

**Figure 3-48: Timer**

### 3.5.19. Marker Beacon Symbolology


Marker beacons data acquired from the Navigation Receiver are displayed on the PFD and disabled when the selected NAV source is FMS. Valid marker beacon signals cause circular indicators with appropriate coloring and markings to be displayed in the lower central portion of the PFD (shown in Figure 3-49).



**Figure 3-49: Marker Beacons**

### 3.5.20. Flight Director Symbolology (FD1 Single Cue)

The Flight Director Symbolology is pilot-selectable through controls on the IDU or integrated autopilot/flight director equipment. When selected, Flight Director Symbolology and valid steering commands are received from the Flight Director with one of the following symbols shown in the Normal Mode. A waterline symbol is fixed in the center of the PFD. Rotation of the background, pitch scale, and background oriented display elements occur relative to the location of the waterline symbol or Large Aircraft Reference Marks.




**Figure 3-50: Flight Director FD1 (Single Cue)**



**Figure 3-51: Flight Director FD1 (Basic Mode)**

### 3.5.21. Flight Director Symbology (FD2 Dual Cue)



**Figure 3-52: Flight Director FD2 (Normal Mode)**



Figure 3-53: Flight Director FD2 (Basic Mode)

### 3.5.22. Course Deviation Indicator



Figure 3-54: Course Deviation Indicator



**Table 3-11: CDI Behavior and Color**

CDI Pointer and Condition	Color or Behavior
Full Scale Deflection	Flash
When Slaved to GPS/SBAS	Scale is appropriate FSD value for mode of flight:  <b>Enroute: <math>\pm 2</math> NM</b> <b>From Enroute to Terminal:</b> Change from $\pm 2$ NM FSD to $\pm 1$ NM FSD over distance of 1 NM; start transition when entering terminal mode. <b>From Terminal to Enroute:</b> Change from $\pm 1$ NM FSD to $\pm 2$ NM FSD over distance of 1 NM; start transition when entering enroute mode. <b>From Terminal to Approach:</b> If VTF, switch immediately. Otherwise, change from $\pm 1$ NM FSD to approach FSD over distance of 2 NM; start transition at 2 NM from FAWP. <b>From Approach to Terminal:</b> Change to $\pm 1$ NM. <b>From Departure to Terminal:</b> If initial leg is aligned with runway, change from $\pm 0.3$ NM FSD to $\pm 1$ NM FSD at the turn initiation point of the first fix in the departure procedure.
When Slaved to GPS/SBAS (With GPS Loss of Navigation)	Amber (Yellow)
Normal Conditions	Magenta
In sources other than FMS	Angular scale annunciation
Navigation source is Localizer (Course error exceeds $105^\circ$ )	Reverse sensing
When lateral deviations are in a failed state	Red "X" displayed over CDI

### 3.5.23. OBS Setting of CDI

In automatic mode, the system automatically controls the scale and OBS setting according to the requirements of GPS/SBAS (TSO-C-146C). The currently selected navigation source is annunciated immediately below the CDI as follows:

- |   |   |
|---|---|
| 1) NAV: <b>FMS1</b>   | 6) NAV: <b>VOR2</b>   |
| 2) NAV: <b>FMS2</b>   | 7) NAV: <b>LOC2</b>   |
| 3) NAV: <b>VOR1</b>   | 8) NAV: <b>BC2</b> (annunciated instead of LOC2 when course error exceeds 105°) |
| 4) NAV: <b>LOC1</b>   |   |
| 5) NAV: <b>BC1</b> (annunciated instead of LOC1 when course error exceeds 105°) |   |

### 3.5.24. Heading/Roll-Steering Sub-Mode

The heading/roll-steering sub-mode annunciation appears immediately to the right of the selected navigation source annunciation and displays either:

- 1) HDG: **LVL** (Wing-Leveling Sub-Mode Guidance)
- 2) HDG: **LNAV** (LNAV Sub-Mode Guidance)
- 3) HDG: **BUG** (Heading Bug Sub-Mode Guidance)
- 4) HDG: --- (Failure Sub-Mode)

### 3.5.25. Vertical Deviation Indicator

**Table 3-12: Vertical Deviation Indicator Behavior**

Source (Below VDI)	Behavior/Condition	Pointer Color
FMS	Conforms to the VDI display GPS/SBAS requirements (TSO-C-146C) when source is valid	Magenta
Glideslope	The source must be valid when a valid glideslope is received.	Magenta


**Table 3-12: Vertical Deviation Indicator Behavior**

Source (Below VDI)	Behavior/Condition	Pointer Color
LPV or VNAV mode	Source is valid if:  On VNAV descent segments when approaching the Top of Descent point so as to provide descent anticipation as long as the following are true:  1) On VNAV descent segments; OR  2) If the vertical deviations on VNAV level segments option is enabled, on VNAV level segments; OR  3) If the vertical deviations on VNAV level segments option is disabled, when approaching the Top of Descent point so as to provide descent anticipation;  Providing:  1) The aircraft is within 2NM or twice the full scale deflection for the mode of flight (whichever is greater) of the lateral navigation route; AND  2) The aircraft is in TO operation relative to the active VNAV waypoint (i.e., taking into account VNAV offsets); AND  3) If on the final approach segment, the aircraft is within a 35° lateral wedge of the azimuth reference point (either the GARP or MAWPT + 10,000 ft.).	Magenta


**Table 3-12: Vertical Deviation Indicator Behavior**

Source (Below VDI)	Behavior/Condition	Pointer Color
LPV,VNV-G	During GPS Loss of Navigation or GPS Vertical Loss of Navigation	Pointer and Text Color Amber (Yellow)

Vertical deviation indicator disappears in Unusual Attitude Mode.


**Figure 3-55: Vertical Deviation Indicator**

- 1) **LPV1**: When descending on the final approach segment in LPV mode.
- 2) **LPV2**: When descending on the final approach segment in LPV mode.
- 3) **VNV1-G**: When descending on the final approach segment in LP, LNAV/VNAV, LNAV, or RNP modes when using GPS VNAV.
- 4) **VNV2-G**: When descending on the final approach segment in LP, LNAV/VNAV, LNAV, or RNP modes when using GPS VNAV.
- 5) **VNV1-B**: Default FMS barometric VNAV mode.
- 6) **VNV2-B**: Default FMS barometric VNAV mode.
- 7) **GS1**: When valid glideslope receiver #1 is received.
- 8) **GS2**: When valid glideslope receiver #2 is received.



**Figure 3-56: Vertical Deviation Indicator Color during GPS/SBAS LON or VLON**

### 3.5.26. Vertical Deviation Indicator (EFIS Coupled)



**Figure 3-57: EFIS Coupled Vertically with Glideslope Mode Engaged**

When vertically integrated with an autopilot (either fully integrated or partially integrated) through use of the glideslope mode discrete input with the glideslope mode engaged, the selected vertical navigation source is green to indicate the autopilot is vertically coupled to the selected vertical navigation source. Otherwise, the selected vertical navigation source is white.

### 3.5.27. Highway in the Sky/Skyway




Figure 3-58: Highway in the Sky

### 3.5.28. Active Waypoint and Waypoint Identifier



Figure 3-59: Active Waypoint

The PFD displays the active waypoint symbol as a magenta “tethered balloon” consisting of an “X” depicted at the ground location of the active waypoint, a hoop or “tethered balloon” (fly-over waypoints) or “tethered diamond” (fly-by waypoints) depicted at the VNAV altitude or at aircraft altitude (if there is no VNAV altitude), and a line connecting the “X” and the hoop. The “X” and the connecting line are not shown if no ground elevation information is encoded with the NavData waypoint information (e.g., terminal and

enroute fixes). The active waypoint symbol is drawn using the hidden surface removal techniques of the terrain and obstruction rendering, so an active waypoint behind terrain appears to be so. The active waypoint symbol disappears in Unusual Attitude Mode and turns amber (yellow) in the event of GPS Loss of Navigation caution.

The identifier of the waypoint along with the bearing and distance to the waypoint are displayed in the lower right corner of the PFD in magenta. If a target altitude is not set and the active waypoint has a VNAV altitude associated as the example above, the identifier includes a display of the VNAV altitude.

### NOTE:

Only the active waypoint is shown on the PFD display. Subsequent waypoints in a route are displayed sequentially as the current active waypoint is passed.


With terrain turned off, the active waypoint is always visible regardless of distance.

If the active waypoint is beyond the lateral limits of the screen, the magenta waypoint direction pointer (i.e., the magenta triangle) on the directional scale indicates the shortest direction of turn to the waypoint.

If the waypoint is only a hoop hanging in space, it is a fix and not directly associated with a NAVAID on the ground (such as a VOR, NDB, user waypoint, or airport).


If the waypoint X disappears behind terrain on the PFD display, there is terrain between the aircraft present position and the waypoint.

### 3.5.29. Mini Map




**Figure 3-60: Mini Map**

<b>Table 3-13: Mini-Map Behavior (When Not Decluttered)</b>		
<b>VOR Pointer, Active Leg Ownship Symbol</b>	<b>Color</b>	<b>Condition</b>
VOR 1	Blue	When Valid
VOR 2	Green	When Valid
Active Leg (GPS/SBAS normal)	Magenta	
Active Leg (GPS/SBAS LON condition)	Amber (Yellow)	
Ownship Symbol Airplane w/o M <sub>MO</sub> Airplane with M <sub>MO</sub>	White	
<b>Mutually exclusive with the Analog AGL Indicator</b>		
<b>Mini-Map disappears in Unusual Attitude Mode</b>		
<b>Mutually exclusive with Traffic Thumbnail</b>		



VOR #1




VOR #2

Figure 3-61: Mini Map VOR Symbology



### 3.5.30. Runways







**Figure 3-62: Runways**

The PFD displays airport runways in a three-dimensional manner. Upon activation of a DP, VFR approach, IFR approach, or STAR procedure, the runways for the airport associated with the procedure are also displayed. In addition, the runways associated with the three nearest airports (as computed by the TAWS algorithms) are displayed. The runways are drawn using the hidden surface removal techniques of the terrain and obstruction rendering so runways behind terrain appear to be so. Runways are shown in dark gray according to characteristics contained in the navigation database, including elevation, position, orientation, length, and width. The landing portion of the selected runway, taking into account displaced threshold data, is shown in light gray.

When the depiction of a runway is wide enough, runway markings, including aiming point markings, centerline, designation, and displaced threshold arrows, are shown in Table 3-14.

**Table 3-14: Runway Drawing Criteria**

Feature	Color	Notes
Runway markings, aiming point markings, centerline, designation, and displaced threshold arrows	Dark gray 	According to characteristics from navigation database, e.g., including position, orientation, length, and width.
Runway markings	Medium gray 	
Landing portion of the selected runway.	Light gray 	Taking into account displaced threshold data.
Runway markings for the selected runway	Lighter gray than the light gray.	

**3.5.31. Traffic Thumbnail****Figure 3-63: Traffic Thumbnail**

When selected from declutter options, the traffic thumbnail has clock face markings normally fixed at the 6 NM scale. In the event of a traffic warning (TA or RA), the traffic thumbnail is automatically enabled while the traffic warning is active and the aircraft is above 500' AGL. During a traffic warning, the traffic thumbnail scale automatically adjusts in multiple multiples of 2 NM (2 NM, 4NM, or 6NM) to optimally display the traffic. While the traffic thumbnail is mutually exclusive with the Mini-map, it too disappears in the Unusual Attitude Mode.

### 3.5.32. Traffic Display Definitions

- 1) Resolution Advisory (**RA**): Traffic with a dangerous closest point of approach and generates climb or descent commands as defined by internal TCAS-II sensor logic.
- 2) Traffic Advisory (**TA**): Traffic with a dangerous closest point of approach as defined by internal traffic sensor logic.
- 3) Proximate Advisory (**PA**): Traffic within 6 NM and  $\pm 1200$  feet from ownship that is not an RA or TA.
- 4) Other Traffic (**OT**): Traffic beyond 6 NM or  $\pm 1200$  feet from ownship that is not an RA or TA.

### 3.5.33. Traffic Rendering Rules







Traffic thumbnail and PFD traffic are rendered as follows.

<b>Table 3-15: Traffic Rendering Rules</b>		
<b>Type Traffic</b>	<b>Distance</b>	<b>Results</b>
OT and PA Traffic	Beyond 6 NM	Not displayed
TCAS-I, TCAS-II, TAS, or TIS-A Sensor	Within 200' of ground	Not Displayed

**Table 3-16: Pilot Selected OT and PA Traffic Altitude-Filter**

Mode	Parameter
<b>AUTO</b>	If aircraft VSI is less than -500FPM, traffic within +2,700 and -9,900 feet of aircraft altitude is displayed. If aircraft VSI is more than +500FPM, traffic within -2,700 and +9,900 feet of aircraft altitude is displayed. Otherwise, traffic within -2,700 and +2,700 feet of aircraft altitude is displayed.
<b>ABOVE</b>	Traffic within -2,700 and +9,900 feet of aircraft altitude is displayed.
<b>BELOW</b>	Traffic within +2,700 and -9,900 feet of aircraft altitude is displayed.
<b>NORMAL</b>	Traffic within -2,700 and +2,700 feet of aircraft altitude is displayed.
<b>ALL</b>	All received traffic is displayed; no altitude filtering is performed.


**Table 3-17: Traffic Symbolology**

Type Traffic	Symbology
TCAS-I, TCAS-II, and TIS-A	    Other Traffic    Proximate Advisory    Traffic Advisory (Flashing)    Resolution Advisory (Flashing)
Ownship symbol	<b>Airplane w/o M<sub>Mo</sub></b>  <b>Airplane with M<sub>Mo</sub></b> 



**Figure 3-64: Traffic Symbology**

### 3.6. Fully Integrated Autopilot Annunciations



Notes:

- 1) Boxed engaged mode annunciation = AP is engaged
- 2) Engaged mode annunciation flashes for 10 seconds upon mode/sub mode change

**Figure 3-65: Autopilot Annunciation**



Figure 3-66: Autopilot Initializing in Roll and Pitch Modes




Figure 3-67: Autopilot Ready (Absence of Fail or INIT)




Figure 3-68: Autopilot Roll and Pitch Modes




Figure 3-69: FD Displayed on PFD with Roll and Pitch Modes






Figure 3-70: Autopilot HDG and ALT Modes Engaged




**Figure 3-71: Autopilot with HDG, NAV:VOR, and ALT Modes Engaged**




**Figure 3-72: Autopilot with HDG, APR:LOC, and ALT Modes Engaged**




**Figure 3-73: Autopilot with HDG, APR:LOC, ALT, and APR: GS**




**Figure 3-74: Autopilot with HDG and VS Modes Engaged**




**Figure 3-75: Autopilot with HDG and IAS Modes Engaged**




**Figure 3-76: Autopilot with HDG and Pitch Modes Engaged**




**Figure 3-77: Autopilot with HDG, NAV:BC, and Pitch Modes Engaged**



**Figure 3-78: Autopilot with APR:LOC and APR:GS Modes Engaged**




**Figure 3-79: Autopilot with APR:FMS and APR:GS Modes Engaged**




**Figure 3-80: Autopilot with NAV:FMS and ALT Modes Engaged**







**Figure 3-81: Autopilot with NAV:LOC and ALT Modes Engaged**



**Figure 3-82: Autopilot with APR:BC and ALT Modes Engaged**



**Figure 3-83: Autopilot with CWS Mode Engaged**



**Figure 3-84: Autopilot with G/A (Go-Around) Engaged in Roll and Pitch Modes**

### 3.7. Navigation Display Symbology

The Navigation Display is presented in a variety of formats, including:

- |                     |             |
|---------------------|-------------|
| 1) Moving Map       | 6) Datalink |
| 2) Conventional HSI | 7) WX RDR   |
| 3) Navigation Log   | 8) Video    |
| 4) Strikes          | 9) EICAS    |
| 5) Traffic          |             |



### 3.7.3. Moving Map with Instrument Approach



Figure 3-87: Moving Map with Instrument Approach

### 3.7.4. North-Up Arc Mode



Figure 3-88: North-Up Arc Mode





### 3.8.1. Compass Rose Symbols




Figure 3-93: Compass Rose

When selected, a digital heading readout and pointer aligned with the longitudinal axis of the ownship symbol appear on the compass rose boundary circle. If referenced to magnetic North, the heading readout uses the degree (°) symbol. Otherwise, a stylized True North (T) symbol is used. A green diamond-shaped track pointer aligned with the aircraft's track across the earth appears on the compass rose but is not displayed when groundspeed is less than 30 knots. The pilot-settable heading bug geometrically interacts with the heading pointer and appears on the compass rose. A magenta, star-shaped waypoint pointer is displayed on the heading scale at a point corresponding with the active waypoint and turns amber (yellow) in the event of GPS Loss of Navigation caution.

**NOTE:**

See Section 7 IFR Procedures for description of the following Heading modes with the AHRS and EFIS:

- 1) ADAHRS Slaved—EFIS Magnetic North
- 2) ADAHRS Slaved—EFIS True North
- 3) ADAHRS Free/"DG"—EFIS Magnetic North
- 4) ADAHRS Free/"DG"—EFIS True North

### 3.8.2. Fuel Totalizer/Waypoint Bearing and Distance Functions



**Figure 3-94: Fuel Totalizer/Waypoint Bearing and Distance Functions**

**Table 3-18: Fuel Totalizer/Waypoint Bearing and Distance Functions**

Function	Conditions	Type Symbols Options
<b>TO Waypoint:</b>	<p>If there is an active flight plan, waypoint type, identifier, range, bearing and estimated time enroute/estimated time of arrival for the active waypoint (“TO” waypoint) of the active flight plan is shown.</p> <p>Waypoint information is magenta and turns amber (yellow) in the event of a GPS Loss of Navigation caution.</p>	ETA or ETE Degree (°) symbol or True North (T) symbol

**Table 3-18: Fuel Totalizer/Waypoint Bearing and Distance Functions**

<b>Function</b>	<b>Conditions</b>	<b>Type Symbols Options</b>
<b>DEST Waypoint:</b>	<p>If there is an active flight plan, waypoint type, identifier, range, and estimated time enroute/estimated time of arrival for the last waypoint (“DEST” waypoint) of the active flight plan are shown.</p> <p>Range and time to the destination waypoint are based upon the flight plan route if the active waypoint is not the last waypoint, otherwise range and time to the destination waypoint are based upon a direct geodetic path.</p> <p>The DEST Waypoint information is white and turns amber (yellow) in the event of a GPS Loss of Navigation caution.</p>	ETA or ETE Degree (°) symbol or True North (T) symbol
<b>Range:</b>	Aircraft range based upon instantaneous fuel flow, fuel remaining and groundspeed are shown immediately below the “DEST” waypoint information for easy comparison.	
<b>Endurance:</b>	Aircraft endurance based upon instantaneous fuel flow and fuel remaining is shown.	



### 3.8.3. Clock/Timers/Options



**Figure 3-95: Clock and Timers**

The following data items are displayed in the upper right corner of the ND.




Table 3-19: Clock/Timers/Options		
Feature	Options	Notes
<b>Zulu Time</b>	No other format available	<b>hh:mm:ss</b> format and synchronized with the GPS/SBAS constellation.
<b>Timer</b>	<b>COUNT UP</b> <b>COUNT DN..</b> <b>FLT TIME</b>	Countdown or count-up timer displayed when selected and matches timer shown on PFD.
<b>Declutter Mode</b>	<b>DCLTR A</b> <b>DCLTR M</b>	= Automatic declutter mode = Manual declutter mode
<b>Terrain Status</b>	Enabled or Disabled	<div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p>Status annunciated as "TERRAIN" with overlying "X", if manually deselected. If Terrain is decluttered from the PFI area, the only indication is the absence of terrain from the PFI area. If TERRAIN is disabled, the "X" is red.</p> </div> </div>







Table 3-19: Clock/Timers/Options

Feature	Options	Notes
<b>Traffic Status</b>	Enabled or Disabled	 <p>Status annunciated disabled as if manually deselected. In the event of a traffic warning (TA or RA), traffic thumbnail is automatically enabled while traffic warning is active and the aircraft is above 500'AGL.</p> <p>If traffic is disabled, the "X" is red. When traffic is selected and enabled, status of traffic altitude filtering is displayed as follows:  <b>AUTO = TRF AUTO</b>, <b>NORMAL = TRF NORM</b>, <b>ABOVE = TRF ABV</b>, <b>ALL = TRF ALL</b>, <b>BELOW = TRF BLW</b>.</p>
<b>WX-500 Status</b>	Enabled or Disabled	 <p>When selected, the ND displays Cell Mode lightning strikes in correct relationship to the ownship symbol with limits found in § 3.19</p>



(yellow) in the event of a GPS Loss of Navigation caution. Suppressed waypoints are indicated by brackets. Navigation data symbols are shown with the waypoint identifier for the pilot to easily distinguish the waypoint type. In the case of an airport with an available datalinked METAR, a graphical METAR is displayed as a color-filled circular part of the airport symbol with the following coloring convention.

**Table 3-20: Graphical METAR Symbols**

Color		Meaning
Sky Blue		Visual Flight Rules (VFR)
Green		Marginal Visual Flight Rules (MVFR)
Amber (Yellow)		Instrument Flight Rules (IFR)
Red		Low Instrument Flight Rules (LIFR)
Magenta		Less than Category 1 Approach Minimums
Black		No Data

When a waypoint is part of a procedure, small procedure legends are drawn on top of the navigation data symbol for the pilot to easily distinguish procedure waypoints. The following procedure legends are used:

- 1) **FAF** = Waypoint is a Final Approach Fix
- 2) **MAP** = Waypoint is a Missed Approach Point
- 3) **MA** = Waypoint is part of the missed approach segment of an Instrument Approach Procedure.
- 4) **APP** = Waypoint is part of an Instrument Approach Procedure, but is not a Final Approach Fix, Missed Approach Point, or part of the Missed Approach segment.
- 5) **VFR** = Waypoint is part of a VFR Approach.
- 6) **STAR** = Waypoint is part of a Standard Terminal Arrival Procedure.
- 7) **DP** = Waypoint is part of a Departure Procedure.

- 8) **PTK** = Parallel Offset. Note that in case of a STAR or DP waypoint that subject to a parallel offset, both STAR/DP and PTK are shown.

### 3.9.4. VNAV and VNAV Offset Column


The VNAV altitude and associated VNAV Offset (in NM) are displayed immediately to the right of the Waypoint Identifier Column. In the case of an approach with a Final Approach Segment data block, the VNAV Offset readout associated with the Missed Approach Point is “GPI” to designate distance to the Glidepath Intercept point. VNAV altitudes and offsets from the navigation database or manually entered are shown in white. VNAV altitudes and offsets computed automatically are shown in gray. The vertical position of the VNAV and VNAV Offset Column elements are aligned with the Waypoint Identifier Column elements to indicate the VNAV information applies to the associated waypoint.

#### NOTE:

No VNAV data (dashes) is associated with a suppressed waypoint, as a suppressed waypoint is not actually part of the active flight plan.

### 3.9.5. Path Column

The LNAV path between waypoints is displayed immediately to the right of the VNAV and VNAV Offset Column. The following paths are displayed:

- 1) Geodetic path between waypoints is displayed with the “Direct-To” symbol,  (**R4**), followed by the initial geodetic course for the leg.
- 2) Discontinuities (i.e., a leg where FMS is unable to compute a valid path) are shown with the legend -DISCONT-
- 3) Procedure turns are shown with a pictorial representation of a procedure turn (either left or right turns) as well as the entry and exit course for the procedure turn.
- 4) Holding patterns are shown with a pictorial representation of a holding pattern (either left or right turns) as well as the inbound course for the holding pattern.

- 5) Arcs are shown with a pictorial representation of an arc (either left or right turns) as well as the entry and exit radials for the arc.
- 6) An altitude termination leg is shown by the initial geodetic course for the leg followed by the altitude at which the leg terminates.

The vertical position of the Path Column elements is offset from the Waypoint Identifier Column elements to indicate the path information applies to the leg between waypoints.

### **3.9.6. Distance Column**

The distance between waypoints is displayed immediately to the right of the Path Column. The distance between waypoints is calculated taking into account the associated path as well as parallel offsets. In the case of a discontinuity, the distance between waypoints is the direct geodetic distance between the two waypoints. The vertical position of the Distance Column elements is offset from the Waypoint Identifier Column elements to indicate the distance information applies to the leg between waypoints.

### **3.9.7. Estimated Time Enroute Column**

The ETE between waypoints is displayed immediately to the right of the Distance Column. The ETE between waypoints is calculated taking into account the associated distance between waypoints and current groundspeed. The vertical position of the Estimated Time Enroute Column elements is offset from the Waypoint Identifier Column elements to indicate the ETE information applies to the leg between waypoints.

### **3.9.8. Estimated Time of Arrival Column**

The ETA at the active waypoint and all subsequent waypoints is displayed immediately to the right of the Estimated Time Enroute Column. The ETA at the active waypoint is calculated taking into account the associated time remaining on the active leg and current time. The ETA at subsequent waypoints is calculated taking into account the cumulative ETES and current time. The vertical position of the Estimated Time of Arrival Column elements is aligned with the Waypoint Identifier Column elements to indicate the ETA information applies to the associated waypoint.

### 3.9.9. Fuel Remaining Column

The fuel remaining at the active waypoint and all subsequent waypoints is displayed immediately to the right of the Estimated Time of Arrival Column. The fuel remaining at the active waypoint is calculated taking into account the associated time remaining on the active leg, current fuel flow, and current fuel quantity. The fuel remaining at subsequent waypoints is calculated taking into account the cumulative ETEs, current fuel flow, and current fuel quantity. The vertical position of the Fuel Remaining Column elements is aligned with the Waypoint Identifier Column elements to indicate the fuel remaining information applies to the associated waypoint.

#### NOTE:

The absence of the following are associated with a suppressed waypoint, as a suppressed waypoint is not actually part of the active flight plan:

- |                           |                                 |
|---------------------------|---------------------------------|
| 1) Path data (dashes)     | 4) ETA data (dashes)            |
| 2) Distance data (dashes) | 5) Fuel remaining data (dashes) |
| 3) ETE data (dashes)      |                                 |

### 3.10. Start Point



Activation of the NRST or Direct-To function creates and activates a flight plan from the present position to the selected waypoint. A waypoint named "START" is placed at the current aircraft location when the flight plan is created.


**Figure 3-97: Start Point**

### 3.11. Altitude Capture Predictor

#### 3.11.1. Top of Descent


When a selected altitude or VNAV is specified on the PFD, the point at which a descent must be commenced is marked with a T/D in the

correct location on the flight plan path and contain location on the flight plan path with an indication of the glidepath angle used to calculate their position. After passing the Top of Descent along the lubber line, the altitude is captured and shown as a green arc located ahead of the aircraft. The arc marks the bottom-of-descent or top-of-climb point.



**Figure 3-98: Top-of-Descent or Top-of-Climb**

### 3.12. Projected Path



When the aircraft is in a bank angle, a projected path emanates from the ownship symbol. This curving path is based on aircraft bank angle and groundspeed as projected one minute into the future up to a maximum of 180° of turn. The projected path or “Noodle” assists in course interception and making small adjustments to bank angle for proper roll out.

**Figure 3-99: Projected Path**



### 3.13. Active Flight Plan Path/Manual Course/Runways

When there is an active flight plan and the GPS/SBAS OBS setting is automatic, the flight plan path is shown on the ND in its correct relationship to the ownship symbol. The active flight plan path depiction meets all the requirements of GPS/SBAS path definition and matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in automatic OBS mode, skyway boxes, and mini-map). The fly-over waypoints symbol is distinct from fly-by waypoints and consists of the waypoint symbol within a circle. When there is a parallel offset, the active flight plan path depicts the parallel offset path, and the original flight plan path is shown with haloed gray dashed lines. Top of descent symbols with an indication of glidepath angle are shown where VNAV descents are predicted to commence

When there is an active waypoint and the GPS/SBAS OBS setting is manual, the manual course through the waypoint is shown as a pointer centered on the waypoint. The pointer matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in manual OBS mode, skyway boxes, and mini-map).


The active flight plan path's active leg/manual course and active waypoint are magenta and turn amber (yellow) in the event of a GPS Loss of Navigation caution.

The ND displays airport runways in their correct relationship and scale to the ownship symbol. Immediately upon a system startup on the ground, the runways for the nearest airport are displayed. Upon activation of a DP, VFR approach, IFR approach, or STAR procedure, the runways for the airport associated with the procedure are displayed. In addition, the runways associated with the three nearest airports (as computed by the TAWS algorithms) are displayed and shown in dark gray according to characteristics contained in the navigation database, including position, orientation, length, and width.

When the depiction of a runway is wide enough, runway markings, including aiming point markings, centerline, designation, and displaced threshold arrows, as shown in Table 3-14.

### 3.14. FOV Indication

The ND background indicates the ND FOV with a set of segmented gray lines leading out from the ownship symbol in either 35° or 70° angles depending on the zoom mode setting on the PFD.



**Figure 3-100: Field of View**

### 3.15. Range

The range ring is a white ring (centered on the aircraft's position) used to quickly estimate distances. Distance (in nautical miles) from the aircraft to the ring is shown as a white figure, overlaying the 6 o'clock position of the ring. The range ring is half the distance to the directional scale. Consequently, when the range ring shows a distance of 5NM, the directional scale is 10NM. Scroll **1** or **2** to set the overall map scale ranges to .5, 1, 2.5, 5, 10, 25, 50, 100, and 200NM as appropriate.



Figure 3-101: Range








### 3.16. Navigation Data

The ND displays navigation data in correct relationship to the ownship symbol with navigation data symbols which include airport symbols, NDBs, and user waypoints. High altitude and low altitude airways may be shown.



Figure 3-102: Navigation Data and Airspace Depiction

Table 3-21: Airspace Depiction


Table 3-21: Airspace Depiction		
Type of ARINC 424 Airspace		Vertical Limits
	Single pixel, dashed lines	More than $\pm 500'$
	Single pixel solid lines	Within 500'
	Double pixel solid lines	Within airspace vertical limits
		<b>Color of Airspace</b>
	Class C, Control Area, TRSAs, Class D	GREEN
	Class B, TCAs (Where applicable)	BLUE
	Caution Areas, Danger Areas, MOAs, Training Areas, Warning Areas, Unknown Areas	AMBER (YELLOW)
	Prohibited Areas, Restricted Areas, Temporary Flight Restricted Areas (when equipped with Datalink)	RED

The ND has manual and automatic decluttering of navigation data. There are six levels of automatic declutter based upon the number of navigation data symbols drawn in the current ND format and range. Decluttering is as follows:

- 1) **Airports:** Manually or automatically decluttered. In automatic declutter mode, large airports (IFR procedure and longest runway and automatically adjusted threshold needed to achieve desired symbol count) are always shown; IFR airports that are not large airports are shown in levels 1, 2, 3, and 4; and VFR airports are shown in levels 1, 2, and 3.
- 2) **VORs:** Manually or automatically decluttered. In automatic declutter mode, VORs are shown in levels 1, 2, 3, 4, and 5.

- 3) **NDBs:** Manually or automatically decluttered. In automatic declutter mode, NDBs are shown in levels 1 and 2. Both enroute and terminal NDBs are shown.
- 4) **Fixes** (including User Waypoints): Manually or automatically decluttered. In automatic declutter mode, enroute fixes are shown in level 1. Terminal fixes are manually selected and not shown in automatic declutter mode. Enroute fixes, terminal fixes, and user waypoints may be manually decluttered separately from each other.
- 5) **High Altitude Airways:** Manually selected.
- 6) **Low Altitude Airways:** Manually selected.

### 3.16.1. Air Data and Groundspeed



**Figure 3-103: Air Data and Groundspeed**

The following data are displayed in the upper left corner of the ND as seen Figure 3-103:

- 1) **Wind:** Information consists of the following readouts:
  - a) Direction in degrees;
  - b) Speed in knots;
  - c) Crosswind component in knots; and
  - d) Graphical wind vector arrow oriented to correspond to the ND orientation.

If referenced to magnetic North, the direction readout uses the degree (°) symbol. Otherwise, a stylized True North (T) symbol is used. Wind information is not shown when indicated airspeed is in the noise range generally, less than 30 KIAS, or when the aircraft is in Ground Mode.

- 2) **Outside Air Temperature:** Digitally in Degrees C or F (as configured).
- 3) **International Standard Atmosphere (ISA):** The difference between ISA temperature and current outside air temperature is displayed digitally in Degrees C or F (Negative values = less than Standard OAT).
- 4) **Density Altitude:** Digitally in feet.
- 5) **True Airspeed:** Digitally in knots.
- 6) **Groundspeed:** Digitally in knots.

### 3.16.2. Analog Navigation Symbolology

When selected, the ND displays analog (VOR1 and VOR2) navigation symbolology when valid.



**Figure 3-104: Analog Navigation Symbolology**

When the VOR1 and/or VOR2 pointers are selected for display, bearing and distance for the selected VOR pointers appear at the bottom of the ND view (blue for VOR1, green for VOR2). If the DME channel is in hold mode, the associated distance readout is amber (yellow), and the letter "H" is shown above the distance readout.

### 3.16.3. Borders

National and United States state borders are drawn if selected at map scales of 50NM or greater. The borders are white, but they are black if the ND background includes terrain.



Figure 3-105: Borders

### 3.16.4. Terrain/Obstructions

Terrain is displayed on the ND in its correct relationship to the ownship symbol and shown using color to show relationship to aircraft altitude as follows.

**Table 3-22: Terrain Display on Navigation Display Color Relationship to Aircraft Altitude**

Based on Aircraft Altitude	Color	Notes #
Terrain when at or below 100 feet less than aircraft altitude	Shades of Olive	#1
Terrain when above 100 feet less than aircraft altitude	Shades of Brown	#1
FLTA alerts	Amber and Red	#2
Water at all altitudes	Deep Blue	#3

Note #1: Shade used is determined by the slope between adjacent terrain pixels in an increasing longitude direction.

Note #2: See Section 8 TAWS for terrain elements causing FLTA alerts.

Note #3: Areas of water and takes precedence over other colors.




Figure 3-106: Terrain/Obstructions




**Figure 3-107: Obstructions**

Obstruction symbols are displayed on the ND in their correct relationship to the ownship symbol and shown using color to show relationship to aircraft altitude as follows.

**Table 3-23: Obstructions**

<b>Lateral Distance Away</b>	8.5 NM or greater	Not depicted on the ND
	8.5 NM or less	As described below
<b>Vertical Criteria</b>	More than 2000' below the aircraft	Not depicted on the ND
	Within 2000' but more than 500' below aircraft	Are depicted in amber
	Within 500' but below aircraft	Are depicted in light red
	At or above aircraft altitude	Are depicted in deep red.

Terrain and obstruction rendering is pilot-selectable to declutter the display by deselecting terrain (*independent declutter of obstructions is not possible*). Furthermore, terrain and obstruction rendering is disabled when:

- 1) The GPS/SBAS sensor is failed; OR

- 2) When the ADC is failed; OR
- 3) When the horizontal figure of merit exceeds the greater of 0.3NM or the horizontal alarm limit for the mode of flight.

**NOTE:**

See Section 8 TAWS for obstructions causing TAWS alarms and depiction of separate symbolology.

### 3.17. Pan Mode

The ND screen has a pan mode for the pilot to change the location of the center of the screen away from current location and view map details along the route of flight and at the intended destination or alternate destination while either in flight or on the ground. When pan mode is active, labeled buttons are used to move the pan mode location North, South, East, and West in a North-up, centered orientation. Upon entering the pan mode, the heading pointer, track pointer, lubber line, waypoint pointer, analog navigation symbology, and field of view lines are removed from the display as shown in Figure 3-108.



**Figure 3-108: Pan Mode**

Figure 3-108 shows the line with bearing and distance from the map center to the aircraft's current position in white whenever the aircraft is more than 0.5 NM away. If referenced to magnetic North, the bearing uses the degree (°) symbol. Otherwise, a stylized True North (T) symbol is used. When panning, the nearest displayed airport, VOR, NDB, or fix within the inner range ring is highlighted with a

flashing circle. Buttons are labeled to allow for viewing or hiding waypoint information (including datalink weather information associated with that point). When exiting the pan mode, all previous settings are restored as the pan mode was enabled.

### 3.18. HSI Screen

The ND, when selected, displays conventional HSI symbology, including a selected course needle, a lateral deviation indicator, and a “TO-FROM” indicator. When the HSI is slaved to GPS/SBAS during a GPS Loss of Navigation condition, the HSI pointer color is amber (yellow), otherwise the pointer color remains magenta.



Normal Magenta Pointer



GPS Loss of Navigation Condition Amber (Yellow) Pointer

Figure 3-109: HSI Pointer Color

#### 3.18.1. HSI Screen VDI


A vertical deviation indicator appears, as seen in Figure 3-109, when the VDI source is valid to display vertical deviation information for the currently selected navigation source. When the selected vertical source is FMS, the VDI displayed on the HSI has the same behavior as the VDI displayed on the PFD with the exception of the VDI source displayed on the top of the VDI to avoid clutter with waypoint information below. For clarification the conformance to VDI display requirements of TSO C-146 and RTCD0-229D are as specified in § 3.5.25.

- 1) VNV1-B: Default FMS barometric VNAV mode.

- 2) VNV2-B: Default FMS barometric VNAV mode.
- 3) GS1: Glideslope #1
- 4) GS2: Glideslope #2

### 3.18.2. Analog Navigation Symbolology

The HSI has the capability when selected, to display analog (VOR1 [blue] and VOR2 [green]) navigation symbolology with an RMI pointer format overlaid upon the HSI. When the signal is invalid, the associated pointer is not shown. When the signal is valid for VOR1 and VOR2, a bearing and distance display for the selected VOR pointers appears at the bottom of the display as in Figure 3-110.



**Figure 3-110: Analog Navigation Display VOR1 and VOR2**

If a DME channel is in hold mode, the associated distance readout is amber (yellow) rather than blue or green, and the letter “H” is shown above the distance readout as seen in Figure 3-111.



**Figure 3-111: HSI Bearing Distance Readout with DME in HOLD**

The pilot may tune the radio via the Audio-Radio page of the EFIS. If a DME receiver is interfaced for frequency tuning by the EFIS, when the VOR1 pointer is selected for display, the NAV1 frequency

is displayed in blue over the VOR1 pointer in the bearing/distance display. If a DME receiver is interfaced for frequency tuning by the EFIS, when the VOR2 pointer is selected for display, the NAV2 frequency is displayed in green over the VOR2 pointer in the bearing/distance display (see Figure 3-112).



**Figure 3-112: HSI Bearing Distance Readout without DME in HOLD**

If a DME receiver is interfaced for frequency tuning by the EFIS, and a DME channel is in hold mode, the associated frequency displayed is the DME's channel hold frequency shown in amber (yellow) (see Figure 3-113).



**Figure 3-113: HSI Bearing Distance Readout with DME in HOLD**

Valid Marker Beacon discrettes are displayed as indicators on the PFD and ND HSI display as seen in Figure 3-114 with appropriate coloring markings. Only during a built-in-test, more than one marker beacon may be active. The display of marker beacons is disabled when the NAV source is FMS.



Figure 3-114: HSI with Marker Beacon Displayed

### 3.18.3. Air Data and Groundspeed



Air data and groundspeed are displayed as shown in this example and the same as explained as specified in § 3.16.1.

Figure 3-115: HSI Display Air Data and Groundspeed

### 3.18.4. Clock/Timers/Options

The following data items are displayed in the upper right corner of the HSI:

- 1) **Zulu Time:** As specified in § 3.8.3.
- 2) **Timer:** As specified in § 3.8.3.
- 3) **HSI Source:** HSI source is white but shown in amber (yellow) when the HSI is slaved to GPS/SBAS and there is a GPS Loss of Navigation.
- 4) **OBS:** The OBS setting associated with the HSI source is shown. When the HSI source is FMS, the FMS OBS setting matches the OBS setting shown on the PFD FMS CDI. The FMS OBS setting is labeled with an “A” for automatic or “M” for manual. OBS setting is white but is amber (yellow) when the HSI is slaved to GPS/SBAS and there is a GPS Loss of Navigation condition.
- 5) **CDI Scale:** The current CDI scale is shown and matches the CDI scale shown on the PFD course deviation. The CDI scale is white but is amber (yellow) when the HSI is slaved to GPS/SBAS and there is a GPS Loss of Navigation condition.



**Figure 3-116: HSI Clock/Timers**

### 3.18.5. Fuel Totalizer/Waypoint Bearing and Distance Functions



Fuel totalizer, waypoint bearing, and waypoint distance is displayed in the lower right corner of the HSI as specified in § 3.8.2.

**Figure 3-117: HSI Fuel Totalizer/Waypoint Bearing**

### 3.19. WX-500 Data

When selected, the ND displays Cell Mode lightning strikes in their correct relationship to the ownship symbol with the following limits.


**Table 3-24: Lightning Strikes**

View	Time or distance limit
Strikes not shown	Display scale less than 25 NM
Strikes not shown	More than 3 minutes old
Strikes less than 20 seconds old	Shown with lightning symbol
Strikes between 20 seconds and 2 minutes old	Shown with large cross symbol
Strikes between 2 minutes and 3 minutes old	Shown with small cross symbol





**ND Lightning Display**



**Strike Screen Display Format**


**Figure 3-118: Lightning Symbols**

The pilot may select either an arced or centered display format with the ownship displaced toward the bottom of the screen, so strike data are displayed in a larger scale while displaying all data within range ahead of the aircraft. The strike screen has “Strikefinder” markings aligned with either magnetic North or True North depending upon the status of the True North discrete input.

### 3.19.1. Strike Screen Range

The following strike screen ranges may be selected with all distances representing the distance from the ownship symbol to the “Strikefinder” markings: 12.5 NM, 25 NM, 50 NM, 100 NM, and 200 NM. The range ring is centered upon the ownship symbol to help judge range to displayed symbols. The range ring has half the radius of the “Strikefinder” markings displayed indicating the range corresponding to the radius of the range ring such as (1.5 NM, 25 NM, 50 NM, and 10 NM.) The range ring is completely visible in arced display format for the pilot to ascertain the current strike screen setting.

### 3.19.2. Active Flight Plan Path/Manual Course/Runways



**Figure 3-119: Active Flight Plan Path/Manual Course/Runways**

When there is an active flight plan and the GPS/SBAS OBS setting is automatic, the flight plan path is shown on the strike screen in its correct relationship to the ownship symbol.




When there is an active waypoint and the GPS/SBAS OBS setting is manual, the manual course through the waypoint is shown as a pointer centered on the waypoint. The pointer matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in manual OBS mode, skyway boxes, and mini-map).

The active flight plan path's active leg/manual course and active waypoint are magenta and turn amber (yellow) in the event of a GPS Loss of Navigation caution.

The strike screen displays airport runways in their correct relationship and scale to the ownship symbol.

WX-500 strike status data are shown as described in the following table.

**Table 3-25: WX-500 Status**



Condition	Annunciation
System Normal, Strikes Selected	<b>RATE ###</b> depicts current strike rate  . Strike symbols shown.
System Normal, Strikes De-selected	<b>STRIKES</b> overlaid with green "X"  . Strike symbols removed.
System Failed	<b>STRIKES</b> overlaid with red "X"  . Strike symbols removed.
System in Test Mode	<b>STRK TST</b> shown. Strike symbols removed.


A new strike rate value is calculated every five seconds during normal operation, based upon strikes within the selected display range. The number of fresh strikes (less than 20 seconds old) is used to generate a strike rate representing strikes per minute. Strike rate increases are displayed immediately upon calculation while decreases in strike rate are damped. Activating the strike clear function resets the strike rate to zero.

### 3.20. Dedicated Traffic Screen

When selected, a traffic screen is available based roughly on the appearance of a TCAS display. The traffic screen has the following elements:

#### 3.20.1. Ownship Symbol

**Airplane w/o  $M_{MO}$** 

**Airplane with  $M_{MO}$** 

**Figure 3-120: Dedicated Traffic Screen Ownship Symbols**



**Figure 3-121: Traffic Display Format**

The traffic display uses a centered display format with the ownship symbol centered in the traffic screen with data displayed out to an equal distance in all directions. The compass rose is aligned with either magnetic North or True North depending upon the status of the True North discrete input.

### 3.20.2. Traffic Screen Range

The following traffic screen selected ranges are (all distances represent the distance from the ownship symbol to the compass rose): 5NM, 10NM, and 20NM.

A TCAS range ring is centered upon the ownship symbol to help judge range to displayed symbols with a 3NM radius in 5NM and 10NM ranges and has a radius half the range in 20NM, 50NM, and 100NM ranges and presented on the TCAS range ring (e.g., 3NM, 10NM, 25NM, or 50NM).

### 3.20.3. Compass Rose Symbols



**Normal Mode**



**True North Mode**

**Figure 3-122: Traffic Screen Range Compass Rose Symbols**

A digital heading readout and pointer aligned with the longitudinal axis of the ownship symbol appears on the compass rose boundary circle. Compass rose symbols are as specified in § 3.8.1. A green dashed lubber line connects the center of the aircraft symbol and the track pointer. If a target altitude is set and not captured, an altitude capture predictor arc is displayed on the lubber line at a point corresponding with predicted climb or descent distance (based upon current VSI). A top of descent symbol is shown at the point where a VNAV descent is predicted to commence. A pilot-settable heading bug geometrically interacting with the heading pointer appears on the compass rose. A magenta, star-shaped waypoint pointer is displayed on the heading scale at a point corresponding with the active waypoint and turns amber (yellow) in the event of GPS Loss of Navigation caution.

### **3.20.4. Active Flight Plan Path/Manual Course/Runways**

When there is an active flight plan and the GPS/SBAS OBS setting is automatic, the flight plan path when selected is shown on the traffic screen in its correct relationship to the ownship symbol. The active flight plan path depiction meets all the requirements of GPS/SBAS path definition and matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in automatic OBS mode, skyway boxes, and mini-map). Active flight plan path waypoint symbols for fly-over waypoints are distinct from fly-by waypoints and consist of the waypoint symbol within a circle. When there is a parallel offset, the active flight plan path depicts the parallel offset path, and the original flight plan path is shown with halloed gray dashed lines.

When there is an active waypoint and the GPS/SBAS OBS setting is manual, the manual course through the waypoint is shown as a pointer centered on the waypoint and matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in manual OBS mode, skyway boxes, and mini-map).

The active flight plan path's active leg/manual course and active waypoint are magenta and turn amber (yellow) in the event of a GPS Loss of Navigation caution.

The traffic screen displays airport runways in their correct relationship and scale to the ownship symbol.

### 3.21. Datalink Symbology



**Figure 3-123: Datalink Symbology**

When individually selected, the ND displays and indicates status for Temporary Flight Restriction, NEXRAD radar, graphical METAR, and lightning ground strike data. Only the following products received are supported and may be displayed according to the following table.

**Table 3-26: WSI Inflight™ Data Products**

Temporary Flight Restriction Data	Available if included in user subscription
NEXRAD Radar Data	Available if included in user subscription
Graphical METAR Data	Available if Textual METAR data is included in user subscription. Derived from Textual METAR data using EFIS algorithm.
Lightning Ground Strike Data	Available if included in user subscription

**Datalink Temporary Flight Restriction Data Status:** When Temporary Flight Restriction Data has not completely downlinked, status is annunciated as “TFR” with an overlying red “X.”

**NOTE:**

Up to 300 Temporary Flight Restrictions may be displayed.

Temporary Flight Restrictions (TFRs) are displayed on the ND in their correct relationship to the ownship symbol. The NEXRAD Radar Data is displayed on the ND in its correct relationship as colored regions of precipitation using the following convention.

**Table 3-27: Datalink NEXRAD Radar Data**

<b>Color</b>	<b>Meaning</b>
Gray Shading	Areas beyond the limits of radar coverage or areas with missing data
Magenta	Rain $\geq$ 50dBZ
Red	Rain $\geq$ 45dBZ and $<$ 50dBZ
Light Red	Rain $\geq$ 40dBZ and $<$ 45dBZ
Amber (Yellow)	Rain $\geq$ 30dBZ and $<$ 40dBZ
Green	Rain $\geq$ 20dBZ and $<$ 30dBZ
Cyan	Snow $\geq$ 20dBZ
Light Cyan	Snow $\geq$ 5dBZ and $<$ 20dBZ
Magenta	Mixed Precipitation $\geq$ 20dBZ (Area is distinguishable from Rain $\geq$ 50dBZ by graphical context)
Light Magenta	Mixed Precipitation $\geq$ 5dBZ and $<$ 20dBZ

Echo tops (the vertical height of NEXRAD Radar Data returns) are displayed on the datalink screen in their correct relationship to the ownship symbol. Echo tops are automatically decluttered at 400NM, 800NM, and 1,600NM screen ranges. Major echo tops (i.e., the group of highest returns on the currently displayed datalink screen) are displayed as a large circle containing a textual readout of speed and a graphical arrow indicating direction of travel. The height of the major echo top, in hundreds of feet, is textually displayed to the right of the major echo top symbol. The echo top symbol is color-coded and present amplifying text as follows.

**Table 3-28: Datalink NEXRAD Echo Tops**

<b>Severe Weather Condition</b>	<b>Color</b>	<b>Amplifying Text</b>
Possible Hail	Light Cyan	“HAIL”
Confirmed Hail	Light Cyan	“HAIL+”
Mesocyclonic (Rotation Detected)	Red	“MESO”
Tornadic	Magenta	“TRNDO”

Minor echo tops are displayed as a small white circle with the height of the minor echo top, in hundreds of feet, and textually displayed to the left of the minor echo top symbol. The text size for the minor echo top symbol is smaller than for the major echo top symbol.

Graphical METARs are displayed on the datalink screen in their correct relationship to the ownship symbol as a large color-filled circle in accordance with the following convention.

**Table 3-29: Datalink Graphical METARs**


<b>Color</b>	<b>Meaning</b>
Sky Blue	Visual Flight Rules (VFR)
Green	Marginal Visual Flight Rules (MVFR)
Amber (Yellow)	Instrument Flight Rules (IFR)
Red	Low Instrument Flight Rules (LIFR)
Magenta	Less than Category 1 Approach Minimums
Black	No Data

**Table 3-30: Graphical METARS (GMETARS) Screen Range**

<b>Screen Range</b>	<b>Display</b>
50 NM	All GMETARS with Airport Symbol and ID
100 NM	All GMETARS with Airport Symbol only
200 NM	All GMETARS
400 NM	VFR GMETARS are decluttered
800NM and 1,600 NM	VFR and MVFR GMETARS are decluttered

Graphical METARs are also displayed in the menu system “nearest airport,” “nearest weather,” and “info” functions.





Airport	Heading	Distance	Altitude	Value
KISP	150°	7NM	7000'	119.300
23N	150°	10NM	2700'	122.700
KFRG	240°	13NM	6800'	118.800
6JY8	255°	15NM	0'	0.000
KHLV	116°	16NM	4200'	122.800

Figure 3-124: NRST Airport INFO

Graphical weather conditions data are displayed in the menu system “info” function as large colored squares as per the following convention.


**Table 3-31: Datalink Graphical METAR Precipitation**

Color	Meaning
Sky Blue	No Significant Precipitation
Green	Rain
White	Snow
Red	Hazardous Weather
Right Half Gray	Obscuration to Visibility
Small Black Square Centered in Large Square	High Wind
Black	No Data

The following data may be displayed on the datalink screen:

- 1) **Lightning ground strikes:** In correct relationship to the ownship symbol as a small, amber (yellow) cross symbol.
- 2) **Convective SIGMET:** As magenta line segments showing the boundary of the area in its correct relationship to the ownship symbol. The pilot may view the text of individual convective SIGMETs. When viewing text, the associated convective SIGMET symbol flashes.
- 3) **Icing AIRMET and SIGMET:** As cyan line segments showing the boundary of the area in its correct relationship to the ownship symbol. The pilot may view the text of individual icing AIRMETs and SIGMETs. When viewing text, the associated icing AIRMET or SIGMET symbol flashes.

- 4) **IFR AIRMET and SIGMET:** As red line segments showing the boundary of the area in its correct relationship to the ownship symbol. The pilot may view the text of individual IFR AIRMETs and SIGMETs. When viewing text, the associated IFR AIRMET or SIGMET symbol flashes.
- 5) **Turbulence AIRMET and SIGMET:** As amber (yellow) line segments showing the boundary of the area in its correct relationship to the ownship symbol. The pilot may view the text of individual turbulence AIRMETs and SIGMETs. When viewing text, the associated turbulence AIRMET or SIGMET symbol flashes.



**Figure 3-125: Datalink Winds and Temperature Aloft**

Winds and temperature aloft data are displayed on the datalink screen in correct relationship to the ownship symbol as a grid of black squares containing textual readouts of wind speed and temperature (in units determined by the Temp Units flag) and a graphical arrow indicating wind direction. When winds and temperature aloft data are displayed, soft tiles are present to allow the pilot to change the data altitude.

Textual METAR and TAF data are displayed when appropriate in the menu system **INFO** function.

**NOTE:**

Time of observation and forecast are contained within the text.

### 3.21.1. Datalink Screen Legend

A datalink screen legend appears, when selected by the pilot, for depicting symbology used for Graphical METARs, AIRMETs, SIGMETs, NEXRAD Radar with winter colors, Echo Tops, Temperatures Aloft and Winds Aloft.




Figure 3-126: Datalink Screen Legend

### 3.21.2. Air Data and Groundspeed

Air data and groundspeed are displayed in the upper left corner of the datalink screen as specified in § 3.16.1.

### 3.21.3. Clock/Timers/Options




Figure 3-127: Clock/Timers/Options

The following data items are displayed in the upper right corner of the ND:

- 1) **Zulu Time:** As specified in § 3.8.3.

- 2) **Timer:** As specified in § 3.8.3.
- 3) **Datalink Weather Status:** The status of datalink products is displayed as follows:
- 4) **Datalink Temporary Flight Restriction Data Status:** When the Temporary Flight Restriction Data has not been completely downlinked, such status is annunciated as “TFR” with an overlying red “X.”
- 5) **Datalink Weather Status:** When the status of NEXRAD radar, graphical METARs and lightning ground strike data are displayed as follows.

**Table 3-32: Datalink NEXRAD Radar Status**

<b>Condition</b>	<b>Annunciation</b>
<b>NEXRAD Radar Status:</b>	
NEXRAD Radar never completely downlinked	No Annunciation
NEXRAD Radar downlinked within last 5 minutes and selected for display (weather radar, if installed, deselected from display).	“NXRD ##” drawn in Green where ## is age in minutes.  NEXRAD Radar shown on display.
NEXRAD Radar downlinked within last 5 minutes and deselected from display or weather radar, if installed, has been selected for display.	“NXRD ##” drawn in Green where ## is age in minutes.  “NXRD ##” overlaid with Green “X”  NEXRAD Radar not shown on display.
NEXRAD Radar not downlinked within last 5 minutes but downlinked within last 10 minutes and selected for display (weather radar, if installed, deselected from display).	“NXRD ##” drawn in amber (yellow) where ## is age in minutes.  NEXRAD Radar shown on display.

**Table 3-32: Datalink NEXRAD Radar Status**

<b>Condition</b>	<b>Annunciation</b>
NEXRAD Radar not downlinked within last 5 minutes but downlinked within last 10 minutes and deselected from display or weather radar, if installed, has been selected for display.	“NXRD ##” drawn in amber (yellow) where ## is age in minutes.  “NXRD ##” overlaid with Green “X”  NEXRAD Radar not shown on display.
NEXRAD Radar not downlinked within last 10 minutes but downlinked within last 75 minutes and selected for display (weather radar, if installed, deselected from display).	“NXRD ##” drawn in Red where ## is age in minutes.  NEXRAD Radar shown on display.
NEXRAD Radar not downlinked within last 10 minutes but downlinked within last 75 minutes and deselected from display or weather radar, if installed, has been selected for display.	“NXRD ##” drawn in Red where ## is age in minutes.  “NXRD ##” overlaid with Green “X”  NEXRAD Radar not shown on display.
NEXRAD Radar not downlinked within last 75 minutes (timed-out)	“NXRD XX” drawn in Red  “NXRD XX” overlaid with Red “X”  NEXRAD Radar not shown on display.
<b>Graphical METAR Status:</b>	
METARs never completely downlinked	No Annunciation
METARs downlinked within last 5 minutes and selected for display	“GMTR ##” drawn in Green where ## is age in minutes.  Graphical METARs shown on display.

**Table 3-32: Datalink NEXRAD Radar Status**

<b>Condition</b>	<b>Annunciation</b>
METARs downlinked within last 5 minutes and deselected from display	<p>“GMTR ##” drawn in Green where ## is age in minutes.</p> <p>“GMTR ##” overlaid with Green “X”</p> <p>Graphical METARs not shown on display.</p>
METARs not downlinked within last 5 minutes but downlinked within last 10 minutes and selected for display	<p>“GMTR ##” drawn in amber (yellow) where ## is age in minutes.</p> <p>Graphical METARs shown on display.</p>
METARs not downlinked within last 5 minutes but downlinked within last 10 minutes and deselected from display	<p>“GMTR ##” drawn in amber (yellow) where ## is age in minutes.</p> <p>“GMTR ##” overlaid with Green “X”</p> <p>Graphical METARs not shown on display.</p>
METARs not downlinked within last 10 minutes but downlinked within last 75 minutes and selected for display	<p>“GMTR ##” drawn in Red where ## is age in minutes.</p> <p>Graphical METARs shown on display.</p>
METARs not downlinked within last 10 minutes but downlinked within last 75 minutes and deselected from display	<p>“GMTR ##” drawn in Red where ## is age in minutes.</p> <p>“GMTR ##” overlaid with Green “X”</p> <p>Graphical METARs not shown on display.</p>

**Table 3-32: Datalink NEXRAD Radar Status**

Condition	Annunciation
METARs not downlinked within last 75 minutes (timed-out)	"GMTR XX" drawn in Red "GMTR XX" overlaid with Red "X" Graphical METARs not shown on display.
<b>Lightning Ground Strike Status:</b>	
Lightning Ground Strikes never completely downlinked	No Annunciation
Lightning Ground Strikes downlinked within last 5 minutes and selected for display	"LTNG ##" drawn in Green where ## is age in minutes. Lightning Ground Strikes shown on display.
Lightning Ground Strikes downlinked within last 5 minutes and deselected from display	"LTNG ##" drawn in Green where ## is age in minutes. "LTNG ##" overlaid with Green "X" Lightning Ground Strikes not shown on display.
Lightning Ground Strikes not downlinked within last 5 minutes but downlinked within last 10 minutes and selected for display	"LTNG ##" drawn in amber (yellow) where ## is age in minutes. Lightning Ground Strikes shown on display.
Lightning Ground Strikes not downlinked within last 5 minutes but downlinked within last 10 minutes and deselected from display	"LTNG ##" drawn in amber (yellow) where ## is age in minutes. "LTNG ##" overlaid with Green "X" Lightning Ground Strikes not shown on display.

<b>Table 3-32: Datalink NEXRAD Radar Status</b>	
<b>Condition</b>	<b>Annunciation</b>
Lightning Ground Strikes not downlinked within last 10 minutes but downlinked within last 75 minutes and selected for display	<p>“LTNG ##” drawn in Red where ## is age in minutes.</p> <p>Lightning Ground Strikes shown on display.</p>
Lightning Ground Strikes not downlinked within last 10 minutes but downlinked within last 75 minutes and deselected from display	<p>“LTNG ##” drawn in Red where ## is age in minutes.</p> <p>“LTNG ##” overlaid with Green “X”</p> <p>Lightning Ground Strikes not shown on display.</p>
Lightning Ground Strikes not downlinked within last 75 minutes (timed-out)	<p>“LTNG XX” drawn in Red</p> <p>“LTNG XX” overlaid with Red “X”</p> <p>Lightning Ground Strikes not shown on display.</p>

### 3.21.4. Datalink Screen Orientation




Figure 3-128: Datalink



The datalink screen is always displayed in North-up orientation and has a boundary circle instead of a compass rose. DATALINK appears above the boundary circle, and, if not in pan mode, the ownship symbol aligns with aircraft heading.

### 3.21.5. Datalink Screen Range

When selected, the following datalink screen ranges are available as follows.

Table 3-33: Datalink Screen Range Values	
Distance from the ownship to the boundary circle	Radius range values
50 NM	25 NM
100 NM	50 NM
200 NM	100 NM
400 NM	200 NM
800 NM	400 NM
1,600 NM	800 NM

### 3.21.6. Boundary Circle Symbols



Figure 3-129: Boundary Circle Symbol

A white triangular heading pointer aligned with the longitudinal axis of the ownship symbol appears on the boundary circle with a green diamond-shaped track pointer aligned with the aircraft's track across the earth. A green dashed lubber line connects the center of the aircraft symbol and track pointer. If a target or VNAV altitude is set and not captured, an altitude capture predictor arc is displayed on the lubber line at a point corresponding with predicted climb or descent distance (based upon current VSI). A top of descent symbol is shown as specified in § 3.11.1, however this is not displayed when

groundspeed is less than 30 knots. A pilot-settable heading bug geometrically interacting with the heading pointer appears on the boundary circle. A magenta, star-shaped waypoint pointer is displayed on the boundary circle at a point corresponding with the active waypoint. The waypoint pointer turns amber (yellow) in the event of GPS Loss of Navigation caution.

#### **NOTE:**

Boundary circle symbols are not drawn, if the datalink screen is in pan mode.

### **3.21.7. Active Flight Plan Path/Manual Course/Runways**

When there is an active flight plan and the GPS/SBAS OBS setting is automatic, the flight plan path, if selected, shows on the datalink screen in its correct relationship to the ownship symbol. The active flight plan path depiction meets all the requirements of GPS/SBAS path definition and matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in automatic OBS mode, skyway boxes, and mini-map). Active flight plan path waypoint symbols for fly-over waypoints are distinct from fly-by waypoints and consist of the waypoint symbol within a circle. When there is a parallel offset, the active flight plan path depicts the parallel offset path and the original flight plan path with haloed gray dashed lines.

When there is an active waypoint and the GPS/SBAS OBS setting is manual, the manual course through the waypoint is shown as a pointer centered on the waypoint. The pointer matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in manual OBS mode, skyway boxes, and mini-map).

The active flight plan path's active leg/manual course and active waypoint are magenta and turn amber (yellow) in the event of a GPS Loss of Navigation caution.

The datalink screen displays airport runways in their correct relationship and scale to the ownship symbol.

### **3.21.8. Borders**

National and United States state borders are drawn in white in their correct relationship to the ownship symbol.

### 3.21.9. Pan Mode

The datalink screen has a pan mode to allow the pilot to change the location of the center of the screen away from current location. The pan mode allows the pilot to view weather conditions along the route of flight and at the intended destination or alternate destination. When pan mode is active, press appropriate button(s) to move the pan mode location North, South, East, and West. When pan mode is active, a line from the map center to the aircraft's current position is drawn. When pan mode is active, bearing and distance to the map center are always displayed above the ownship symbol when the aircraft is more than 0.5 NM away. If referenced to magnetic North, (as specified in § 3.8.1) when panning, the nearest displayed graphical METAR symbol within the inner range ring becomes highlighted with a flashing circle. When such a point is highlighted, dedicated menu tiles are present to allow the pilot to view and hide the waypoint information (including datalink weather information) associated with that point.

### 3.22. Weather Radar

Weather Radar automatically declutters when weather radar returns are selected for display on the ND map screen in correct relationship to the ownship symbol unless inhibited during active FLTA alerts. When Weather Radar is selected for display, datalink NEXRAD is automatically deselected. The following table defines all inhibited factors with display.

**Table 3-34: Weather Radar Inhibited Conditions**

During Active FLTA alerts
ND Moving Map Panning Mode
When North Up orientation is selected
When RDR-2100 is in vertical profile mode
When screen range is too small to effectively show the weather returns (defined as when the length of the weather radar scan line is longer than 512 pixels given current weather radar scale setting, screen range and screen mode)




Figure 3-130: Weather Radar on ND

### 3.2.2.1. Weather Screen Format

In a horizontal depiction, the weather screen uses an arced format with the ownship symbol centered in the bottom of the display with the weather area depicted as an arc ahead of the ownship symbol.





Figure 3-131: Radar in Arced Format

In a profile depiction, the weather screen uses an arced format with the ownship symbol centered on the left side of the display and the weather area depicted as an arc to the right of the ownship symbol.



**Figure 3-132: Radar in Profile Depiction**

Pilot selection of the profile depiction is performed using a separate Weather Radar Control Panel connected to the IDU. The IDU ensures at least one weather radar-enabled screen is showing the weather radar page prior to entering into the profile depiction and automatically disables profile depiction, if the pilot sets up the screens so no weather radar page is shown on any weather radar-enabled screen. The purpose is to maximize the availability of weather radar information on the ND screen. The ND screen only shows a horizontal depiction and automatically disables profile depiction, if the weather radar mode is set to off or standby via Radar Control Panel.

### 3.22.2. Weather Screen Range

Weather screen range is pilot-selectable through either ❶ (RDR-2000 and RDR-2100 weather radar types) or a control panel directly attached to the weather radar receiver-transmitter. Weather screen range is displayed as a series of equidistant dashed arcs centered upon the ownship symbol to help the pilot judge range to the displayed weather radar returns.

All distances represent the distance from the ownship symbol to the outer dashed arc: 5NM, 10NM, 20NM, 40NM, 80NM, 160NM, 240NM, and 320NM.

For most screen ranges, there are four equidistant dashed arcs. When in 2.5NM range, there are five equidistant dashed arcs. Each

arc is labeled with distance in nautical miles at its right-most point (horizontal depiction) or bottom-most point (profile depiction). In the profile depiction mode, there are also three horizontal altitude lines drawn relative to the aircraft's altitude to help the pilot judge the vertical distance to the displayed weather radar returns. The center line is level with the ownship symbol to represent the aircraft's altitude. The other two lines are equally spaced above and below the center line to represent altitude differences above and below the aircraft. The number of feet above and below the aircraft varies with the selected range to compensate for the radar scan width at the different ranges.

### 3.22.3. Track Line

When the weather radar type is RDR-2000 or RDR-2100 and the horizontal depiction is being shown, a dashed track line appears emanating from the ownship symbol to the outer dashed arc. The value of the track line in whole degrees left or right of aircraft heading is displayed adjacent to the outer end of the track line.





Figure 3-133: Radar Track Line

### 3.22.4. Active Flight Plan Path/Manual Course/Runways


The active flight plan path (when selected), waypoints, and manual course appear when the weather radar screen is showing horizontal depiction. The weather radar screen displays airport runways when the weather radar screen is showing horizontal depiction.



**Figure 3-134: Radar Active Flight Plan**

### 3.22.5. Weather Radar Return Data

Weather radar return data are displayed on the weather radar screen in its correct relationship to the ownship symbol.



**Figure 3-135: Radar Return Data**

Weather radar return data are displayed as colored regions according to the value of the ARINC 453 3-bit range bins as follows.

Table 3-35: Weather Radar Return Data

ARINC 453 3-Bit Range Bin	Color	Meaning
000b	BLACK	No Returns
001b	GREEN	Low-Level Weather or Low-Level Ground Returns
010b	AMBER (YELLOW)	Mid-Level Weather or Mid-Level Ground Returns
011b	RED	Third-Level Weather Returns. Color is replaced with BLACK when in MAP mode. MAP mode is encoded in ARINC 453 label 055 and 171 bits 27-29 as 010b.
100b	MAGENTA	Fourth-Level Weather or Third-Level Ground Returns. With an RDR-2000 or RDR-2100 weather radar type, this color alternates between MAGENTA and BLACK at 1Hz when the internal submode is WXA.
101b	CYAN	Automatic Range Limit Returns. Indicates areas of unreliable returns due to radar power absorption.
110b	LIGHT GRAY	Moderate Turbulence Returns.
111b	WHITE	Severe Turbulence Returns.

The following weather radar-specific warning appears in a conspicuous area adjacent to the weather radar return data so they do not conflict with the weather radar return data. Only one weather radar-specific warning appears at any given time with the following order of precedence:

- 1) **WX ALERT:** Weather alert condition is active. A weather alert condition is indicated according to weather radar type as follows:
  - a) ARINC 708-6: ARINC 453 label 055 Bit 15



- b) Collins 800/840: ARINC 453 label 055 Bit 15
  - c) Honeywell Primus: ARINC 453 label 055 Bit 12
  - d) Honeywell RDR-2000/2100: ARINC 453 label 055 or label 171 Bit 20
- 2) **TURB ALERT:** Turbulence alert condition is active. A turbulence alert condition is indicated by ARINC 453 label 055 Bit 14. Honeywell Primus and Honeywell RDR-2000/2100 do not set this bit.
  - 3) **STAB LIMIT:** Aircraft attitude has moved to a point where the weather radar antenna is no longer effectively stabilized. A stability limit condition is indicated by ARINC 453 label 055 or label 171 Bit 18.
  - 4) **ANT FAULT:** Weather radar antenna is temporarily dislodged by turbulence.

### 3.22.6. Air Data and Groundspeed

Air data and groundspeed are displayed in the upper left corner of the weather radar screen as specified in § 3.16.1.

### 3.22.7. Clock/Timers/Options



**Figure 3-136: Radar Clock/Timer/Options**

- 1) **Zulu Time:** Displayed as specified in § 3.8.3;
- 2) **Timer:** A countdown or count-up timer is displayed as specified in § 3.8.3;
- 3) Weather Radar Mode Annunciation is as in Table 3-37.

**Table 3-36: RDR 2100 Applicability**

<b>Mode</b>	<b>Annunciation</b>
Off	<b>WXR:OFF</b>
Standby	<b>WXR:STBY</b>
Weather Only	<b>WXR:WX</b>
Weather Alert	<b>WXR:WXA</b>
Ground Map	<b>WXR:GMAP</b>
Contour	<b>WXR:CONT</b>
Test	<b>WXR:TEST</b>
Not Defined	<b>WXR:----</b>

**Table 3-37: RDR 2100 Mode Annunciation**

<b>Annunciation</b>	<b>Conditions</b>
<b>Overlaid with Red X</b>	<p>Weather Radar Mode is off or not defined.</p> <p>A Cooling Fault Condition exists.</p> <p>An Attitude or Range Fault Condition exists.</p> <p>A Control Fault Condition exists.</p> <p>A T/R Fault Condition exists.</p> <p>A Control Fault Condition exists.</p> <p>A T/R Fault Condition exists.</p>
<b>STAB OFF (Stabilization)</b>	<p>The weather radar mode annunciation is not overlaid with a Red "X";</p> <p>The weather radar mode is not standby or forced standby; and</p> <p>The weather radar indicates stabilization is off.</p>
<b>TGT ALERT (Target Alert)</b>	<p>The weather radar mode annunciation is not overlaid with a Red "X";</p> <p>The weather radar mode is not standby or forced standby;</p>

**Table 3-37: RDR 2100 Mode Annunciation**

Annunciation	Conditions
<p><b>TLT:UXX.X” or “TLT:AUTO (TILT)</b></p>	<p>The weather radar is presenting the horizontal depiction;</p> <p><b>U</b> = Up or Down (either U or D, but not both, appears – use <b>U</b> for 0°);</p> <p><b>XX.X</b> represents the absolute value of the tilt angle in degrees truncated to the nearest tenth;</p> <p><b>TLT:AUTO</b> is used where the weather radar reports a value of -16°, representing automatic tilt.</p> <p>The weather radar tilt annunciation only appears when all of the following conditions are true:</p> <p>The weather radar mode annunciation is not overlaid with a Red “X”;</p> <p>The weather radar mode is not standby or forced standby; and</p> <p>The weather radar is not in Vertical Profile submode.</p>
<p><b>TRK:LXX (TRACK)</b></p>	<p><b>L</b> = Left or Right (either L or R, but not both, appears – use <b>R</b> for 0°); and</p> <p><b>XX</b> represents the absolute value of the track angle in degrees.</p> <p>The weather radar track annunciation only appears when all of the following conditions are true:</p> <p>The weather radar mode annunciation is not overlaid with a Red “X”;</p> <p>The weather radar mode is not standby or forced standby; and</p> <p>The weather radar is in Vertical Profile submode (profile depiction).</p>

**Table 3-37: RDR 2100 Mode Annunciation**

<b>Annunciation</b>	<b>Conditions</b>
<p><b>“GN:SXXDB,”</b>  <b>“GN:CAL” or</b>  <b>“GN:MAX”</b>  <b>(GAIN)</b></p>	<p><b>S</b> = Sign (either “+” or “-”, but not both, appears – use + for 0°); and</p> <p><b>XXDB</b> represents the manual gain setting in decibels.</p> <p><b>GN:CAL</b> represents the calibrated condition</p> <p><b>GN:MAX</b> represents maximum manual gain</p> <p>The weather radar manual gain annunciation only appears when all of the following weather radar mode conditions are true:</p> <ol style="list-style-type: none"> <li>1) Mode annunciation is not overlaid with a Red “X”;</li> <li>2) Mode is not standby or forced standby; and</li> <li>3) Mode is Ground Map.</li> </ol>

### 3.22.8. Fuel Totalizer/Waypoint Bearing and Distance Functions

Fuel totalizer, waypoint bearing, and waypoint distance are displayed in the lower right corner of the weather radar screen as specified in § 3.8.2.

### 3.23. Video Input Screen


The video input screen is an image of 640 by 480 pixels and accepts video input signals in the RS-170 composite format. The system is configurable to the NTSC, PAL (including the PAL-m and PAL-nc variants) or SECAM versions of RS-170 separately for each video input. In addition, an auto-detection mode which programs the video input chip to process most standard RS-170 formats is configurable for each video input.

- 1) **NO VIDEO IMAGE AVAILABLE:** When no video signal is detected, the video input screen is black with the annunciation displayed in white centered on the screen. To aid in diagnosing problems with undetected video signals, the following annunciations are displayed below this annunciation in white centered on the screen.
- 2) **NO INTERLACED SIGNAL:** No interlaced signal is detected.
- 3) **NO HORIZ OR VERT SYNC:** No horizontal or vertical synchronization detected.
- 4) **NO COLOR SIGNAL:** No video chroma signal is detected.
- 5) **LOAD ERROR DETECTED:** Video chip reports a load error.
- 6) **TRIGGER ERROR DETECTED:** Video chip reports a trigger error.
- 7) **PROGRAMMING ERROR DETECTED:** Video chip reports a programming error.

### 3.23.1. ZOOM Level

The pilot may zoom the video image by replicating pixels to a desired ZOOM levels from 1 (no pixel replication) to 10 in increments of 1.

### 3.23.2. Pan Mode



When the ZOOM level is greater than 1, the Video Input screen has a pan mode to allow the pilot to select the portion of the video image displayed by replicating pixels. When pan mode is active, controls are present to allow moving the portion displayed Up, Down, Left, and Right.


**Figure 3-137: Video Pan View**

A mini-map of the displayed image's position in the full video image is displayed for 10 seconds after:

- 1) Entering pan mode,
- 2) Changing the ZOOM level to a value greater than 1,
- 3) Panning the zoomed image.

Exiting the pan mode removes the pan mode controls and the mini-map, if any.

### 3.23.3. Video Input Status Display



When selected by the pilot, the following data items are optionally displayed in the upper right corner of the Video Input display.

**Figure 3-138: Video Status**

**Label:** Identifies the video input source and is configurable to one of a set of predefined labels. If no label is configured, the label is “**VIDEO-n**” where ‘n’ is the video input source number.

**ZOOM:** Amount of pixel expansion is displayed as “**ZOOM nnX**” where ‘nn’ is the ZOOM level.

**Brightness:** Video brightness setting is displayed and formatted as “**BRT nnn%**” where ‘nnn’ is the brightness setting as a percentage of the maximum value.

**Contrast:** Video contrast setting is displayed and formatted as “**CTRST nnn%**” where ‘nnn’ is the contrast setting as a percentage of the maximum value.

**Saturation:** Video chroma saturation setting is displayed and formatted as “**SAT nnn%**” where ‘nnn’ is the saturation setting as a percentage of the maximum value.

**Hue:** Video chroma hue setting is displayed and formatted as “**HUE nnn%**” where ‘nnn’ is the hue setting as a percentage of the maximum value.

## **Section 4      Reversionary Modes**

## Table of Contents

SECTION 4	REVERSIONARY MODES .....	4-1
4.1.	REVERSIONARY MODES .....	4-7
4.2.	SYSTEM OPERATION IN REVERSIONARY MODES .....	4-8
4.2.1.	<i>OAT Sensor Failure Mode</i> .....	4-11
4.2.2.	<i>Heading Failure Mode</i> .....	4-11
4.2.3.	<i>PFD Screen Auto Reversion</i> .....	4-11
4.2.4.	<i>EICAS Screen Single-Action Reversion</i> .....	4-12
4.2.5.	<i>GPS Failure</i> .....	4-12
4.3.	PFD FAILURE MODE 0 (NORMAL MODE) .....	4-15
4.3.1.	<i>MFD Failure Mode 0 (Normal Mode)</i> .....	4-17
4.4.	PFD FAILURE MODE 1 (NORMAL MODE) .....	4-19
4.4.1.	<i>PFD Failure Mode 1 (Essential Mode)</i> .....	4-21
4.4.2.	<i>MFD Failure Mode 1 (Normal Mode)</i> .....	4-23
4.5.	PFD FAILURE MODE 2 (NORMAL MODE) .....	4-25
4.5.1.	<i>MFD Failure Mode 2 (Normal Mode)</i> .....	4-27
4.5.2.	<i>MFD Failure Mode 2 (Essential Mode)</i> .....	4-29
4.6.	PFD FAILURE MODE 3 (NORMAL MODE) .....	4-31
4.6.1.	<i>MFD Failure Mode 3 (Normal Mode)</i> .....	4-33
4.7.	PFD FAILURE MODE 4 (NORMAL MODE) .....	4-35
4.7.1.	<i>MFD Failure Mode 4 (Normal Mode)</i> .....	4-37
4.7.2.	<i>MFD Failure Mode 4 (Essential Mode)</i> .....	4-39
4.8.	PFD FAILURE MODE 5 (NORMAL MODE) .....	4-41
4.8.1.	<i>MFD Failure Mode 5 (Normal Mode)</i> .....	4-43
4.8.2.	<i>MFD Failure Mode 5 (Essential Mode)</i> .....	4-45
4.9.	PFD FAILURE MODE 6 (NORMAL MODE) .....	4-47



- 4.9.1. *MFD Failure Mode 6 (Normal Mode)*.....4-49
- 4.9.2. *MFD Failure Mode 6 (Essential Mode)*.....4-51
- 4.10. PFD FAILURE MODE 7 (NORMAL MODE).....4-53
  - 4.10.1. *MFD Failure Mode 7 (Normal Mode)*.....4-55
  - 4.10.2. *MFD Failure Mode 7 (Essential Mode)*.....4-57

## List of Figures and Tables

TABLE 4-1: PFD FUNCTIONS.....	4-8
TABLE 4-2: ND FUNCTIONS.....	4-9
TABLE 4-3: OUTPUT FUNCTIONS .....	4-9
FIGURE 4-1: PFD FAILURE MODE 0 (NORMAL MODE) GPS, ADC, AND AHRS NORMAL.....	4-15
TABLE 4-4: PFD FAILURE MODE 0 (NORMAL MODE) GPS, ADC, AND AHRS NORMAL.....	4-16
FIGURE 4-2: MFD FAILURE MODE 0 (NORMAL MODE) GPS, ADC, AND AHRS NORMAL.....	4-17
TABLE 4-5: MFD FAILURE MODE 0 (NORMAL MODE) GPS, ADC, AND AHRS NORMAL.....	4-18
FIGURE 4-3: PFD FAILURE MODE 1 (NORMAL MODE) GPS/SBAS FAILED; ADC AND AHRS NORMAL.....	4-19
TABLE 4-6: FUNTION TABLE PFD FAILURE MODE 1 (NORMAL MODE) GPS/SBAS FAILED; ADC AND AHRS NORMAL.....	4-20
FIGURE 4-4: PFD FAILURE MODE 1 (ESSENTIAL MODE) GPS/SBAS FAILED; ADC AND AHRS NORMAL.....	4-21
TABLE 4-7: MFD FAILURE MODE 1 (ESSENTIAL MODE) GPS/SBAS FAILED; ADC AND AHRS NORMAL.....	4-22
FIGURE 4-5: MFD FAILURE MODE 1 (NORMAL MODE) GPS/SBAS FAILED; ADC AND AHRS NORMAL.....	4-23
TABLE 4-8: MFD FAILURE MODE 1 (NORMAL MODE) GPS/SBAS FAILED; ADC AND AHRS NORMAL .....	4-24
FIGURE 4-6: PFD MODE 2 (NORMAL MODE) ADC FAILED; GPS/SBAS AND AHRS NORMAL.....	4-25
TABLE 4-9: PFD MODE 2 (NORMAL MODE) ADC FAILED; GPS/SBAS AND AHRS NORMAL.....	4-26
FIGURE 4-7: MFD FAILURE MODE 2, (NORMAL MODE) ADC FAILED; GPS/SBAS AND AHRS NORMAL.....	4-27
TABLE 4-10: MFD FAILURE MODE 2, (NORMAL MODE) ADC FAILED; GPS/SBAS AND AHRS NORMAL.....	4-28
FIGURE 4-8: MFD FAILURE MODE 2 (ESSENTIAL MODE) ADC FAILED; GPS/SBAS AND AHRS NORMAL.....	4-29
TABLE 4-11: MFD FAILURE MODE 2 (ESSENTIAL MODE) ADC FAILED; GPS/SBAS AND AHRS NORMAL.....	4-30
FIGURE 4-9: PFD FAILURE MODE 3 (NORMAL MODE) AHRS FAILED; GPS/SBAS AND ADC NORMAL .....	4-31
TABLE 4-12: PFD FAILURE MODE 3 (NORMAL MODE) AHRS FAILED; GPS/SBAS AND ADC NORMAL .....	4-32
FIGURE 4-10: MFD FAILURE MODE 3 (NORMAL MODE) AHRS FAILED; GPS/SBAS AND ADC NORMAL .....	4-33

TABLE 4-13: MFD FAILURE MODE 3 (NORMAL MODE) AHRS FAILED; GPS/SBAS AND ADC NORMAL .....	4-34
FIGURE 4-11: PFD FAILURE MODE 4 (NORMAL MODE) GPS/SBAS AND ADC FAILED; AHRS NORMAL .....	4-35
TABLE 4-14: PFD FAILURE MODE 4 (NORMAL MODE) GPS/SBAS AND ADC FAILED; AHRS NORMAL .....	4-36
FIGURE 4-12: MFD FAILURE MODE 4 (NORMAL MODE) GPS/SBAS AND ADC FAILED; AHRS NORMAL .....	4-37
TABLE 4-15: MFD FAILURE MODE 4 (NORMAL MODE) GPS/SBAS AND ADC FAILED; AHRS NORMAL .....	4-38
FIGURE 4-13: MFD FAILURE MODE 4 (ESSENTIAL MODE) GPS/SBAS AND ADC FAILED; AHRS NORMAL .....	4-39
TABLE 4-16: MFD FAILURE MODE 4 (ESSENTIAL MODE) GPS/SBAS AND ADC FAILED; AHRS NORMAL .....	4-40
FIGURE 4-14: PFD FAILURE MODE 5 (NORMAL MODE) GPS/SBAS AND AHRS FAILED; ADC NORMAL .....	4-41
TABLE 4-17: PFD FAILURE MODE 5 (NORMAL MODE) GPS/SBAS AND AHRS FAILED; ADC NORMAL .....	4-42
FIGURE 4-15: MFD FAILURE MODE 4 (NORMAL MODE) GPS/SBAS AND AHRS FAILED; ADC NORMAL .....	4-43
TABLE 4-18: MFD FAILURE MODE 4 (NORMAL MODE) GPS/SBAS AND AHRS FAILED; ADC NORMAL .....	4-44
FIGURE 4-16: MFD FAILURE MODE 5 (ESSENTIAL MODE) GPS/SBAS AND AHRS FAILED; ADC NORMAL .....	4-45
TABLE 4-19: MFD FAILURE MODE 5 (ESSENTIAL MODE) GPS/SBAS AND AHRS FAILED; ADC NORMAL .....	4-46
FIGURE 4-17: PFD FAILURE MODE 6 (NORMAL MODE) ADC AND AHRS FAILED; GPS/SBAS NORMAL .....	4-47
TABLE 4-20: PFD FAILURE MODE 6 (NORMAL MODE) ADC AND AHRS FAILED; GPS/SBAS NORMAL .....	4-48
FIGURE 4-18: MFD FAILURE MODE 6 (NORMAL MODE) ADC AND AHRS FAILED; GPS/SBAS NORMAL .....	4-49
TABLE 4-21: MFD FAILURE MODE 6 (NORMAL MODE) ADC AND AHRS FAILED; GPS/SBAS NORMAL .....	4-50
FIGURE 4-19: MFD FAILURE MODE 6 (ESSENTIAL MODE) ADC AND AHRS FAILED; GPS/SBAS NORMAL.....	4-51
TABLE 4-22: MFD FAILURE MODE 6 (ESSENTIAL MODE) ADC AND AHRS FAILED; GPS/SBAS NORMAL.....	4-52
FIGURE 4-20: PFD FAILURE MODE 7 (NORMAL MODE) GPS/SBAS, ADC, AND AHRS FAILED .....	4-53
TABLE 4-23: PFD FAILURE MODE 7 (NORMAL MODE) GPS/SBAS, ADC, AND AHRS FAILED .....	4-54
FIGURE 4-21: MFD FAILURE MODE 7 (NORMAL MODE) GPS/SBAS, ADC, AND AHRS FAILED .....	4-55

TABLE 4-24: MFD FAILURE MODE 7 (NORMAL MODE) GPS/SBAS, ADC, AND AHRS FAILED.....	4-56
FIGURE 4-22: MFD FAILURE MODE 7 (ESSENTIAL MODE) GPS/SBAS, ADC, AND AHRS FAILED.....	4-57
TABLE 4-25: MFD FAILURE MODE 7 (ESSENTIAL MODE) GPS/SBAS, ADC, AND AHRS FAILED.....	4-58

## 4.1. Reversionary Modes

The equipment has eight reversionary modes as follows:

- Mode 0: GPS/SBAS, ADC, and AHRS normal.
- Mode 1: GPS/SBAS failed; ADC and AHRS normal.
- Mode 2: ADC failed; GPS/SBAS and AHRS normal.
- Mode 3: AHRS failed; GPS/SBAS and ADC normal.
- Mode 4: GPS/SBAS and ADC failed; and AHRS normal.
- Mode 5: GPS/SBAS and AHRS failed; and ADC normal.
- Mode 6: ADC and AHRS failed; and GPS/SBAS normal.
- Mode 7: GPS, ADC, and AHRS failed.

To use this section, review the following tables and notes to determine what feature or function is affected by one or more of the three sensors failed conditions. Examples follow with the IDU-680 displays in various configurations with a table breaking down the affected functions.

Not all possible IDU-680 display configurations and format combinations are represented here. All eight modes of system operation are represented for description purposes.

## 4.2. System Operation in Reversionary Modes

**Table 4-1: PFD Functions**

PFD Function	Mode							
	0	1	2	3	4	5	6	7
Airspeed	OK	OK	19	OK	19	OK	19	19
Altimeter	OK	OK	19	OK	19	OK	19	19
Altimeter Set Display	OK	OK	-	OK	-	OK	-	-
Bank Scale	OK	OK	OK	-	OK	-	-	-
CDI	OK	1 + 20	OK	OK	20	20	OK	20
Runway	OK	1	-	-	-	-	-	-
Waypoint Pointer	7	1	7	7	-	-	7	-
Heading Scale	7	7	7	7	7	-	7	-
AGL Ind.	OK	2	4	OK	11	11	4	-
Flight Path Marker	OK	1 + 14	-	-	-	-	-	-
G-meter	OK	OK	OK	-	OK	-	-	-
Ground Track	7	1	7	7	-	-	7	-
Heading Indicator	7	7	7	-	7	-	-	-
Horizon	OK	OK	OK	-	OK	-	-	-
Mini-Map	7	1	7	7	-	-	7	-
Pitch Limit Indicator	OK	OK	-	8	-	8	-	-
Pitch Scale	OK	OK	OK	-	OK	-	-	-
Highway in the Sky	OK	1 + 15	-	-	-	-	-	-
Terrain/ Obstructions	OK	-	-	-	-	-	-	-
Clock Functions	OK	OK	OK	OK	OK	OK	OK	OK
VSI	OK	OK	-	OK	-	OK	-	-
Waterline Symbol	22	22	5	13	5	13	13	13
Waypoint Symbol	OK	1	-	-	-	-	-	-
Waypoint Brg/Dist	OK	1	OK	OK	-	-	OK	-
Traffic	OK	OK	OK	-	-	-	-	-
Traffic Thumbnail	OK	OK	OK	OK	OK	OK	OK	OK
Speed Trend	OK	OK	-	-	-	-	-	-
Dynamic Stall Speed	OK	OK	-	8	-	8	-	-

**Table 4-2: ND Functions**

ND Functions	Mode							
	0	1	2	3	4	5	6	7
Aircraft Position	OK	1	OK	OK	-	-	OK	-
Special Use Airspace	9	1	6	9	-	-	6 + 9	-
Waypoint Pointer	9	1	9	9	-	-	9	-
Active Flight Plan Path	9	1	9	9	-	-	9	-
Glide Range	9	1	-	10	-	-	-	-
Groundspeed	OK	1	OK	OK	-	-	OK	-
Ground Track	9	1	9	9	-	-	9	-
Heading Indicator	9	9	9	-	9	-	-	-
Navigation Symbols	9	1	9	9	-	-	9	-
Outside Air Temp.	OK	OK	-	OK	-	OK	-	-
Projected Path	OK	1	OK	-	-	-	-	-
Traffic	OK	OK	OK	OK	OK	OK	OK	OK
Terrain/ Obstructions	OK	-	-	OK	-	-	-	-
Clock Functions	OK	OK	OK	OK	OK	OK	OK	OK
Waypoint Brg./Dist.	OK	1	OK	OK	-	-	OK	-
Wind	21	3	-	-	-	-	-	-
Compass Rose	9	9	9	9	9	-	9	-
Fuel Totalizer Functions	23	24	23	23	12	12	12	12
True Airspeed	OK	OK	-	OK	-	OK	-	-
Density Altitude	OK	OK	-	OK	-	OK	-	-
OAT/ISA Display	OK	OK	-	OK	-	OK	-	-

**Table 4-3: Output Functions**

Output Functions	Mode							
	0	1	2	3	4	5	6	7
Air/Ground Output	16	16	17	16	17	16	17	17
Autopilot EFIS Valid	16	16	16	-	-	-	-	-
TAWS Alarm Output	16	16	16	16	16	16	16	16
Transmit Enabled	16	16	16	16	16	16	16	16
Warning Light Output	16	16	16	16	16	16	16	16
Caution Light Output	16	16	16	16	16	16	16	16
Mstr. Caut. Light Output	16	16	16	16	16	16	16	16
MDA/DH Output	16	16	18	16	18	16	18	18
Altitude Capture Output	16	16	-	16	-	16	-	-
IAS Switch Output	16	16	-	16	-	16	-	-

- Note 1: Presented using inertial dead-reckoning based on last known wind information. If unable to dead-reckon (e.g., heading is failed or true airspeed cannot be calculated), function is disabled.
- Note 2: Only radar altitude presented when available.
- Note 3: Last known wind is saved during GPS/SBAS failure.
- Note 4: Either radar altitude or geodetic altitude less database elevation.
- Note 5: N/A for fixed wing aircraft.
- Note 6: Special use airspace boundaries are drawn with bold lines due to lack of aircraft altitude data.
- Note 7: In heading-only failure mode or AHRS failure mode, heading scale aligned with aircraft track and heading indication is removed. In heading-only failure mode or AHRS failure mode combined with GPS failure, heading scale is replaced with a red-X.
- Note 8: Based upon 1G stall speed.
- Note 9: In heading-only failure mode or AHRS failure mode, compass rose aligned with aircraft track and heading indication is removed when in heading up mode. In heading-only failure mode or AHRS failure mode combined with GPS failure, compass rose is removed.
- Note 10: Presenting using last-known wind information and aligned with aircraft track in heading up mode.
- Note 11: Only radar altitude presented when available.
- Note 12: Assuming valid fuel flow information, endurance is presented.
- Note 13: Large attitude bars presented and X'd out.
- Note 14: Flight Path Marker grayed after one minute to indicate degraded operation.
- Note 15: Highway in the Sky removed after one minute.
- Note 16: See IDU SCC Card and Limits Requirements for activation requirements.



- Note 17: Defaults to AIR unless Weight on Wheel/Weight on Ground discrete input is active.
- Note 18: Only DH function (with valid AGL altitude) in this mode.
- Note 19: Red X in place of scale.
- Note 20: VLOC CDI always available if optional VOR symbology enabled.
- Note 21: Function removed during heading-only failure mode.
- Note 23: Assuming valid fuel flow information, both range and endurance are presented.
- Note 24: Assuming valid fuel flow information, both range and endurance are presented using inertial dead-reckoning based on last known wind information. If the pilot is unable to dead-reckon due to loss of heading or true airspeed cannot be calculated, endurance only information is presented.

#### **4.2.1. OAT Sensor Failure Mode**

In addition, the equipment has an OAT sensor failure mode. With the OAT sensor failed, the display of wind, OAT, density altitude and true airspeed on the ND are disabled.

#### **4.2.2. Heading Failure Mode**

In addition, the equipment has a heading failure mode. With heading failed, the PFD heading scale and MFD compass rose align with track (if available) or is removed and replaced with a red-X. In this failure mode, the PFD heading scale includes "GPS TRK" around the track marker to clearly delineate the failure mode.

#### **4.2.3. PFD Screen Auto Reversion**

For IFR approval in aircraft, flight instrument information essential to safety of flight remains available to the pilot without additional crewmember action after a failure. To accommodate this, MFDs must have the ability to sense when the PFD has failed and take over the PFD function automatically. The manner in which this occurs on the IDU-680 is as follows:

When an MFD (IDU #2, #3, or #4) becomes the "transmit-enabled" IDU, the MFD automatically switches to Essential Mode. Essential

Mode shows a PFD screen in the top area. In addition, if an EICAS is defined, Essential Mode shows the Essential Mode EICAS screen in the bottom area. If an EICAS is not defined, the bottom area of Essential Mode is free to show any MFD screen as defined. To change the MFD back to Normal Mode after the automatic switch, press **TO NORMAL/TO ESSNTL (R5)**.

#### 4.2.4. EICAS Screen Single-Action Reversion

When configured with an EICAS, it is a design goal for the pilot to select the display of EICAS on an alternate IDU with a single action. This mitigates the hazards associated with losing the primary display of EICAS. The manner in which this occurs on the IDU-680 is as follows:

Press **TO NORMAL/TO ESSNTL (R5)** to alternate between Normal and Essential Modes on all displays. Essential Mode consists of a PFD screen in the top area and, if configured, an Essential Mode EICAS screen in the bottom area. On a PFD (IDU #1), there is only a distinction between Normal and Essential Modes when an EICAS is configured, and the display of **TO NORMAL/TO ESSNTL (R5)** is inhibited when an EICAS is not configured. Because switching between Normal and Essential Modes is an alternating action of pressing **TO NORMAL/TO ESSNTL (R5)**, access to an EICAS display on any IDU only requires a single pilot action.

#### 4.2.5. GPS Failure

GPS may degrade or fail as a result of loss of satellite information or GPS equipment failure. When the integrity is provided by SBAS, the IDU issues **GPS LOI** within two seconds, if the current HPL (Horizontal Protection Level) exceeds the HAL (Horizontal Alert Level). **GPS LOI** appears when there is no integrity monitoring and disappears when integrity monitoring is restored.

Further GPS degradation causes the EFIS to lose GPS updating of aircraft position, ground speed, and ground track, and the ability to calculate the wind information.

- 1) **GPS LOI** (Loss of Integrity) is displayed with no time delay.
- 2) HPL > HAL for the current phase of flight currently. Position is still presented based upon a GPS navigation solution.

- 3) **GPS LON** (Loss of Navigation) is displayed with no time delay of the onset of the following:
- The absence of power;
  - Equipment malfunction or failure;
  - The presence of a condition lasting five seconds or more where there are an inadequate number of satellites to compute position solution;
  - Fault detects a position failure that cannot be excluded within time-to-alert when integrity is provided by FDE;
  - HPL > HAL on the final approach segment. Genesys Aerosystems EFIS does not transition to DR Navigation at this stage. A GPS Navigation solution is still presented; and
  - Where HPL > HAL on the final approach segment, this position may still be satisfactory for GPS Navigation. For example, an HPL of 0.31NM exists which means as soon as a transition to TERMINAL mode occurs, all alerts would disappear. This is significantly important during a wind change if the system had been in a DR mode.

**NOTE:**

At any time, the pilot may view HFOM on the FAULTS page to see the system-reported accuracy.

- DR** (Dead Reckoning)
  - In the event GPS position cannot be calculated, a dead reckoning solution is provided with a timer **DR 01:23** which is calculated from Heading and TAS derived from the AHRS and ADC.
  - NO POSITION**, no position available from the GPS, and the EFIS cannot DR due to a second failure.
- VERT LON** (Loss of Vertical Navigation)

In the event the navigation equipment is no longer adequate to conduct or continue the LNAV/VNAV approach, **VERT LON** appears within one second of the onset of any of the following conditions:

- a) The absence of power;
- b) Equipment malfunction or failure;
- c) The presence of a condition where fault detection detects a position failure that cannot be excluded;
- d) There is insufficient number of SBAS HEALTY satellites;
- e) The horizontal protection level exceeds the alert limit as follows for LNAV/VNAV approaches:
  - i) Prior to sequencing the FAWP- HAL should be 0.3 NM with no limit on VAL.
  - ii) After sequencing the FAWP- HAL 556m (0.3NM) and VAL 50m.

When in LNAV mode, the fault detection function detects positioning failures within 10 seconds after the onset of the positioning failure.

GPS failure results in the EFIS operating in “dead reckoning” mode. The EFIS continues to provide navigational position, groundspeed, and ground track information, based upon the last known wind, current air data, and heading. The IDU-680 PFD and MFD are affected as follows.


### 4.3. PFD Failure Mode 0 (Normal Mode)



**Table 4-4: PFD Failure Mode 0 (Normal Mode) GPS, ADC, and AHRS Normal**

<b>PFD Functions</b>	<b>Mode 0</b>	<b>ND Functions</b>	<b>Mode 0</b>
Airspeed	<b>OK</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>OK</b>	Special Use Airspace	<b>9</b>
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	<b>9</b>
Bank Scale	<b>OK</b>	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	<b>9</b>
Runway	<b>OK</b>	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>OK</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	<b>OK</b>	Outside Air Temp	<b>OK</b>
G-Meter	<b>OK</b>	Projected Path	<b>OK</b>
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	<b>OK</b>
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	<b>OK</b>	Wind	<b>21</b>
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	<b>OK</b>	Fuel Totalizer	<b>23</b>
Terrain/Obstruction	<b>OK</b>	True Airspeed	<b>OK</b>
Clock Functions	<b>OK</b>	Density Altitude	<b>OK</b>
VSI	<b>OK</b>	OAT/ISA Display	<b>OK</b>
Waterline Symbol	<b>22</b>		
Waypoint Symbol	<b>OK</b>		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	<b>OK</b>		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	<b>OK</b>		
Dynamic Stall Speed	<b>OK</b>		

### 4.3.1. MFD Failure Mode 0 (Normal Mode)



**Figure 4-2: MFD Failure Mode 0 (Normal Mode) GPS, ADC, and AHRS Normal**

**Table 4-5: MFD Failure Mode 0 (Normal Mode) GPS, ADC, and AHRS Normal**

<b>PFD Functions</b>	<b>Mode 0</b>	<b>ND Functions</b>	<b>Mode 0</b>
Airspeed	<b>OK</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>OK</b>	Special Use Airspace	<b>9</b>
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	<b>9</b>
Bank Scale	<b>OK</b>	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	<b>9</b>
Runway	<b>OK</b>	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>OK</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	<b>OK</b>	Outside Air Temp	<b>OK</b>
G-Meter	<b>OK</b>	Projected Path	<b>OK</b>
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	<b>OK</b>
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	<b>OK</b>	Wind	<b>21</b>
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	<b>OK</b>	Fuel Totalizer	<b>23</b>
Terrain/Obstruction	<b>OK</b>	True Airspeed	<b>OK</b>
Clock Functions	<b>OK</b>	Density Altitude	<b>OK</b>
VSI	<b>OK</b>	OAT/ISA Display	<b>OK</b>
Waterline Symbol	<b>22</b>		
Waypoint Symbol	<b>OK</b>		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	<b>OK</b>		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	<b>OK</b>		
Dynamic Stall Speed	<b>OK</b>		



### 4.4. PFD Failure Mode 1 (Normal Mode)





Figure 4-3: PFD Failure Mode 1 (Normal Mode) GPS/SBAS Failed; ADC and AHRS Normal

**Table 4-6: Funtion Table PFD Failure Mode 1 (Normal Mode)  
GPS/SBAS Failed; ADC and AHRS Normal**

<b>PFD Functions</b>	<b>Mode 1</b>	<b>ND Functions</b>	<b>Mode 1</b>
Airspeed	<b>OK</b>	Aircraft Position	<b>1</b>
Altimeter	<b>OK</b>	Special Use Airspace	<b>1</b>
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	<b>1</b>
Bank Scale	<b>OK</b>	Active Flight Plan Path	<b>1</b>
CDI	<b>1 + 20</b>	Glide Range	<b>1</b>
Runway	<b>1</b>	Groundspeed	<b>1</b>
Waypoint Pointer	<b>1</b>	Ground Track	<b>1</b>
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>2</b>	Navigation Symbols	<b>1</b>
Flight Path Marker	<b>1 + 14</b>	Outside Air Temp	<b>OK</b>
G-Meter	<b>OK</b>	Projected Path	<b>1</b>
Ground Track	<b>1</b>	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	<b>-</b>
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	<b>1</b>	Waypoint Brg./Dist.	<b>1</b>
Pitch Limit Indicator	<b>OK</b>	Wind	<b>3</b>
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	<b>1 + 15</b>	Fuel Totalizer	<b>24</b>
Terrain/Obstruction	<b>-</b>	True Airspeed	<b>OK</b>
Clock Functions	<b>OK</b>	Density Altitude	<b>OK</b>
VSI	<b>OK</b>	OAT/ISA Display	<b>OK</b>
Waterline Symbol	<b>22</b>		
Waypoint Symbol	<b>1</b>		
Waypoint Brg./Dist.	<b>1</b>		
Traffic	<b>OK</b>		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	<b>OK</b>		
Dynamic Stall Speed	<b>OK</b>		

### 4.4.1. PFD Failure Mode 1 (Essential Mode)



**Figure 4-4: PFD Failure Mode 1 (Essential Mode) GPS/SBAS Failed; ADC and AHRS Normal**

**Table 4-7: MFD Failure Mode 1 (Essential Mode) GPS/SBAS Failed; ADC and AHRS Normal**

<b>PFD Functions</b>	<b>Mode 1</b>	<b>ND Functions</b>	<b>Mode 1</b>
Airspeed	<b>OK</b>	Aircraft Position	<b>1</b>
Altimeter	<b>OK</b>	Special Use Airspace	<b>1</b>
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	<b>1</b>
Bank Scale	<b>OK</b>	Active Flight Plan Path	<b>1</b>
CDI	<b>1 + 20</b>	Glide Range	<b>1</b>
Runway	<b>1</b>	Groundspeed	<b>1</b>
Waypoint Pointer	<b>1</b>	Ground Track	<b>1</b>
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>2</b>	Navigation Symbols	<b>1</b>
Flight Path Marker	<b>1 + 14</b>	Outside Air Temp	<b>OK</b>
G-Meter	<b>OK</b>	Projected Path	<b>1</b>
Ground Track	<b>1</b>	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	<b>-</b>
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	<b>1</b>	Waypoint Brg./Dist.	<b>1</b>
Pitch Limit Indicator	<b>OK</b>	Wind	<b>3</b>
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	<b>1 + 15</b>	Fuel Totalizer	<b>24</b>
Terrain/Obstruction	<b>-</b>	True Airspeed	<b>OK</b>
Clock Functions	<b>OK</b>	Density Altitude	<b>OK</b>
VSI	<b>OK</b>	OAT/ISA Display	<b>OK</b>
Waterline Symbol	<b>22</b>		
Waypoint Symbol	<b>1</b>		
Waypoint Brg./Dist.	<b>1</b>		
Traffic	<b>OK</b>		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	<b>OK</b>		
Dynamic Stall Speed	<b>OK</b>		

4.4.2. MFD Failure Mode 1 (Normal Mode)





Figure 4-5: MFD Failure Mode 1 (Normal Mode) GPS/SBAS Failed; ADC and AHRS Normal

**Table 4-8: MFD Failure Mode 1 (Normal Mode) GPS/SBAS Failed; ADC and AHRS Normal**

<b>PFD Functions</b>	<b>Mode 1</b>	<b>ND Functions</b>	<b>Mode 1</b>
Airspeed	<b>OK</b>	Aircraft Position	<b>1</b>
Altimeter	<b>OK</b>	Special Use Airspace	<b>1</b>
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	<b>1</b>
Bank Scale	<b>OK</b>	Active Flight Plan Path	<b>1</b>
CDI	<b>1 + 20</b>	Glide Range	<b>1</b>
Runway	<b>1</b>	Groundspeed	<b>1</b>
Waypoint Pointer	<b>1</b>	Ground Track	<b>1</b>
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>2</b>	Navigation Symbols	<b>1</b>
Flight Path Marker	<b>1 + 14</b>	Outside Air Temp	<b>OK</b>
G-Meter	<b>OK</b>	Projected Path	<b>1</b>
Ground Track	<b>1</b>	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	<b>-</b>
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	<b>1</b>	Waypoint Brg./Dist.	<b>1</b>
Pitch Limit Indicator	<b>OK</b>	Wind	<b>3</b>
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	<b>1 + 15</b>	Fuel Totalizer	<b>24</b>
Terrain/Obstruction	<b>-</b>	True Airspeed	<b>OK</b>
Clock Functions	<b>OK</b>	Density Altitude	<b>OK</b>
VSI	<b>OK</b>	OAT/ISA Display	<b>OK</b>
Waterline Symbol	<b>22</b>		
Waypoint Symbol	<b>1</b>		
Waypoint Brg./Dist.	<b>1</b>		
Traffic	<b>OK</b>		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	<b>OK</b>		
Dynamic Stall Speed	<b>OK</b>		

### 4.5. PFD Failure Mode 2 (Normal Mode)



**Figure 4-6: PFD Mode 2 (Normal Mode) ADC Failed; GPS/SBAS and AHRS Normal**

**Table 4-9: PFD Mode 2 (Normal Mode) ADC Failed;  
GPS/SBAS and AHRS Normal**

<b>PFD Functions</b>	<b>Mode 2</b>	<b>ND Functions</b>	<b>Mode 2</b>
Airspeed	<b>19</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>19</b>	Special Use Airspace	<b>6</b>
Altimeter Set Display	-	Waypoint Pointer	<b>9</b>
Bank Scale	<b>OK</b>	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	-
Runway	-	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>4</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	-	Outside Air Temp	-
G-Meter	<b>OK</b>	Projected Path	<b>OK</b>
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/ Obstructions	-
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	-	Wind	-
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>23</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>5</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	<b>OK</b>		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		






**Table 4-10: MFD Failure Mode 2, (Normal Mode) ADC Failed; GPS/SBAS and AHRS Normal**

<b>PFD Functions</b>	<b>Mode 2</b>	<b>ND Functions</b>	<b>Mode 2</b>
Airspeed	<b>19</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>19</b>	Special Use Airspace	<b>6</b>
Altimeter Set Display	-	Waypoint Pointer	<b>9</b>
Bank Scale	<b>OK</b>	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	-
Runway	-	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>4</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	-	Outside Air Temp	-
G-Meter	<b>OK</b>	Projected Path	<b>OK</b>
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	-
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	-	Wind	-
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>23</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>5</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	<b>OK</b>		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.5.2. MFD Failure Mode 2 (Essential Mode)



**Figure 4-8: MFD Failure Mode 2 (Essential Mode) ADC Failed; GPS/SBAS and AHRS Normal**

**Table 4-11: MFD Failure Mode 2 (Essential Mode) ADC Failed; GPS/SBAS and AHRS Normal**

<b>PFD Functions</b>	<b>Mode 2</b>	<b>ND Functions</b>	<b>Mode 2</b>
Airspeed	<b>19</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>19</b>	Special Use Airspace	<b>6</b>
Altimeter Set Display	-	Waypoint Pointer	<b>9</b>
Bank Scale	<b>OK</b>	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	-
Runway	-	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>4</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	-	Outside Air Temp	-
G-Meter	<b>OK</b>	Projected Path	<b>OK</b>
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	-
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	-	Wind	-
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>23</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>5</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	<b>OK</b>		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.6. PFD Failure Mode 3 (Normal Mode)



**Figure 4-9: PFD Failure Mode 3 (Normal Mode) AHRS Failed; GPS/SBAS and ADC Normal**

**Table 4-12: PFD Failure Mode 3 (Normal Mode) AHRS Failed; GPS/SBAS and ADC Normal**

<b>PFD Functions</b>	<b>Mode 3</b>	<b>ND Functions</b>	<b>Mode 3</b>
Airspeed	<b>OK</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>OK</b>	Special Use Airspace	<b>9</b>
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	<b>9</b>
Bank Scale	-	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	<b>10</b>
Runway	-	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	-
AGL Ind.	<b>OK</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	-	Outside Air Temp	<b>OK</b>
G-Meter	-	Projected Path	-
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	<b>OK</b>
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	<b>8</b>	Wind	-
Pitch Scale	-	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>23</b>
Terrain/Obstruction	-	True Airspeed	<b>OK</b>
Clock Functions	<b>OK</b>	Density Altitude	<b>OK</b>
VSI	<b>OK</b>	OAT/ISA Display	<b>OK</b>
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	<b>8</b>		




**Table 4-13: MFD Failure Mode 3 (Normal Mode) AHRS Failed; GPS/SBAS and ADC Normal**

<b>PFD Functions</b>	<b>Mode 3</b>	<b>ND Functions</b>	<b>Mode 3</b>
Airspeed	<b>OK</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>OK</b>	Special Use Airspace	<b>9</b>
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	<b>9</b>
Bank Scale	-	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	<b>10</b>
Runway	-	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	-
AGL Ind.	<b>OK</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	-	Outside Air Temp	<b>OK</b>
G-Meter	-	Projected Path	-
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	<b>OK</b>
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	<b>8</b>	Wind	-
Pitch Scale	-	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>23</b>
Terrain/Obstruction	-	True Airspeed	<b>OK</b>
Clock Functions	<b>OK</b>	Density Altitude	<b>OK</b>
VSI	<b>OK</b>	OAT/ISA Display	<b>OK</b>
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	<b>8</b>		



### 4.7. PFD Failure Mode 4 (Normal Mode)




**Figure 4-11: PFD Failure Mode 4 (Normal Mode) GPS/SBAS and ADC Failed; AHRs Normal**

**Table 4-14: PFD Failure Mode 4 (Normal Mode) GPS/SBAS and ADC Failed; AHRS Normal**

<b>PFD Functions</b>	<b>Mode 4</b>	<b>ND Functions</b>	<b>Mode 4</b>
Airspeed	<b>19</b>	Aircraft Position	-
Altimeter	<b>19</b>	Special Use Airspace	-
Altimeter Set Display	-	Waypoint Pointer	-
Bank Scale	<b>OK</b>	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>11</b>	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	-
Hover Vector	-	Projected Path	-
G-Meter	<b>OK</b>	Traffic	<b>OK</b>
Ground Track	-	Terrain/Obstructions	-
Heading Indicator	<b>7</b>	Clock Functions	<b>OK</b>
Horizon	<b>OK</b>	Waypoint Brg./Dist.	-
Mini-Map	-	Wind	-
Pitch Limit Indicator	-	WX-500 Data	<b>OK</b>
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>5</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.7.1. MFD Failure Mode 4 (Normal Mode)




**Figure 4-12: MFD Failure Mode 4 (Normal Mode) GPS/SBAS and ADC Failed; AHRS Normal**

**Table 4-15: MFD Failure Mode 4 (Normal Mode) GPS/SBAS and ADC Failed; AHRS Normal**

<b>PFD Functions</b>	<b>Mode 4</b>	<b>ND Functions</b>	<b>Mode 4</b>
Airspeed	<b>19</b>	Aircraft Position	-
Altimeter	<b>19</b>	Special Use Airspace	-
Altimeter Set Display	-	Waypoint Pointer	-
Bank Scale	<b>OK</b>	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>11</b>	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	-
G-Meter	<b>OK</b>	Projected Path	-
Ground Track	-	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	-
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	-	Waypoint Brg./Dist.	-
Pitch Limit Indicator	-	Wind	-
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>5</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.7.2. MFD Failure Mode 4 (Essential Mode)



**Figure 4-13: MFD Failure Mode 4 (Essential Mode) GPS/SBAS and ADC Failed; AHRs Normal**

**Table 4-16: MFD Failure Mode 4 (Essential Mode)  
GPS/SBAS and ADC Failed; AHRS Normal**

<b>PFD Functions</b>	<b>Mode 4</b>	<b>ND Functions</b>	<b>Mode 4</b>
Airspeed	<b>19</b>	Aircraft Position	-
Altimeter	<b>19</b>	Special Use Airspace	-
Altimeter Set Display	-	Waypoint Pointer	-
Bank Scale	<b>OK</b>	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	<b>7</b>	Heading Indicator	<b>9</b>
AGL Ind.	<b>11</b>	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	-
G-Meter	<b>OK</b>	Projected Path	-
Ground Track	-	Traffic	<b>OK</b>
Heading Indicator	<b>7</b>	Terrain/Obstructions	-
Horizon	<b>OK</b>	Clock Functions	<b>OK</b>
Mini-Map	-	Waypoint Brg./Dist.	-
Pitch Limit Indicator	-	Wind	-
Pitch Scale	<b>OK</b>	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>5</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.8. PFD Failure Mode 5 (Normal Mode)





Figure 4-14: PFD Failure Mode 5 (Normal Mode) GPS/SBAS and AHRS Failed; ADC Normal

**Table 4-17: PFD Failure Mode 5 (Normal Mode) GPS/SBAS and AHRS Failed; ADC Normal**

<b>PFD Functions</b>	<b>Mode 5</b>	<b>ND Functions</b>	<b>Mode 5</b>
Airspeed	<b>OK</b>	Aircraft Position	-
Altimeter	<b>OK</b>	Special Use Airspace	-
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	-
Bank Scale	-	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	-	Heading Indicator	-
AGL Ind.	<b>11</b>	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	<b>OK</b>
G-Meter	-	Projected Path	-
Ground Track	-	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	-	Waypoint Brg./Dist.	-
Pitch Limit Indicator	<b>8</b>	Wind	-
Pitch Scale	-	Compass Rose	-
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	<b>OK</b>	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	<b>8</b>		



### 4.8.1. MFD Failure Mode 5 (Normal Mode)




**Figure 4-15: MFD Failure Mode 4 (Normal Mode) GPS/SBAS and AHRS Failed; ADC Normal**

**Table 4-18: MFD Failure Mode 4 (Normal Mode) GPS/SBAS and AHRS Failed; ADC Normal**

<b>PFD Functions</b>	<b>Mode 5</b>	<b>ND Functions</b>	<b>Mode 5</b>
Airspeed	<b>OK</b>	Aircraft Position	-
Altimeter	<b>OK</b>	Special Use Airspace	-
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	-
Bank Scale	-	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	-	Heading Indicator	-
AGL Ind.	<b>11</b>	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	<b>OK</b>
G-Meter	-	Projected Path	-
Ground Track	-	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	-	Waypoint Brg./Dist.	-
Pitch Limit Indicator	<b>8</b>	Wind	-
Pitch Scale	-	Compass Rose	-
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	<b>OK</b>	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		-
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	<b>8</b>		

### 4.8.2. MFD Failure Mode 5 (Essential Mode)




**Figure 4-16: MFD Failure Mode 5 (Essential Mode) GPS/SBAS and AHRS Failed; ADC Normal**

**Table 4-19: MFD Failure Mode 5 (Essential Mode)  
GPS/SBAS and AHRS Failed; ADC Normal**

<b>PFD Functions</b>	<b>Mode 5</b>	<b>ND Functions</b>	<b>Mode 5</b>
Airspeed	<b>OK</b>	Aircraft Position	-
Altimeter	<b>OK</b>	Special Use Airspace	-
Altimeter Set Display	<b>OK</b>	Waypoint Pointer	-
Bank Scale	-	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	-	Heading Indicator	-
AGL Ind.	<b>11</b>	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	<b>OK</b>
G-Meter	-	Projected Path	-
Ground Track	-	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	-	Waypoint Brg./Dist.	-
Pitch Limit Indicator	<b>8</b>	Wind	-
Pitch Scale	-	Compass Rose	-
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	<b>OK</b>	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	<b>8</b>		

### 4.9. PFD Failure Mode 6 (Normal Mode)




**Figure 4-17: PFD Failure Mode 6 (Normal Mode) ADC and AHRS Failed; GPS/SBAS Normal**

**Table 4-20: PFD Failure Mode 6 (Normal Mode) ADC and AHRS Failed; GPS/SBAS Normal**

<b>PFD Functions</b>	<b>Mode 6</b>	<b>ND Functions</b>	<b>Mode 6</b>
Airspeed	<b>19</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>19</b>	Special Use Airspace	<b>6 + 9</b>
Altimeter Set Display	-	Waypoint Pointer	<b>9</b>
Bank Scale	-	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	-
Runway	-	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	-
AGL Ind.	<b>4</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	-	Outside Air Temp	-
G-Meter	-	Projected Path	-
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	-	Wind	-
Pitch Scale	-	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.9.1. MFD Failure Mode 6 (Normal Mode)




**Figure 4-18: MFD Failure Mode 6 (Normal Mode) ADC and AHRS Failed; GPS/SBAS Normal**

**Table 4-21: MFD Failure Mode 6 (Normal Mode) ADC and AHRS Failed; GPS/SBAS Normal**

<b>PFD Functions</b>	<b>Mode 6</b>	<b>ND Functions</b>	<b>Mode 6</b>
Airspeed	<b>19</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>19</b>	Special Use Airspace	<b>6 + 9</b>
Altimeter Set Display	-	Waypoint Pointer	<b>9</b>
Bank Scale	-	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	-
Runway	-	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	-
AGL Ind.	<b>4</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	-	Outside Air Temp	-
G-Meter	-	Projected Path	-
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	-	Wind	-
Pitch Scale	-	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		



### 4.9.2. MFD Failure Mode 6 (Essential Mode)




**Figure 4-19: MFD Failure Mode 6 (Essential Mode) ADC and AHRS Failed; GPS/SBAS Normal**

**Table 4-22: MFD Failure Mode 6 (Essential Mode) ADC and AHRS Failed; GPS/SBAS Normal**

<b>PFD Functions</b>	<b>Mode 6</b>	<b>ND Functions</b>	<b>Mode 6</b>
Airspeed	<b>19</b>	Aircraft Position	<b>OK</b>
Altimeter	<b>19</b>	Special Use Airspace	<b>6 + 9</b>
Altimeter Set Display	-	Waypoint Pointer	<b>9</b>
Bank Scale	-	Active Flight Plan Path	<b>9</b>
CDI	<b>OK</b>	Glide Range	-
Runway	-	Groundspeed	<b>OK</b>
Waypoint Pointer	<b>7</b>	Ground Track	<b>9</b>
Heading Scale	<b>7</b>	Heading Indicator	-
AGL Ind.	<b>4</b>	Navigation Symbols	<b>9</b>
Flight Path Marker	-	Outside Air Temp	-
G-Meter	-	Projected Path	-
Ground Track	<b>7</b>	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	<b>7</b>	Waypoint Brg./Dist.	<b>OK</b>
Pitch Limit Indicator	-	Wind	-
Pitch Scale	-	Compass Rose	<b>9</b>
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	<b>OK</b>		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.10. PFD Failure Mode 7 (Normal Mode)




**Figure 4-20: PFD Failure Mode 7 (Normal Mode) GPS/SBAS, ADC, and AHRs Failed**

**Table 4-23: PFD Failure Mode 7 (Normal Mode) GPS/SBAS, ADC, and AHRS Failed**

<b>PFD Functions</b>	<b>Mode 7</b>	<b>ND Functions</b>	<b>Mode 7</b>
Airspeed	<b>19</b>	Aircraft Position	-
Altimeter	<b>19</b>	Special Use Airspace	-
Altimeter Set Display	-	Waypoint Pointer	-
Bank Scale	-	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	-	Heading Indicator	-
AGL Ind.	-	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	-
G-Meter	-	Projected Path	-
Ground Track	-	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	-	Waypoint Brg./Dist.	-
Pitch Limit Indicator	-	Wind	-
Pitch Scale	-	Compass Rose	-
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.10.1. MFD Failure Mode 7 (Normal Mode)




**Figure 4-21: MFD Failure Mode 7 (Normal Mode) GPS/SBAS, ADC, and AHRS Failed**

**Table 4-24: MFD Failure Mode 7 (Normal Mode) GPS/SBAS, ADC, and AHRS Failed**

<b>PFD Functions</b>	<b>Mode 7</b>	<b>ND Functions</b>	<b>Mode 7</b>
Airspeed	<b>19</b>	Aircraft Position	-
Altimeter	<b>19</b>	Special Use Airspace	-
Altimeter Set Display	-	Waypoint Pointer	-
Bank Scale	-	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	-	Heading Indicator	-
AGL Ind.	-	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	-
G-Meter	-	Projected Path	-
Ground Track	-	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	-	Waypoint Brg./Dist.	-
Pitch Limit Indicator	-	Wind	-
Pitch Scale	-	Compass Rose	-
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		

### 4.10.2. MFD Failure Mode 7 (Essential Mode)



**Figure 4-22: MFD Failure Mode 7 (Essential Mode) GPS/SBAS, ADC, and AHRS Failed**


**Table 4-25: MFD Failure Mode 7 (Essential Mode)  
GPS/SBAS, ADC, and AHRS Failed**

<b>PFD Functions</b>	<b>Mode 7</b>	<b>ND Functions</b>	<b>Mode 7</b>
Airspeed	<b>19</b>	Aircraft Position	-
Altimeter	<b>19</b>	Special Use Airspace	-
Altimeter Set Display	-	Waypoint Pointer	-
Bank Scale	-	Active Flight Plan Path	-
CDI	<b>20</b>	Glide Range	-
Runway	-	Groundspeed	-
Waypoint Pointer	-	Ground Track	-
Heading Scale	-	Heading Indicator	-
AGL Ind.	-	Navigation Symbols	-
Flight Path Marker	-	Outside Air Temp	-
G-Meter	-	Projected Path	-
Ground Track	-	Traffic	<b>OK</b>
Heading Indicator	-	Terrain/Obstructions	-
Horizon	-	Clock Functions	<b>OK</b>
Mini-Map	-	Waypoint Brg./Dist.	-
Pitch Limit Indicator	-	Wind	-
Pitch Scale	-	Compass Rose	-
Highway in the Sky	-	Fuel Totalizer	<b>12</b>
Terrain/Obstruction	-	True Airspeed	-
Clock Functions	<b>OK</b>	Density Altitude	-
VSI	-	OAT/ISA Display	-
Waterline Symbol	<b>13</b>		
Waypoint Symbol	-		
Waypoint Brg./Dist.	-		
Traffic	-		
Traffic Thumbnail	<b>OK</b>		
Speed Trend	-		
Dynamic Stall Speed	-		



## **Section 5 Menu Functions and Step-By-Step Procedures**

## Table of Contents

SECTION 5 MENU FUNCTIONS AND STEP-BY-STEP PROCEDURES .....	5-1
5.1. MENU FUNCTIONS.....	5-10
5.2. MENU SYNCHRONIZATION.....	5-10
5.3. MENU FUNCTION TYPES .....	5-13
5.4. TOP-LEVEL MENU .....	5-14
5.4.1. <i>IDU-680 PFD Normal Mode Top-Level Menu..</i>	<i>5-14</i>
5.5. IDU-680 MFD NORMAL MODE TOP-LEVEL MENU .....	5-15
5.6. IDU-680 PFD OR MFD ESSENTIAL MODE TOP-LEVEL MENU .....	5-16
5.6.1. <i>Top-Level Menu Option Descriptions.....</i>	<i>5-16</i>
5.6.2. <i>#1 Encoder (  ).....</i>	<i>5-18</i>
5.6.3. <i>Top-Level Menu Automatic Pop-up Function Descriptions.....</i>	<i>5-19</i>
5.7. FIRST PAGE (PFD) .....	5-27
5.7.1. <i>PFD Page First-Level Option Descriptions .....</i>	<i>5-28</i>
5.7.2. <i>First Level (MFD) .....</i>	<i>5-29</i>
5.7.3. <i>First Level (PFD IDU#1) Normal Mode .....</i>	<i>5-30</i>
5.7.4. <i>First Level (MFD IDU other than #1) Normal Mode .....</i>	<i>5-31</i>
5.7.5. <i>MFD Page First-Level Option Descriptions.....</i>	<i>5-32</i>
5.7.6. <i>IDU-680 EICAS Page First-Level in Essential Mode .....</i>	<i>5-33</i>
5.7.7. <i>PFD Page in Top Area and Essential Mode EICAS Page in Bottom Area .....</i>	<i>5-34</i>
5.7.8. <i>First-Level Menu of an MFD (IDU Other Than #1) in Normal Mode .....</i>	<i>5-35</i>
5.7.9. <i>EICAS Page First-Level Option Descriptions... </i>	<i>5-35</i>

5.8.	EICAS EXCEEDANCE MENU .....	5-36
5.9.	EXPAND CAS MENU .....	5-36
5.9.1.	<i>Expand CAS Menu (Step-By-Step) .....</i>	<i>5-37</i>
5.10.	LOWER-LEVEL MENUS (BELOW FIRST-LEVEL) .....	5-38
5.11.	FLIGHT PLAN (FPL) MENU .....	5-39
5.11.1.	<i>Flight Planner Page .....</i>	<i>5-39</i>
5.11.2.	<i>PFD Page Shown on IDU .....</i>	<i>5-40</i>
5.11.3.	<i>No PFD Page Shown on IDU .....</i>	<i>5-40</i>
5.11.4.	<i>To Create an Overfly User Waypoint .....</i>	<i>5-41</i>
5.11.5.	<i>Flight Plan (FPL) Menu Selecting (Step-By-Step)...</i> <i>.....</i>	<i>5-41</i>
5.11.6.	<i>Flight Plan (FPL) Menu Create-Edit (Step-By-Step)</i> <i>.....</i>	<i>5-42</i>
5.11.7.	<i>Activate Flight Plan (Step-By-Step) .....</i>	<i>5-45</i>
5.11.8.	<i>Edit Flight Plan (Step-By-Step) .....</i>	<i>5-46</i>
5.11.9.	<i>Reverse Flight Plan (Step-By-Step) .....</i>	<i>5-47</i>
5.11.10.	<i>Delete Flight Plan (Step-By-Step) .....</i>	<i>5-48</i>
5.11.11.	<i>Create User Waypoint (LAT-LON) (Step-By-Step) .</i> <i>.....</i>	<i>5-49</i>
5.11.12.	<i>Create User Waypoint (RAD-DST) (Step-By-Step).</i> <i>.....</i>	<i>5-52</i>
5.11.13.	<i>Delete User Waypoint (Step-By-Step) .....</i>	<i>5-54</i>
5.11.14.	<i>RAIM Prediction .....</i>	<i>5-56</i>
5.12.	ACTIVE FLIGHT PLAN (ACTV) MENU .....	5-58
5.12.1.	<i>Main Menu .....</i>	<i>5-58</i>
5.12.2.	<i>Active Flight Plan (ACTV) Menu Options .....</i>	<i>5-63</i>
5.13.	ACTIVE FLIGHT PLAN (ACTV) MENU OPTIONS .....	5-68

5.13.1.	<i>Active Flight Plan (ACTV) Menu (Step-By-Step) ....</i>	5-69
5.13.2.	<i>Active Flight Plan (ACTV) Options NRST Menu Option (Step-By-Step) .....</i>	5-70
5.14.	INFORMATION (INFO) MENU.....	5-71
5.14.1.	<i>Information (INFO) Menu (Step-By-Step) .....</i>	5-74
5.15.	OMNIBEARING SELECTOR (OBS) MENU .....	5-75
5.15.1.	<i>Omnibearing Selector (OBS) Menu (Step-By-Step) .....</i>	5-76
5.16.	HEADING BUG (HDG) MENU.....	5-77
5.16.1.	<i>Heading Bug (HDG) Menu (Step-By-Step) .....</i>	5-77
5.17.	NEAREST (NRST) MENU.....	5-78
5.17.1.	<i>Nearest (NRST) Menu (Step-By-Step) .....</i>	5-81
5.17.2.	<i>Nearest (NRST) Menu ILS.....</i>	5-82
5.18.	DIRECT MENU.....	5-82
5.18.1.	<i>Direct Menu (Step-By-Step).....</i>	5-84
5.19.	TIMER (TIMER) MENU .....	5-85
5.19.1.	<i>Timer (TIMER) Menu (Step-By-Step) .....</i>	5-86
5.20.	PFD SOURCE (SOURCE) MENU .....	5-87
5.21.	PFD BUG (BUGS) MENU.....	5-88
5.21.1.	<i>PFD Bug (BUGS) Menu (Step-By-Step) .....</i>	5-91
5.22.	REMOTE BUGS PANEL.....	5-93
5.23.	PFD DECLUTTER (DCLTR) MENU.....	5-97
5.23.1.	<i>PFD Declutter (DCLTR) Menu (Step-By-Step) .....</i>	5-100
5.24.	PFD ALTIMETER MENU .....	5-101
5.24.1.	<i>PFD Altimeter Menu (Step-By-Step) .....</i>	5-102
5.25.	MFD FAULT DISPLAY (FAULTS) MENU .....	5-103

5.25.1.	<i>MFD Fault Display (FAULTS) Menu (Step-By-Step)</i>	5-106
5.26.	MFD FUEL TOTALIZER QUANTITY SETTING (SET FUEL) MENU	5-107
5.27.	MFD PAGE (PAGE) MENU	5-108
5.27.1.	<i>MFD Page (PAGE) Menu (Step-By-Step)</i>	5-109
5.27.2.	<i>MFD MAP ND Page</i>	5-110
5.27.3.	<i>MFD HSI Page</i>	5-110
5.27.4.	<i>MFD NAV Log Page</i>	5-111
5.27.5.	<i>MFD ND Page Format (FORMAT) Menu</i>	5-112
5.27.6.	<i>MFD HSI Pointer (PTRS) Menu</i>	5-115
5.27.7.	<i>MFD Traffic Format (FORMAT) Menu</i>	5-116
5.27.8.	<i>MFD Datalink Format (FORMAT) Menu</i>	5-117
5.27.9.	<i>MFD Video Input Format (FORMAT) Menu</i>	5-119
5.27.10.	<i>MFD Video Input Format (FORMAT) Menu Center Rotary Encoder Controls</i>	5-121
5.27.11.	<i>MFD ND Page Format Menu</i>	5-122
5.27.12.	<i>MFD ND Page Format (FORMAT) Menu (Step-By-Step)</i>	5-125
5.28.	MFD HSI POINTER (PTRS) MENU	5-125
5.28.1.	<i>MFD HSI Pointer (PTRS) Menu (Step-By-Step)</i>	5-126
5.28.2.	<i>MFD Strike Format (FORMAT) Menu</i>	5-126
5.29.	AUDIO/RADIO (AR) PAGE MENU	5-127
5.29.1.	<i>AR Tune</i>	5-127
5.29.2.	<i>AR Expand Page</i>	5-130
5.29.3.	<i>AR Expand Page First-Level Options</i>	5-130
5.29.4.	<i>AR Expand Page Second-Level Options</i>	5-131

5.30.	AUDIO/RADIO CONTROLS .....	5-134
5.30.1.	<i>Audio/Radio Controls (Step-By-Step)</i> .....	5-134

## List of Figures and Tables

FIGURE 5-1: IDU-680 INPUT CONTROLS .....	5-10
TABLE 5-1: MENU SYNCHRONIZATION .....	5-11
FIGURE 5-2: PFD NORMAL MODE TOP-LEVEL MENU.....	5-14
FIGURE 5-3: MFD NORMAL MODE TOP-LEVEL MENU .....	5-15
FIGURE 5-4: PFD OR MFD ESSENTIAL MODE TOP-LEVEL MENU ....	5-16
TABLE 5-2: TOP-LEVEL AUTO POPUP FUNCTION DESCRIPTIONS .....	5-19
FIGURE 5-5: FIRST PAGE PFD .....	5-27
FIGURE 5-6: FIRST LEVEL MFD .....	5-29
FIGURE 5-7: FIRST LEVEL PFD .....	5-30
FIGURE 5-8: FIRST LEVEL (MFD IDU OTHER THAN #1) NORMAL MODE .....	5-31
FIGURE 5-9: EICAS PAGE FIRST-LEVEL IN ESSENTIAL MODE .....	5-33
FIGURE 5-10: PFD PAGE IN TOP AREA AND ESSENTIAL MODE EICAS PAGE IN BOTTOM AREA.....	5-34
FIGURE 5-11: FIRST-LEVEL MENU OF AN MFD (IDU OTHER THAN #1 IN NORMAL MODE .....	5-35
FIGURE 5-12: EICAS EXCEEDANCE MENU .....	5-36
FIGURE 5-13: EXPAND CAS MENU .....	5-36
FIGURE 5-14: CAS LIST SCROLLING.....	5-37
FIGURE 5-15: IDU 680 INPUT CONTROLS .....	5-38
FIGURE 5-16: FLIGHT PLAN MENU .....	5-39
FIGURE 5-17: CREATION OF OVERFLY USER WAYPOINT .....	5-41
FIGURE 5-18: FLIGHT PLAN MENU SELECTION .....	5-41
FIGURE 5-19: FLIGHT PLAN MENU CREATION (STEP-BY-STEP).....	5-42
FIGURE 5-20: FLIGHT PLAN MENU CREATION (STEP-BY-STEP) (CONTINUED).....	5-43
FIGURE 5-21: FLIGHT PLAN MENU CREATION (STEP-BY-STEP) (CONTINUED).....	5-44
FIGURE 5-22: ACTIVATE FLIGHT PLAN .....	5-45
FIGURE 5-23: EDIT FLIGHT PLAN .....	5-46
FIGURE 5-24: REVERSE FLIGHT PLAN.....	5-47
FIGURE 5-25: DELETE FLIGHT PLAN .....	5-48
FIGURE 5-26: CREATE USER WAYPOINT (LAT-LON) .....	5-50
FIGURE 5-27: CREATE USER WAYPOINT (OVERFLY DESIG).....	5-51
FIGURE 5-28: CREATE USER WAYPOINT (RAD-DST).....	5-52
EDIT USER WAYPOINT (STEP-BY-STEP) .....	5-52
FIGURE 5-29: EDIT USER WAYPOINT .....	5-53
FIGURE 5-30: DELETE USER WAYPOINT .....	5-54
FIGURE 5-31: RAIM PREDICTION .....	5-56
FIGURE 5-32: ACTIVE FLIGHT PLAN MAIN MENU.....	5-58
FIGURE 5-33: ACTIVE FLIGHT PLAN MENU OPTIONS.....	5-63

FIGURE 5-34: ACTIVE FLIGHT PLAN MENU OPTIONS (STEP-BY-STEP) ...	5-68
FIGURE 5-35: ACTIVE FLIGHT PLAN MENU (STEP-BY-STEP).....	5-69
FIGURE 5-36: ACTIVE FLIGHT PLAN OPTIONS NRST MENU OPTION (STEP-BY-STEP) .....	5-70
FIGURE 5-37: INFORMATION MENU.....	5-71
FIGURE 5-38: CRS SYNC.....	5-73
FIGURE 5-39: INFORMATION (STEP-BY-STEP).....	5-74
FIGURE 5-40: OMNIBEARING SELECTOR (OBS) MENU .....	5-75
FIGURE 5-41: OMNIBEARING SELECTOR (OBS) (STEP-BY-STEP) ...	5-76
FIGURE 5-42: HEADING BUG (HDG) MENU.....	5-77
FIGURE 5-43: HEADING BUG (HDG) MENU (STEP-BY-STEP).....	5-77
FIGURE 5-44: NEAREST (NRST) MENU .....	5-78
FIGURE 5-45: NEAREST (NRST) MENU (STEP-BY-STEP).....	5-81
FIGURE 5-46: NEAREST (NRST) MENU ILS.....	5-82
FIGURE 5-47: DIRECT MENU .....	5-82
FIGURE 5-48: DIRECT MENU (STEP-BY-STEP).....	5-84
FIGURE 5-49: TIMER (TIMER) MENU .....	5-85
FIGURE 5-50: TIMER MENU (STEP-BY-STEP).....	5-86
FIGURE 5-51: PFD SOURCE (SOURCE) MENU.....	5-87
FIGURE 5-52: PFD BUG (BUGS) MENU .....	5-88
FIGURE 5-53: PFD BUG (BUGS) MENU (CONTINUED) .....	5-89
FIGURE 5-54: PFD BUGS MENU (STEP-BY-STEP).....	5-91
FIGURE 5-55: PFD BUGS (STEP-BY-STEP).....	5-92
FIGURE 5-56: REMOTE BUGS PANEL .....	5-93
TABLE 5-3: REMOTE BUGS PANEL (RBP) .....	5-94
FIGURE 5-57: PFD DECLUTTER (DCLTR) MENU .....	5-97
FIGURE 5-58: PFD DECLUTTER (DCLTR) MENU WITH RESET-G..	5-99
FIGURE 5-59: PFD DECLUTTER (DCLTR) MENU (STEP-BY-STEP).....	5-100
FIGURE 5-60: PFD ALTIMETER MENU .....	5-101
FIGURE 5-61: ALTIMETER MENU (STEP-BY-STEP) .....	5-102
FIGURE 5-62: MFD FAULT DISPLAY MENU .....	5-103
FIGURE 5-63: MFD FAULT DISPLAY MENU (STEP-BY-STEP) .....	5-106
FIGURE 5-64: MFD FUEL TOTALIZER QUANTITY MENU.....	5-107
FIGURE 5-65: MFD PAGE (PAGE) MENU.....	5-108
FIGURE 5-66: MFD PAGE MENU (STEP-BY-STEP).....	5-109
FIGURE 5-67: MFD MAP ND PAGE .....	5-110
FIGURE 5-68: MFD HSI PAGE .....	5-110
FIGURE 5-69: MFD NAV LOG PAGE .....	5-111
FIGURE 5-70: MFD ND PAGE FORMAT (FORMAT) MENU .....	5-112
FIGURE 5-71: MFD SYMBOL DECLUTTER .....	5-113
FIGURE 5-72: MFD HSI POINTER (PTRS) MENU.....	5-115
FIGURE 5-73: MFD TRAFFIC FORMAT (FORMAT) MENU .....	5-116



FIGURE 5-74: MFD DATALINK FORMAT (FORMAT) MENU .....	5-117
FIGURE 5-75: MFD VIDEO INPUT FORMAT (FORMAT) MENU.....	5-119
TABLE 5-4: VIDEO INPUT CONTROLS.....	5-120
FIGURE 5-76: CENTER ROTARY ENCODER CONTROLS .....	5-121
FIGURE 5-77: MFD ND PAGE FORMAT (FORMAT) MENU .....	5-122
FIGURE 5-78: MFD ND PAGE FORMAT (FORMAT) MENU (STEP-BY-STEP).....	5-125
FIGURE 5-79: MFD HSI POINTER (PTRS) MENU .....	5-125
FIGURE 5-80: MFD HSI POINTER (PTRS) MENU (STEP-BY-STEP).....	5-126
FIGURE 5-81: MFD STRIKE FORMAT (FORMAT) MENU .....	5-126
FIGURE 5-82: AR TUNE PAGE FIRST-LEVEL OPTIONS .....	5-127
FIGURE 5-83: AR TUNE PAGE SECOND-LEVEL OPTIONS .....	5-128
TABLE 5-5: AR PAGE FUNCTIONS .....	5-128
FIGURE 5-84: AUDIO-RADIO EXPAND PAGE FIRST LEVEL.....	5-130
FIGURE 5-85: AUDIO-RADIO EXPAND PAGE SECOND LEVEL.....	5-131
TABLE 5-6: ADR7050 VHF COM TRANSCEIVER.....	5-131
TABLE 5-7: ADR7050 VHF NAV RECEIVER .....	5-132
TABLE 5-8: BXP 6402 MODE-S TRANSPONDER EXPANDED PAGE	5-132
FIGURE 5-86: AUDIO/RADIO CONTROLS (STEP-BY-STEP).....	5-134
FIGURE 5-87: AUDIO/RADIO CONTROLS (STEP-BY-STEP).....	5-135
FIGURE 5-88: AUDIO/RADIO CONTROLS (STEP-BY-STEP).....	5-136

## 5.1. Menu Functions

Navigate IDU-680 menu functions by using the 16 peripheral buttons and three rotary encoders (3, 2, and 1). The rotary encoder in the lower left corner of the IDU-680 is only used for adjusting screen and button brightness and cannot be used for menu functions. It is always labeled **DIM**.



Figure 5-1: IDU-680 Input Controls

## 5.2. Menu Synchronization

System settings changed by the menu system are synchronized between multiple IDUs and between top and bottom areas of an IDU-680 in MFD-MFD mode according to the following tables.

**Table 5-1: Menu Synchronization**

Menu Parameter	Notes
<i>The following menu parameters are synchronized across all displays at all times. These are bugs and fundamental aircraft values that should never have independence.</i>	
Fuel Totalizer Quantity	
VNAV Climb Angle	
Countdown Timer Start Time	
Countdown Timer Default Value	
Remote Tune Frequencies	
VNAV Descent Angle	
Decision Height Setting	"Used when Dual Decision Height Flag is false." (In the configuration settings).
Emergency and Minimum Fuel Settings	
Heading Bug	
Minimum Altitude Bug Value	
VLOC OBS Settings	
Airspeed Bug Setting	
Target Altitude Bug Setting	
Timer Starting Signal	
Traffic Filter Setting	
Settable V-Speeds	
VSI Bug Setting	
Crosslink Synchronization Status	
G-Force Limit Parameters	
<i>The following menu parameters are synchronized across all displays when crosslink is enabled. Otherwise, they are only synchronized onside. These parameters are FMS parameters and allow the pilot and co-pilot FMSs to be operated independently when crosslink is inhibited.</i>	
Active Flight Plan Parameters	
Runway Display Parameters	

**Table 5-1: Menu Synchronization**

Menu Parameter	Notes
<i>The following menu parameters are only synchronized onside. These parameters are usually sensor selections or PFD options used to keep the appearance of any pilot's PFD consistent in the case of PFD reversion. The onside characteristic means that individual pilots may still adjust their PFD settings to their preference.</i>	
Sensor Selections	
Transition Altitude	
Barometric Setting Units	
Barometric Setting Value	
Barometric Setting Mode	
Decision Height Setting	Used when "Dual Decision Height Flag" is true. (In the configuration settings).
Navigation Source	
PFD Basic Mode	
PFD Zoom Mode	
PFD Analog AGL	
PFD Full-time Bank Scale Flag	
PFD Flight Director Show Flag	
PFD Generic EICAS Overlay Show Flag	
PFD Mini-map Show Flag	
PFD Altitude (meters) Show Flag	
PFD Traffic Thumbnail Show Flag	
PFD Skyway Show Flag	
PFD Terrain Show Flag	
PFD Traffic Show Flag	
Rate of turn indication flag	
<i>The following menu parameters are independent between displays. These are used to support non-PFD display options to give the pilot maximum MFD operating flexibility. Note that some of these parameters are also independent between top and bottom 680 MFD areas as specified in the notes.</i>	

**Table 5-1: Menu Synchronization**

<b>Menu Parameter</b>	<b>Notes</b>
MFD Selected Page	Independent between top and bottom 680 MFD areas. Note that this parameter is transmitted to all other IDUs to support weather radar vertical profile mode selection
MFD Map Page Settings	Independent between top and bottom 680 MFD areas. Note that map scale is transmitted outside to support weather radar range selection.
MFD Map and HSI Page Pointer Settings	Independent between top and bottom 680 MFD areas
MFD Map Function Declutter Settings	Independent between top and bottom 680 MFD areas
MFD Show ETA Flag	
MFD Map NavData Symbol Declutter Settings	Independent between top and bottom 680 MFD areas
MFD Traffic Page Settings	Independent between top and bottom 680 MFD areas

### 5.3. Menu Function Types


Only soft menu functions are used (even at the top-level) and are annunciated in a dedicated, blacked-out area in the screen margins. Soft menu function tiles include an indication of further menu levels with a filled triangle (with further levels) or hollow triangle (without further levels) pointing to the associated peripheral button.

Soft menu function tiles appear next to the appropriate IDU button or adjacent to one of the rotary encoders. Menus appearing adjacent to rotary encoders are frequently a selection list. Within such selection lists, the indication of further menu levels consists of a two-dot trailer. Selection lists too long to be presented in the space available provide an indication of location within the list. Whenever the menu system is beyond the top-level, **EXIT (R1)** provides one touch escape to the top-level. Whenever a soft menu level is deeper than the first-level, **BACK (L1)** regresses through the menu system by one level.

## 5.4. Top-Level Menu

On the IDU-680, the top-level menu consists of soft menu options along with option labels for the rotary encoders.

### 5.4.1. IDU-680 PFD Normal Mode Top-Level Menu



**Figure 5-2: PFD Normal Mode Top-Level Menu**

### 5.5. IDU-680 MFD Normal Mode Top-Level Menu




Figure 5-3: MFD Normal Mode Top-Level Menu

## 5.6. IDU-680 PFD or MFD Essential Mode Top-Level Menu





Figure 5-4: PFD or MFD Essential Mode Top-Level Menu

### 5.6.1. Top-Level Menu Option Descriptions

- 1) **FPL (L1)**: Flight plan menu.
- 2) **ACTV (L2)**: Active flight plan menu.
- 3) **INFO (L3)**: Information menu.
- 4) **OBS (L4)**: Omnibearing selector menu.
- 5) **MENU (R1)**: First-level associated with the current display page and automatically times out after 10 seconds if there are no subsequent pilot actions.



- 6) **BARO (R2)**: Altimeter menu option.
- 7) **NRST (R3)**: Nearest menu option.
- 8) ** (R4)**: Direct menu option.
- 9) **TO ESSNTL/TO NORMAL (R5)**: Manually switches between Normal and Essential modes.
- 10) **#3 Encoder (Ⓢ)**: Function depends upon IDU number and mode (Normal vs. Essential) as follows:
  - a) On a PFD (IDU #1), push **Ⓢ** to sync current heading and scroll to activate the Heading menu.
  - b) On an MFD (IDUs other than #1) operating in Essential Mode, push **Ⓢ** to sync current heading and scroll to activate the Heading menu.
- 11) **#2 Encoder (Ⓣ)**:
  - a) On a PFD (IDU #1), any encoder action activates the target altitude selection function of the PFD Bugs menu. The encoder is labeled **ALT SEL**.
  - b) On an MFD (IDUs other than #1) operating in Normal Mode, if the top area is showing a page with an adjustable display scale, e.g., ND, Strike, Traffic, Datalink, or Weather Radar, scroll to change the display scale (clockwise = increase, counterclockwise = decrease).
  - c) On an MFD (IDUs other than #1) operating in Normal Mode, if the top area is showing a video page, scroll to change the zoom level (clockwise = increase, counterclockwise = decrease).
  - d) On an MFD (IDUs other than #1) operating in Normal Mode, if the top area is showing an EICAS including a CAS box, scroll to the CAS box.
  - e) On an MFD (IDUs other than #1) operating in Normal Mode, if the top area is showing an Audio/Radio page, scroll to change the selected Audio/Radio device.
  - f) On an MFD (IDUs other than #1) operating in Normal Mode, if the top area is showing an Audio/Radio page, scroll to change the selected Audio/Radio device .

- g) On an MFD (IDUs other than #1) operating in Normal Mode, press the encoder to activate the top MFD page menu as described in the MFD page menu section. The top MFD page menu is drawn above ②, unlike other menu lists. If the pilot selected a full screen EICAS in the bottom area consuming both the top and bottom areas, completion of the MFD page menu action automatically switches the EICAS in the bottom area to its related “backup” displays.
- h) On an MFD (IDUs other than #1) operating in Essential Mode, the encoder is labeled **TOP** when either an encoder scroll or push could have an effect.
- i) On an MFD (IDUs other than #1) operating in Essential Mode, any encoder action activates the target altitude selection function of the PFD Bugs menu. The encoder is labeled **ALT SEL**.

### 5.6.2. #1 Encoder (①)

- 1) On a PFD or MFD operating in Normal Mode, if the bottom area is showing a page with an adjustable display scale (e.g., ND, Strike, Traffic, Datalink or Weather Radar), scroll to change the display scale (clockwise = increase, counterclockwise = decrease).
- 2) On a PFD or MFD operating in Normal Mode, if the bottom area is showing a video page, scroll to change the zoom level (clockwise = increase, counterclockwise = decrease).
- 3) On a PFD or MFD operating in Essential Mode with an Essential EICAS page configured, if the Essential EICAS page includes a CAS box, scroll to progress the CAS box.
- 4) On a PFD or MFD operating in Normal Mode, if the bottom area is showing an Audio/Radio page, scroll to change the selected Audio/Radio device.
- 5) On a PFD or MFD operating in Essential Mode with an EICAS configured, if the EICAS includes a CAS box, scroll to progress the CAS box.
- 6) In Normal Mode or Essential Mode without an Essential EICAS page configured, push the encoder to activate the MFD bottom page menu option as described in the MFD page menu section. If the pilot selected a full screen EICAS page in the top area

consuming both the top and bottom areas, completion of the MFD page menu action automatically switches the EICAS page in the top area to its related “backup” display.

- a) **1** is labeled **BTM** but is not labeled if in Essential Mode with an Essential EICAS page configured, and the EICAS page does not include a CAS box.

### 5.6.3. Top-Level Menu Automatic Pop-up Function Descriptions

Under certain conditions, soft menu tiles automatically appear at the top-level to provide the pilot with single-touch access to needed functions. The following soft menu tiles appear adjacent to the specified pushbutton under the specified conditions.

**Table 5-2: Top-Level Auto Popup Function Descriptions**

IDU-680 (Note 1)	IDU-680 (Note 2)	Precedence, Tile Legend, and Action
L1	L5	<ol style="list-style-type: none"> <li>1) As specified in Section 8 TAWS, <b>RESET</b> appears when a terrain popup occurs during a TAWS FLTA alert.</li> <li>2) When showing Datalink page with Pan Mode enabled, <b>PN OFF</b> appears. Press to disable Pan Mode. <b>RESET</b> has precedence over <b>PN OFF</b>.</li> <li>3) When showing ND page with Pan Mode enabled, <b>PN OFF</b> appears. Press to disable Pan Mode. <b>RESET</b> has precedence over <b>PN OFF</b>.</li> <li>4) When display is “transmit enabled”, <b>LNAV</b> appears when there is an active flight plan, the heading bug sub-mode is active, and the system is integrated with an analog autopilot. Press to deactivate heading bug sub-mode and resume guidance to the active flight plan path. <b>RESET</b> and <b>PN OFF</b> have precedence over <b>LNAV</b>.</li> </ol>

**Table 5-2: Top-Level Auto Popup Function Descriptions**

IDU-680 (Note 1)	IDU-680 (Note 2)	Precedence, Tile Legend, and Action
		5) When display is “transmit enabled”, <b>MISS</b> appears upon transitioning the Final Approach Fix. Press to activate the missed approach procedure. <b>RESET, PN OFF, and LNAV</b> have precedence over <b>MISS</b> .  6) When display is “transmit enabled”, <b>CONT</b> appears when in a holding pattern with further active flight plan legs after the holding pattern. Press to re-enable automatic waypoint sequencing to allow normal sequencing to the leg after the holding pattern. <b>PN OFF and MISS</b> have precedence over <b>CONT</b> .
<b>L2</b>	<b>L6</b>	1) When showing Datalink page with Winds and Temperatures Aloft enabled, <b>UP</b> appears. Press to increase the Winds and Temperatures Aloft grid level. <b>UP</b> does appear when the highest grid level is displayed.  2) When showing Video Input page with pan mode enabled, <b>UP</b> appears. Press to move up the section of the video image displayed in the full video image.  3) When showing Datalink page with: (a) pan mode enabled; (b) information for the nearest highlighted waypoint being shown; and (c) airport weather information present in the information block; <b>WX</b> appears to allow the display of textual METAR and TAF data for the airport. <b>UP</b> has precedence over <b>WX</b> .

**Table 5-2: Top-Level Auto Popup Function Descriptions**

IDU-680 (Note 1)	IDU-680 (Note 2)	Precedence, Tile Legend, and Action
		<p>4) When showing ND page with: (a) pan mode enabled; (b) information for the nearest highlighted waypoint being shown; and (c) airport weather information present in the information block; <b>WX</b> appears to allow the display of textual METAR and TAF data for the airport.</p> <p>5) When display is “transmit enabled”, <b>VNAV</b> appears when VNAV guidance is valid, the selected altitude sub-mode is active, and the system is integrated with an analog autopilot. Press to deactivate selected altitude sub-mode and resume guidance to the VNAV path. <b>UP</b> and <b>WX</b> have precedence over <b>VNAV</b>.</p> <p>6) When display is “transmit enabled”, <b>ARM</b> appears when on the Final Approach Segment (between the Final Approach Fix and Missed Approach Point). Press to arm the missed approach procedure to automatically activate upon sequencing the Missed Approach Point. <b>UP</b>, <b>WX</b>, and <b>VNAV</b> have precedence over <b>ARM</b>.</p> <p>7) When showing AR page and a device with adjustable volume is selected, <b>MUTE</b> appears. Press to toggle mute for the selected device. Not applicable for intercom system. <b>VNAV</b> has precedence over <b>MUTE</b>.</p> <p>8) When showing AR page and an intercom system is selected, <b>SYNC TX</b> appears when the intercom</p>

**Table 5-2: Top-Level Auto Popup Function Descriptions**

IDU-680 (Note 1)	IDU-680 (Note 2)	Precedence, Tile Legend, and Action
		system is set to Split Transmit. Press to synchronize the selected transceivers in a multi-unit configuration and clear the Split Transmit feature. For Intercom systems, <b>SPLIT TX</b> appears when the intercom system is set to synchronize transmit. Press to set the system to Split Transmit. <b>VNAV</b> has precedence over <b>SPLIT TX</b> and <b>SYNC TX</b> .
<b>L3</b>	<b>L7</b>	<ol style="list-style-type: none"> <li>1) When showing Datalink page with Pan Mode enabled, <b>NORTH</b> appears. Press to shift the center of the Pan Mode Datalink page in the specified direction.</li> <li>2) When showing ND page with Pan Mode enabled, <b>NORTH</b> appears. Press to shift the center of the Pan Mode ND page in the specified direction.</li> <li>3) When showing Video Input page with pan mode enabled, <b>DOWN</b> appears. Press to move down the section of the video image displayed in the full video image.</li> <li>4) When showing AR page when interfaced with a transponder, <b>IDENT</b> appears. Press to enable the special position identification or “ident” feature of the transponder.</li> </ol>
<b>L4</b>	<b>L8</b>	<ol style="list-style-type: none"> <li>1) When showing Datalink page with Pan Mode enabled, <b>SOUTH</b> appears. Press to shift the center of the Pan Mode Datalink page in the specified direction.</li> </ol>

Table 5-2: Top-Level Auto Popup Function Descriptions

IDU-680 (Note 1)	IDU-680 (Note 2)	Precedence, Tile Legend, and Action
		<ol style="list-style-type: none"> <li>2) When showing ND page with Pan Mode enabled, <b>SOUTH</b> appears. Press to shift the center of the Pan Mode ND page in the specified direction.</li> <li>3) When showing AR page and a device with an expanded AR page is selected, <b>EXP</b> appears. Press to enable the AR Expand page First-Level options.</li> </ol>
<b>R2</b>	<b>R6</b>	<ol style="list-style-type: none"> <li>1) When showing Datalink page with Winds and Temperatures Aloft enabled, <b>DOWN</b> appears. Press to decrease the Winds and Temperatures Aloft grid level. <b>DOWN</b> does not appear when the lowest grid level is displayed.</li> <li>2) When showing Video Input page with pan mode enabled, <b>LEFT</b> appears. Press to move left the section of the video image displayed in the full video image.</li> <li>3) When showing the Datalink page with Pan Mode enabled, <b>INFO</b> or <b>HIDE</b> appears. Press to toggle the display of information for the nearest highlighted waypoint. Refer to the INFO Menu requirements for the amount and type of information presented. <b>DOWN</b> has precedence over the <b>INFO/HIDE</b>.</li> <li>4) When showing ND page with Pan Mode enabled, <b>INFO</b> or <b>HIDE</b> appears. Press to toggle the display of information for the nearest highlighted waypoint. Refer to the</li> </ol>

**Table 5-2: Top-Level Auto Popup Function Descriptions**

IDU-680 (Note 1)	IDU-680 (Note 2)	Precedence, Tile Legend, and Action
		<p>INFO Menu requirements for the amount and type of information presented.</p> <p>5) When showing AR page and a transceiver is selected which is not currently enabled for transmit, <b>TX</b> appears. Press to enable the selected device for transmit and un-mute the selected device. When interfaced AMU fails, AR page omits <b>TX</b> and button operation for the devices.</p> <p>6) When showing AR page and a VHF Nav Receiver is selected, and a DME receiver is interfaced and DME presents a valid signal, <b>HOLD</b> appears. Press to toggle DME Hold for the Nav receiver and associated DME channel. Press to set the hold frequency of the DME channel for the current Nav Receiver equal to the Nav receiver active frequency.</p> <p>7) When showing AR page and an ADF Receiver is selected, <b>BFO</b> appears when the ADF receiver is in ADF mode. When the ADF receiver is in BFO or TEST mode, <b>REC</b> appears. When the ADF Receiver is in receive mode, <b>ADF</b> appears. Press to enable the BFO mode when the receiver is in ADF mode. Press to enable the ADF mode when the receiver is in receive mode. Press to enable the receive mode when the receiver is in BFO or TEST mode.</p> <p>8) When showing the AR page and a transponder is selected, <b>VFR</b></p>



Table 5-2: Top-Level Auto Popup Function Descriptions

IDU-680 (Note 1)	IDU-680 (Note 2)	Precedence, Tile Legend, and Action
		<p>appears. When pressed, this button sets the transponder standby code to the transponder VFR code set by the user interface.</p> <p>9) When showing the AR page and a marker beacon having sensitivity control is selected, <b>SENSE</b> appears. When pressed, this button toggles the marker beacon hi/lo discrete output.</p>
<b>R3</b>	<b>R7</b>	<p>1) When showing ND page with Pan Mode enabled, <b>EAST</b> appears. Press to shift the center of the Pan Mode ND page in the specified direction.</p> <p>2) When showing the ND page with Pan Mode enabled, <b>EAST</b> appears. Press to shift the center of the Pan Mode ND Page in the specified direction.</p> <p>3) When showing the Video Input page with pan mode enabled, <b>RIGHT</b> appears. Press to move section of the video image displayed to the right.</p> <p>4) When showing the AR page and a device having a tunable frequency or code is selected, <b>SWAP</b> appears. When pressed, this button switches the standby frequency/code and the active frequency/code for the selected device.</p>
<b>R4</b>	<b>R8</b>	<p>1) When showing the Datalink page with Pan Mode enabled, <b>WEST</b> appears. Press to shift the center of the Pan Mode Datalink Page in the specified direction.</p> <p>2) When showing the ND page with Pan Mode enabled, <b>WEST</b> appears. Press</p>

**Table 5-2: Top-Level Auto Popup Function Descriptions**


IDU-680 (Note 1)	IDU-680 (Note 2)	Precedence, Tile Legend, and Action
		<p>to shift the center of the Pan Mode ND Page in the specified direction.</p> <ol style="list-style-type: none"> <li>3) When showing the AR page and a VHF COM transceiver, VHF NAV Receiver, or ADF Receiver is selected, <b>TUNE VOL..</b> appears. When pressed, this button enables AR Tune page first-level options.</li> <li>4) When showing the AR page and a transponder is selected, <b>CODE MODE..</b> appears. When pressed, this button enables the AR Tune page first-level options.</li> <li>5) When showing the AR page and the following devices are selected; audio-only device, marker beacon, DME receiver; a <b>"VOL"</b> tile appears. When pressed, this button enables AR Tune page first level options.</li> <li>6) When showing the AR page and an AMU is selected, a <b>"VOX VOL"</b> tile appears. When pressed, this button enables AR Tune page first-level options.</li> </ol>

**Notes:**

- 1) The designated buttons are used when the function is tied to a page in the top area.
- 2) The designated buttons are used when the function is tied to a page in the bottom area or when the function is tied to being "Transmit Enabled".

## 5.7. First Page (PFD)

The top area of IDU #1 is fixed to the PFD page, and other IDUs show the PFD page in the top area by selecting Essential Mode. IDU-680 PFD page first-level options are shown adjacent to the eight pushbuttons in the top area. Options may also appear on the bottom eight pushbuttons as appropriate to the page shown in the bottom area. When an identical option is shown adjacent to both the top area and bottom area, the option is only shown adjacent to the top area.




**Figure 5-5: First Page PFD**

### 5.7.1. PFD Page First-Level Option Descriptions

- 1) **XFILL SYNC (L1)**: Appears in dual-system installations where the pilot and co-pilot systems are not synchronized, but crosslink is enabled. Press to synchronize the pilot and co-pilot active flight plan parameters to the system where the button press occurred.
- 2) **Source (L2)**: Activates the PFD source selection menu option.
- 3) **DESIG (L3)**: Creates a user waypoint at the current aircraft location. In addition, if on an IDU-680 with an ND page operating in panning mode, press to create a user waypoint at the panning location. User waypoint is automatically named “**OF###**”, where ‘###’ is the next available over-fly user waypoint number.
- 4) **TIMER (L4)**: Activates the timer menu option.
- 5) **BUGS (R2)**: Activates the PFD bug set menu option.
- 6) **ZOOM ON/ZOOM OFF (R3)**: Toggles between wide FOV mode and narrow FOV mode. **ZOOM ON** appears when the current mode is wide FOV. **ZOOM OFF** appears when the current mode is narrow FOV.
- 7) **DCLTR (R4)**: Activates the PFD declutter menu option.
- 8) **EXPAND CAS (Ⓛ)**: Only appears when there are more than 11 active CAS messages displayed and activates the Expand CAS menu option.


## 5.7.2. First Level (MFD)

The bottom area of all IDUs always shows the MFD page in all modes (the Essential EICAS page is considered a type of MFD page). IDUs other than IDU#1 also show the MFD page in the top area when in Normal Mode. The MFD page first-level options are shown adjacent to the area in which the MFD page resides. When an identical option is shown adjacent to both the top area and bottom area, the option is only shown adjacent to the top area (options spelled the same but affect different areas of the screen are not identical.) The MFD page first-level options are as follows (all possible options shown adjacent to the top area for illustrative purposes).



**Figure 5-6: First Level MFD**

### 5.7.3. First Level (PFD IDU#1) Normal Mode



**Figure 5-7: First Level PFD**

### 5.7.4. First Level (MFD IDU other than #1) Normal Mode

First level (MFD IDU other than #1) in Normal Mode with an MFD page in both areas.




Figure 5-8: First Level (MFD IDU Other Than #1) Normal Mode

### 5.7.5. MFD Page First-Level Option Descriptions

- 1) **FAULTS**: Activates the fault display menu option.
- 2) **CLR STRKS or WX LGND**: On ND page or Strike page with WX-500 option enabled, “**CLR STRKS**” activates the strike clear option for the Goodrich/L-3 WX-500. On Datalink page, “**WX LGND**” activates the datalink weather legend.
- 3) **DESIG**: Same function as PFD page first-level.
- 4) **TIMER**: Same function as PFD page first-level.
- 5) **SET FUEL**: Activate fuel totalizer set menu option.
- 6) **PAGE**: Press **1** and **2** to handle this function.
- 7) **FORMAT: PTRS, Route ON/ROUTE OFF, or EXCD (R8)**: On the ND, activates the appropriate page format menu option.
- 8) **PTRS**: On HSI page with optional VOR or ADF symbology enabled, activates HSI RMI pointer menu option.
- 9) **ROUTE ON/ROUTE OFF**: On Weather Radar page, toggles the display of the active flight plan on the horizontal weather radar display. **ROUTE ON** appears when the display of the active flight plan is disabled. **ROUTE OFF** appears when the display of the active flight plan is enabled.
- 10) **EXCD**: On a generic EICAS page of type EICAS, activates the EICAS Exceedance menu option. **EXCD** only appears if exceedances are logged.
- 11) **EXPAND CAS (1)**: Only appears when there are more than 11 active CAS messages displayed and activates the Expand CAS menu option.



### 5.7.6. IDU-680 EICAS Page First-Level in Essential Mode

The bottom area of the IDU-680 shows the EICAS page. In Normal Mode on IDUs other than #1, the EICAS page may be shown in the top area (a full-screen EICAS page using both the top and bottom areas is considered to be a top area page). IDU-680 EICAS page first-level options are shown adjacent to the area in which the EICAS page resides. When an identical option is shown adjacent to both the top area and bottom area, the option is only shown adjacent to the top area. IDU-680 EICAS page first-level options are as follows:

All possible options are shown adjacent to the top area for illustrative purposes in Figure 5-9.





Figure 5-9: EICAS Page First-Level in Essential Mode

### 5.7.7. PFD Page in Top Area and Essential Mode EICAS Page in Bottom Area



**Figure 5-10: PFD Page in Top Area and Essential Mode EICAS Page in Bottom Area**

### 5.7.8. First-Level Menu of an MFD (IDU Other Than #1) in Normal Mode





Figure 5-11: First-Level Menu of an MFD (IDU Other Than #1) in Normal Mode

### 5.7.9. EICAS Page First-Level Option Descriptions

- 1) **SET FUEL:** Same function as MFD page first-level.
- 2) **PAGE 1 through PAGE 5** (only applicable in Normal Mode): Allows selection of optionally configured EICAS pages. Menu tile text is configured in the EICAS configuration file. Options are only shown if more than one EICAS page is configured and only shown for configured EICAS pages.

- 3) **EXPAND CAS (1)**: Activates the Expand CAS menu option and only appear when there are more than 11 active CAS messages.
- 4) **EXCD**: Activates the EICAS Exceedance menu option and only appear if exceedances are logged.

### 5.8. EICAS Exceedance Menu




The EICAS Exceedance menu presents a listing of logged EICAS exceedances. Scroll **1** to view each line.

**Figure 5-12: EICAS Exceedance Menu**

The format for each exceedance line is the following:

- 1) Exceedance element name;
- 2) Logged peak value in element units; and
- 3) Logged duration in Hour: Minute: Second format.


### 5.9. Expand CAS Menu



The Expand CAS menu changes the display of CAS messages from a stacked presentation to a CAS Display Box element. Scroll the CAS Display Box to view off-screen messages when the message count exceeds 11.

**Figure 5-13: Expand CAS Menu**

### 5.9.1. Expand CAS Menu (Step-By-Step)




GPS1 FAIL  
GPS2 FAIL  
NO POSITION  
GPS LON  
COOLING FAN  
XFILL FAIL  
DAU 1B FAIL  
DAU 2A FAIL  
DAU 2B FAIL  
ADC1 FAIL  
MORE-PRS MENU

- 1) When more than 11 CAS messages are available press MENU.




EXPAND CAS..

- 2) Scroll **1** to view additional CAS messages



RADALT FAIL  
GPS1 FAIL  
GPS2 FAIL  
NO POSITION  
COOLING FAN  
XFILL FAIL  
DAU 1B FAIL  
DAU 2A FAIL  
DAU 2B FAIL  
ADC1 FAIL  
↓5

- 3) This example indicates there are an additional five messages below.



GPS1 FAIL  
GPS2 FAIL  
NO POSITION  
COOLING FAN  
XFILL FAIL  
DAU 1B FAIL  
DAU 2A FAIL  
DAU 2B FAIL  
ADC1 FAIL  
ADC2 FAIL  
↑1 ↓4

- 4) This example indicates there is one message above and four below.

**Figure 5-14: CAS List Scrolling**


### 5.10. Lower-Level Menu (Below First-Level)

The top-level and first-level menus, called lower-level menus, are described in this section, and the pushbuttons and rotary encoders control them. In the following diagrams, button and encoder numbers are interpreted according to the following view.



**Figure 5-15: IDU 680 Input Controls**

## 5.11. Flight Plan (FPL) Menu



**Figure 5-16: Flight Plan Menu**

### 5.11.1. Flight Planner Page

When the Flight Planner is accessed, it only appears in the Bottom Area. If the pilot selected a full screen OASIS page in the Top Area that consumes both the Top and Bottom Areas. In this case, the Top area automatically switches to its related “backup” display.

Through the Flight Planner page, the following types of functions are performed:

- 1) Manage stored flight plans (activate, create, edit, delete, and reverse);
- 2) Manage user waypoints (create, edit, and delete); and
- 3) Perform RAIM predictions.

These operations demand pilot attention and are not normal operating conditions for the IDU. When the Flight Planner page is in use, the Flight Planner page takes over the IDU’s controls and disables the menu operations described in this document (other than the automatic IDU-680 EICAS page reversions described above). Normal menu operation and IDU control function are restored upon:

- 1) Exit the Flight Planner page; or
- 2) Automatic reversion of the IDU to the PFD or Essential Mode. Automatic reversion exits the Flight Planner page and wipes out any changes being performed.

Because the Flight Planner page takes over the IDU's controls, limitations are placed upon access and display of the Flight Planner page. When the Flight Planner is accessed, the Flight Planner only appears in the bottom area.

Upon activation of the flight plan menu, the application checks for the existence of saved flight plans. If there are no saved flight plans, the Flight Planner is activated. Otherwise, an option list is presented allowing the pilot to either select a saved flight plan or enter the flight planning page. Selecting the saved flight plan select option leads to a list of saved flight plans. Upon selection of a saved flight plan, the second waypoint in the flight plan is activated.

#### **NOTE:**

If the pilot selected a full screen OASIS page in the top area consuming both the top and bottom areas, the top area automatically switches to its related "backup" display.

#### **5.11.2. PFD Page Shown on IDU**

Upon activation of the flight plan menu, the application checks for the existence of saved flight plans. If there are no saved flight plans, **NO SAVED FPLS** advisory is issued. Otherwise, a selection list of saved flight plans is presented. Upon selection of a saved flight plan, the second waypoint in the flight plan is activated.

#### **5.11.3. No PFD Page Shown on IDU**

Upon activation of the flight plan menu, the application checks for the existence of saved flight plans. If there are no saved flight plans, the Flight Planner page is activated. Otherwise, an option list is presented allowing the pilot to either select a saved flight plan or enter the flight planning page. Selecting the saved flight plan select option leads to a list of saved flight plans. Upon selection of a saved flight plan, the second waypoint in the flight plan is activated.



### 5.11.4. To Create an Overfly User Waypoint

When flying over intended waypoint, press **MENU (R1)** then **DESIG (L3)** on the PFD or MFD. A user waypoint is created at the present position and automatically named OF####, where #### is the next in sequence overfly user waypoint number available. The waypoint name may be changed using the “EDIT USER WPT” function.



Figure 5-17: Creation of Overfly User Waypoint

#### NOTE:

A maximum of 998 user waypoints may be created and stored.

### 5.11.5. Flight Plan (FPL) Menu Selecting (Step-By-Step)




- 1) Press **FPL (L1)**.
- 2) Scroll **1** to desired flight plan and push to enter.

Figure 5-18: Flight Plan Menu Selection


### 5.11.6. Flight Plan (FPL) Menu Create-Edit (Step-By-Step)




1) Press **FPL (L1)**.



2) Scroll **1** to **CREATE-EDIT..** and push to enter.




3) Push **1** to enter.



4) Press **ADD (R8)** to begin creating first waypoint.


**Figure 5-19: Flight Plan Menu Creation (Step-By-Step)**



- 5) Press **NRST APT (L6)**, **NRST VOR (L7)**, **NRST NDB (L8)**, **NRST FIX (R6)**, **NRST USR (R7)**, or **AIRWAY (R8)** to view applicable list, scroll **1** to desired selection and push to insert into flight plan.



- 6) Once the desired selection "**KBDR**" appears as the first waypoint, continue with adding more waypoints.



- 7) If necessary scroll up to **KBDR**.



- 8) Press **INFO (R6)** to view information about selected waypoint.


**Figure 5-20: Flight Plan Menu Creation (Step-By-Step)  
(Continued)**



- 9) Scroll to next space and add another waypoint
- 10) Push **1** to enter waypoint.
- 11) If necessary press **ADD (R8)** to create additional waypoints.
- 12) View current flight plan and press **SAVE (R8)** if accepted.

**Figure 5-21: Flight Plan Menu Creation (Step-By-Step)  
(Continued)**

### 5.11.7. Activate Flight Plan (Step-By-Step)



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **ACTIVATE FLIGHT PLAN** and push to enter.
- 4) Scroll **1** to desired saved flight plan and push to enter.
- 5) **SLCT 1** serves to remind the pilot which encoder is used for this operation.
- 6) If no other action is necessary press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit the **ACTIVATE FLIGHT PLAN** menu.


Figure 5-22: Activate Flight Plan

### 5.11.8. Edit Flight Plan (Step-By-Step)

- 
- 1) Press **FPL (L1)**.
  - 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
  - 3) Scroll **1** to **EDIT FLIGHT PLAN** and push to enter.
  - 4) Scroll **1** to desired flight plan and push to enter.
  - 5) Edit flight plan by adding or deleting waypoints as appropriate.
  - 6) **SLCT 1** serves to remind the pilot which encoder is used for this operation.
  - 7) Press **SAVE EXIT (R5)** to save and exit to **EDIT WHICH FPL:** list.
  - 8) If no other action is necessary, press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit the **EDIT WHICH FPL** menu.

Figure 5-23: Edit Flight Plan


### 5.11.9. Reverse Flight Plan (Step-By-Step)



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **REVERSE FLIGHT PLAN** and push to enter.
- 4) **SLCT 1** serves to remind the pilot which encoder is used for this operation.
- 5) Scroll **1** to desired flight plan and push to enter.
- 6) If no other action is necessary, press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit the **REVERSE WHICH FPL** menu.

**Figure 5-24: Reverse Flight Plan**

### 5.11.10. Delete Flight Plan (Step-By-Step)



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to desired flight plan to be deleted and push to enter.
- 4) **SLCT 1** serves to remind the pilot which encoder is used for this operation.
- 5) Push **1** to confirm deletion of **FPL**.
- 6) The next flight plan is highlighted and if no further deletions are required.
- 7) If no other action is necessary, press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit the **DELETE WHICH FPL** menu.

**Figure 5-25: Delete Flight Plan**



### **5.11.11. Create User Waypoint (LAT-LON) (Step-By-Step)**






User waypoints may be created with three methods:

- 1) Latitude and Longitude
- 2) Radial and Distance
- 3) Overfly (Designate)

#### **NOTE:**

User waypoints are synchronized across all displays when created, modified, or deleted. Due to the large amount of information transmitted for these actions, this process is not instantaneous. The time required for a user waypoint to appear or disappear on any display is dependent on each display's symbol declutter setting.

To create a user waypoint using latitude and longitude the following step-by-step procedure should be followed.



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **CREATE USER WPT (LAT-LON)** and push to enter.
- 4) To name a new user waypoint, scroll **1** and push to enter all five character spaces.
- 5) With new name created for user waypoint, press **1** to proceed through all fields as necessary.

Preloading of the approach bearing is dependent upon mode of flight as follows:

On Ground: Preloaded with current heading.

In Flight: Preloaded with "OFF" value.

If desired, specify the approach bearing to the user waypoint in degrees 1°-360°. "OFF" value disables VFR approaches to the user waypoint.

- 6) Once all fields are entered, push **1** to save the user waypoint and return to the editing screen.


**Figure 5-26: Create User Waypoint (LAT-LON)**



- 1) Press **MENU (R1)**.
- 2) Press **DESIG (L3)**.
- 3) The Overfly designated waypoint has been created and automatically been named "OF002".

**Figure 5-27: Create User Waypoint (Overfly DESIG)**

### 5.11.12. Create User Waypoint (RAD-DST) (Step-By-Step)



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **CREATE USER WPT (RAD-DST)** and push to enter.
- 4) The identifier is automatically named **RD###** where **###** is the next available radial distance waypoint number. \*
- 5) After all fields have been entered, push **SAVE (R8)** to save and return to the editing screen.

**\* Reference Waypoint:** The pilot is prompted to enter an identifier for the reference waypoint on the second line. Use **1** to enter the reference waypoint in the same manner as a waypoint is entered for a flight plan. If there is a single result from the search, the pilot is advanced to the radial entry box. If there is no result from the search, the pilot is re-prompted to enter an identifier. If there are multiple results from the search, a selection list with matching identifiers is displayed, and upon selection, the pilot is advanced to the radial entry box. **INFO (R6)** appears at this level to provide access to information for the highlighted result and aid in selection.

**Radial Entry:** The third line allows the pilot to specify a radial from the reference waypoint in increments of degrees.

**Distance Entry:** The fourth line allows the pilot to specify a distance from the reference in increments of tenths of nautical miles.


**Figure 5-28: Create User Waypoint (RAD-DST) (Step-By-Step)**



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **EDIT USER WPT** and push to enter.
- 4) Scroll **1** to desired waypoint to be edited.
- 5) **SLCT 1** serves to remind the pilot which encoder is used for this operation.
- 6) Using **1** enter alphanumeric characters, follow on-screen prompts to edit information. Push **1** to step through all character spaces. To back up, press **BACK (L1)** and continue to the end of all character spaces.
- 7) If necessary select another **USR WPT** to edit or press **SAVE (R8)** to save changes.
- 8) If no other action is necessary, press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit the **EDIT WHICH USER WAYPOINT** menu.

**Figure 5-29: Edit User Waypoint**

### 5.11.13. Delete User Waypoint (Step-By-Step)



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **DELETE USER WPT** and push to enter.
- 4) **SLCT 1** serves to remind the pilot which encoder is used for this operation.
- 5) Scroll **1** to desired waypoint to be deleted.
- 6) Push **1** to **CONFIRM DEL USER WPT**.
- 7) If no other action is necessary, press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit the **DELETE WHICH USER WAYPOINT** menu.

Figure 5-30: Delete User Waypoint

**NOTE:**

Pilot alterations of user waypoint parameters while in flight do not automatically update to an active flight plan.

When changes are made to a user waypoint, and those changes are desired in existing flight plans which use the waypoint, it must be deleted and replaced in the flight plans with the following steps:

- 1) EDIT the user waypoint as described above
- 2) Open a flight plan which uses the user waypoint
- 3) Delete the existing waypoint from the flight plan
- 4) Save and Exit
- 5) Reload the flight plan if it was in use.

### 5.11.14. RAIM Prediction

When selected, this RAIM prediction screen is only shown if the GPS/SBAS receiver is capable of performing a RAIM Prediction. This requires there are no faults along with a current almanac in memory. Monitor the **FAULTS** menu to determine if the GPS/SBAS receiver is capable of performing a RAIM prediction.



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **RAIM PREDICTION** and push to enter.  
**SEE NOTE BELOW.**
- 4) If another RAIM Prediction is necessary press **START OVER (L1)** for starting the process again or press **EXIT (R1)** to exit the RAIM Prediction screen.

**Figure 5-31: RAIM Prediction**




**NOTE:**

The RAIM prediction screen allows the pilot to perform RAIM prediction at a designated waypoint. The screen has various data entry boxes as follows:

- 1) **Designated Waypoint:** The default entry is the current active flight plan destination, otherwise the pilot is prompted to enter an identifier for the designated waypoint. If there is a single result from the search, the pilot is advanced to the UTC time entry box. If there is no result from the search, the pilot is re-prompted to enter an identifier. If there are multiple results from the search, a selection list with matching identifiers is presented and upon selection, the pilot is advanced to the UTC time entry box. **INFO (R6)** appears at this level to provide access to information for the highlighted result and aid in selection.
- 2) **UTC Time Entry:** Allows entry of the 24-Hour UTC estimated time of arrival at the designated waypoint.
- 3) **UTC Date Entry:** Allows entry of the UTC estimated date of arrival at the designated waypoint.
- 4) **PRN Mask Entry:** Allows the pilot to specify the PRN number of satellites expected to be unavailable at the destination.
- 5) **EXIT:** Allow exit the RAIM prediction screen at any time.
- 6) Once a designated waypoint and UTC estimated time of arrival are entered, **CALC (R6)** appears to allow the pilot to initiate the RAIM Prediction. Press **CALC (R6)** to check the UTC estimated time of arrival and ensure it is within the current almanac (i.e., <3.5 days from current date and time). If it is, a Predictive FDE Request message requesting "Detection Availability" with a required HAL of 0.3NM is sent to the GPS/SBAS receiver. In response, the GPS/SBAS receiver replies with a sequence of Predictive FDE Response messages. These messages are parsed and used to fill in the RAIM Prediction result area at the bottom of the screen. The RAIM Prediction result area shows the RAIM Prediction results as "OK" or "XX" for ETA  $\pm$  in 5-minute increments. Once a prediction is complete, **START OVER (L1)** appears to allow the pilot to perform another prediction without having to exit the RAIM Prediction screen.

## 5.12. Active Flight Plan (ACTV) Menu

### 5.12.1. Main Menu



**Figure 5-32: Active Flight Plan Main Menu**

Upon activation of the active flight plan menu, the application checks for the existence of an active waypoint. If there is no active waypoint, **NO ACTIVE WPT** is issued. Otherwise, a selection list in the form of a Nav log of waypoints in the active flight plan is presented. The nav log shows:

- 1) Each waypoint identifier and characterization (default, overfly [**OF**] or no radius [**OR**]);
- 2) A symbol designating waypoint type and what type of procedure (if any) the waypoint is associated with, and whether the waypoint is subject to a parallel offset (“PTK”);

- 3) VNAV altitudes and offsets associated with each waypoint;
- 4) Information related to the flight plan path between each waypoint.

In the case of an approach with a Final Approach Segment data block, the VNAV Offset readout associated with the Missed Approach Point is “GPI” to designate distance to the Glidepath Intercept point. When courses are presented as part of the path information, they are displayed referenced to magnetic North with the degree (°) symbol.

VNAV altitudes and offsets from the navigation database or manually entered are shown in white, and offsets altitudes computed automatically are shown in gray. The current active waypoint is designated by an asterisk and shown in magenta and turns amber (yellow) in the event of a GPS Loss of Navigation caution.

A suppressed waypoint (designated by brackets) is an airport associated with an IFR or VFR approach procedure. After an approach procedure is activated, the associated airport is no longer part of the active flight plan for guidance purposes. However, the associated airport is still shown in the nav log so it may be highlighted for information or to activate other procedures to the airport. Since there may only be one approach active at any given time, there may only be one suppressed waypoint at any given time.

A skipped waypoint is a waypoint associated with a dynamic termination leg with a zero length. These are either:

- 1) An altitude termination leg when current aircraft altitude is above the termination altitude; or
- 2) System-created (i.e., not NavData specified) intercept to a “Course to a Fix” leg where there is insufficient distance to calculate an intercept heading.

Scroll through each waypoint of the flight plan and one position past the end to add a waypoint to the end of the active flight plan. If not, the application makes the selected waypoint active. Otherwise, an option list is presented.

Upon selection of a waypoint from the selection list, the EFIS checks to see whether the selected waypoint meets the criteria for waypoint activation, manual VNAV parameter entry, custom holding pattern entry, manual overfly characterization, VFR approach entry, IFR

approach entry, STAR entry, or DP entry. If it does, an option list is presented as follows:


- 1) **WAYPOINT:** If the selected waypoint is neither suppressed, skipped nor a manual termination, make the selected waypoint the active waypoint with this option.
- 2) **VNAV:** If the selected waypoint is neither suppressed, skipped, a manual termination, part of an IFR approach, nor part of a VFR approach nor a parallel offset entry or exit waypoint, the pilot may enter a manual VNAV altitude and offset for the selected waypoint with this option. This level includes tiles for synchronizing the VNAV altitude to current altitude and for removing the manual VNAV altitude and offset entry. VNAV altitudes are settable in increments of 100 feet and offsets are settable in increments of 1NM.
- 3) **HOLD:** If the selected waypoint is neither suppressed, skipped, a manual termination, part of an IFR approach after the FAF/FAWP, part of a VFR approach, a holding waypoint, nor a DP anchor waypoint nor a parallel offset entry or exit waypoint, the pilot may enter a manual holding pattern at the selected waypoint with this option. The pilot may define the course, turn direction (left or right), and leg length (expressed as either distance or time) for the manual holding pattern. Holding pattern course is settable in increments of 1° and leg length is settable in increments of 1NM or a tenth of a minute.
- 4) **OFFLY/AUTO:** If the selected waypoint is neither suppressed, skipped, a manual termination, a parallel offset entry, nor exit waypoint, the pilot may change the waypoint's overfly characterization. The choices are:
  - a) **AUTO:** Reset automatic overfly characterization by the FMS system.
  - b) **OVERFLY:** Manually force the overfly characterization to be an Overfly Adjust-Exit waypoint. This forces the inbound course to go directly to the waypoint regardless of the amount of course change required.
  - c) **NO RADIUS:** Manually force the turn radius at the waypoint to be zero. This forces the inbound course and outbound course to go directly to and from the waypoint regardless of the amount of course change required. It is not possible to track a "NO RADIUS" path perfectly, but the FMS path

guidance quickly recaptures the outbound course after automatic waypoint sequencing. Designating a waypoint as a “**NO RADIUS**” waypoint affects the turn radius used to calculate procedure turn and holding pattern leg paths.

- 5) **VFR APP:** If the selected waypoint is a user waypoint with an approach bearing, a VFR approach to the user waypoint based upon the approach bearing is created, and the user waypoint is suppressed. If the selected waypoint is a VFR airport or an IFR airport with surveyed runways, the pilot is presented with a selection list of runways. After selecting a runway, a VFR approach to the runway is created, and the airport waypoint is suppressed. Activating a VFR approach automatically deletes any pre-existing IFR or VFR approaches. If a heading bug is not already active, activating a VFR approach automatically activates the heading bug on current aircraft heading and is used to define the course intercept angle.
- 6) **IFR APP:** If the selected waypoint is an airport with an IFR approach, this option is available. Upon selecting this option, the pilot is presented with a selection list of available approaches (including, if applicable, the 5-digit channel number, followed by a selection list of available transitions, if there are more than one), and a selection list of runways (if there are surveyed runways at the airport). After selection, the appropriate IFR approach is created and the airport waypoint is suppressed. Activating an IFR approach automatically deletes any pre-existing IFR or VFR approaches. If there is a pre-existing STAR to the airport, the IFR approach waypoints are inserted after the STAR waypoints. If a heading bug is not already active, and the activated transition is “Vectors to Final”, activating an IFR approach automatically activates the heading bug on current aircraft heading for purposes of defining the course intercept angle.
- 7) **STAR:** If the selected waypoint is an airport with a STAR, this option is available. Upon selecting this option, the pilot is presented with a selection list of available STARs, followed by a selection list of available transitions (if there are more than one), and a selection list of runways (if there are surveyed runways at the airport). After selection, the appropriate STAR is created. Activating a STAR automatically deletes any pre-existing STAR. If there is a pre-existing approach (IFR or VFR) to the airport, the STAR waypoints are inserted prior to the approach waypoints.

- 8) **DP:** If the selected waypoint is an airport with a DP, this option is available. Upon selecting this option, the pilot is presented with a selection list of DPs, followed by a selection list of available transitions (if there are more than one), and a selection list of runways (if there are surveyed runways at the airport and more than one runway is authorized for the DP). After selection, the appropriate DP is created and upon activation, automatically deletes any pre-existing DPs.

### 5.12.2. Active Flight Plan (ACTV) Menu Options



**Figure 5-33: Active Flight Plan Menu Options**

Various options appear at the same menu level as the nav log selection list. These options allow various modifications to be made to the active flight plan as follows:

- 1) **SAVE (L1)**: Saves the active flight plan. Stored flight plans are saved without procedures or phantom waypoint (this is a safety item as procedures potentially change every 28 days). Stored flight plans are named by their first and last waypoints. If the new stored flight plan has the same start and end points as a previously saved flight plan but has different routing, a number (0 - 9) are appended to the name to uniquely identify up to 10 routings with the same start and end points.
- 2) **ACTV OFF (L2)**: Deletes the active flight plan. The pilot is prompted to confirm deletion prior to completion of the operation.
- 3) **INFO (L3)**: Activates the information menu option for the highlighted waypoint.
- 4) **PTK (L4)**: Shown if the active leg can be offset and allows the pilot to specify a parallel offset distance applying to the active and contiguous legs. The range of parallel offsets can be from 20NM left of track to 20NM right of track in 1NM increments.
- 5) **INSERT/ADD (R2)**: Allows the pilot to insert or add a waypoint or airway into the active flight plan. If the highlighted position is one position past the end of the active flight plan, the tile is **ADD**, otherwise it is **INSERT**. When the highlighted waypoint is the second or subsequent waypoint of a procedure, the tile does not appear. This prevents corruption of IFR approaches, STARS, and DPs. When activated, the pilot is prompted to enter an identifier. Performing a search for waypoints requires the entry of at least two characters. If only one character is entered, only airways are searched.

For waypoints, if there is a single result from the search, the result is inserted or added to the active flight plan. If there is no result from the search, the pilot is re-prompted to enter an identifier. If there are multiple results from the search, a selection list with matching identifiers is presented and, upon selection, the selected waypoint is inserted or added to the active flight plan. **INFO (L3)** appears at this level to give access to information for the highlighted result and aid in selection.

- 6) **AIRWAY (R4)**: This option only appears when an airway transits through the waypoint prior to the insertion point. When activated, a search is performed for all airways going through the waypoint prior to the insertion point. After the search, a selection list with airway identifiers is presented and, upon



selection, a list of airway waypoints is shown for pilot to select the desired exit point. Upon selecting the desired exit point, all airway waypoints from the waypoint prior to the insertion point to the desired exit point are inserted or added to the flight plan.

- 7) **NRST APT (L2)**: This option performs a search for 20 airports within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (e.g., no airports within 240NM with a runway length greater than or equal to the minimum runway length setting), **NO RESULTS** is displayed. Otherwise, a selection list is displayed including identifier, bearing, and distance to each result. Upon selecting a result from the selection list, the item is inserted or added to the flight plan. **INFO (L3)** appears at this level to give access to information for the highlighted result and aid in selection. Highlighted result information includes datalinked weather information when available. With optional datalink, WX LGND and EXPND WX tiles are available at this level to show a weather symbol legend and highlighted result METAR and TAF text respectively.
- 8) **NRST FIX (R2)**: This option performs a search for 20 fixes within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no fixes within 240NM), **NO RESULTS** is displayed. Otherwise, a selection list is displayed including identifier, bearing, and distance to each result. Upon selecting a result from the selection list, the item is inserted or added to the flight plan. **INFO (L3)** appears at this level to give access to information for the highlighted result and aid in selection.
- 9) **NRST NDB (L4)**: This option performs a search for 20 NDBs within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no NDBs within 240NM), **NO RESULTS** is displayed. Otherwise, a selection list is displayed including identifier, bearing, and distance to each result. Upon selecting a result from the selection list, the item is inserted or added to the flight plan. **INFO (L3)** appears at this level to give access to information for the highlighted result and aid in selection.

- 10) **NRST USR (R3)**: This option performs a search for 20 user waypoints within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no user waypoints within 240NM), **NO RESULTS** is displayed. Otherwise, a selection list is displayed including identifier, bearing, and distance to each result. Upon selecting a result from the selection list, the item is inserted or added to the flight plan. **INFO (L3)** appears at this level to give access to information for the highlighted result and aid in selection.
- 11) **NRST VOR (L3)**: This option performs a search for 20 VORs within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no VORs within 240NM), **NO RESULTS** is displayed. Otherwise, a selection list is displayed including identifier, bearing, and distance to each result. Upon selecting a result from the selection list, the item is inserted or added to the flight plan. **INFO (L3)** appears at this level to give access to information for the highlighted result and aid in selection.

Identifier Entry Box: The pilot has the option to enter an identifier. Performing a search for waypoints requires the entry of at least two characters. If there is a single result from the search, the result is inserted or added to the active flight plan. If there is no result from the search, the pilot is re-prompted to enter an identifier. If there are multiple results from the search, a selection list with matching identifiers is presented and, upon selection, the selected waypoint is inserted or added to the active flight plan. **INFO (L3)** appears at this level to give access to information for the highlighted result and aid in selection.

- 12) **DELETE (R3)**: Not shown if the highlighted waypoint is a parallel offset entry or exit waypoint. Otherwise the highlighted waypoint is a non-procedure waypoint, the function deletes the highlighted waypoint from the active flight plan. If the highlighted waypoint is part of a procedure, the function deletes the entire procedure from the active flight plan after confirmation. This tile does not appear if the highlighted waypoint is a non-procedure waypoint and there are fewer than three non-procedure waypoints in the active flight plan. This is because an active flight plan must always have at least two non-procedure waypoints. The tile also does not appear when the highlighted

waypoint is suppressed or when the highlighted position is one position past the end of the active flight plan.

- 13) **DIRECT (R8)**: Not shown if the highlighted waypoint is a parallel offset entry or exit waypoint. Otherwise, inserts a phantom waypoint at the current aircraft location and makes the highlighted waypoint active. The phantom waypoint is a fly-over defined entry waypoint and the leg prior to the phantom waypoint is designated a discontinuity. This assures the skyway is “re-centered” to provide guidance to the new active waypoint. This tile does not appear when the highlighted waypoint is suppressed or when the highlighted position is one position past the end of the active flight plan.

### 5.13. Active Flight Plan (ACTV) Menu Options



- 1) Press **ACTV (L2)** to view current ACTIVE Flight Plan.
- 2) Scroll **1** to desired waypoint and push to enter.
- 3) Scroll **1** to desired option and push to enter.
- 4) As one option, a VNAV setting is entered.
- 5) As another option, deleting the next waypoint (IGN) is accomplished.

Figure 5-34: Active Flight Plan Menu Options (Step-By-Step)

### 5.13.1. Active Flight Plan (ACTV) Menu (Step-By-Step)



- 1) With the desired flight plan selected and activated, press **ACTV (L2)** to view ACTIVE flight plan.
- 2) Scroll **1** to desired waypoint option and push to enter.
- 3) Another option scroll to **OFLY/AUTO** and push to enter.
- 4) After selecting **NO RADIUS**, push to enter.
- 5) View ACTIVE flight plan with waypoint characterization indicated.
- 6) Scroll **1** to desired option and push to enter.

Figure 5-35: Active Flight Plan Menu (Step-By-Step)


### 5.13.2. Active Flight Plan (ACTV) Options NRST Menu Option (Step-By-Step)



- 1) With Active flight plan displayed, press **INSERT (R2)** to see NRST options.
- 2) Press **NRST APT (L2)**, **NRST VOR (L3)**, **NRST NDB (L4)**, **NRST FIX (R2)**, **NRST USR (R3)**, or **AIRWAY (R4)** to view applicable list, scroll **1** to desired selection and push to insert into ACTIVE flight plan.
- 3) If desired, press **SAVE (L1)** to save this active flight plan as one of the 100 stored flight plans. (Any procedure within the saved active flight plan is not saved.)

**Figure 5-36: Active Flight Plan Options NRST Menu Option (Step-By-Step)**

### 5.14. Information (INFO) Menu



**Figure 5-37: Information Menu**

If **INFO (L3)** is activated from within the **ACTV**, **NRST**, or **Direct** menus, information on the highlighted waypoint from the applicable selection list is shown directly. Otherwise, the function checks for a current active waypoint. If there is an active waypoint, the active waypoint becomes the default entry. If there is no active waypoint, the nearest airport becomes the default entry. If the default entry is accepted, information for the default entry is shown. If the pilot rejects the default entry by entering identifier characters, a search for matching identifiers is performed. If there is a single result from the search, information for the result is shown. If there is no result from the search, the pilot is re-prompted to enter an identifier. If there are multiple results from the search, a selection list with matching identifiers is presented for the pilot to select the desired identifier.

The amount and type of information presented depends upon the type of waypoint as follows:

- |                             |                               |
|-----------------------------|-------------------------------|
| 1) Waypoints                | 7) Latitude/Longitude         |
| 2) Identifier               | 8) Navigation Aides           |
| 3) Type                     | 9) Frequency                  |
| 4) Elevation (if available) | 10) Airports                  |
| 5) Long Name                | 11) Communication frequencies |
| 6) Bearing and distance     | 12) Runway data               |

For remote tuning, a single frequency is associated with the waypoint, tiles allow transmission of the frequency to remote NAV or COM radios. **TO COM1** or **TO NAV1 (R2)**, while **TO COM2** or **TO NAV2 (R3)**. If more than one frequency is associated with the waypoint (e.g., airport waypoint), tiles are shown to allow transmission of a frequency to remote NAV or COM radios when a frequency is highlighted in the **INFO** block. If the frequency is less than 118MHz, the tiles read **TO NAV#** and the transmission is addressed to NAV radios. If the frequency is greater than or equal to 118MHz, the tiles are **TO COM#**, and the transmission is addressed to COM radios.

Where remote tuning is enabled for Garmin SL-30/40 radios, only a single ("**TO COM**" or "**TO NAV**") tile is shown. Where remote tuning is enabled for Honeywell KX155A/165A and Wulfsberg Flightline radios are installed, a "**TO COM1**" or "**TO NAV1 (R2)**" tile is shown, while a "**TO COM2**" or "**TO NAV2 (R3)**" tile is shown. Where remote tuning is enabled and an L-3 ADR7050 is configured for tuning from the EFIS audio radio page, a "**TO COM1**" or "**TO NAV1 (R2)**" tile is shown, while a "**TO COM2**" or "**TO NAV2 (R3)**" tile is shown.

When airport weather is presented in the information block, a "**WX LGND (L2)**" is shown to allow display of an airport graphical METAR legend and an "**EXPND WX (L3)**" is shown to allow the display of textual METAR and TAF data for the airport.

#### **NOTE:**

Frequencies are only sent to either Com or Nav radios in the standby position. It is up to the pilot to swap frequencies to the active position in the applicable radio.



When the information is being presented for an ILS or localizer waypoint and the current VLOC1 or VLOC2 omnibearing selectors are not synchronized with the localizer course, **CRS SYNC (L4)** allows one-touch synchronization of the VLOC1 and VLOC2 omnibearing selectors to the localizer course (See Figure 5-38).



**Figure 5-38: CRS SYNC**

### 5.14.1. Information (INFO) Menu (Step-By-Step)




1) Press **INFO (L3)** to view current active waypoint.

2) Push **1** to view information.

**Figure 5-39: Information (Step-By-Step)**

## 5.15. Omnibearing Selector (OBS) Menu



**Figure 5-40: Omnibearing Selector (OBS) Menu**

The OBS (L4) menu allows the pilot to control the setting of the omnibearing selector for purposes of showing course deviations. The OBS for **FMS** (L2) allows the pilot to specify either a manual or automatic OBS setting in which the current active OBS is controlled by the active flight plan. The OBS for VLOC1 allows the pilot to specify the active OBS setting for the VLOC1 navigation function. The OBS for VLOC2 allows the pilot to specify the active OBS setting for the VLOC2 navigation function. Manual FMS, **VLOC1** and **VLOC2 OBS** settings are settable in increments of 1°. **OBS SYNC** (R3) is available to synchronize the Manual FMS, **VLOC1** or **VLOC2 OBS** settings (depending upon HSI source) to the inbound course or, if the inbound course cannot be determined, to aircraft heading. When HSI source is FMS, **OBS AUTO/OBS MAN** (R4) is available to toggle between automatic and manual OBS settings.

With VOR symbology enabled, the OBS function also permits the pilot to select either **FMS**, **VLOC1**, or **VLOC2** as the HSI source. The HSI source selects the navigation source used to generate HSI guidance symbology. The OBS function also permits the pilot to select between manual and automatic RNP settings. Upon selecting


the RNP tile, **RNP AUTO/RNP MAN** is available to toggle between automatic and manual RNP settings. Manual RNP is selectable between 0.10NM and 15NM as follows:

- 1) 0.01NM increments between RNP 0.10 and RNP 0.3
- 2) 0.1NM increments between RNP 0.3 and RNP 2
- 3) 1NM increments between RNP 2 and RNP 15

### 5.15.1. Omnibearing Selector (OBS) Menu (Step-By-Step)




- 1) Before pressing **OBS (L4)** to make any OBS changes, view the current setting to see **FMS1** is selected.



- 2) Press **OBS (L4)** then make HSI source selection or change to **OBS MANUAL (R4)**.

**Figure 5-41: Omnibearing Selector (OBS) (Step-By-Step)**

## 5.16. Heading Bug (HDG) Menu



**Figure 5-42: Heading Bug (HDG) Menu**

The heading bug menu allows the pilot to set the heading bug in increments of 1°, synchronize the heading bug to current heading, or turn off the heading bug.


### 5.16.1. Heading Bug (HDG) Menu (Step-By-Step)



- 1) Scroll **3** to enter Heading mode.
- 2) Scroll **3** to change heading bug in 1° increments.
- 3) Push **3** to select new heading or press **SYNC (L7)** to sync current heading or press **OFF (L8)** if desired.

**Figure 5-43: Heading Bug (HDG) Menu (Step-By-Step)**

## 5.17. Nearest (NRST) Menu



**Figure 5-44: Nearest (NRST) Menu**

Upon activating the nearest menu, an option list appears to allow the pilot to select from a list of the following categories:

- |             |                   |                      |
|-------------|-------------------|----------------------|
| 1) Airports | 4) NDBs           | 7) ARTCC frequencies |
| 2) VORs     | 5) Fixes          | 8) FSS frequencies   |
| 3) ILSs     | 6) User waypoints | 9) Weather           |

Upon selecting a category from the option list, a selection list of up to 20 items within 240NM matching the category appears. If the list is empty (i.e., no items within 240NM), **NO RESULTS** is displayed. The selection list includes identifier, bearing and distance to the item. The selection list for airports also contains an indication of the

longest runway length at the airport. The selection lists for airports contain only airports with runway length greater than or equal to the minimum runway length setting when the system was configured during installation.

The selection list for airports, VORs, ILSs, NDBs, ARTCCs and FSSs includes an associated frequency (CTAF in the case of airports). Tiles are shown to allow transmission of the associated frequency to remote NAV or COM radios. If the frequency is greater than or equal to 118MHz, the tiles read **TO COM#** and the transmission is addressed to COM radios. If the frequency is less than 118MHz, the tiles read **TO NAV#** and the transmission is addressed to NAV radios. A **TO COM1** or **TO NAV1 (R2)**, while a **TO COM2** or **TO NAV2 (R3)** position.

#### NOTE:

Frequencies are only sent to either Com or Nav radios in the standby position. It is up to the pilot to swap frequencies to the active position in the applicable radio.

When the results for airports, VORs, NDBs, fixes, and user waypoints are being displayed, **INSERT (R2)** allows the pilot to quickly insert a waypoint into the active flight plan at the current active waypoint position. This feature is intended to facilitate rapid clearance changes from air traffic control. **INSERT (R2)** appears, if the current active waypoint is within a procedure. This prevents corruption of IFR approaches, STARs, and DPs.

When the results for airports, VORs, ILSs, NDBs, fixes, and user waypoints are being displayed, **INFO (L3)** activates the information function and provides further information on the highlighted item.

In the case of **NRST ILS** where the current VLOC1 or VLOC2 OBS does not match the localizer course, **CRS SYNC (L4)** is presented to synchronize VLOC1 and VLOC2 OBS to the localizer course.

Upon selecting a waypoint of type airport, VOR, NDB, fix or user waypoint, a new active flight plan is created from present aircraft position to the selected waypoint. Upon selecting a waypoint of type ILS, **CONFIRM ACTIVATE ILS** is displayed. When the pilot confirms the ILS activations, the following actions occur:

- 1) A direct flight plan to the airport associated with the ILS is created;


- 2) A vectors-to-final ILS approach to the ILS is activated;
- 3) If the heading bug is OFF, the heading bug is activated to current heading to act as a starting point for receiving vectors.
- 4) The VLOC1 and VLOC2 OBS settings are set to the associated localizer course;
- 5) HSI source is switched as follows:
  - a) If there is only one NAV radio installed, the source for the selecting side is changed to **VLOC1**. The source for the other side does not change.
  - b) If there are two NAV radios installed, the default sensor for the selecting side controls which source is used. The source for the other side does not change.
- 6) Connected NAV radios are remote tuned to ILS frequency.



### 5.17.1. Nearest (NRST) Menu (Step-By-Step)



1) Press **NRST (R2)** to enter Nearest Menu.



2) Scroll **1** to select **APT** from list then push to enter.



3) Scroll **1** to desired airport and push to select.

**Figure 5-45: Nearest (NRST) Menu (Step-By-Step)**


### 5.17.2. Nearest (NRST) Menu ILS



- 1) Press **NRST (R2)** to enter Nearest Menu.
- 2) Scroll **1** to select **ILS** from list then push to enter.
- 3) Scroll **1** to desired airport and ILS approach then push to select and enter.
- 4) Push **1** to confirm and activate ILS.

**Figure 5-46: Nearest (NRST) Menu ILS**

### 5.18. Direct Menu



**Figure 5-47: Direct Menu**

Upon activating the direct menu from the top-level menu, the function checks for a current active waypoint. If there is an active waypoint, the active waypoint becomes the default entry. If there is no active waypoint, the nearest airport becomes the default entry.

If the default entry is the active waypoint and is accepted by the pilot, a phantom waypoint is inserted at the current aircraft location. The phantom waypoint is a fly-over defined entry waypoint, and the leg prior to the phantom waypoint is designated a discontinuity. This assures the skyway is “re-centered” to provide guidance to the new active waypoint. The rest of the active flight plan remains unchanged.

If the default entry is not the active waypoint and is accepted by the pilot, the resulting action depends upon whether the aircraft is in the air or on the ground. If in the air, a new active flight plan is created from present aircraft position to the selected waypoint. If on the ground, a search is conducted for a database airport within 6NM. If an airport is found, a new active flight plan is created from the found airport to the selected waypoint. Otherwise, a new active flight plan is created from present aircraft position to the selected waypoint.

If the pilot rejects the default entry by entering identifier characters, a search for matching identifiers is performed. If there is a single result from the search, the resulting action depends upon whether the aircraft is in the air or on the ground. If in the air, a new active flight plan is created from present aircraft position to the selected waypoint. If on the ground, a search is conducted for a database airport within 6NM. If an airport is found, a new active flight plan is created from the found airport to the selected waypoint. Otherwise, a new active flight plan is created from present aircraft position to the selected waypoint.

If there is no result from the search, the pilot is re-prompted to enter an identifier. If there are multiple results from the search, a selection list with matching identifiers is presented. Upon selection, the resulting action depends upon whether the aircraft is in the air or on the ground. If in the air, a new active flight plan is created from present aircraft position to the selected waypoint. If on the ground, a search is conducted for a database airport within 6NM. If an airport is found, a new active flight plan is created from the found airport to the selected waypoint. Otherwise, a new active flight plan is created from present aircraft position to the selected waypoint. **INFO (L3)** appears at this level to give access to information for the highlighted result and aid in selection.


### 5.18.1. Direct Menu (Step-By-Step)



- 1) Press **DIR** (R4) to enter the Direct menu.
- 2) The current active waypoint appears.
- 3) Either push **1** to insert a phantom waypoint at the current aircraft location or scroll **1** to begin entering new identifier.
- 4) After creating new identifier, scroll **1** to the end and push to enter. A new active flight plan is created from the present aircraft position.
- 5) If necessary **SEARCH** (R4) maybe pressed to complete the search of waypoints in the database. Scroll **1** to desired waypoint and push to enter.

**Figure 5-48: Direct Menu (Step-By-Step)**

## 5.19. Timer (TIMER) Menu



**Figure 5-49: Timer (TIMER) Menu**

Upon selecting the timer menu, an option list appears for the pilot to choose the count up timer, countdown timer, or flight time display. **OFF (R4)** also appears to turn off any active timer functions.

If the pilot selects the count up timer, the count up timer is activated. If the pilot selects the countdown timer, the pilot is prompted to enter a start time from which the countdown begins. Shortcuts to quickly add or decrement by five minute increments are provided at this level. After entering a start time, the pilot is able to either start the countdown timer or select **STORE (R4)** to store the start time for later use.

If the pilot selects the flight time display option, the current elapsed time since the aircraft transitioned from ground to air mode is displayed for 10 seconds or until any button is pressed. If the aircraft has not yet transitioned from ground to air mode, upon selecting the flight time display option, the elapsed time is displayed as **FLT TM: 00:00:00**.


### 5.19.1. Timer (TIMER) Menu (Step-By-Step)



- 1) Press **MENU (R1)**.
- 2) Press **TIMER (L4)** to enter the Timer menu.
- 3) Scroll **1** to select **COUNT UP**, **COUNT DN.**, or **FLT TIME**.
- 4) If **COUNT UP** is selected, a timer appears on the PFD area below the bank scale
- 5) To turn off timer, press **MENU (R1)** and **TIMER(L4)** then press **OFF (R4)**.

**Figure 5-50: Timer Menu (Step-By-Step)**

## 5.20. PFD Source (SOURCE) Menu




**Figure 5-51: PFD Source (SOURCE) Menu**

Upon activating the PFD source menu, an option list of sensor sources is shown if enabled during configuration. Select or deselect the following items:

- |            |                           |
|------------|---------------------------|
| 1) ADC1;   | 6) EICAS2;                |
| 2) ADC2;   | 7) GPS1;                  |
| 3) AHRS1;  | 8) GPS2;                  |
| 4) AHRS2;  | 9) Radar Altimeter 1; and |
| 5) EICAS1; | 10) Radar Altimeter 2.    |

### 5.21. PFD Bug (BUGS) Menu



**Figure 5-52: PFD Bug (BUGS) Menu**






Figure 5-53: PFD Bug (BUGS) Menu (Continued)

Upon selecting the PFD BUGS menu, set either minimums (**MINS**) (**R3**), an airspeed bug (**IAS**) (**L2**), the VNAV climb or descent angle (**VNAV CDA**) (**R4**), V-speeds (**V-SPDS**) (**L3**), or vertical speed (**VSI**) (**L4**).

Selecting the minimums option brings up a further option list for setting either decision height or minimum altitude. Selecting the minimum altitude option allows the pilot to either, synchronize the minimum altitude to current altitude, turn the minimum altitude off, or set the minimum altitude in increments of 10 feet. Selecting the decision height option allows the pilot to either set the decision

height to a default height of 200 feet, turn the decision height off, or set the decision height in increments of 10 feet.

Selecting the airspeed bug option allows the pilot to either synchronize the airspeed bug to current airspeed, turn the airspeed bug off, or set the airspeed bug in increments of 1 knot indicated airspeed. On the low end, airspeed bug settings are no less than 1.2  $V_S$  or 60KIAS, whichever is higher.  $V_S$  is derived from the higher of the  $V_S$  aircraft limits setting or the pilot-input  $V_{REF}$  value divided by 1.23. On the high end, airspeed bug settings are limited to the aircraft redline.

#### NOTE:

When integrated with an Intelliflight 1950 autopilot and in the IAS mode, it is not possible to turn off the airspeed bug.

Selecting the VNAV climb or descent angle option brings up a further option list for setting either climb angle or descent angle. At this further level, selecting either option allows the pilot to set the climb angle or the descent angle (as appropriate) in increments of  $0.1^\circ$  (a value of 0 is not allowed). Corresponding feet per nautical mile are shown adjacent to the climb or descent angle setting in parentheses. In addition, a shortcut tile is available to set the climb or descent angle to  $3^\circ$ .


Selecting the V-speed option brings up a further option list for setting either takeoff V-speed ( $V_1$ ,  $V_R$ ,  $V_2$ , and  $V_{ENR}$ ) or approach V-speeds ( $V_{REF}$  and  $V_{APP}$ ). Selecting the takeoff V-speed option allows the pilot to set takeoff V-speeds ( $V_1$ ,  $V_R$ ,  $V_2$ , and  $V_{ENR}$ ) in sequence. Selecting the approach V-speed option allows the pilot to set approach V-speeds ( $V_{REF}$  and  $V_{APP}$ ) in sequence.

Selecting the VSI bug option allows the pilot to either synchronize the VSI bug to the current VSI, turn the VSI bug off, or set the VSI bug in increments of 100 feet per minute.


#### NOTE:

The airspeed bug and VSI bug are mutually exclusive and therefore selecting one turns off the other.

### 5.21.1. PFD Bug (BUGS) Menu (Step-By-Step)



- 1) Press **MENU (R1)** then **BUGS (R2)** to enter the Bugs menu.



- 2) Press either **IAS (L2)**, **VSI (L4)**, **MINS (R3)**, or **VNAV CDA (R4)** to select desired menu.



- 3) If IAS was entered, either press **SYNC (R3)** or **OFF (R4)** to accept or turn off IAS bug.



- 4) If a different IAS bug is desired, scroll **1** to select desired airspeed and push to enter new value.


**Figure 5-54: PFD BUGS Menu (Step-By-Step)**



Figure 5-55: PFD BUGS (Step-By-Step)

- 1) If **MINS (R3)** was selected, scroll **1** to select either **DEC HT..** or **MIN ALT..** and push to enter.
- 2) If **DEC HT..** was selected, scroll **1** to create new decision height and push to enter.
- 3) The new DH displays on the PFI area below the FPM.
- 4) If **VNAV CDA (R4)** was selected, scroll **1** to select either **DCND..** or **CLIMB..** and push to enter.
- 5) If **DCND..** was selected, scroll **1** to create the descent angle.
- 6) Push **1** to enter new descent angle or select default 3°.

## 5.22. Remote Bugs Panel



**Figure 5-56: Remote Bugs Panel**

The Remote Bugs Panel (RBP) provides dedicated controls for frequently needed bugs and additional controls for setting IDU parameters such as defined in the table below.

The RBP has an internal light sensor to control its own initial display and backlight brightness. Press the two arrow buttons simultaneously to gain access for brightness control and use the multifunction encoder to make brightness adjustments. Press the option button to exit the brightness control program and return the RBP to normal operation.

The design of this RBP promotes the ease of operation while minimizing pilot workload complexity. The HDG and ALT encoders behave exactly as the encoders on the IDU-680 where they appear during most screen configurations. During initialization, the RBP always begin with GENESYS RBP displayed on the main and option display screens.

**Table 5-3: Remote Bugs Panel (RBP)**

<b>Button/ Encoder</b>	<b>Function</b>	<b>Scroll</b>	<b>Press/Push</b>
Heading Encoder	Heading Bug	Increment or decrement heading bug	Synchronize heading bug to current heading
Altitude Encoder	Altitude Bug	Increment or decrement target altitude bug	Synchronize target altitude bug to current altitude
Multifunction Encoder	GPS Course	Increment or decrement GPS Course setting	Synchronize GPS Course to current bearing to active waypoint
Multifunction Encoder	VOR 1 Course	Increment or decrement VOR 1 Course setting	Synchronize VOR 1 Course to current bearing to station
Multifunction Encoder	VOR 2 Course	Increment or decrement VOR 2 Course setting	Synchronize VOR 2 Course to current bearing to station
Multifunction Encoder	Airspeed Bug	Increment or decrement Airspeed Bug setting	Synchronize Airspeed Bug to current Airspeed
Multifunction Encoder	Vertical Speed Bug	Increment or decrement Vertical Speed Bug setting	Synchronize Vertical Speed Bug to current VSI
Multifunction Encoder	Climb Angle Set	Increment or decrement Climb Angle setting	Set Climb Angle Setting to 3°
Multifunction Encoder	Descent Angle Set	Increment or decrement Descent Angle setting	Set Descent Angle Setting to 3°

**Table 5-3: Remote Bugs Panel (RBP)**


<b>Button/ Encoder</b>	<b>Function</b>	<b>Scroll</b>	<b>Press/Push</b>
Multifunction Encoder	Decision Height Bug	Increment or decrement Decision Height Bug	Set Decision Height Bug to 200' AGL
Multifunction Encoder	Minimum Altitude Bug	Increment or decrement Minimum Altitude Bug	Set Minimum Altitude to current altitude
Option "----" Button	GPS Course	N/A	Change OBS mode (Manual or Automatic)
Option "----" Button	VOR 1 Course	N/A	No Function
Option "----" Button	VOR 2 Course	N/A	No Function
Option "----" Button	Airspeed Bug	N/A	Toggle Airspeed Bug (On or Off)
Option "----" Button	Vertical Speed Bug	N/A	Toggle Vertical Speed Bug (On or Off)
Option "----" Button	Climb Angle Setting	N/A	No Function
Option "----" Button	Descent Angle Setting	N/A	No Function
Option "----" Button	Decision Height Bug	N/A	Toggle Decision Height Bug (On or Off)
Option "----" Button	Minimum Altitude Bug	N/A	Toggle Decision Height Bug (On or Off)

**Table 5-3: Remote Bugs Panel (RBP)**

Button/ Encoder	Function	Scroll	Press/Push
Arrow Buttons	Function Scroll	N/A	Scroll through possible "Set" encoder functions. Press both arrow buttons simultaneously to place RBP into dimming mode
VNAV Button	VNAV	N/A	Switch EFIS autopilot pitch steering and commanded VSI between VNAV sub-mode and target altitude sub-mode
LNAV Button	LNAV	N/A	Switch EFIS autopilot roll steering between LNAV sub-mode and heading sub-mode



## 5.23. PFD Declutter (DCLTR) Menu



**Figure 5-57: PFD Declutter (DCLTR) Menu**

Upon activating the PFD declutter menu, an option list of declutter items is shown. In Normal Mode, select or deselect the following items:

- 1) PFD analog AGL indicator;
- 2) Full-time or auto-decluttered bank scale display;
- 3) Basic Mode (switches PFD to Basic Mode);
- 4) PFD mini-map;
- 5) Skyway guidance symbology;

- 6) Non-TAWS perspective terrain and obstacle depiction (mutually exclusive with TAWS perspective terrain and obstacle depiction);
- 7) TAWS perspective terrain and obstacle depiction (mutually exclusive with Non-TAWS perspective terrain and obstacle depiction);
- 8) Single Cue Flight Director symbology and mutually exclusive with Dual Cue Flight Director symbology;
- 9) Dual Cue Flight Director symbology and mutually exclusive with Single Cue Flight Director symbology;
- 10) Perspective traffic depiction;
- 11) Turn rate indication;
- 12) Metric display of barometric altitude and target altitude bug setting.

In Basic Mode, select or deselect the following items:

- 1) PFD analog AGL indicator;
- 2) Basic Mode (switches PFD back to Normal Mode);
- 3) PFD mini-map;
- 4) Single Cue Flight Director symbology and mutually exclusive with Dual Cue Flight Director symbology;
- 5) Dual Cue Flight Director symbology and mutually exclusive with Single Cue Flight Director symbology; and
- 6) Metric display of barometric altitude and target altitude bug setting.

**NOTE:**

When integrated with the Intelliflight 1950, it is only be possible to toggle between the single cue and dual cue flight director options (e.g., it is not possible to turn both OFF). This is because the display of the flight directors when integrated with the Intelliflight 1950 is controlled through the mode control panel.


**NOTE:**

**RESET G (L2)** option is within the PFD declutter menu for conditions when a G-Force has been displayed and remains in the PFI area and has not exceeded the maximum positive and negative values in the aircraft limits. The following do not appear if a G-Force is not displayed.



**Figure 5-58: PFD Declutter (DCLTR) Menu with RESET-G**


### 5.23.1. PFD Declutter (DCLTR) Menu (Step-By-Step)



- 1) Press **MENU (R1)** then **DCLTR (R4)** to enter the Declutter menu.
- 2) Scroll **1** to select either **ANLG AGL**, **BANK SCL**, **BASIC**, **MINI MAP**, **MINI TRFC**, **SKYWAY**, **SVS TAWS**, **SVS BASIC**, **TRAFFIC**, **TURN IND**, **TERRAIN**, **FD1**, **FD2**, **METERS**, or **EICAS OVRL** and push to enter.
- 3) If **BANK SCL** is unchecked and is scrolled to **DONE**, push to enter.
- 4) The Bank Scale is removed while in level flight.

**Figure 5-59: PFD Declutter (DCLTR) Menu (Step-By-Step)**

## 5.2.4. PFD Altimeter Menu




**Figure 5-60: PFD Altimeter Menu**

Press **BARO (R2)** to activate the altimeter menu. In the altimeter menu, scroll the encoder to increment (clockwise) or decrement (counter-clockwise) the barometric setting. Press the encoder to accept the new barometric setting. In addition, the following options are available in the altimeter menu:

- 1) **QNH/QFE (L2)**: Toggles between QNH altimeter operation and QFE altimeter operation. When in QNH mode, QNE operation is automatically selected when above the transition altitude with a standard altimeter setting. The following definitions:
  - a) **QFE**: Barometric setting resulting in the altimeter displaying height above a reference elevation (e.g., airport or runway threshold).
  - b) **QNE**: Standard barometric setting (29.92 inHg or 1013 mbar) used to display pressure altitude for flight above the transition altitude.
  - c) **QNH**: Barometric setting resulting in the altimeter displaying altitude above mean sea level at the reporting station.

- 2) **TRANS ALT (L3)**: Allows the pilot to change the transition altitude used by the system in units of 1000 feet. Transition altitude is used to generate barometric setting warnings and to determine QNE/QNH operation. If current transition altitude is not 18,000 feet, **18000'** tile is available to quickly set 18,000 feet as the transition altitude.
- 3) **MBAR/IN HG (L4)**: Allows the pilot to select the barometric setting units (inHg or mbar).
- 4) **STD (R4)**: Sets the barometric setting to standard (29.92 inHg or 1013 mbar).


### 5.24.1. PFD Altimeter Menu (Step-By-Step)



- 1) Press **BARO (R2)** to enter the Altimeter menu.
- 2) Scroll **1** to set proper QNH and push to enter.
- 3) Crosscheck proper QNH under altitude indication.
- 4) Press **BARO** again and **STD (R4)** to reset QNH to 29.92 and push to enter.

**Figure 5-61: Altimeter Menu (Step-By-Step)**

## 5.25. MFD Fault Display (FAULTS) Menu



**Figure 5-62: MFD Fault Display Menu**

Upon selecting the MFD faults menu, the status of the following system parameters is displayed:

- 1) GPS/SBAS loss of navigation due to absence of power (GPS PWR)
- 2) GPS/SBAS loss of navigation due to probable equipment failure (GPS EQPMNT)

- 3) GPS/SBAS loss of navigation due to inadequate satellites to compute a position solution (GPS SATLT)
- 4) GPS/SBAS loss of navigation due to a position failure that cannot be excluded within the time to alert (GPS FDE)
- 5) GPS/SBAS loss of integrity and loss of navigation due to loss of integrity (GPS LOI)
- 6) Readout of the current GPS/SBAS horizontal protection level (GPS HPL) in nautical miles. This value may be used as the estimate of position uncertainty required in RNP airspace.
- 7) Readout of the current GPS/SBAS vertical protection level (GPS VPL) in meters.
- 8) Readout of the current GPS/SBAS horizontal figure of merit (GPS HFOM) in nautical miles. This value is an indication of the 95% confidence horizontal position accuracy.
- 9) Readout of the current GPS/SBAS vertical figure of merit (GPS VFOM) in meters. This value is an indication of the 95% confidence vertical position accuracy.
- 10) An indication of whether the GPS/SBAS receiver has a valid almanac in memory (GPS ALMANAC).
- 11) GPS/SBAS loss of navigation due to no valid SBAS message received for 4 seconds or more (SBAS MSG).
- 12) GPS/SBAS loss of navigation due to insufficient number of SBAS HEALTHY satellites (SBAS HLTH).
  - a) An Attitude or Range Fault Condition exists.
  - b) A Control Fault Condition exists.
  - c) A T/R Fault Condition exists.
- 13) If the WX-500 option is enabled, loss of communications with the WX-500 (WX-500).
- 14) If the traffic option is enabled, loss of communications with the traffic sensor (TRFC).
- 15) If the analog interface option is enabled, loss of communications with the analog interface (AIU).



- 16) If WSI datalink is enabled, the datalink item indicates either loss of communications with the datalink receiver (DLNK X), loss of satellite lock (DLNK NO LOCK), or the current bit error rate or the datalink (DLNK BER ###). WSI datalink is mutually exclusive with ADS-B datalink.
- 17) If ADS-B datalink is enabled, an indication of ADS-B position validity (ADSB POSN), an indication of whether maintenance of the ADS-B receiver is required (ADSB MAINT) and an indication of whether the Conflict Situational Awareness algorithm is working (ADSB CSA). ADS-B datalink is mutually exclusive with WSI datalink.
- 18) If weather radar is enabled, an indication of weather radar power/communication status (WXR PWR X or WXR PWR OK). Weather radar power/communication status failed (WXR PWR X) reflects any one of the following conditions are true:
  - a) Loss of weather radar communication
  - b) Weather radar mode is OFF.
- 19) If weather radar is enabled, an indication of weather radar fault status (WXR FAULT -, WXR FAULT X, or WXR FAULT OK). When weather radar power/communication status is failed, weather radar fault status indicates determination of weather radar faults is not possible (WXR FAULT -). Weather radar fault status failed (WXR FAULT X) reflects any one of the following conditions are true:
  - a) A Cooling Fault Condition exists
  - b) For weather radar types ARINC 708-6 or Collins 800/840, a Display or Control Bus Fault Condition exists.
  - c) For weather radar types ARINC 708-6, Collins 800/840 or Honeywell PRIMUS, a Calibration or Air Data Fault Condition exists.
  - d) An Attitude or Range Fault Condition exists.
  - e) A Control Fault Condition exists.
  - f) A T/R Fault Condition exists.
- 20) If weather radar is enabled and the weather radar type is RDR-2000 or RDR-2100, an indication of radar control panel status

(WXR RCP X or WXR RCP OK). Radar control panel status failed (WXR RCP X) indicates either loss of communication or a failure status using the same test as invalid data SSM for output labels 270, 271, 273, or 275.


### 5.25.1. MFD Fault Display (FAULTS) Menu (Step-By-Step)



- 1) Press **MENU (R1)** then **FAULTS (L1 or L5)** to view the faults menu.
- 2) View status of GPS and equipment parameters.

Figure 5-63: MFD Fault Display Menu (Step-By-Step)

## 5.26. MFD FUEL Totalizer Quantity Setting (SET FUEL) Menu




**Figure 5-64: MFD Fuel Totalizer Quantity Menu**

The fuel quantity setting menu allows the pilot to:

- 1) Set the fuel totalizer quantity in increments of volume units.
- 2) If either a fuel totalizer or fuel level sensing (with no unmonitored fuel) is configured in the aircraft limits, set emergency and minimum fuel bugs in increments of volume units.

Press **MAINS (R3)** to quickly set the quantity to the “fuel tabs” fuel capacity, and **FULL (R4)** to quickly set the quantity to the total aircraft fuel capacity. Units of measure and fuel flow are shown in the quantity window when available.

## 5.27. MFD Page (PAGE) Menu




**Figure 5-65: MFD Page (PAGE) Menu**

The **PAGE** menu allows the pilot to select which MFD page to display. Options are:

- 1) **MAP**: Shows the ND page.
- 2) **HSI**: Shows the HSI page.
- 3) **NAV LOG**: Shows the FMS page.
- 4) **STRIKES**: Shows the Strike page.
- 5) **TRAFFIC**: Shows the Traffic page.
- 6) **DATALINK**: Shows the Datalink page.

- 7) **WX-RDR**: Shows the Weather Radar page.
- 8) **VIDEO**: Shows the Video page.
- 9) **EICAS**: Shows the EICAS page. Only available on the top page menu on a MFD.
- 10) **OASIS**: Shows the selected OASIS page. Only available if OASIS pages are configured and expands to the number of OASIS pages defined (i.e., one tile per defined OASIS page). Tile text comes from the “name” parameter for the OASIS page. When in Essential Mode and the Flight Planner is shown, 640x960 pages are skipped on IDU-680 screens on the PFD (IDU #1).
- 11) **AUDIO/RADIO**: Shows the Audio/Radio page.

### 5.27.1. MFD Page (PAGE) Menu (Step-By-Step)



- 1) Select either **TOP** or **BTM** MFD to change pages.
- 2) Push and scroll **2** to select either **MAP**, **HSI**, **NAV LOG**, or **ENGINE Page** on top and push to enter.
- 3) Or push and scroll **1** to select either **MAP**, **HSI**, **NAV LOG**, or **ENGINE Page** on bottom and push to enter.

Figure 5-66: MFD Page Menu (Step-By-Step)

### 5.27.2. MFD MAP ND Page



- 1) Push **1** or **2** and scroll to **MAP** and push to enter.
- 2) Example shown is on PFD with MAP on bottom area.

Figure 5-67: MFD MAP ND Page

### 5.27.3. MFD HSI Page



- 1) Push **1** or **2** and scroll to **HSI** and push to enter.
- 2) Example shown is on PFD with HSI on bottom area.




Figure 5-68: MFD HSI Page

### 5.27.4. MFD NAV Log Page



1) Push **1** or **2** and scroll to **NAV LOG** and push to enter.




WAYPOINT	UNRA/OFFSET	PATH	DIST	ETE	ETA	FUEL
START	7500'	-D1500M'	18.2	0+00	13:09	2312
IP	7500'	-D1500M'	17.5	0+00	13:09	2312
YGSUR	1500'	B- 180°	8.5	0+00	13:11	2305
RW8B	1461'	B- 059°	3.7	0+01	13:12	2307
CCC	500'	B- 073°	0.6	0+00	13:12	2307
CCC	2000'	B- 073°	10.6	0+00	13:10	2300
CKTSP	2000'	B- 265°	11.9	0+00	13:11	2305

2) Example shown is on PFD with **NAV LOG** on bottom area.

3) This **NAV LOG** page cannot be formatted or used for editing the active flight plan.

Figure 5-69: MFD NAV Log Page

### 5.27.5. MFD ND Page Format (FORMAT) Menu



**Figure 5-70: MFD ND Page Format (FORMAT) Menu**



Upon selecting the MFD format menu when in the ND page, an option list appears with the following options:

- 1) **CENTER/ARC**: Selecting this option toggles between a centered and arced ND display format (if not panning).
- 2) **HDG UP/N UP**: Selecting this option toggles between a heading up and a North up ND display format (if not panning).
- 3) **PAN ON/PAN OFF**: Selecting this option toggles ND page pan mode.
- 4) **SYMB DCLTR**: Selecting this option activates an option list to allow the pilot to choose either automatic navigation symbol declutter or manual navigation symbol declutter. If the pilot chooses manual navigation symbol declutter, a further option list appears to allow the pilot to individually select:
  - a) large airports;
  - b) IFR airports;
  - c) VFR airports;
  - d) VORs;
  - e) NDBs;
  - f) fixes;
  - g) terminal fixes; and
  - h) user waypoints.




**Figure 5-71: MFD Symbol Declutter**

Turning on VFR airports also turns on large airports and IFR airports. Turning on IFR airports also turns on large airports. Turning off large airports also turns off IFR airports and VFR airports. Turning off IFR airports also turns off VFR airports.

- 5) **FNCT DCLTR**: Selecting this option activates an option list to allow the pilot to individually toggle display of:
- a) airspace;
  - b) borders;
  - c) datalinked NEXRAD, graphical METARs and lightning ground strikes (if datalink or ADS-B option is enabled);
  - d) estimated time of arrival (ETA);
  - e) glide range (if glide ratio is enabled and set in the limits, airplane configuration only);
  - f) high-altitude airways;
  - g) low-altitude airways;
  - h) current latitude and longitude display of ADF #1 pointer (if ADF symbology is enabled);
  - i) ADF #2 pointer (if dual ADF symbology is enabled);
  - j) VOR1 pointer (if VOR symbology is enabled);
  - k) VOR2 pointer (if dual VOR symbology is enabled);
  - l) strikes (if WX-500 option is enabled);
  - m) terrain;
  - n) traffic (if traffic option is enabled); and
  - o) weather radar (if weather radar option is enabled).

### 5.27.6. MFD HSI Pointer (PTRS) Menu




**Figure 5-72: MFD HSI Pointer (PTRS) Menu**

Upon selecting the HSI pointers menu when in the HSI page, an option list appears to allow the pilot to individually select display of:

- 1) ADF1 pointer (if ADF symbology is enabled);
- 2) ADF2 pointer (if dual ADF symbology is enabled);
- 3) VOR1 pointer (if VOR symbology is enabled); and
- 4) VOR2 pointer (if dual VOR symbology is enabled).

### 5.27.7. MFD Traffic Format (FORMAT) Menu




**Figure 5-73: MFD Traffic Format (FORMAT) Menu**

Upon selecting the MFD format menu when in the Traffic page, an option list appears with the following options:

- 1) **ROUTE ON/ROUTE OFF:** Toggles showing the active flight plan route on the Traffic page.
- 2) **IDENT OFF/IDENT ON:** When the TCAS flag is TIS-B, toggles showing traffic identifier/squawk information.
- 3) **ALT FILTER:** Sets the traffic altitude filter to either **AUTO**, **ABOVE**, **BELOW**, **NORMAL**, or **ALL**.
- 4) **TCAD TEST:** When the TCAS flag is Ryan/Avidyne TCAD, activates the TCAD pilot initiated test function.
- 5) **TREND VECTOR:** When the TCAS flag is TIS-B, use to select the traffic trend vector length in minutes. **OFF (R4)** appears at this level to quickly turn off the traffic trend vector.

### 5.27.8. MFD Datalink Format (FORMAT) Menu



**Figure 5-74: MFD Datalink Format (FORMAT) Menu**


Upon selecting the MFD format menu when in the Datalink page, an option list appears with the following options:

- ROUTE ON/ROUTE OFF:** Selecting this option toggles showing the active flight plan route on the Datalink page.
- PAN ON/PAN OFF:** Selecting this option toggles Datalink page Pan mode.
- AMET-SMET:** This option only is available when an AIRMET or SIGMET is within the Datalink page viewable area. Selecting this option allows the pilot to view the text for the displayed AIRMETS and SIGMETs. While viewing the text for a particular

AIRMET or SIGMET, the border associated with the AIRMET or SIGMET flashes on the page.

- 4) **DCLTR:** This option is available when datalink weather products are available for display. Selecting this option allows the pilot to select individual datalink weather products for display. Only those datalink weather products that are available for display appear in the selection box.

### 5.27.9. MFD Video Input Format (FORMAT) Menu



**Figure 5-75: MFD Video Input Format (FORMAT) Menu**


Upon selecting the MFD format menu when in the Video Input page, an option list appears with the following options.

**Table 5-4: Video Input Controls**

Controls Settings	Definition	Notes
<b>BRT</b>	Adjust the brightness setting for the current Video input.	When not at the nominal default (50%) value, press <b>DFLT (R4)</b> to reset brightness to nominal default value.
<b>CTRST</b>	Adjust the contrast setting for current video input	When not at the nominal default (50%) value, press <b>DFLT (R4)</b> to reset contrast to nominal default value.
<b>SAT</b>	Adjust the chroma saturation (Color Intensity) setting for current video input.	When not at the nominal default (50%) value, press <b>DFLT (R4)</b> to reset to nominal default value.
<b>HUE</b>	Adjust the chroma hue (red-green balance) settings for current video input.	When not at the nominal default (50%) value, press <b>DFLT (R4)</b> to reset to nominal default value.
<b>SOURCE</b>	Selection of optional video source.	Only available if more than one video input is enabled. Allows for selected video input to be displayed.
<b>DCLTR</b>	Activates an option list allowing individual selection of which video input status settings are displayed.	a) NAME: (Video input label) b) ZOOM: (Current amount of image expansion) c) BRT: (Current brightness setting) d) CTRST: (Current contrast setting) e) SAT: (Current chroma saturation setting) f) HUE: (Current chroma hue setting)




### 5.27.10. MFD Video Input Format (FORMAT) Menu Center Rotary Encoder Controls



**Figure 5-76: Center Rotary Encoder Controls**

Upon selecting the MFD format menu when in the Video Input page, **3** becomes a dedicated brightness control and **2** becomes a dedicated contrast control. Moving these controls activates the **BRT** or **CTRST** menus.

**5.27.11. MFD ND Page Format Menu**



**Figure 5-77: MFD ND Page Format (FORMAT) Menu**

Upon selecting the MFD format menu when in the ND page, an option list appears with the following options:

- 1) **CENTER/ARC:** Toggles between a centered and arced ND display format (if not panning).
- 2) **HDG UP/N UP:** Toggles between a heading up and a North up ND display format (if not panning).
- 3) **PAN ON/PAN OFF:** Toggles ND page pan mode.
- 4) **SYMB DCLTR:** Allows selection of either, automatic navigation symbol declutter or manual navigation symbol declutter.

**(Automatic):**

A periodic increase in navigation symbols displayed on the map which happens every five minutes in automatic declutter mode is as follows:

The system counts the navigation symbols being drawn on a continuous basis. If more than 35 symbols are being drawn, the declutter level is increased. There are six automatic declutter levels as follows:

- 1) Large Airports, IFR Airports, VFR Airports, VORs, NDBs, Fixes, and User Waypoints (all possible symbols).
- 2) Large Airports, IFR Airports, VFR Airports, VORs, and NDBs.
- 3) Large Airports, IFR Airports, VFR Airports, and VORs.
- 4) Large Airports, IFR Airports, and VORs.
- 5) Large Airports and VORs.
- 6) Large Airports only.


This automatic increasing of the decluttering level process is accomplished continuously and smoothly only as symbols are increasing. When the aircraft is flown into a less dense area, every five minutes the automatic declutter level is reduced by one, and the system is allowed to re-seek the proper level. In the frame where this occurs, there may be a momentary large increase in the number of navigation symbols being drawn; this is a normal view change.

**(Manual):**

If the pilot chooses manual navigation symbol declutter, a further option list appears to allow the pilot to individually select:

- 1) Large Airports
  - 2) IFR Airports
  - 3) VFR Airports
  - 4) VORs
  - 5) NDBs
  - 6) Fixes
  - 7) Terminal Fixes
  - 8) User Waypoints
- 5) **FNCT DCLTR:** Selecting this option activates an option list to allow the pilot to individually toggle display of:
- a) airspace;
  - b) borders;
  - c) datalinked NEXRAD, graphical METARs and lightning ground strikes (if datalink or ADS-B option is enabled);
  - d) estimated time of arrival (ETA);
  - e) glide range (if glide ratio is enabled and set in the limits, airplane configuration only);
  - f) high-altitude airways;
  - g) low-altitude airways;
  - h) current latitude and longitude display of ADF #1 pointer (if ADF symbology is enabled);
  - i) display of ADF #2 pointer (if dual ADF symbology is enabled);
  - j) display of VOR1 pointer (if VOR symbology is enabled);
  - k) display of VOR2 pointer (if dual VOR symbology is enabled);
  - l) display of strikes (if WX-500 option is enabled);
  - m) display of terrain;
  - n) display of traffic (if traffic option is enabled); and
  - o) display of weather radar (if weather radar option is enabled).


### 5.27.12. MFD ND Page Format (FORMAT) Menu (Step-By-Step)



- 1) Press **MENU (R1)** and **FORMAT (R4 or R8)** to enter the format menu.
- 2) Scroll **1** or **2** to either **ARC**, **N UP**, **PAN ON**, **SYMB DCLTR..**, or **FNCT DCLTR..** and push to enter.

**Figure 5-78: MFD ND Page Format (FORMAT) Menu (Step-By-Step)**

### 5.28. MFD HSI Pointer (PTRS) Menu




**Figure 5-79: MFD HSI Pointer (PTRS) Menu**

Upon selecting the HSI pointers menu when in the HSI page, an option list appears to allow the pilot to individually select:

- 1) ADF1 pointer
- 2) ADF2 pointer
- 3) VOR1 pointer
- 4) VOR2 pointer

### 5.28.1. MFD HSI Pointer (PTRS) Menu (Step-By-Step)



- 1) Press **MENU (R1)** then **PTRS (R4 or R8)** to enter the Pointer menu.
- 2) Scroll **1** to either **PTR ADF**, **PTR NAV1**, or **PTR NAV2** and push to place check mark then scroll to **DONE** and push to enter.

Figure 5-80: MFD HSI Pointer (PTRS) Menu (Step-By-Step)

### 5.28.2. MFD Strike Format (FORMAT) Menu




Figure 5-81: MFD Strike Format (FORMAT) Menu

Upon selecting the MFD format menu when in the Strike page, an option list appears with the following options:

- 1) **CENTER/ARC:** Selecting this option toggles between a centered and arced Strike page display format.
- 2) **ROUTE ON/ROUTE OFF:** Selecting this option toggles showing the active flight plan route on the Strike page.
- 3) **STRK MODE/CELL MODE:** Selecting this option toggles between strike mode strikes and cell mode strikes on the Strike page.
- 4) **STRK TEST:** Selecting this option activates the WX-500 pilot initiated test function.

## 5.29. Audio/Radio (AR) Page Menu

The bottom area of all IDUs may show an AR Page in all modes. IDUs other than IDU#1 may also show the AR page in the top area when in Normal Mode.

### 5.29.1. AR Tune

AR page automatic pop up options are shown adjacent to the area in which the AR page resides.





Figure 5-82: AR Tune page First-Level Options


**Figure 5-83: AR Tune Page Second-Level Options**
**Table 5-5: AR Page Functions**

Device Type	Action
<b>VHF COM Transceiver</b>	Scroll <b>3</b> to increment or decrement the standby frequency by 1 MHz, from 118 to 136.
	Scroll <b>2</b> to increment or decrement the standby frequency by 25 kHz, from 0 to 975 kHz, if device is set to 25 kHz spacing.
	Scroll <b>2</b> to increment or decrement the standby frequency by 8.33 kHz channels*, from 0 to 990, if device is set to 8.33 kHz spacing.
	Scroll <b>1</b> to increment or decrement the volume level.
<b>VHF NAV Receiver</b>	Scroll <b>3</b> to increment or decrement the standby frequency by 1 MHz, from 108 to 117.



**Table 5-5: AR Page Functions**

Device Type	Action
	Scroll <b>2</b> to increment or decrement the standby frequency by 50 kHz, from 0 to 950 kHz.  Scroll <b>1</b> to increment or decrement the volume level.
<b>ADF Receiver</b>	Scroll <b>2</b> to increment or decrement the selected digit of the standby frequency from 190.0 – 1799.5 kHz.  Push <b>2</b> to select the next standby frequency digit.  Scroll <b>1</b> to increment or decrement the volume level.
<b>Transponder</b>	Scroll <b>2</b> to increment or decrement the selected digit of the standby code from 0 – 7.  Push <b>1</b> to select the next standby code digit.  Scroll <b>1</b> to increment or decrement the transponder mode from “STBY” to “GRD” to “On” to “ALT”.
<b>Audio-Only DME Receiver Marker Beacon</b>	<b>MUTE (L6)</b> unmute if necessary, Scroll <b>1</b> to increment or decrement the volume level.
<b>Intercom System</b>	Scroll <b>2</b> to increment or decrement the VOX level.  Scroll <b>1</b> to increment or decrement the volume level.


When an intercom or audio management unit (AMU) fails, the failure of the AMU may cascade across the other devices. When the AMU fails, only the devices having audio control through those devices' interfaces increment or decrement the volume level.

## 5.29.2. AR Expand Page

The AR Expand page displays features for those devices with more features than accessible from the AR automatic pop-up or AR Tune first level. These pages are device-specific, but they have a common menu interface. The first line of each device AR expand page is drawn the same as the line for that device on the AR Tune page.

## 5.29.3. AR Expand Page First-Level Options

First-level options for AR Expand Page is shown adjacent to the area in which the AR Expand page resides.



**Figure 5-84: Audio-Radio Expand Page First Level**

### 5.29.4. AR Expand Page Second-Level Options

Second-level options for AR Expand Page are shown adjacent to the area in which the AR Expand page resides.





Figure 5-85: Audio-Radio Expand Page Second Level

Table 5-6: ADR7050 VHF Com Transceiver

Device Line	Desired Change	Method of Change
Com transceiver		
SQUELCH	Adjust squelch	Scroll ❶ to this line, push to enable for change. Scroll to adjust.
SIDETONE	Adjust sidetone	
MIC GAIN	Adjust mic gain	
MIC THLD	Adjust mic threshold	
CHANNEL	Set channel for spacing between 25 kHz and 8.33 KHz spacing.	

Second-level options for ADR7050 VHF Nav receiver are shown on

the highlighted NAV1 or NAV2 line. Press  (R8) to begin all tuning operations then as follows.

**Table 5-7: ADR7050 VHF Nav Receiver**

Device Line	Desired Change	Method of Change
NAV1	Set MHZ from 108.00 to 117.00.	Scroll <b>1</b> to this line, push to enable for change. Scroll to adjust.
NAV2	Set KHZ from 00 to .95	
<b>AR Expanded page and AUDIO MODE selected</b>		
AUDIO MODE	<b>VOICE</b> or <b>IDENT</b>	Scroll <b>1</b> to adjust between the two options.

**Table 5-8: BXP 6402 Mode-S Transponder Expanded Page**

Highlighted Line	Encoder Action	Encoder Action to ADJ	End Result of Encoder Action
<b>FLT ID</b>	<b>1</b> Push when <b>SLCT</b> is in encoder list	<b>Transponder aircraft identification</b> is enabled for change.	Scroll <b>1</b> to increment and decrement the selected character of the transponder aircraft ID from "A" to "Z" (space) "0"-"9". Push <b>1</b> to select the next character. ( <i>The ID change may only occur when transponder is in standby mode.</i> )

**Table 5-8: BXP 6402 Mode-S Transponder Expanded Page**


<b>Highlighted Line</b>	<b>Encoder Action</b>	<b>Encoder Action to ADJ</b>	<b>End Result of Encoder Action</b>
<b>ALTITUDE</b>	➊ Push when SLCT is in encoder list	<b>Altitude display mode</b> is enabled for change	Scroll ➊ to cycle the altitude display mode between "METERS" and "FL".
<b>VFR</b>	➊ Push when SLCT is in encoder list	<b>Transponder VFR code</b> is enabled for change	Scroll ➊ to increment and decrement the selected digit of the transponder VFR code from 0-7. Push ➊ to select the next VFR code digit.

**NOTE:**

The valid transponder aircraft identification may only have spaces at the end of the string, not at the beginning or in the middle. The aircraft identification may only be changed when the transponder is confirmed in standby mode.


## 5.30. Audio/Radio Controls


### 5.30.1. Audio/Radio Controls (Step-By-Step)



- 1) Push **1** and scroll to **AUDIO/RADIO**, push to enter.


- 2) Scroll **1** to select desired line to be highlighted.



- 3) Press  to swap standby with active frequency or squawk code.

- 4) Press  when desired line is highlighted for single line display.



- 5) Press  or **EXIT (R1)** to restore full display.

**Figure 5-86: Audio/Radio Controls (Step-By-Step)**



- 1) When the ATC line is highlighted, the




and



tiles are

present.

- 2) Press  to change standby squawk code to **VFR**.

- 3) Press  to squawk ident.

- 4) When any line is highlighted other than the

ATC, press 

for entering new frequency or scroll **1** to set volume limits.



**Figure 5-87: Audio/Radio Controls (Step-By-Step)**



- 1) To change transmitter selector, scroll to desired line by scrolling **1** to desired COM and press



- 2) To **MUTE** any receiver, scrolling **1** to desired receiver to highlight desired line then press



to toggle on or off.

**Figure 5-88: Audio/Radio Controls (Step-By-Step)**



# **Section 6      Quick Start Tutorial**

Quick Reference Guide (DOC 64-000097-080D)




Begin by reading the EFIS Aircraft Flight Manual Supplement.



Power up the EFIS system. The system performs a built-in test routine. If all tests pass, the system displays a screen identifying the database coverage. Press any button to acknowledge, and the system begins a two-minute count down while awaiting sensor initialization. For the purposes of flight planning, etc., press any button to override this countdown.



The encoders are numbered 1-3 from the right side as noted. Scroll ③ to adjust the heading bug setting.



Press **R2** to enter the Altimeter menu to enter the proper QNH. Scroll **1** to proper setting and push to enter value.



Press **R4** to enter a destination active waypoint.

Scroll **1** to the desired alpha or numerical character, push to confirm and advance to the next position. Push to enter once until all five spaces have been either entered or viewed.

A magenta bearing to the waypoint symbol is displayed on the directional scale.


A direct route to the active waypoint is activated and appears as magenta tethered balloon on the PFD as shown.


Active waypoint information, including type and identifier, elevation or crossing altitude, bearing and distance are displayed below the Analog AGL indicator or Mini Map as configured.




Indicated airspeed is on the left, altitude is on the right, and heading is across the top. FMS/VLOC CDI is located on the bottom. The VSI appears on the right side of the altitude tape.



Press  (**R5**) to change the PFD to a display with Primary flight information on top and EICAS on the bottom display.




Press  (**R5**) to restore the IDU to the previous display configuration.



On the MFD, press **(R5)** to change displays to PFD on the top view and EICAS on the bottom view.



On the MFD, press **(R5)** to change displays to MFD page on top and bottom view.



On the MFD, press **(R5)** to display primary flight information on top and EICAS on the bottom view.



On the MFD, press **(R5)** to display EICAS on top, and MAP displays, or as later configured, push **1** or **2**.

## Flight Plans (Stored Routes)

### Activate a Stored Flight Plan (PFD or MFD)

- 1) Press **FPL (L1)**.
- 2) Push **1** to display list of stored flight plans.
- 3) Scroll **1** to select desired flight plan.
- 4) Push **1** to activate desired flight plan.

### Create Flight Plan (PFD or MFD)

- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Select **CREATE FLIGHT PLAN** and push to enter.
- 4) Press **ADD (R6)** to begin creating first waypoint with **1** by entering waypoints from beginning to end.
- 5) Press **BACK (R1)** to return to Function Select page.
- 6) Press **SAVE EXIT (R8)** to save flight plan.
- 7) Press **EXIT (R1)** to exit Flight Planner.

## Waypoints

### Edit a User Waypoint (PFD or MFD)

- 1) Press **FPL (L1)**.
- 2) Scroll **1** to highlight **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **EDIT USER WPT** and push to enter.
- 4) Scroll **1** to highlight waypoint to be edited and push to enter.
- 5) Press **BACK (R1)** to return to Function Select page.
- 6) Edit waypoint and press **SAVE (R8)** to save new USER WPT data.
- 7) Press **EXIT (R1)** to exit flight planner.

### Create a User Waypoint (PFD or MFD)

- 1) Press **MENU (R1)**.
- 2) Press **DESIG (L3)**.

### Add Waypoint to an Active Route (PFD or MFD)

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to location on waypoint list where added waypoint is to be inserted above.
- 3) Press **INSERT (R2)**.
- 4) Scroll **1** to enter waypoint identifier and push to enter.

### Delete Waypoint from an Active Route (PFD or MFD)

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to highlight waypoint to delete. If this is part of a published procedure, press **DELETE (R3)** to prompt **CONFIRM DEL PROC**. If this is a waypoint within flight plan press **DELETE (R3)** to prompt **CONFIRM DEL WPT**.
- 3) Push **1** to **CONFIRM DEL PROC** or **CONFIRM DEL WPT** to enter.

## Omnibearing Selector Function

### Automatic OBS (FMS OBS Only) (PFD or MFD)

- 1) Press **OBS (L4)**.
- 2) Push **1 OBS:AUTO** to enter.

### Manual OBS (PFD or MFD)

- 1) Press **OBS (L4)**.
- 2) Select desired HSI source, press **NAV VLOC1 (L3)** or **NAV VLOC2 (L4)**.
- 3) If HSI source is **NAV FMS**, press **OBS MANUAL (R4)** then scroll **1** to desired OBS value and push to enter or **OBS SYNC (R3)** and push to enter.
- 4) If HSI source is **NAV VLOC1 (L3)** or **NAV VLOC2 (L4)**, scroll **1** to desired course (OBS:XXX° (XXX°)) and push to enter.



## Approaches/Track

### Select a VFR Approach (PFD or MFD)

(The active flight plan must contain an eligible airport [or USR WPT with runway bearing] for VFR approach creation.)

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to desired airport or user waypoint, push to enter.
- 3) Scroll **1** to **VFR APPR..** and push to enter.
- 4) Scroll **1** to desired runway (N/A for USR WPT) and push to enter.

### Change Runway during VFR Approach (PFD or MFD)

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to highlight the following and push to enter:
  - a) Destination airport
  - b) **VFR APPR..**
  - c) Desired runway, push to enter.

(This deletes the previous VFR or IFR approach and creates a new VFR approach to the selected runway.)

### Change Runway on IFR Approach (PFD or MFD)

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to destination airport and push to enter.
- 3) Select **IFR APPR:.** Scroll **1** to desired approach. Push to enter.
- 4) Select **APPR:.** Scroll **1** to desired approach. Push to enter.
- 5) Select **TRANS:.** Scroll **1** to desired transition. Push to enter.
- 6) Select **RW:.**, scroll **1** to desired runway and push to enter.


(This deletes the previous IFR approach and creates a new IFR approach to the selected runway.)

## XFILL SYNC Operation

### XFILL SYNC Operation (PFD Only)

(Crossfill is the normal default mode of operation.)

- 1) During crossfill inhibited operation, **XFILL INHBT** appears on the PFD in the lower left corner.
- 2) When the pilot and co-pilot systems are not synchronized, **XFILL ARM** appears on the PFD in the lower left corner.
- 3) When the pilot and co-pilot systems are not synchronized, press **MENU (R1)** then **XFILL SYNC (L2)** to synchronize the pilot and co-pilot active flight plan parameters to the system where the button press occurred.



# **Section 7 IFR Procedures**

## Table of Contents

SECTION 7	IFR PROCEDURES .....	7-1
7.1.	IFR PROCEDURES.....	7-6
7.2.	OVERVIEW OF APPROACHES.....	7-6
7.2.1.	<i>Vertical Deviation Indicator Linear Limits</i> .....	7-8
7.2.2.	<i>Highway in the Sky (Skyway)</i> .....	7-8
7.2.3.	<i>Waypoint Sequencing</i> .....	7-14
7.2.4.	<i>Fly-Over Waypoints</i> .....	7-15
7.2.5.	<i>Fly-By Waypoints</i> .....	7-17
7.2.6.	<i>Direct-To</i> .....	7-21
7.3.	MAGNETIC COURSE .....	7-22
7.3.1.	<i>AHRS Modes for Heading Source</i> .....	7-22
7.3.2.	<i>GPS Altitude</i> .....	7-23
7.3.3.	<i>Dead Reckoning</i> .....	7-23
7.3.4.	<i>Geodesic Path Computation Accuracy</i> .....	7-23
7.3.5.	<i>Parallel Offsets</i> .....	7-23
7.4.	DEFAULT GPS/SBAS NAVIGATION MODES .....	7-25
7.5.	GPS/SBAS CDI SCALE .....	7-28
7.6.	APPROACH TYPE SELECTION.....	7-29
7.6.1.	<i>Approach Path Definition</i> .....	7-31
7.7.	VTF IFR APPROACH .....	7-32
7.8.	VTF VFR APPROACH.....	7-32
7.9.	MISSED APPROACH AND DEPARTURE PATH DEFINITION	7-33
7.10.	LOSS OF NAVIGATION MONITORING.....	7-34
7.11.	DISCONTINUITIES .....	7-34
7.12.	SELECTION OF AN INSTRUMENT PROCEDURE.....	7-35

7.12.1.	<i>Standard Terminal Arrival Route (STAR) .....</i>	<i>7-36</i>
7.12.2.	<i>ILS Instrument Approach.....</i>	<i>7-39</i>
7.12.3.	<i>LOC Back Course Instrument Approach .....</i>	<i>7-43</i>
7.12.4.	<i>RNAV (GPS) Instrument Approach to LPV Minima .....</i>	<i>7-47</i>
7.12.5.	<i>NRST ILS Instrument Approach.....</i>	<i>7-50</i>
7.12.6.	<i>VOR/DME Instrument Approach .....</i>	<i>7-53</i>

## List of Figures and Tables

FIGURE 7-1: VERTICAL DEVIATION LINEAR DEVIATION .....	7-8
TABLE 7-1: HIGHWAY IN THE SKY CONFIGURATION.....	7-9
FIGURE 7-2: HIGHWAY IN THE SKY (AIRCRAFT-REFERENCED).....	7-10
FIGURE 7-3: HIGHWAY IN THE SKY (GEO-REFERENCED BACKWARD).....	7-11
FIGURE 7-4: HIGHWAY IN THE SKY (GEO-REFERENCED FORWARD)	7-11
TABLE 7-2: FINAL SEGMENT OF IFR APPROACH, DESCENT ANGLE AND VNAV WAYPOINT.....	7-12
FIGURE 7-5: HIGHWAY IN THE SKY (DESCENT).....	7-13
FIGURE 7-6: FLY-OVER WAYPOINTS.....	7-15
TABLE 7-3: RNAV PATH TERMINATOR LEG TYPE.....	7-16
FIGURE 7-7: FLY-BY WAYPOINTS .....	7-17
TABLE 7-4: LEG SEGMENTS FOR PATHS CONSTRUCTED BY IDU .....	7-18
FIGURE 7-8: PARALLEL OFFSET ENTRY WAYPOINT .....	7-24
TABLE 7-5: DEFAULT GPS/SBAS NAVIGATION MODES .....	7-25
TABLE 7-6: DEFAULT NAVIGATION MODES BASED UPON REGION OF OPERATION.....	7-26
TABLE 7-7: SUMMARY OF CHANGES IN CROSS-TRACK FSD .....	7-28
FIGURE 7-9: GPS MODE (LNAV APPR) .....	7-31
FIGURE 7-10: VTF VFR APPROACH.....	7-32
FIGURE 7-11: MISSED APPROACH DASHED LINE.....	7-33
FIGURE 7-12: STANDARD TERMINAL ARRIVAL ROUTE (STAR).....	7-36
FIGURE 7-13: STAR PROCEDURE (STEP-BY-STEP).....	7-37
FIGURE 7-14: STAR PROCEDURE (STEP-BY-STEP) (CONTINUED)..	7-38
FIGURE 7-15: ILS RWY 6 (BDR).....	7-39
FIGURE 7-16: ILS INSTRUMENT APPROACH (STEP-BY-STEP) .....	7-40
FIGURE 7-17: ILS INSTRUMENT APPROACH (STEP-BY-STEP) (CONTINUED) .....	7-41
FIGURE 7-18: ILS INSTRUMENT APPROACH (STEP-BY-STEP) (CONTINUED) .....	7-42
FIGURE 7-19: LOC BACK COURSE APPROACH .....	7-43
FIGURE 7-20: LOC BACK COURSE APPROACH (STEP-BY-STEP) ....	7-44
FIGURE 7-21: LOC BACK COURSE APPROACH (STEP-BY-STEP) (CONTINUED) .....	7-45
FIGURE 7-22: LOC BACK COURSE APPROACH (STEP-BY-STEP) (CONTINUED) .....	7-46
FIGURE 7-23: RNAV (GPS) INSTRUMENT APPROACH TO LPV MINIMA ..	7-47
FIGURE 7-24: RNAV (GPS) INSTRUMENT APPROACH TO LPV MINIMA (STEP-BY-STEP) .....	7-48
FIGURE 7-25: RNAV (GPS) INSTRUMENT APPROACH TO LPV MINIMA (STEP-BY-STEP) (CONTINUED) .....	7-49

FIGURE 7-26: NRST ILS INSTRUMENT APPROACH .....7-50

FIGURE 7-27: NEAREST ILS INSTRUMENT APPROACH (STEP-BY-STEP)  
.....7-51

FIGURE 7-28: NEAREST ILS INSTRUMENT APPROACH (STEP-BY-STEP)  
(CONTINUED).....7-52

FIGURE 7-29: VOR/DME INSTRUMENT APPROACH .....7-53

FIGURE 7-30: VOR/DME INSTRUMENT APPROACH (STEP-BY-STEP).....  
.....7-54

FIGURE 7-31: VOR/DME INSTRUMENT APPROACH (STEP-BY-STEP)  
(CONTINUED).....7-55

FIGURE 7-32: VOR/DME INSTRUMENT APPROACH (STEP-BY-STEP)  
(CONTINUED).....7-56

FIGURE 7-33: VOR/DME INSTRUMENT APPROACH (STEP-BY-STEP)  
(CONTINUED).....7-57

## 7.1. IFR Procedures

Pilots operating in a radar environment are expected to associate departure headings or an RNAV departure advisory with vectors or the flight path to their planned route or flight. Use of both types of departure procedures, Obstacle Departure Procedures (ODP) printed either textually or graphically and Standard Instrument Departure procedures (SIDs) which are always printed graphically. All DPs, either textual or graphic may be designed using either conventional or RNAV criteria. RNAV procedures have RNAV printed in the title.

ODPs (Obstacle Departure Procedure) are not found in the navigation database, and therefore the climb angle found in the PFD BUGS menu should be set to comply with the steeper than normal climb gradient during the departure until established on the enroute structure. ODPs are recommended for obstruction clearance and may be flown without ATC clearance, unless an alternate departure procedure (SID or radar vector) has been specifically assigned by ATC.

Approach minima are never coded in NavData. On some approaches, the altitude coded at the MAP for a non-precision approach coincides with an MDA (normally where the final approach course does not align with the runway), but more often the coded altitude is some height above the threshold.

## 7.2. Overview of Approaches

This Genesys Aerosystems EFIS provides three-dimensional GPS Precision and Non-precision instrument approach guidance using a system integral TSO C146c BETA 3 GPS receiver with GPS and augmented GPS with SBAS (Satellite Based Augmentation System) commonly referred to as WAAS (Wide Area Augmentation System). In order to support full integration of RNAV procedures into the National Airspace System (NAS), a new charting format for Instrument Approach Procedures (IAPs) has been designed to avoid confusion and duplication of Instrument Approach Charts.

Use of this GPS receiver provides a level of certified service supporting RNAV (GPS) approaches to LNAV, LP, LNAV/VNAV, and LPV lines of minima within system coverage. Some locations close to the edge of the coverage may have lower availability of vertical guidance.



The new procedures, called Approach with Vertical Guidance (APV), are defined in ICAO Annex 6 and include approaches such as the LNAV/VNAV procedures presently being flown with barometric vertical navigation (BARO-VNAV). These approaches provide vertical guidance but do not meet the more stringent standards of a precision approach. With the WAAS BETA 3 GPS receiver and updatable navigation database in this system, these approaches may be flown using an electronic glidepath, which eliminates the possible errors introduced by using Barometric altimetry.

In addition to the LNAV/VNAV procedures, the APV approach has been implemented to take advantage of the high accuracy guidance and increased integrity provided by GBS/SBAS. This SBAS (TEROS/ICAO) generated angular guidance allows the use of the same TERPS approach criteria used for ILS approaches. The resulting approach procedure minima, titled LPV (Localizer Performance with Vertical guidance), may have a decision altitude as low as 200 feet height above touchdown (EASA OPS LPV 250 ft.) with visibility minimums as low as ½ mile (providing the terrain and airport infrastructure and regulations support the lowest minima criteria).

Another new non-precision GPS/SBAS Approach has been certified as an LP (Localizer Performance) approach where terrain or obstructions prohibit the certification of the LPV vertically guided approach. This new approach takes advantage of the angular lateral guidance and smaller position errors (provided by GPS/SBAS) to provide a lateral only procedure similar to an ILS Localizer. LP procedures may provide lower minima than a LNAV procedure due to the narrower obstacle clearance surface.


The Genesys Aerosystems EFIS guides the pilot through every step of the approach procedure with Highway in the Sky 3-D symbology. The system defines a desired flight path based upon the active flight plan. The current position of the aircraft is determined relative to that desired path in order to determine lateral deviation for display on the GPS/SBAS CDI and VDI. The IDU auto-sequences from one waypoint to the next in accordance with the flight plan along the flight path with the following exceptions as described:

- 1) The pilot has selected a manual GPS/SBAS OBS (**SUSPEND** shown).

- 2) The active waypoint is the missed approach waypoint and the missed approach procedure has not been armed (**ARM**) or initiated (**MISS**) (**SUSPEND** shown).
- 3) The aircraft is in a published or manually created holding pattern, and the pilot has not chosen to continue (**CONT**) out of the holding pattern (**SUSPEND** shown).
- 4) The active waypoint is the last waypoint of the active flight plan (no flag shown).

The linear vertical scale limits of the VDI for LNAV/VNAV and LPV approaches are shown in Figure 7-1.

### 7.2.1. Vertical Deviation Indicator Linear Limits



Note: Offset conical vertical deviation reference surface and hyperboloid surface are not depicted.

**Figure 7-1: Vertical Deviation Linear Deviation**

### 7.2.2. Highway in the Sky (Skyway)

When not decluttered, the PFD displays the active navigation route or manual OBS course in a three-dimensional manner using a series of skyway boxes which are a series of perspective objects overlying the flight plan route at a desired altitude providing lateral and vertical guidance. The skyway boxes conform to the VNAV requirements of GPS/SBAS receiver requirements (TSO-C-146C). The top and bottom sides of the boxes are parallel to the horizon on straight leg segments, and dynamically tilt with respect to the horizon on turning leg segments based upon leg segment turn radius and groundspeed. When the active route is in view, up to five boxes are shown with the dimensions being a constant 400 feet wide ( $\pm 200$

feet from the desired lateral path) by 320 feet tall ( $\pm 160$  feet from the desired vertical path) spaced horizontally 2000 feet. The skyway boxes are drawn using the hidden surface removal techniques of the terrain and obstruction rendering so a skyway box behind terrain appears to be so. The skyway boxes disappear in Basic Mode and Unusual Attitude Mode. In reversionary mode 1 (GPS failure), the skyway boxes disappear after one minute to indicate degraded navigation performance.

**Table 7-1: Highway in the Sky Configuration**


<b>Type HITS Lines</b>	<b>Fully Integrated Autopilot</b>	<b>Partially Integrated Analog Autopilot</b>  (Through use of HDG Mode and or NAV/APR mode discrete inputs)	<b>Un-Integrated Autopilot</b>  <b>Or</b> <b>No Autopilot</b>
<b>Dashed</b>	Not coupled to Skyway	Not coupled to Skyway	
<b>Solid</b>	Coupled to Skyway	Coupled to Skyway. Either autopilot is in HDG mode with LNAV heading/roll-steering sub-mode engaged or autopilot is in NAV/APR mode with the FMS, FMS1, or FMS2 as the selected navigation source.	Always Solid

Skyway box altitude is controlled by VNAV altitude, aircraft altitude, aircraft climb performance and climb/descent angle setting. If no VNAV altitude is set, the skyway boxes describe the desired lateral flight path of the aircraft at the aircraft's current altitude.

With a VNAV altitude set, the boxes provide both lateral and vertical guidance. Climb and descent angle settings may be controlled individually with a resolution of  $0.1^\circ$ . VNAV is guided by VNAV waypoints determined by VNAV altitude and VNAV offset from flight plan waypoints. There are two sources for VNAV altitudes, the navigation database and manual input through the ACTV menu. VNAV altitudes for waypoints without a navigation database or


manually input VNAV altitude are automatically computed by the system using “look-ahead” rules. When “look-ahead” finds a further VNAV altitude constraint above the previous VNAV altitude constraint (i.e., climb commanded), an automatic VNAV altitude is continuously calculated for the waypoint based upon an immediate climb to the altitude constraint at the higher of actual climb angle or the climb angle setting (dynamic climb angle). When “look-ahead” finds a further VNAV altitude constraint below the previous VNAV altitude constraint (i.e., descent commanded), an automatic VNAV altitude is calculated for the waypoint based upon a descent to reach the VNAV altitude constraint at the associated waypoint using the descent angle setting. If no further VNAV altitude constraints are found, the automatic VNAV altitude is set to the last valid VNAV altitude constraint.

When a VNAV climb is desired, the boxes are drawn at a vertical position the higher of: (a) the dynamic climb angle emanating from the aircraft's present position (aircraft-referenced); (b) the dynamic climb angle emanating from the next waypoint VNAV altitude (geo-referenced forward); or (c) the climb angle setting emanating from the previous waypoint VNAV altitude (geo-referenced backward). The geo-referenced backward calculation is only considered when the current leg is part of a procedure and is designed to provide pilot awareness if a specified climb gradient is not being met. Once the boxes intercept the VNAV altitude, further boxes are drawn with a zero angle to show a level off followed by a level flight segment. Due to the fact five boxes are shown, the level-off depiction becomes an anticipatory cue for the pilot. Climb guidance is depicted below.




**Figure 7-2: Highway in the Sky (Aircraft-Referenced)**

### Geo-Referenced Backward



**Figure 7-3: Highway in the Sky (Geo-Referenced Backward)**

### Geo-Referenced Forward



**Figure 7-4: Highway in the Sky (Geo-Referenced Forward)**

When a VNAV descent is desired, boxes are drawn with a zero angle until reaching a descent point. Further boxes are drawn downward at an angle corresponding to the descent angle setting. The descent point is defined by the intercept of a line emanating upward from the subsequent VNAV waypoint at the descent angle setting, and a line representing level flight at the previous VNAV altitude. On the final approach segment of an IFR approach, descent angle and VNAV waypoint are defined as follows.


**Table 7-2: Final Segment of IFR Approach, Descent Angle and VNAV Waypoint**

Condition	VNAV Waypoint Definition	Descent Angle Definition
IFR Approach with valid Final Approach Segment data block	Glidepath Intercept Point as defined in Final Approach Segment data block	Descent Angle as defined in Final Approach Segment data block
No or invalid Final Approach Segment data block No intermediate waypoints exist between Final Approach Fix and Missed Approach Point.	Missed Approach Point location	Straight line from Final Approach Fix to Missed Approach Point location and altitudes.
No or invalid Final Approach Segment data block. Intermediate waypoints exist between Final Approach Fix and Missed Approach Point.	Missed Approach Point location	The steepest descent angle based upon straight lines from the Final Approach Fix and subsequent Intermediate Waypoints to Missed Approach Point location and altitudes.


On the final approach segment of a VFR approach procedure, the higher of the descent angle setting or 3° is used.

Because five boxes are shown, the descent point depiction becomes an anticipatory cue for the pilot. Descent guidance is depicted in Figure 7-5.


**Normal Descent**




**Final Approach Segment Descent w/FAS Data Block**



**Final Approach Segment Descent w/o FAS Data Block or Intermediate Waypoints**



**Final Approach Segment Descent w/o FAS Data Block with Intermediate Waypoint**



**Figure 7-5: Highway in the Sky (Descent)**

Figure 7-5 creates an easily understood, yet safe, VNAV paradigm meeting the VNAV requirements current guidance. Simplicity is a primary objective. Further, the paradigm is biased towards keeping the aircraft at the highest altitude possible for the longest period of time, an important safety benefit for operators of single-engine aircraft. The climb paradigm automatically compensates for an aircraft's ability to climb more steeply than specified and also warns of being below a desired climb gradient when the aircraft is unable to meet the specified climb angle. The descent paradigm encourages flying stabilized approaches.

### 7.2.3. Waypoint Sequencing

Where automatic waypoint sequencing is suspended due to reasons 1, 2, or 4 § 7.2, the EFIS automatically switches from TO operation to FROM operation when appropriate. If not suspended, automatic waypoint sequencing occurs upon the following conditions:

- 1) Bearing to the transition point (turn bisector for fly-by waypoint, active waypoint for fly-over waypoint) is more than 90° from the current course (i.e., transition from "TO" to "FROM" operation);
- 2) Aircraft location is within two turn diameters (based upon current True Airspeed and 15° angle of bank) of the active waypoint location; and
- 3) Aircraft heading is within 90° of the current course (i.e., generally pointed in the correct direction).

The desired flight path is created from a sequence of straight, left turning and right turning leg segments designed to provide smooth skyway, GPS/SBAS CDI and lateral autopilot guidance. Each leg between waypoints is composed of up to nine segments. Radii for turning segments (other than DME arc or Radius to a Fix segments) are automatically calculated with the parameter speed determined as follows:

- 1) If the waypoint is part of a DP and within 30NM of the departure runway, speed is the preprogrammed Procedure Speed
- 2) If the waypoint is part of a STAR and within 30NM of the arrival runway, speed is the preprogrammed Procedure Speed
- 3) If the waypoint is part of an IAP or VFR Approach Procedure, speed is the preprogrammed Procedure Speed




- 4) If the waypoint is part of a Holding Pattern, speed is the preprogrammed Procedure Speed
- 5) Otherwise, speed is the current True Airspeed or Preprogrammed Programmed, whichever is higher

In all cases, if NavData derived speed limit is associated with the waypoint, speed is the lower of the NavData derived speed limit or the speed determined above.

#### 7.2.4. Fly-Over Waypoints

For creating the desired flight path, each waypoint is designated a fly-by waypoint or a fly-over waypoint. Waypoints are further subdivided into waypoints having a defined entry heading and waypoints having a defined exit heading. Waypoint auto-sequencing for fly-by waypoints occurs at the bisector of the turn. Waypoint auto-sequencing for fly-over waypoints occurs over the waypoint.



**Figure 7-6: Fly-Over Waypoints**

The following waypoints are type Fly-Over with Defined Entry Heading:

- 1) Exit from holding pattern;
- 2) Exit from procedure turn;
- 3) Entry into holding pattern;
- 4) Missed Approach Point;
- 5) Phantom Waypoint (waypoint created by either inserting a waypoint into the active flight plan or performing the Direct-To function within the active flight plan -- avoids S-Turns);

- 6) Last waypoint;
- 7) Start waypoint (waypoint created by creating a new active flight plan with the Direct-To function – avoids S-Turns);
- 8) Reference (takeoff runway end) waypoint of a DP;
- 9) Waypoint leading into discontinuity; and
- 10) Altitude, DME, or Radial termination legs (ARINC 424 path types CA, FA, VA, CR, VR, CD, FD and VD).
- 11) Waypoints marked as overfly in the navigation database.

The definitions of leg type designators are as follows.

**Table 7-3: RNAV Path Terminator Leg Type**


Path	Designator		Terminator
Constant DME arc	A	A	Altitude
Course to	C	C	Distance
Direct Track	D	D	DME Distance
Course from a Fix to	F	F	Fix
Holding Pattern	H	I	Next Leg
Initial	I	M	Manual Termination
Constant Radius	R	R	Radial Termination
Track Between	T		
Heading To	V		

Examples: **CF**= Course to Fix, and **FM**= Course from a Fix to a Manual Termination, etc. (See Table 9-5: Path Terminators for ARINC 424 Path-Terminator Leg Types.)

### 7.2.5. Fly-By Waypoints




MFD



PFI

#### FLY-BY WAYPOINTS



**Figure 7-7: Fly-By Waypoints**

The following waypoints are type Fly-Over with Defined Exit Heading:

- 1) Entry into procedure turn; and
- 2) Waypoint exiting a discontinuity with the exception of phantom waypoints or DP reference waypoints;
- 3) First waypoint with the exception of start waypoints or DP reference waypoints;
- 4) Course to a fix legs that are not to the FAF/FAWP are type Fly-By with defined Entry Heading. All other waypoints are type Fly-By with Defined Exit Heading.

Leg segments for paths are constructed by the IDU as follows.

**Table 7-4: Leg Segments for Paths Constructed by IDU**

Path Type	Entry Waypoint	Exit Waypoint	# of Segments and Description
Straight Leg, DME Arc or Radius to a Fix	Fly-By	Fly-By	2nd Half of Fly-By turn at Entry Waypoint.  WGS-84 Geodesic or Arc path from Entry to Exit turns.  1st Half of Fly-By turn at Exit Waypoint.
	Fly-By	Fly-Over Defined Exit Heading	2nd Half of Fly-By turn at Entry Waypoint.  WGS-84 Geodesic or Arc path from Entry to Exit turns.  Turn to exit heading prior to Exit Waypoint.
	Fly-By	Fly-Over Defined Entry Heading	2nd Half of Fly-By turn at Entry Waypoint.  WGS-84 Geodesic or Arc path from Entry turn to Exit Waypoint.
	Fly-Over Defined Exit Heading	Fly-By	WGS-84 Geodesic or Arc path from Entry Waypoint to Exit turn.  1st Half of Fly-By turn at Exit Waypoint.
	Fly-Over Defined Exit Heading	Fly-Over Defined Exit Heading	WGS-84 Geodesic or Arc path from Entry Waypoint to Exit turn.  Turn to exit heading prior to Exit Waypoint.
	Fly-Over Defined Exit Heading	Fly-Over Defined Entry Heading	WGS-84 Geodesic or Arc path from Entry Waypoint to Exit Waypoint.

**Table 7-4: Leg Segments for Paths Constructed by IDU**

<b>Path Type</b>	<b>Entry Waypoint</b>	<b>Exit Waypoint</b>	<b># of Segments and Description</b>
	Fly-Over Defined Entry Heading	Fly-By	<p>Turn from entry heading after Entry Waypoint.</p> <p>WGS-84 Geodesic or Arc path from Entry to Exit turns.</p> <p>1st Half of Fly-By turn at Exit Waypoint.</p>
	Fly-Over Defined Entry Heading	Fly-Over Defined Exit Heading	<p>Turn from entry heading after Entry Waypoint.</p> <p>WGS-84 Geodesic or Arc path from Entry to Exit turns.</p> <p>Turn to exit heading prior to Exit Waypoint.</p>
	Fly-Over Defined Entry Heading	Fly-Over Defined Entry Heading	<p>Turn from entry heading after Entry Waypoint.</p> <p>WGS-84 Geodesic or Arc path from Entry turn to Exit Waypoint.</p>
Procedure Turn	Fly-Over Defined Exit Heading	Fly-Over Defined Entry Heading	<p>WGS-84 Geodesic path from Entry Waypoint on outbound heading for 30 seconds.</p> <p>Turn to procedure turn heading (45°).</p> <p>Outbound on procedure turn heading for 72 seconds.</p> <p>Turn to inbound heading (135°).</p> <p>WGS-84 Geodesic path to Exit Waypoint. Entry</p>

**Table 7-4: Leg Segments for Paths Constructed by IDU**

Path Type	Entry Waypoint	Exit Waypoint	# of Segments and Description
			Waypoint and Exit Waypoint are same point.
Holding Pattern	Fly-Over Defined Entry Heading	Fly-Over Defined Entry Heading	<p>Turn to proper entry procedure heading. This heading varies. For a parallel entry, it is 180° from the holding course. For direct and teardrop entries, it is the heading required to get to entry of inbound turn.</p> <p>WGS-84 Geodesic path to entry of inbound turn.</p> <p>Inbound turn. Degree of turn varies depending upon entry procedure and heading.</p> <p>WGS-84 Geodesic path to holding fix for direct and teardrop entries. WGS-84 Geodesic path to entry of turn to holding pattern heading for parallel entries.</p> <p>Turn to holding pattern heading for parallel entries. This leg is not used for direct and teardrop entries.</p> <p>Turn to holding pattern outbound leg (180°).</p> <p>Holding pattern outbound leg (length based upon either time or distance as specified by navigation database).</p>

**Table 7-4: Leg Segments for Paths Constructed by IDU**

<b>Path Type</b>	<b>Entry Waypoint</b>	<b>Exit Waypoint</b>	<b># of Segments and Description</b>
			Turn to holding pattern inbound leg (180°).  Holding pattern inbound leg (length based upon either time or distance as specified by navigation database).

### 7.2.6. Direct-To

If the IDU generates a WGS-84 geodesic path to a designated “To” fix, the aircraft captures this path without “S-turning” or undue delay. Where the selected “To” fix is in the active flight plan, the required transition is created as follows:

- 1) A phantom waypoint is created at the current aircraft location.
- 2) The leg prior to the phantom waypoint is designated a discontinuity.
- 3) The phantom waypoint is designated a Fly-Over Defined Entry Heading waypoint where the entry heading is current aircraft track.

Where the selected “To” fix is not in the active flight plan, the required transition is created as follows:

- 1) A new active flight plan is created from “Start” (current aircraft location) to the “To” fix.
- 2) “Start” waypoint is designated as a Fly-Over Defined Entry Heading waypoint where the entry heading is current aircraft track.

### 7.3. Magnetic Course

The source of magnetic variation used for paths defined using magnetic course is in accordance with the following:

- 1) If the leg is part of a database terminal area procedure and the magnetic variation is specified by the State for that procedure, the magnetic variation to be used is the value specified.
- 2) If the leg is not part of a procedure and the active fix is a VOR, the magnetic variation to be used is the published station declination for the VOR.
- 3) If the leg is not part of a procedure and the terminating fix is not a VOR, the magnetic variation to be used is defined by the system using an internal model.

The EFIS has the capability of computing magnetic variation at any location within the region where flight operations may be conducted using Magnetic North reference. The assigned magnetic variation is calculated using the NIMA GEOMAG algorithm and the World Magnetic Model appropriate to the five-year cycle.

#### 7.3.1. AHRS Modes for Heading Source

**AHRS Slaved—EFIS Magnetic North:** Standard mode of operation. Everything is displayed relative to Magnetic North drift free.

**AHRS Slaved—EFIS True North:** Everything is displayed relative to True North with drift free heading. This is the preferred way to operate in areas where navigation is done relative to True North. (See Appendix in Section 9 for limitations on Earth's magnetic flux horizontal field)

**AHRS Free/"DG"—EFIS Magnetic North:** Use this mode when operating around significant magnetic disturbances in areas where navigation is done relative to Magnetic North. Ensure the compass rose is slewed to a Magnetic North value.

**AHRS Free/"DG"—EFIS True North:** Method of operation in high-latitude areas where navigation is accomplished relative to True North. Heading is not drift free and requires periodic correction. This mode may also be used when operating around significant magnetic disturbances in areas where navigation is done relative to True North. Ensure the compass rose is slewed to a True North Value.



### **7.3.2. GPS Altitude**

WGS-84 ellipsoid altitude received from the GPS/SBAS is converted to geodetic (MSL) altitude using the EGM 2008 geoidal database which is revised on a 12-year cycle.

### **7.3.3. Dead Reckoning**

The EFIS provides a Dead Reckoning capability and is active whenever the GPS/SBAS sensor is not sending a valid position. The EFIS projects the last known GPS/SBAS position forward using TAS and heading, corrected for last known wind as it continues to navigate using this position and the active flight plan. The system provides the capability to determine bearing to an airport, based upon the dead reckoning position.

### **7.3.4. Geodesic Path Computation Accuracy**

The cross-track path deviation error between the computed path used to determine cross-track deviations and the true WGS-84 geodesic is less than 10% of the horizontal alert limit of the navigation mode applicable to the leg containing the path.

### **7.3.5. Parallel Offsets**

The parallel offset is a route parallel to, but offset from, the original active route. The basis of the offset path is the original flight plan leg(s) and one or more offset reference points as computed by the IDU. The computed offset reference points are located so they lie on the intersection of lines drawn parallel to the host route at the desired offset distance and the line that bisects the track change angle. An exception to this occurs where the parallel offset ends. In this case, the offset reference point is located abeam of the original flight plan waypoint at the offset distance.

The parallel offset function is not available nor applies to:

- 1) Legs that are parts of approach procedures (IFR Approach or VFR Approach);
- 2) Legs that are ARINC 424 path types other than DF or TF (i.e., any path type that is not straight/geodesic or has a dynamically calculated beginning or ending); or

- 3) Legs that begin at an aircraft starting position (e.g., reference waypoint in a DP or Start/Phantom waypoints created by the Direct-To function).

The parallel offset function does not propagate through:

- 1) Any waypoint at the beginning or end of a route discontinuity;
- 2) Any waypoint at the beginning or end of a prohibited leg type; or
- 3) A waypoint with an unreasonable path geometry (defined as a turn greater than 120°).

When the parallel offset function begins or ends within a flight plan due to the above constraints, parallel offset entry or exit waypoints are inserted into the flight plan. Discontinuities precede parallel offset entry waypoints and follow parallel offset exit waypoints. This allows the pilot to navigate to and from the parallel offset as required. A parallel offset entry waypoint (PTK+) is shown in Figure 7-8.



**Figure 7-8: Parallel Offset Entry Waypoint**

The IDU has the capability to provide guidance to parallel tracks at a selected offset distance. When executing a parallel offset, the navigation mode and all performance requirements of the original route in the active flight plan are applicable to the offset route. The

IDU provides for entry of offset distance in increments of 1 nm, left or right of course and capable of offsets of at least 20 nm. The IDU is operating in offset mode is clearly indicated with advisory labels.

When in offset mode, the IDU provides reference parameters (e.g., cross-track deviation, distance-to-go, time-to-go) relative to the offset path and offset reference points. Annunciation is given to the flight crew prior to the end of the offset path, **PTK ENDING**, with sufficient time to return to the original path. Once a parallel offset is activated, the offset remains active for all flight plan route segments until removed automatically (i.e., by transitioning through a parallel track exit waypoint), until the flight crew enters a “Direct-To” routing or activates a new flight plan route, or until flight crew (manual) cancellation.

The EFIS provides guidance to parallel tracks at a selected offset distance. When executing a parallel offset, the navigation mode and all performance requirements of the original route in the active flight plan are applicable to the offset route. The EFIS provides for entry of offset distance in increments of 1 NM, left or right of course, and is capable of offsets of at least 20 NM. When the IDU is operating in offset mode, it is clearly indicated with blue letters on a black background advisory label (**PTK = D XXNM**). When in offset mode, the EFIS provides reference parameters (e.g., cross-track deviation, distance-to-go, time-to-go) relative to the offset path and offset reference points.

#### 7.4. Default GPS/SBAS Navigation Modes

In the default GPS/SBAS operating mode, the IDU has Enroute, Terminal, LNAV Approach, LNAV/VNAV Approach, LP Approach, LPV Approach, VFR Approach and Departure navigation modes. Mode annunciation, alert limits (horizontal and vertical), and CDI FSD (horizontal and vertical) are automatically determined by navigation mode as follows.

<b>Table 7-5: Default GPS/SBAS Navigation Modes</b>	
<b>Navigation Mode</b>	<b>Annunciation</b>
Enroute	None
Terminal	TERMINAL
LNAV Approach	LNAV APPR
LNAV/VNAV Approach	LNAV/VNAV APPR
LP Approach	LP APPR

**Table 7-5: Default GPS/SBAS Navigation Modes**

Navigation Mode	Annunciation
LPV Approach	LPV APPR
VFR Approach	VFR APPR
Departure	TERMINAL

**NOTE:**

The system automatically switches to default navigation modes based upon region of operation as follows.

**Table 7-6: Default Navigation Modes Based Upon Region of Operation**

Default Navigation Mode	Definition of Region
Departure	Selected when the active waypoint is the first waypoint of a departure or Missed Approach Procedure <u>and</u> the active leg heading is aligned ( $\pm 3^\circ$ ) with the active runway heading. Also set when the active waypoint is the MAWP but a missed approach has been manually activated*.
VTF Approach (LNAV, LNAV/VNAV, LP or LPV)	VTF IFR Approach has been selected; <u>and</u> within 30NM of the active runway*; <u>and</u> the FAWP is the active waypoint*; <u>and</u> the bearing to the FAWP is within $45^\circ$ of the final approach segment track (treated as a mode entry criteria)*; <u>and</u> the desired track to FAWP is within $45^\circ$ of the final approach segment track (treated as a mode entry criteria).

**Table 7-6: Default Navigation Modes Based Upon Region of Operation**

Default Navigation Mode	Definition of Region
Approach (LNAV, LNAV/VNAV, LP or LPV)	<p>IFR Approach has been selected; <u>and</u>            within 30NM of the active runway*; <u>and</u>            the MAWP or the FAWP is the active waypoint; <u>and</u>            if the FAWP is the active waypoint:            the bearing to the FAWP is within 45° of the final approach segment track (treated as a mode entry criteria)*; <u>and</u>            the desired track to FAWP is within 45° of the final approach segment track (treated as a mode entry criteria)*; <u>and</u>            either the segment leading into the FAWP is not a holding pattern or the pilot has elected to continue out of holding.</p>
VFR Approach	<p>VFR Approach has been selected*; <u>and</u>            within 30NM of the active runway*; <u>and</u>            the active runway is the active waypoint.</p>
Terminal	<p>Not in Departure Mode; <u>and</u>            Not in Approach Mode; <u>and</u>            The active waypoint is part of a departure <u>or</u> the active waypoint and previous waypoint are parts of an arrival or approach <u>or</u> within 30NM of the departure airport, arrival airport, or runway.</p>
Enroute	Not in Departure, Approach or Terminal Modes.

**NOTE:**

During RNP 0.3 Approach (manually or coded) the scale remains in RNP 0.3.

**7.5. GPS/SBAS CDI Scale**
**Table 7-7: Summary of Changes In Cross-Track FSD**

	To Enroute	To Terminal	To Approach
<b>From Enroute</b>		Change from $\pm 2$ NM FSD to $\pm 1$ NM FSD over distance of 1 NM; start transition when entering terminal mode.	
<b>From Terminal</b>	Change from $\pm 1$ NM FSD to $\pm 2$ NM FSD over distance of 1 NM; start transition when entering enroute mode.		If VTF, switch immediately. Otherwise, change from $\pm 1$ NM FSD to approach FSD over distance of 2 NM; start transition at 2 NM from FAWP.
<b>From Approach</b>		Change to $\pm 1$ NM.	
<b>From Departure</b>		If initial leg is aligned with runway, change from $\pm 0.3$ NM FSD to $\pm 1$ NM FSD at the turn initiation point of the first fix in the departure procedure.	

**NOTE:**

For RNP 0.3 routes, the Time to Alert is the same as for the approach. For RNP 0.3, the EFIS uses a 10 second TTA when using GPS-only, and a 2-second TTA when using EGNOS.

## 7.6. Approach Type Selection

The IDU automatically selects the approach type (LNAV, LNAV/VNAV, LP or LPV) when entering approach mode. The automatically-selected approach type is selected with the following order of precedence and prerequisites:

### 1) **LPV:**

- a) LPV Enable is enabled;
- b) ARINC-424 “Level of Service” indicates LPV minimums are published;
- c) Valid long-term, fast and ionospheric SBAS corrections are available and being applied to at least 4 GPS satellites;
- d) Final Approach Segment data block exists and passes CRC check; and
- e) Horizontal and vertical alert limits from Final Approach Segment data block are predicted to be supported.

### 2) **LP:**

- a) LPV Enable is enabled;
- b) ARINC-424 “Level of Service” indicates LP minimums are published;
- c) Valid long-term, fast and ionospheric SBAS corrections are available and being applied to at least 4 GPS satellites;
- d) Final Approach Segment data block exists and passes CRC check; and
- e) Horizontal alert limit from Final Approach Segment data block is predicted to be supported.

### 3) **LNAV/VNAV:**

- a) ARINC-424 “Level of Service” indicates LNAV/VNAV minimums are published;
- b) If a Final Approach Segment data block exists, LPV Enable is enabled;
- c) If a Final Approach Segment data block exists, it passes CRC check; and

- d) Horizontal alert limit of 556m is predicted to be supported.

**NOTE:**

Because the IDU inherently supports barometric VNAV, it is not a prerequisite for the vertical alert limit to be predicted or supported. Nor is it a prerequisite for valid long-term, fast, and ionospheric SBAS corrections be available and applied to at least four GPS satellites. Rather, the vertical alert limit (50 m) and SBAS correction tests are used to determine whether to present guidance based upon GPS altitude or barometric altitude.

- 4) **LNAV:** This is the default approach type and is selected when none of the above selections are made. There are no prerequisites for selecting LNAV.

The IDU continuously displays the approach type (mode indication) after selection. The IDU does not degrade the approach type after selection unless the approach procedure is reselected or changed.

**NOTE:**

These are GPS/SBAS modes and still appear during a ground based approach such as an ILS approach.





**Figure 7-9: GPS Mode (LNAV APPR)**

**NOTE:**

Some instrument procedures include notes saying “RNP 0.3 required” and are coded as an RNAV procedure. In these cases, manual RNP must be selected to see the RNP and ANP values on the PFD.

### 7.6.1. Approach Path Definition

Normal IAP path definitions are as specified in the procedure contained in the navigation database. Deviations are provided with respect to the active leg of the approach procedure.

## 7.7. VTF IFR Approach

In addition, the IDU provides the capability for the pilot to manually select a VTF IFR approach, indicating the pilot does not intend to fly the entire procedure. When a VTF IFR approach is selected, the IDU creates an “IP” waypoint on the extended final approach course so as to provide deviations relative to the extended final approach course. The “IP” is designated a fly-over defined exit heading waypoint, and the leg prior to the “IP” is designated a discontinuity. Until the FAWP has been sequenced, the IDU indicates a VTF IFR approach has been selected (using the mode annunciation **VECTORS**) to advise the pilot guidance is not relative to a published approach path and TERPS clearances are not assured.

## 7.8. VTF VFR Approach



The IDU also provides the capability for the pilot to manually select a VFR approach to a runway or user waypoint with a defined approach bearing. When a VFR approach is selected, the IDU creates an “IP” waypoint approximately 12 NM on the extended final approach course so as to provide deviations relative to the extended final approach course. The “IP” is designated a fly-over defined exit heading waypoint, and the leg prior to the “IP” is designated a discontinuity.



During this VTF IFR approach, the aircraft is proceeding towards the IP. Since the IP is designated as a discontinuity, proceeding direct is not possible. When attempting to proceed direct to the IP, only the active leg between the IP and RW01 is activated.

**Figure 7-10: VTF VFR Approach**

## 7.9. Missed Approach and Departure Path Definition

Once on the final approach segment (dashed line course similar to instrument approach chart portrayal), the pilot has the option to initiate an immediate missed approach or to arm the system to execute the missed approach at the MAWP. When arming the missed approach, the pilot may take this action before crossing the MAWP, in which case the equipment arms the missed approach for automatic initiation at the MAWP. If a missed approach is not initiated prior to crossing the MAWP, the IDU automatically switches to FROM mode at the MAWP and continues on the same course.



**Figure 7-11: Missed Approach Dashed Line**

If the pilot initiates the missed approach, the IDU provides guidance relative to the procedure. If a missed approach is armed prior to crossing the MAWP, the desired path, to and after the MAWP is defined by the procedure. If the first leg in the missed approach procedure is not a straight path aligned within 3° of the final approach course, the FSD changes to terminal mode FSD ( $\pm 1\text{NM}$ ) when the missed approach is initiated. Otherwise, the FSD changes to  $\pm 0.3\text{NM}$  when the missed approach is initiated (departure mode), and changes to terminal mode FSD ( $\pm 1\text{NM}$ ) at the turn initiation point of the first waypoint in the missed approach procedure.

The pilot may manually select DP guidance, and if the first leg in the DP is not a straight path aligned within 3° of the runway heading, terminal mode FSD ( $\pm 1\text{NM}$ ) is used. Otherwise, the FSD is  $\pm 0.3\text{NM}$  (departure mode) and changes to terminal mode FSD ( $\pm 1\text{NM}$ ) at the turn initiation point of the first waypoint in the DP.

The pilot may select DP guidance. If the first leg in the DP is not a straight path aligned within 3° of the runway heading, terminal mode FSD ( $\pm 1$ NM) is used. Otherwise, the FSD is  $\pm 0.3$  NM (departure mode) and changes to terminal mode FSD ( $\pm 1$ NM) at the turn initiation point of the first waypoint in the DP.

### 7.10. Loss of Navigation Monitoring

The IDU continuously monitors, independent of any operator action, for loss of navigation capability. In Manual RNP mode or Automatic RNP mode prior to sequencing the FAWP, the loss of navigation caution is displayed using a 10 second time to alert if the RNP value is less than 2NM and a 30 second time to alert otherwise. The **FAULTS** menu enables the pilot to distinguish the cause of the loss of navigation caution. The caution returns to its normal state upon termination of the responsible condition.

### 7.11. Discontinuities

Where the IDU is unable to construct a smooth flight path as described above due to active flight plan waypoint spacing (i.e., spacing too close for turn radius), a discontinuity is placed between the waypoints. When a discontinuity exists, no path or skyway is drawn between the waypoints. The pilot cannot activate the waypoint exiting the discontinuity, as it is not possible to provide path guidance to this waypoint. Attempts to activate the waypoint exiting the discontinuity result in activation of the next waypoint or, if there is no next waypoint (i.e., end of active flight plan) activation of the waypoint leading into the discontinuity. Discontinuities are created where the NavData coding specifies a manual termination leg (ARINC 424 path types FM (Course from a Fix to Manual Termination) and VM (Heading to Manual Transition)).


## 7.12. Selection of an Instrument Procedure

When an instrument procedure is selected and active, the receiver notifies the pilot of the most accurate level of service supported by the combination of the GPS/SBAS signal, the receiver, and the selected approach with naming conventions on the minima lines of the selected approach procedure. Once the level of service has been given, the EFIS operates in this mode for the duration of the procedure, unless that level of service becomes unavailable. The EFIS cannot change back to a more accurate level of service until the next time an approach is activated. The following includes examples of the following procedures serving as sample Step-By-Step procedures:

- 1) STAR
- 2) ILS Instrument Approach
- 3) LOC BC Instrument Approach
- 4) RNAV GPS Instrument Approach to LPV minima
- 5) NRST ILS Instrument Approach
- 6) VOR DME Instrument Approach




If the selected waypoint is an airport with a published STAR, this option is available for selection from a list of available STARs, transitions, and runways. After selection, the appropriate STAR is created and displayed on the MAP page. Activating a STAR automatically deletes any pre-existing STAR and is inserted prior to any approach waypoints if previously entered.



- 1) The arrival airport must be entered as a waypoint.
- 2) Push **1** with desired airport highlighted.
- 3) Scroll **1** to **STAR..** and push to enter.
- 4) Scroll **1** to desired STAR and push to enter.
- 5) Scroll **1** to desired transition and push to enter.
- 6) Scroll **1** to desired runway and push to enter.
- 7) Scroll **1** to desired waypoint to comply with ATC clearance and push to enter.
- 8) Once a VNAV altitude has been entered for any waypoint within the STAR, subsequent waypoints follow with altitude, bearing, distance, and ETE/ETA values.

Figure 7-13: STAR Procedure (Step-By-Step)



- 9) The STAR route may be viewed on the MAP page.
- 10) If ATC issues a clearance to another waypoint on the STAR, press **ACTV (L2)**, scroll **1** to desired waypoint, press **(R4)**, then push **1** to enter.
- 11) ATC has issued a clearance to HOLD at HYDRR intersection on course left turns.
- 12) Course guidance and turn anticipation are provided on the PFD with HITS boxes which connect waypoints throughout the procedure.

**Figure 7-14: STAR Procedure (Step-By-Step) (Continued)**

STARS normally terminate at a FIX near the airport, then a radar vector or feeder route is used for transition to the approach phase of the arrival. If an Instrument approach is activated during the STAR, the approach waypoints are inserted after the STAR.



### 7.12.2. ILS Instrument Approach




Figure 7-15: ILS RWY 6 (BDR)

All approach operations typically begin with the same basic steps. This example selects the ILS RWY 6 at Bridgeport/IGOR I. Sikorsky (KBDR).




- 1) Press **ACTV (L2)**.
- 2) The intended landing airport must be selected as the Active waypoint.
- 3) Scroll **1** to select the desired airport then push to enter.



- 4) Scroll **1** and select **IFR APPR..** then push to enter.



- 5) Scroll **1** to select desired approach then push to enter.



- 6) To select transition, scroll **1** to desired transition (\* indicates the most logical from current position) then push to enter.



- 7) Scroll **1** to desired landing runway then push to enter.

**Figure 7-16: ILS Instrument Approach (Step-By-Step)**



- 8) If instructed to Hold at STANE, auto waypoint sequencing is suspended, and **CONT (L5)** is presented until ready for the approach
- 9) The Outer Marker is displayed on the PFD
- 10) Decision Height has been set to 300' and the MDA for the Localizer minima has been set to 380' MSL
- 11) Nav #1 is tuned to the I-BDR Localizer frequency, and The Final Approach Course is set to 060°



- 12) Inside the FAF with Auto waypoint sequencing suspended again until the ARM tile button is pressed.
- 13) After **ARM (L2)** is pressed, **SUSPEND** disappears, and auto waypoint sequencing continues through the full Missed approach procedure.
- 14) The VDI disappears upon passage of the MAP.

**Figure 7-17: ILS Instrument Approach (Step-By-Step)  
(Continued)**



- 15) On short final slightly below glideslope.
- 16) Below localizer minimums and not yet at decision height.
- 17) The LNAV APPR advisory label is present as a default type of approach.

**Figure 7-18: ILS Instrument Approach (Step-By-Step)  
(Continued)**

### 7.12.3. LOC Back Course Instrument Approach





Figure 7-19: LOC Back Course Approach




- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to desired airport active waypoint and push to enter.
- 3) Scroll **1** to **IFR APPR..** and push to enter.
- 4) Scroll **1** to **LBCA** and push to enter.
- 5) Scroll **1** to desired transition (\* indicates the most logical from current position) then push to enter.
- 6) Scroll **1** to desired runway and push to enter.
- 7) Follow ATC clearance and determine where to proceed. To view NAV LOG, push **1** then scroll to **NAV LOG** and push to enter.
- 8) Assume ATC issued clearance to proceed direct to **KOAKS**, **ACTV (L2)** was pressed, and **R4** was pressed when **KOAKS** was highlighted.

Figure 7-20: LOC Back Course Approach (Step-By-Step)



- 9) To set minimums, press **MENU (R1)**, **BUGS (R2)**, **MINS (R3)**, scroll **1** to **MIN ALT...**, and push to enter. Scroll **1** to set desired minimum altitude and push to enter.
- 10) Set 108.9 MHz in Nav #1 or #2 as applicable and Press **OBS (L4)**. Press **NAV VLOC1 (L3)** or **NAV VLOC2 (L4)** as applicable. Scroll **1** to set front course bearing of 120 ° and push to enter. This results in proper sensing of Back Course CDI indications.
- 11) Due to aircraft heading being more than 105° beyond the front course bearing of 120°, the HSI indicates a BC1 120° setting. Back Course sensing is therefore automatic with reversal of the CDI presentation for natural tracking guidance.
- 12) Approaching step down fix PATER, press **ARM (L6)** to arm the Missed Approach Procedure.

**Figure 7-21: LOC Back Course Approach (Step-By-Step)  
(Continued)**



13) The missed approach procedure automatically sequences when passing the MAWP or press **MISS (L5)** at any time.



14) During the missed approach procedure, the FMS automatically changes to FMS guidance.

**Figure 7-22: LOC Back Course Approach (Step-By-Step) (Continued)**



### 7.12.4. RNAV (GPS) Instrument Approach to LPV Minima




Figure 7-23: RNAV (GPS) Instrument Approach to LPV Minima



- 1) Select airport as in previous example.
- 2) In this example scroll **1** to **RNAV32 (99617)** then push to enter.
- 3) Scroll **1** to desired transition and runway then push to enter as described in previous example.
- 4) Scroll **1** to scale map to desired value and observe Top of Descent point within Instrument approach procedure.
- 5) Observe active leg magenta line and next leg in white.

**Figure 7-24: RNAV (GPS) Instrument Approach to LPV Minima (Step-By-Step)**



- 6) Inside FAF, press **ARM (L6)** prior to Step down FIX, HOLUS.
- 7) Upon passing SIVYO with **ARM (L6)** pressed, auto waypoint sequencing continues.
- 8) The VDI displays vertical guidance for the LPV vertical profile based on GPS/SBAS.
- 9) Obstructions appear on PFD and MAP page.
- 10) The bottom example shows the Flight Path Marker lined up on the active runway after passing through minimums and on glidepath.

**Figure 7-25: RNAV (GPS) Instrument Approach to LPV Minima (Step-By-Step) (Continued)**

## 7.12.5. NRST ILS Instrument Approach






Figure 7-26: NRST ILS Instrument Approach



- 1) Press **NRST (R3)** then scroll **1** to **ILS..** and push to enter.
- 2) Scroll **1** to desired airport and runway then push to enter. (ILS must precede airport.)
- 3) Push **1** to **CONFIRM ACTIVATE ILS.**



The following actions occur:

- 1) Direct flight plan to the ILS Airport is created.
- 2) Vectors-to-Final ILS approach is activated.
- 3) Heading Bug is activated to the current heading.
- 4) VLOC 1 and VLOC 2 OBS settings are set to the Associated Localizer course.
- 5) HSI source is switched as follows:
  - a) ILS is automatically switched to VLOC 1.




**Figure 7-27: Nearest ILS Instrument Approach (Step-By-Step)**




- 6) The EFIS automatically changes to LOC1 and the VDI indicates source of Glideslope GS1.
- 7) Inside the **FAF**, **ARM (L6)** and **MISS (L5)** appear with auto waypoint suspended.
- 8) Press **ARM (L6)** to continue auto waypoint sequencing.
- 9) During the Missed Approach, the HSI is automatically reset to FMS1. Dashed magenta and white lines lead the flight to the Holding Waypoint
- 10) Scroll **1** to scale the MAP for desired view of published Missed Approach Procedure.

**Figure 7-28: Nearest ILS Instrument Approach (Step-By-Step) (Continued)**

### 7.12.6. VOR/DME Instrument Approach



**Figure 7-29: VOR/DME Instrument Approach**



- 1) With the destination airport entered as the waypoint select the **IFR APPR..** and type of approach.
- 2) Scroll **1** to select desired runway and push to enter.
- 3) View **ACTV** flight plan and press **EXIT (R1)** to remove menu.
- 4) Scroll **1** to view procedure with desired MAP scale.

**Figure 7-30: VOR/DME Instrument Approach (Step-By-Step)**





- 5) Minimums are set to 500' as the aircraft tracks along the DME ARC to WEMEN at 2000'.
- 6) The full procedure is shown on the MAP page including MAP on dashed white line.
- 7) Approaching the FAF on glidepath.



- 8) The HSI has been changed to NAV: VOR2 with CDI centered on the final approach course.



**Figure 7-31: VOR/DME Instrument Approach (Step-By-Step) (Continued)**





- 13) PFD below MINIMUMS and beyond the MAWP.
- 14) MAP Page in ARC view displaying MAP routing to MAHWP and terrain rendering with obstructions.

**Figure 7-33: VOR/DME Instrument Approach (Step-By-Step)  
(Continued)**

**NOTE:**

Navigation databases are expected to be current for the duration of the flight. If the Aeronautical Information Regulation and Control (AIRAC) cycle is due to change during the flight, operators and pilots should establish procedures to ensure the accuracy of navigation data including suitability of navigation facilities used to define the routes and procedures for flight. Traditionally, this has been accomplished by verifying electronic data against paper products. Once acceptable means is to compare aeronautical charts (new and old) to verify navigation fixes prior to departure. If an amended chart is published for the procedure, the database must not be used to conduct the operation.

**NOTE:**

Pilots may notice a slight difference between the navigation information portrayed on the chart and their primary navigation display heading. Differences of three degrees or less may result from equipment manufacturer's application of magnetic variation and are operationally acceptable.

**NOTE:**

GPS Receivers do not "Fail Down" to lower levels of service once the approach has been activated. If only **VERT LON** appears, the pilot may elect to use the LNAV minima if the rules under which the flight is operating allow changing the type of approach being flown after commencing the procedure. If the lateral integrity limit is exceeded on an LP approach, a missed approach is necessary since there is no way to reset the lateral alarm limit while the approach is active.

# Section 8 Terrain Awareness Warning System

All Airplane TAWS Classes

## Table of Contents

SECTION 8	TERRAIN AWARENESS WARNING SYSTEM...	8-1
8.1.	TAWS (TERRAIN AWARENESS AND WARNING SYSTEM) FUNCTIONS.....	8-5
8.1.1.	<i>Terrain Display</i> .....	8-6
8.2.	FORWARD LOOKING TERRAIN ALERT FUNCTION .....	8-7
8.2.1.	<i>FLTA Modes</i> .....	8-8
8.2.2.	<i>GPS/SBAS Navigation Mode Slaving</i> .....	8-8
8.2.3.	<i>Default FLTA Mode</i> .....	8-8
8.3.	FLTA SEARCH ENVELOPE.....	8-10
8.3.1.	<i>FLTA Search Volume</i> .....	8-12
8.3.2.	<i>FLTA Alerts and Automatic Popup</i> .....	8-12
8.4.	PREMATURE DESCENT ALERT FUNCTION .....	8-14
8.5.	EXCESSIVE RATE OF DESCENT (GPWS MODE 1).....	8-15
8.6.	EXCESSIVE CLOSURE RATE TO TERRAIN (GPWS MODE 2).....	8-17
8.7.	SINK RATE AFTER TAKEOFF OR MISSED APPROACH (GPWS MODE 3).....	8-19
8.8.	FLIGHT INTO TERRAIN WHEN NOT IN LANDING CONFIGURATION (GPWS MODE 4).....	8-20
8.9.	EXCESSIVE DOWNWARD DEVIATION FROM AN ILS GLIDESLOPE (GPWS MODE 5).....	8-22
8.10.	500-FOOT WAKE-UP CALL .....	8-24
8.11.	EXTERNAL SENSORS AND SWITCHES.....	8-24
8.12.	TAWS SYSTEM BASIC PARAMETER DETERMINATION ...	8-25
8.13.	TAWS AUTOMATIC INHIBIT FUNCTIONS (NORMAL OPERATION) .....	8-31
8.13.1.	<i>TAWS Automatic Inhibit Functions (Abnormal Operation)</i> .....	8-31

8.13.2.	<i>TAWS Manual Inhibit Functions</i> .....	8-34
8.14.	TAWS SELECTIONS ON PFD .....	8-34

## List of Figures and Tables

TABLE 8-1: TAWS FUNCTIONS PROVIDED BY THE EFIS .....	8-6
FIGURE 8-1: TERRAIN DISPLAY .....	8-7
FIGURE 8-2: FLTA INHBT .....	8-8
FIGURE 8-3: DEFAULT FLTA INHBT .....	8-9
FIGURE 8-4: FLTA INHBT MODE AREAS .....	8-9
TABLE 8-2: FLTA SEARCH ENVELOPE .....	8-10
FIGURE 8-5: FLTA SEARCH VOLUME .....	8-12
FIGURE 8-6: ND IN POPUP MODE .....	8-13
FIGURE 8-7: PDA ALERT THRESHOLD .....	8-15
TABLE 8-3: GPWS MODE 1 ENVELOPE .....	8-16
FIGURE 8-8: FIXED WING GPWS MODE 1 .....	8-16
TABLE 8-4: GPWS MODE 2 ENVELOPES .....	8-17
TABLE 8-5: GPWS MODE 2A ENVELOPES (NOT IN LANDING CONFIGURATION) .....	8-18
TABLE 8-6: GPWS MODE 2B ENVELOPES (LANDING CONFIGURATION) .....	8-18
FIGURE 8-9: FIXED WING GPWS MODE 2 .....	8-19
FIGURE 8-10: FIXED WING GPWS MODE 3 .....	8-20
TABLE 8-7: MODE 4 ENVELOPES .....	8-21
TABLE 8-8: GPWS MODE 4 PARAMETERS .....	8-21
FIGURE 8-11: FIXED WING GPWS MODE 4 .....	8-22
TABLE 8-9: GPWS MODE 5 ENVELOPES .....	8-23
FIGURE 8-12: FIXED WING GPWS MODE 5 .....	8-23
TABLE 8-10: TAWS EXTERNAL SENSORS AND SWITCHES .....	8-25
TABLE 8-11: AIRPLANE TAWS BASIC PARAMETERS DETERMINATION .... .....	8-26
TABLE 8-12: TAWS AUTOMATIC INHIBIT FUNCTIONS .....	8-31
FIGURE 8-13: PFD SVS BASIC OPTION .....	8-35
FIGURE 8-14: PFD SVS TAWS OPTION .....	8-36
FIGURE 8-15: PFD SVS TAWS OPTION AND OBSTRUCTIONS .....	8-37
FIGURE 8-16: PFD OBSTRUCTION CAUTION .....	8-38
FIGURE 8-17: PFD OBSTRUCTION WARNING .....	8-39



## 8.1. TAWS (Terrain Awareness and Warning System) Functions

The IDU provides TSO-C151b TAWS functionality. The following description is for a TAWS Class A, B and C depending on aircraft configuration and external sensors/switches. Functions provided by TAWS are:

- 1) **Terrain Display:** Display of terrain and obstacles on the PFD and ND.
- 2) **Forward Looking Terrain Awareness (FLTA):** Uses a terrain database and an obstruction database to alert the pilot to hazardous terrain or obstructions in front of the aircraft.
- 3) **Premature Descent Alert (PDA):** Alerts the pilot when descending well below a normal approach glidepath on the final approach segment of an instrument approach procedure.
- 4) **Excessive Rate of Descent (GPWS Mode 1):** Alerts the pilot when the rate of descent is hazardously high as compared to height above terrain (i.e., descending into terrain).
- 5) **Excessive Closure Rate to Terrain (GPWS Mode 2):** Alerts the pilot when the rate of change of height above terrain is hazardously high as compared to height above terrain (i.e., flying level over rising terrain).
- 6) **Sink Rate after Takeoff or Missed Approach (GPWS Mode 3):** Alerts the pilot when a sink rate is detected immediately after takeoff or initiation of a missed approach.
- 7) **Flight into Terrain when not in Landing Configuration (GPWS Mode 4):** Alerts the pilot when descending into terrain without properly configuring the aircraft for landing.
- 8) **Excessive Downward Deviation from an ILS Glideslope (GPWS Mode 5):** Alerts the pilot when an excessive downward glideslope deviation is detected on the final approach segment of an ILS approach.
- 9) **500 foot Wake-up Call:** A single aural callout when descending through 500 feet AGL.

**Table 8-1: TAWS Functions Provided by the EFIS**

Aircraft Type	Airplane				Airplane
	RG + F	RG	FG + F	FG	
<b>TAWS Class</b>	A	A	A	A	B or C
<b>Terrain Display</b>	✓	✓	✓	✓	✓
<b>FLTA</b>	✓	✓	✓	✓	✓
<b>PDA</b>	✓	✓	✓	✓	✓
<b>GPWS Mode 1</b>	✓	✓	✓	✓	✓
<b>GPWS Mode 2</b>	✓	✓	✓	✓	
<b>GPWS Mode 3</b>	✓	✓	✓	✓	✓
<b>GPWS Mode 4</b>	✓	✓	✓		
<b>GPWS Mode 5</b>	✓	✓	✓	✓	
<b>500' Call</b>	✓	✓	✓	✓	✓

Notes: RG + F = Retractable Gear with Defined Landing Flaps Position

RG = Retractable Gear

FG + F = Fixed Gear with Defined Landing Flaps Position

FG = Fixed Gear

### 8.1.1. Terrain Display

The display of terrain on the PFD and ND are described in Sections 3 Display Symbology and 5 Menu Functions and Step-By-Step Procedures of this pilot guide where applicable.



**Figure 8-1: Terrain Display**

## 8.2. Forward Looking Terrain Alert Function

The FLTA function uses the following information to alert the pilot to hazardous terrain or obstructions within a search envelope in front of the aircraft:

- |                                |                            |
|--------------------------------|----------------------------|
| 1) Terrain database            | 5) Aircraft track          |
| 2) Obstruction database        | 6) Aircraft groundspeed    |
| 3) Airport and runway database | 7) Aircraft bank angle     |
| 4) Aircraft position           | 8) Aircraft altitude       |
|                                | 9) Aircraft vertical speed |



Figure 8-2: FLTA INHBT

### 8.2.1. FLTA Modes

The EFIS FLTA mode is either slaved to the GPS/SBAS navigation mode or set automatically based upon default mode logic.

### 8.2.2. GPS/SBAS Navigation Mode Slaving


The EFIS performs TSO-C146c GPS/SBAS system functions in addition to the TAWS functions. As a result, GPS/SBAS navigation mode is available as an input to the TAWS. The pilot may select an IFR procedure (Approach, DP, or STAR) which automatically changes the GPS/SBAS navigation mode to Enroute, Terminal, Departure, or IFR Approach as appropriate. In addition, the EFIS allows the pilot to select a VFR approach to any runway or user waypoint with a defined approach path. Selection of a VFR approach causes automatic GPS/SBAS navigation mode changes to Enroute, Terminal, or VFR Approach as appropriate.

When slaved, the GPS/SBAS active runway threshold or user waypoint is the reference point for automatic FLTA inhibiting. The advantage of this scheme is the GPS/SBAS navigation modes are a direct indication to the FLTA function of pilot intent.

### 8.2.3. Default FLTA Mode

If the default FLTA navigation mode is higher in precedence than the GPS/SBAS navigation mode, the FLTA mode is slaved to the default FLTA navigation mode. These modes, in order of precedence, are as follows:


- 1) **Departure Mode:** This mode is enabled when in Ground Mode. The reference point for automatic FLTA inhibiting and mode envelope definition is the last point at which the ground definition was satisfied (this is near the liftoff point). The Departure Mode ends upon climbing through **1500 feet** above or traveling more than **6NM** from the reference point.



**Figure 8-3: Default FLTA INHBT**

2) **Other Modes:** For other default FLTA modes, the reference point for automatic FLTA inhibiting and mode envelope definition is the nearest runway threshold or the nearest user waypoint with a defined approach bearing. The TAWS system continuously searches all runway thresholds at the nearest three airports to determine the nearest runway threshold. The TAWS system performs a search for the nearest three airports and nearest user waypoints with a defined approach bearing every 3NM of distance traveled. Modes are as follows:

- Approach Mode:** Exists when within **1900 feet and 5NM** of the reference point.
- Terminal Mode:** Exists from **5NM to 15NM** from the reference point when below an altitude that varies from **1900 feet (at 5NM) to 3500 feet (at 15NM)** above the reference point.
- Enroute Mode:** Exists when not in any other mode.



**Figure 8-4: FLTA INHBT Mode Areas**

### 8.3. FLTA Search Envelope

The FLTA search envelope is an area in front of and below the aircraft. If terrain or obstructions are found within the FLTA search envelope, a caution or warning is given to the pilot. The dimensions of the search envelope depend upon TAWS type, FLTA mode (described above), aircraft groundspeed, aircraft bank angle, and aircraft vertical speed. Basic envelope parameters are as follows.

**TAWS Type:** The TAWS type determines the value of several parameters used to calculate the search envelope. These parameters are described in Table 8-2.

**Table 8-2: FLTA Search Envelope**


Envelope	Parameter
Level-Off Rule	<b>Class A &amp; B:</b> 20% of vertical speed <b>Class C:</b> 10% of vertical speed Used for level-off leading for the descending flight Reduced Required Terrain Clearance (RTC) calculation.
Range	60 seconds forward range search envelope. After calculations GPS/SBAS HFOM is added to range.
Enroute Mode Level or Climbing Flight RTC:	<b>Class A &amp; B:</b> 700 feet <b>Class C:</b> 250 feet
Terminal Mode Level or Climbing Flight RTC:	<b>Class A &amp; B:</b> 350 feet <b>Class C:</b> 250 feet
Approach Mode Level or Climbing Flight RTC:	150 feet
Departure Mode Level or Climbing Flight RTC:	100 feet
Enroute Mode Descending RTC:	<b>Class A &amp; B:</b> 500 feet <b>Class C:</b> 200 feet
Terminal Mode Descending RTC:	<b>Class A &amp; B:</b> 300 feet <b>Class C:</b> 200 feet
Approach Mode Descending RTC:	100 feet
Departure Mode Descending RTC:	100 feet

- 1) **Aircraft Track:** The terrain search envelope is aligned with aircraft track.
- 2) **Aircraft Groundspeed:** Aircraft groundspeed is used in conjunction with the range parameter to determine the look-ahead distance. In addition, aircraft groundspeed is used in conjunction with FLTA mode to determine the search volume width as follows:
  - a) **Enroute Mode:** Search volume width is based upon a **30°** change in track followed by **30 seconds** of flight at aircraft groundspeed. Maximum width is 0.5NM either side of track.
  - b) **Terminal Mode:** Search volume width is based upon a **15°** change in track followed by **30 seconds** of flight at aircraft groundspeed. Maximum width is 0.5NM either side of track.
  - c) **Approach Mode:** Search volume width is based upon a **10°** change in track followed by **30 seconds** of flight at aircraft groundspeed. Maximum width is 0.3NM either side of track.
  - d) **Departure Mode:** Search volume width is based upon a **10°** change in track followed by **30 seconds** of flight at aircraft groundspeed. Maximum width is 0.3NM either side of track.

After calculating search volume width as described above, the GPS/SBAS HFOM is added to search volume width.

- 3) **Aircraft Bank Angle:** Used to expand the search volume in the direction of a turn and requires at least 10° of bank. In addition, search volume expansion is delayed such that at 10° of bank, the bank angle must be continuously held for 3.25 seconds. The amount of delay is reduced linearly with increased bank angle so at 30° of bank there is no delay time. Delaying is intended to reduce nuisance search volume expansions when experiencing bank angle excursions due to turbulence.
- 4) **Aircraft Vertical Speed:** Used to determine which RTC values should be used. At vertical speeds above **-500fpm**, level and climbing flight RTC values are used. At vertical speeds less than or equal to **-500fpm**, descending flight RTC values are used. In addition, vertical speed is used to increase the descending flight RTC value used by the system. The increase in descending flight RTC is based upon a three-second pilot reaction time and VSI leading according to the level-off rule parameter.

### 8.3.1. FLTA Search Volume



**Figure 8-5: FLTA Search Volume**

### 8.3.2. FLTA Alerts and Automatic Popup

When terrain or obstructions fall within the FLTA search envelope, an FLTA warning is generated. Terrain rendering is enabled when an FLTA warning is initiated or upgraded as follows:

- 1) On PFD screen, terrain rendering is enabled;
- 2) On navigation display screen, terrain rendering is enabled only if TAWS Inhibit is not enabled (i.e., TAWS Inhibit prevents terrain from being automatically enabled on the navigation display).
- 3) In addition, when an FLTA warning is initiated or upgraded, an automatic popup mode is engaged as follows:



- 4) Display (bottom area) switched to navigation display.
- 5) Display (bottom area) switched to aircraft centered and heading up.
- 6) Display (bottom area) panning disabled.
- 7) Display (bottom area) scale set to:
  - a) 10NM (groundspeed > 200 knots);
  - b) 5 NM (groundspeed <= 200 knots and groundspeed > 100 knots); or
  - c) 2NM (groundspeed <= 100 knots).

After the popup mode is engaged, the pilot may change any setting automatically changed by the popup mode. In addition, **RESET** appears for 20 seconds for the pilot to reset the previous screen configuration with one button press. Popups only occur on IDU #0 or IDU #2 with Class A TAWS enabled and do not occur:

- 1) If TAWS Inhibit is enabled;
- 2) On an IDU-680 in Essential Mode if an Essential EICAS page is shown.



Figure 8-6: ND in Popup Mode

#### 8.4. Premature Descent Alert Function

This function applies to this airplane's TAWS system and uses the following:


- 1) GPS/SBAS navigation database
- 2) GPS/SBAS navigation mode
- 3) Aircraft position
- 4) Aircraft altitude

This alerts the pilot when descending well below a normal approach glidepath on the final approach segment of an instrument approach procedure.

The PDA function is armed when on the final approach segment of an IFR approach procedure and below the FAF crossing altitude. The alerting threshold for the PDA function is  $0.5^\circ$  less than the lower of:

- 1) a straight line from the FAF to the approach runway threshold;  
or
- 2)  $3^\circ$

When the aircraft descends below the threshold, a PDA warning is generated. The PDA alert threshold is depicted in Figure 8-7.




**Figure 8-7: PDA Alert Threshold**

### 8.5. Excessive Rate of Descent (GPWS Mode 1)

The GPWS Mode 1 function uses aircraft vertical speed information and AGL altitude to alert the pilot when the rate of descent is hazardously high as compared to height above terrain. GPWS Mode 1 has a caution and a warning threshold. When below the thresholds, a GPWS Mode 1 warning is generated. The curve is shown in Figure 8-8.

**Table 8-3: GPWS Mode 1 Envelope**

Sink Rate (fpm)	AGL Altitude (ft.)	
	"Sink Rate" Caution Threshold	"Pull Up" Warning Threshold
< 2360	$125\% \times (\text{Sink Rate} - 1416)$	$66\% \times (\text{Caution Threshold})$
2360 to 4900	Lesser of: 2450, or, $50\% \times (\text{Sink Rate})$	


**Figure 8-8: Fixed Wing GPWS Mode 1**

## 8.6. Excessive Closure Rate to Terrain (GPWS Mode 2)

This function is present in Class A TAWS system. The GPWS Mode 2 function uses filtered AGL rate and AGL altitude to alert the pilot when the rate of change of height above terrain is hazardously high as compared to height above terrain (i.e., flying level over rising terrain). AGL rate filtering is based upon a 10 second sampling time.

There are two Mode 2 envelopes: Mode 2A which is active when not in landing configuration, and Mode 2B which is active when in landing configuration. Envelope selection is determined as follows.

**Table 8-4: GPWS Mode 2 Envelopes**

<b>Configuration</b>	<b>Mode 2A</b>	<b>Mode 2B</b>
Retractable Gear with Defined Landing Flaps Position	Flaps NOT in landing configuration	Flaps in landing configuration
Retractable Gear	Landing Gear UP	Landing Gear DOWN
Fixed Gear with Defined Landing Flaps Position	Flaps NOT in landing configuration	Flaps in landing configuration
Fixed Gear	AGL Altitude > 500 ft or Airspeed > $V_{FE}$	AGL Altitude $\leq$ 500 ft or Airspeed $\leq$ $V_{FE}$

When the GPWS Mode 2 envelope is pierced, a GPWS Mode 2 warning is generated.


**Table 8-5: GPWS Mode 2A Envelopes (NOT in Landing Configuration)**

AGL Rate (fpm)	AGL Altitude (ft.)	
	“Caution, Terrain” Caution Threshold	“Pull Up” Warning Threshold
< 3900	$80\% \times (\text{AGL Rate} - 2000)$	
> 3900	1520 + 15% of the lesser of:	
	Airspeed (KIAS)	AGL Rate (fpm)
	< 220	6000
	220 to 300	$6000 + 50 \times (\text{Airspeed} - 220)$
> 300	10,000	
	or AGL Rate	
		$66\% \times (\text{Caution Threshold})$

**Table 8-6: GPWS Mode 2B Envelopes (Landing Configuration)**

AGL Altitude (ft.)	
“Caution, Terrain” Caution Threshold	“Pull Up” Warning Threshold
Lesser of: 800, or, $80\% \times (\text{AGL Rate} - 2000)$	$66\% \times (\text{Caution Threshold})$

Envelope Depictions Mode 2 envelopes are shown in Figure 8-9.




**Figure 8-9: Fixed Wing GPWS Mode 2**

### 8.7. Sink Rate after Takeoff or Missed Approach (GPWS Mode 3)

The GPWS Mode 3 function uses aircraft vertical speed information and AGL altitude to alert the pilot when a sink rate is detected immediately after takeoff or initiation of a missed approach.

GPWS Mode 3 is armed by either being in Ground Mode or by being on the first leg of a missed approach procedure (as determined by the GPS/SBAS) with distance to the active runway threshold increasing. GPWS Mode 3 is disarmed upon climbing through **700 feet AGL**, traveling more than **6NM** from the last point at which the ground definition was satisfied (this is near the liftoff point), or transitioning to the second leg of a missed approach procedure. GPWS Mode 3 has a caution threshold based upon height above terrain and vertical speed. When below the caution threshold, a GPWS Mode 3 warning is generated as defined in Figure 8-10.

$$\text{"Don't Sink" AGL} = 1.4 * \text{sink rate}$$



**Figure 8-10: Fixed Wing GPWS Mode 3**

### 8.8. Flight into Terrain When Not in Landing Configuration (GPWS Mode 4)

This function is present in Class A TAWS systems. The GPWS Mode 4 function uses aircraft speed information and AGL altitude to alert the pilot when descending into terrain without properly configuring the aircraft for landing. There are two Mode 4 envelopes: Mode 4A which gives cautions when landing gear is in other than landing configuration, and Mode 4B which gives cautions when landing gear or flaps are in other than landing configuration. Applicability of Mode 4 envelopes to aircraft types are as follows.



**Table 8-7: Mode 4 Envelopes**

Configuration	Mode 4A	Mode 4B
Retractable Gear with Defined Landing Flaps Position	Landing Gear UP	Landing Gear UP or flaps not in landing configuration.
Retractable Gear	Landing Gear UP	Landing Gear UP
Fixed Gear with Defined Landing Flaps Position	Not Applicable	Flaps not in landing configuration
Fixed Gear	Not Applicable	Not Applicable

Mode 4 alerting criteria requires the Mode 4 envelope is entered from above so changing aircraft configuration while within a Mode 4 envelope does not generate an alert.

Airplane Mode 4 envelopes consists of a low-speed region and a high-speed region. When Mode 4A alerting criteria are met in the low-speed region, **TOO LOW** is presented in conjunction with a single “**Too Low Gear**” aural alert. When Mode 4B alerting criteria are met in the low-speed region, **TOO LOW** is presented in conjunction with either a single “**Too Low Gear**” aural alert (if landing gear is UP) or a single “**Too Low Flaps**” aural alert (if landing gear is DOWN). When either Mode 4 alerting criteria are met in the high-speed region, **TOO LOW** is presented in conjunction with a single “**Too Low Terrain**” aural alert.

**Table 8-8: GPWS Mode 4 Parameters**

Mode	Region	Speed (KIAS)	AGL Altitude (ft.)
4A	Low-Speed	< 182.5	500
	High-Speed	≥182.5	Lesser of: 800, or, 8 × (KIAS – 120)
4B	Low-Speed	< 138.75	150
	High-Speed	≥ 138.75	Lesser of: 800, or, 8 × (KIAS – 120)




**Figure 8-11: Fixed Wing GPWS Mode 4**

### 8.9. Excessive Downward Deviation from an ILS Glideslope (GPWS Mode 5)

The GPWS Mode 5 function uses ILS glideslope deviation information and AGL altitude to alert the pilot when an excessive downward glideslope deviation is detected on the final approach segment of an ILS approach. GPWS Mode 5 is armed when a valid glideslope signal is being received AND the aircraft is below **1000' AGL**.

GPWS Mode 5 has a caution and a warning threshold. When below a threshold, a GPWS Mode 5 warning is generated. The curve compares glideslope deviation to AGL altitude as shown in Figure 8-12 (Reference: RTCA/DO-161A Mode 5 for TAWS systems).

<b>Table 8-9: GPWS Mode 5 Envelopes</b>	
<b>Caution Threshold</b>	<b>Warning Threshold</b>
Greater of: $\left[ 1.3 + 1.4\% \times (150 - \text{AGL Altitude}) \right] \text{ Dots}$ or 1.3 Dots	Greater of: $\left[ 2 + 1\% \times (150 - \text{AGL Altitude}) \right] \text{ Dots}$ or 2 Dots



**Figure 8-12: Fixed Wing GPWS Mode 5**

### 8.10. 500-Foot Wake-Up Call

This function is present in all TAWS classes. The **500-foot** function includes an arming deadband of **500 feet** to prevent nuisance warnings during low altitude operations. Thus, the aircraft must climb above **1000 feet** AGL to arm the **500-foot** function and generate a **500-foot** annunciation.

### 8.11. External Sensors and Switches

The EFIS TAWS system requires a variety of inputs from external sensors and switches to perform its functions. These inputs are as follows:

- 1) **GPS/SBAS receiver.** Source of aircraft position, geodetic height, horizontal figure of merit (HFOM), vertical figure of merit (VFOM), loss of integrity (LOI) and loss of navigation (LON) inputs for the TAWS. The GPS/SBAS receiver connects directly to the EFIS IDU.
- 2) **Air Data Computer (ADC).** Source of barometric altitude, outside air temperature, and vertical speed for the TAWS and connects directly to the EFIS IDU.
- 3) **ILS Receiver.** Source of glideslope deviation for the TAWS.
- 4) **Radar Altimeter (RA).** Source for radar altitude for the TAWS.
- 5) **Gear Position Sensors.** Landing gear position discrettes, as configured in the system limits, are the source of landing gear position for the TAWS.
- 6) **Flap Position Sensor.** A flap position discrete, as configured in the system limits is the source of flap position for the TAWS.
- 7) **TAWS Inhibit Switch.** As configured in the system limits, is used for manual inhibiting of TAWS alerting functions. The TAWS Inhibit Switch is of the latching type and gives an obvious indication of actuation (e.g., toggle/rocker or pushbutton with **TAWS INHBT** in the lower left corner of the PFD).
- 8) **Audio Mute Switch.** Used for silencing active aural alerts. The Audio Mute Switch is of the momentary type and is connected directly to the EFIS IDU. The Audio Mute Switch is momentarily pulled to ground when silencing of active aural alerts is desired.

- 9) **Glideslope Deactivate Switch.** As configured in the system limits, is used for inhibiting the GPWS Mode 5 function. The Glideslope Deactivate Switch is of the momentary type and is momentarily activated when inhibition of the GPWS Mode 5 function is desired.

Applicability of external sensors and switches for the applicable TAWS system are as follows.

**Table 8-10: TAWS External Sensors and Switches**

TAWS Class Configuration	A				B or C
	RG+F	RG	FG+F	FG	
GPS/SBAS	✓	✓	✓	✓	✓
ADC	✓	✓	✓	✓	✓
Gear Position Sensor	✓	✓			
TAWS Inhibit Switch	✓	✓	✓	✓	✓
Audio Cancel Switch	✓	✓	✓	✓	✓
ILS	✓	✓	✓	✓	
Radar Altimeter	✓	✓	✓	✓	
Flap Position Sensor	✓		✓		
Glideslope Deactivate Switch	✓	✓	✓	✓	

Notes: RG + F = Retractable Gear with Defined Landing Flaps Position

RG = Retractable Gear

FG + F = Fixed Gear with Defined Landing Flaps Position

FG = Fixed Gear

## 8.12. TAWS System Basic Parameter Determination

The fundamental parameters used for TAWS system functions are as follows.

**Table 8-11: Airplane TAWS Basic Parameters Determination**

Parameter	Source	Notes
Aircraft position, groundspeed and track	GPS/SBAS	The HFOM must be less than or equal to the greater of 0.3 NM or the Horizontal alert limit (HAL) for the mode of flight
MSL Altitude	GPS/SBAS	<p>Geodetic Height converted to MSL with the current EGM (Earth Gravity Model) database. In order for this to be considered valid for use as MSL altitude, the VFOM must be less than or equal to 106 feet.</p> <p>The secondary source of MSL altitude is barometric altitude from an air data computer. Barometric altitude is determined based upon a barometric setting in the following order of preference:</p> <ol style="list-style-type: none"> <li>1) If either the pilot or co-pilot system is operating in QNH mode, the QNH barometric setting is used (on-side barometric setting preferred); or</li> <li>2) If GPS/SBAS geodetic height has been valid within the last 30 minutes, a barometric setting derived from the</li> </ol>

**Table 8-11: Airplane TAWS Basic Parameters Determination**

Parameter	Source	Notes
		<p>GPS/SBAS geodetic height is used.</p> <p>If neither of the above conditions are met, MSL altitude is marked as invalid.</p> <p>When a reporting station elevation is determined and outside air temperature is valid, a temperature correction is applied.</p> <p>TAWS uses the lower of the barometric altitude or the temperature-corrected altitude. In the case of QNH-mode barometric setting, reporting station elevation is derived from waypoint or active runway elevations in the active flight plan using the following logic:</p> <ol style="list-style-type: none"> <li>1) If the aircraft is in <b>TERMINAL, DEPARTURE, IFR APPROACH, or VFR APPROACH</b> mode and an active runway exists, reporting station elevation is the elevation of the active runway threshold.</li> </ol>

**Table 8-11: Airplane TAWS Basic Parameters Determination**

Parameter	Source	Notes
		<p>2) Otherwise, if the aircraft is in <b>TERMINAL</b> mode, reporting station elevation is the elevation of the airport causing <b>TERMINAL</b> mode.</p> <p>3) In <b>ENROUTE</b> mode, no reporting station elevation is determined.</p> <p>In the case of GPS/SBAS geodetic height-based barometric setting, reporting station elevation is the GPS MSL altitude reported at the time the barometric setting was determined. The following definitions:</p> <p><b>QFE:</b> Barometric setting resulting in the altimeter displaying height above a reference elevation (e.g., airport or runway threshold).</p> <p><b>QNE:</b> Standard barometric setting (29.92 inHg or 1013 mbar) used to display pressure altitude for flight above the transition altitude.</p> <p><b>QNH:</b> Barometric setting resulting in the altimeter displaying altitude above</p>



**Table 8-11: Airplane TAWS Basic Parameters Determination**

Parameter	Source	Notes
		mean sea level at the reporting station.
Terrain Data	Terrain Database	<p>In order for terrain data to be considered valid for use by the TAWS, the following conditions must be met:</p> <ol style="list-style-type: none"> <li>1) Aircraft position is valid;</li> <li>2) Aircraft position is within the boundaries of the terrain database; and</li> <li>3) Terrain database is not corrupt as determined by CRC-32 checks at system initialization and during runtime.</li> </ol>
Obstacle Data	Obstacle Database	<p>In order for obstacle data to be considered valid for use by the TAWS, the following conditions must be met:</p> <ol style="list-style-type: none"> <li>1) Aircraft position is valid;</li> <li>2) Aircraft position is within the boundaries of the obstacle database; and</li> <li>3) Obstacle database is not corrupt as determined by CRC-32 checks at system initialization.</li> </ol>

**Table 8-11: Airplane TAWS Basic Parameters Determination**

Parameter	Source	Notes
AGL Altitude	Radar Altitude	The secondary source for AGL altitude is MSL altitude less terrain altitude.
Vertical Speed	Instantaneous vertical speed	IVSI values come from barometric vertical speed from an ADC “quickened” with vertical acceleration from an AHRS. The secondary source for vertical speed is barometric vertical speed from an ADC. The tertiary source for vertical speed is GPS/SBAS vertical speed providing the VFOM is less than or equal to 106 feet.
Terrain Closure Rate	The smoothed first derivative of AGL altitude	Due to the multiple sources for altitude, there are multiple sources for terrain closure rate.
Runway/Reference point location	EFIS navigation database	In order to be considered valid for use, the following conditions must apply: <ol style="list-style-type: none"> <li>1) Aircraft position is valid;</li> <li>2) Aircraft position is within the boundaries of the navigation database; and</li> <li>3) Navigation database is not corrupt as determined by a CRC-32 check at system initialization.</li> </ol>

### 8.13. TAWS Automatic Inhibit Functions (Normal Operation)

The following automatic inhibit functions occur during normal TAWS operation to prevent nuisance warnings:

- 1) **FLTA function** is automatically inhibited when in the **Terminal, Departure, IFR Approach, or VFR Approach** Modes and within **2NM** and **1900'** of the reference point.
- 2) **PDA function** is automatically inhibited when within **2NM** and **1900'** of the approach runway threshold.
- 3) **GPWS Modes 1 through 4** is automatically inhibited when below **50 feet AGL** (radar altimeter AGL altitude) or below **100 feet AGL** (terrain database AGL altitude).
- 4) **GPWS Mode 5** is inhibited below **200' AGL**. This form of automatic inhibit remains active until the aircraft climbs above **1000' AGL**. The purpose of this form of inhibiting is to prevent nuisance alarms on missed approach when the glideslope receiver detects glideslope sidelobes.

#### 8.13.1. TAWS Automatic Inhibit Functions (Abnormal Operation)

The following automatic inhibit functions occur during the specified abnormal operations.

**System Sensor/Database Failures.** System sensor failures, non-installation of optional sensors, database failures, and combinations thereof affect the TAWS system as follows.

Table 8-12: TAWS Automatic Inhibit Functions										
Sensor	Parameters Lost	Terrain Displaced	FLTA	PDA	GPWS Mode					500' Wake-Up
					1	2	3	4	5	
GPS/SBAS (H)	AC Position	Inhibit	Inhibit	Inhibit						

**Table 8-12: TAWS Automatic Inhibit Functions**

Sensor	Parameters Lost	Terrain Displaced	FLTA	PDA	GPWS Mode					500' Wake-Up
					1	2	3	4	5	
TD	Terrain Elev.	Inhibit	Inhibit							
ILS	Glide-slope Dev.								Inhibit	
MSL	MSL Altitude	Inhibit	Inhibit	Inhibit						
GPS/SBAS (H) + RADLT	AC Position, AGL Altitude	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit
GPS/SBAS (V) + ADC	MSL Altitude, VSI	Inhibit	Inhibit	Inhibit	Inhibit		Inhibit			
TD + RADLT	Terrain Elev. AGL Altitude	Inhibit	Inhibit		Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit
MSL + RADLT	MSL Altitude, AGL Altitude	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit

**Table 8-12: TAWS Automatic Inhibit Functions**

Sensor	Parameters Lost	Terrain Displaced	FLTA	PDA	GPWS Mode					500' Wake-Up
					1	2	3	4	5	
GPS/SBAS (V) + ADC + RADLT	MSL Altitude, VSI, AGL ALT	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit

## Notes:

- 1) The combinations listed give the minimum combinations with the worst consequences. Many other combinations are possible, but their effects are subsumed within the combinations listed.
- 2) GPS/SBAS (H) = HFOM > max (0.3NM, HAL). Indication is loss of terrain display on PFD and ND.
- 3) GPS/SBAS (V) = VFOM > 106'.
- 4) GPS/SBAS = GPS/SBAS (H) + GPS/SBAS (V). Indication is loss of terrain display on PFD and ND.
- 5) TD = Terrain Data invalid. This is due to being beyond the database boundaries or database corruption.
- 6) ADC = Air Data Computer. Indication is **ADC1 FAIL** / **ADC2 FAIL** flags.
- 7) Radalt = Radar Altimeter. Indication is lack of radar altimeter source indication on radar altimeter display.
- 8) ILS = ILS Glideslope Deviation. Indication is lack of glideslope needles.
- 9) MSL=MSL Altitude Invalid. Indication is **NO TAWS** in the absence of other failures.

### 8.13.2. TAWS Manual Inhibit Functions

The pilot may select the following manual inhibit functions:

- 1) **Terrain Display** Use an EFIS soft menu declutter control function to inhibit.
- 2) **All TAWS** alerting functions (including popup functionality) are manually inhibited by actuation of the external TAWS Inhibit Switch. The TAWS Inhibit Switch does not affect the Terrain Display function, including display of FLTA warning (red) and caution (amber [yellow]) flags on the ND.
- 3) **GPWS Mode 5** manually inhibited by actuation of the momentary Glideslope Cancel Switch when below **1000' AGL**. GPWS Mode 5 manual inhibit automatically resets by ascending above **1000' AGL**.

### 8.14. TAWS Selections on PFD


The PFD Declutter menu includes three option possibilities for TAWS as follows:

- 1) SVS TAWS
- 2) SVS BASIC
- 3) None

The following figures below show all possible scenarios including “None” where the aircraft pierces the TAWS FLTA Terrain envelope, and SVS TAWS automatically becomes enabled for the safest possible warning alert condition.




Figure 8-13: PFD SVS BASIC Option



**TAWS FLTA Caution Terrain: Amber (Yellow)**  
**TAWS FLTA Caution Warning: Red**

**Figure 8-14: PFD SVS TAWS Option**





Obstruction above aircraft

Obstruction below aircraft

Figure 8-15: PFD SVS TAWS Option and Obstructions



Obstruction within TAWS FLTA caution envelope with aural annunciation “Caution Obstruction, Caution Obstruction”. The obstruction symbols flash.

**Figure 8-16: PFD Obstruction Caution**



Obstruction within TAWS FLTA warning envelope with aural annunciation “Warning Obstruction, Warning Obstruction”, the obstruction symbols flash.

**Figure 8-17: PFD Obstruction Warning**

# Section 9      Appendix

## Table of Contents

SECTION 9	APPENDIX .....	9-1
9.1.	APPENDIX .....	9-5
9.2.	OPERATING TIPS .....	9-5
9.3.	DOMESTIC OR INTERNATIONAL FLIGHT PLANNING .....	9-5
9.3.1.	<i>Descent Planning</i> .....	9-5
9.3.2.	<i>Terrain Clearance</i> .....	9-5
9.3.3.	<i>Departure Airport Information</i> .....	9-6
9.3.4.	<i>Unique Names for Flight Plans</i> .....	9-6
9.3.5.	<i>Altimeter Settings</i> .....	9-6
9.3.6.	<i>Warnings, Cautions, and Advisories</i> .....	9-6
9.4.	MAGNETIC VS. TRUE NORTH MODES OF OPERATION .....	9-7
9.5.	ALTITUDE MISCOMPARE THRESHOLD .....	9-8
9.6.	AIRSPPEED MISCOMPARE THRESHOLD .....	9-9
9.7.	JEPPESEN NAVDATA CHART COMPATIBILITY .....	9-11
9.8.	ARINC 424 PATH-TERMINATOR LEG TYPES .....	9-12
9.9.	DATA LOGGING AND RETRIEVAL .....	9-17
9.10.	LOG FILES .....	9-18
9.10.1.	<i>Delete LOG Files</i> .....	9-18
9.11.	ROUTES AND WAYPOINTS .....	9-18
9.11.1.	<i>VFR Flight Planning</i> .....	9-18
9.11.2.	<i>Download Routes and User Waypoints</i> .....	9-19
9.12.	EFIS TRAINING TOOL (ETT) .....	9-19
9.13.	UPLOAD ROUTES AND USER WAYPOINTS .....	9-19
9.13.1.	<i>Delete Routes</i> .....	9-19
9.13.2.	<i>Upload Routes and User Waypoints</i> .....	9-19

9.13.3.	<i>Delete Routes</i> .....	9-20
9.14.	USB EXTERNAL DRIVE MEMORY LIMITATIONS .....	9-20
9.15.	SERVICE DIFFICULTY REPORT.....	9-21
9.16.	CERTIFICATION BASIS.....	9-22
9.17.	ENVIRONMENTAL REQUIREMENTS .....	9-24

## List of Figures and Tables

FIGURE 9-1: US/UK WORLD MAGNETIC MODEL .....	9-7
TABLE 9-1: ALLOWABLE INSTRUMENT ERROR .....	9-8
TABLE 9-2: REGULATORY REFERENCE .....	9-9
TABLE 9-3: AIRSPEED ERROR .....	9-10
TABLE 9-4: AIRSPEED REGULATORY REFERENCE .....	9-10
TABLE 9-5: PATH TERMINATORS .....	9-12
FIGURE 9-2: VFR WAYPOINT .....	9-18

## 9.1. Appendix

The appendix of this pilot guide contains a variety of useful information not found elsewhere in the document including operating tips, system specifications, feedback forms, and failure modes.

## 9.2. Operating Tips

With the Genesys Aerosystems EFIS installed and certified in all categories of certified aircraft, numerous tips and suggestions are available for obtaining the maximum performance and benefit from this system. Additional operating tips become available with future releases of this publication.

## 9.3. Domestic or International Flight Planning

Due to the differences in every aircraft avionics suite installation, it is up to the pilot to determine what equipment code is applicable for domestic or international flight plans. It is solely up to the aircraft operator to determine what certifications pertain to them. All certifications are outlined in the Airplane or Rotorcraft Flight Manual Supplement. Helpful FAA links for this information may be found at:

[http://www.faa.gov/about/office\\_org/headquarters\\_offices/ato/service\\_units/air\\_traffic\\_services/flight\\_plan\\_filing/](http://www.faa.gov/about/office_org/headquarters_offices/ato/service_units/air_traffic_services/flight_plan_filing/)

### 9.3.1. Descent Planning

Instead of performing conventional time/speed/distance/descent-rate calculations, use the waypoint symbol for descent planning. Simply maintain the cruise altitude until the "X" at the bottom of the waypoint symbol is 2-3 degrees below the horizon (as indicated by the pitch scale) then begin a 2-3 degree descent. Maintain the correct descent angle by keeping the flight path marker positioned on the waypoint "X" symbol. Following the skyway boxes assures the VNAV descent angle is maintained.

### 9.3.2. Terrain Clearance

Use the flight path marker to evaluate climb performance in regards to terrain clearance. If climbing at the best climb speed to clear terrain and the flight path marker is overlaying the terrain which must be cleared, the climb rate is insufficient. Either the course or climb rate must be altered to adequately clear the terrain. If the flight path



marker is well clear of the terrain (overlying blue), the climb is sufficient for the present time, and no further action is necessary until level off.

### 9.3.3. Departure Airport Information

On startup, all the information for the departure airport is readily available. The altimeter is automatically set (if Baro aut setting on startup is enabled) to the nearest IFR runway touchdown zone elevation. Press **NRST** to reveal the nearest airports when highlighted where all important data such as frequencies are displayed.

### 9.3.4. Unique Names for Flight Plans

Multiple routes between the same airport pairs are numbered automatically (KCEW-KDHN) [0], (KCEW-KDHN) [1], etc.). With some ingenuity, pilots may work around this and apply easily remembered differentiation. If a route is routinely flown from one airport to another but different routing becomes necessary due to MOA areas being hot or weather, etc., two or more different flight plans may be created for the same destination.

Create two different user waypoints at the departure airport named KCEWN and KCEWS as an example for departing Sikes on a northern routing (KCEWN) or a southern routing (KCEWS) followed by the different routing to clear the MOA or whatever creates the necessity for specific routing.


### 9.3.5. Altimeter Settings

Use caution when setting the altimeter and inadvertently changing the transition level. If this is reset to a lower than normal altitude, **CHK BARO** advisory may appear due to the altimeter setting not on 29.92 inHg or 1013 mbar.

### 9.3.6. Warnings, Cautions, and Advisories

Review all conditions found in the Section 2 System Overview for Warnings, Cautions, and Advisories. These conditions precisely define the scenario for the various warnings, cautions, and advisory flags as they appear including the time delay where appropriate and any time delay when applicable.

## 9.4. Magnetic vs. True North Modes of Operation



**Figure 9-1: US/UK World Magnetic Model**

There are two modes for the ADAHRS:

- 1) Slaved mode (i.e., compass rose stabilized by the Earth's magnetic flux horizontal field) is the normal mode. It works well over most of the surface of the Earth (i.e., areas with a horizontal field of 5000nT or above, which includes about 2/3<sup>rd</sup>s of Canadian NDA, see Figure 9-1). The ADAHRS senses magnetic flux with a 3-D magnetometer. Performance in small horizontal fields is installation dependent as variable magnetic disturbances from the aircraft may begin to predominate.
- 2) Free or "DG" mode (i.e., compass rose not stabilized by the Earth's magnetic flux horizontal field and subject to drift) is used in areas of magnetic disturbances (oil rigs, MRI machines, etc.) or in areas where the horizontal field is too weak. In Free/"DG" mode, heading no longer corrects towards the Earth's magnetic flux horizontal field, and the heading solution may be "slewed" by the pilot.

There are two modes for the EFIS:

- 1) Magnetic North mode: In this mode, the heading from the AHRS (whether slaved or Free/"DG") is used as-is and is expected to reflect Magnetic North. GPS Track is converted from True North-referenced to Magnetic North-referenced using a magnetic variation database. The PFD scenes and compass-

rose symbols are aligned with Magnetic North and wind is displayed referenced to Magnetic North.

- 2) True North mode: In this mode, GPS Track is used as-is and reflects True North. When the AHRS is in Slaved mode, the heading from the AHRS is converted from Magnetic North-referenced to True North-referenced using a magnetic variation database. When the AHRS is in Free/"DG" mode, the heading from the AHRS is used as-is and is expected to reflect True North. The PFD scenes and compass-rose symbols are aligned with True North and wind is displayed referenced to True North.

### NOTE:

Designating Magnetic North vs. True North mode is critical since it determines how the inputs are used – i.e., the relationship between GPS Track and ADAHRS Heading. Mixing things up in Free/"DG" mode (e.g., slewing the compass rose to match Magnetic North when in True North mode and vice-versa) may result in large errors in wind calculations and GPS track/flight path marker displays.

## 9.5. Altitude Miscompare Threshold

The altitude miscompare threshold is based upon the allowable altitude error. There are two components to allowable altitude error, instrument error and installed system error. Allowable instrument error is based upon the values of SAE AS8002A Table 1 as follows.

<b>Table 9-1: Allowable Instrument Error</b>	
<b>Altitude</b>	<b>Allowed Error</b>
Sea Level	25'
1,000'	25'
2,000'	25'
3,000'	25'
4,000'	25'
5,000'	25'
8,000'	30'
11,000'	35'
14,000'	40'
17,000'	45'
20,000'	50'
30,000'	75'

**Table 9-1: Allowable Instrument Error**

<b>Altitude</b>	<b>Allowed Error</b>
40,000'	100'
50,000'	125'

Allowable installed system error is added on top of instrument error and these values are derived from the regulations as follows:

**Table 9-2: Regulatory Reference**

<b>Regulation</b>	<b>Allowed Error</b>
14 CFR § 23.1325	At sea level, the greater of 30' or 30% of the calibrated airspeed in knots. This increases proportionally to SAE AS8002A Table 1 at higher altitudes.
14 CFR § 25.1325	
14 CFR § 27.1325	
14 CFR § 29.1325	

An allowable altitude error is computed for each compared value and added together to create the altitude miscompare threshold. This accommodates for the values deviating in different directions.

Worked example for a calibrated airspeed of 100 knots and comparing a first altitude of 3,490' with a second altitude of 3,510':

- 1) Calculate allowable instrument error based upon altitudes:  
 Allowable Instrument Error #1 = 50'  
 Allowable Instrument Error #2 = 50'
- 2) Calculate allowable installed system error based upon altitudes and calibrated airspeed:  
 Allowable Installed System Error #1 = 30'  
 Allowable Installed System Error #2 = 30'
- 3) Calculate altitude miscompare threshold based upon sum of above allowable errors:  
 Altitude Miscompare Threshold = 160'

## 9.6. Airspeed Miscompare Threshold

The airspeed miscompare threshold is based upon the allowable airspeed error. There are two components to allowable airspeed

error, instrument error and installed system error. Allowable instrument error is based upon the values of SAE AS8002A Table 3 as follows.

<b>Table 9-3: Airspeed Error</b>	
<b>Calibrated Airspeed</b>	<b>Allowed Error</b>
50 knots	5 knots
80 knots	3 knots
100 knots	2 knots
120 knots	2 knots
150 knots	2 knots
200 knots	2 knots
250 knots	2.4 knots
300 knots	2.8 knots
350 knots	3.2 knots
400 knots	3.6 knots
450 knots	4 knots

Allowable installed system error is added on top of instrument. Error and these values are derived from the regulations as follows.

<b>Table 9-4: Airspeed Regulatory Reference</b>	
<b>Regulation</b>	<b>Allowed Error</b>
14 CFR § 23.1323	Starting from $(1.3 \times V_{S1})$ : The greater of 5 knots or 3%.  Do not perform a comparison if either value is below $(1.3 \times V_{S1})$ .
14 CFR § 25.1323	Starting from $(1.23 \times V_{SR1})$ : The greater of 5 knots or 3%.  Do not perform a comparison if either value is below $(1.23 \times V_{SR1})$ .  System uses $V_{S1}$ as a substitute for $V_{SR1}$ .
14 CFR § 27.1323	Starting from $(0.8 \times V_{CLIMB})$ : The greater of 5 knots or 3%.  Do not perform a comparison if either value is below $(0.8 \times V_{CLIMB})$ .

**Table 9-4: Airspeed Regulatory Reference**

Regulation	Allowed Error
14 CFR § 29.1323	<p>For Climbing Flight (VSI &gt; 250 feet per minute):</p> <p>Starting from (<math>V_{TOS} - 10</math>): 10 knots</p> <p>Do not perform a comparison if either value is below (<math>V_{TOS} - 10</math>)</p> <p>For Other Flight Regimes:</p> <p>Starting from (<math>0.8 \times V_{TOS}</math>) The greater of 5 knots or 3%.</p> <p>Do not perform a comparison if either value is below (<math>0.8 \times V_{TOS}</math>).</p> <p>System uses <math>V_{CLIMB}</math> as a substitute for <math>V_{TOS}</math>.</p>

An allowable airspeed error is computed for each compared value and added together to create the airspeed miscompare threshold and accommodates for the values deviating in different directions.

### 9.7. Jeppesen NavData Chart Compatibility

As GPS navigation, flight management systems, computer flight maps, and computer flight planning systems have gained acceptance, avionics companies, and software developers have added more and more features. Even with many systems available today paper enroute, departure, arrival, and approach charts are still required and necessary for flight. Avionics systems, flight planning, computer mapping systems, and associated databases *do not* provide all of the navigation information needed to conduct a legal and safe flight. They are not a substitute for current aeronautical charts. See [www.Jeppesen.com](http://www.Jeppesen.com) for the latest information on coding instrument procedures, naming conventions, altitudes within the database, and aeronautical information compatibility.

## 9.8. ARINC 424 Path-Terminator Leg Types





Table 9-5: Path Terminators		
Type ARINC 424 Leg	Abbreviation	Example
DME Arc	<b>AF</b>	<p>Arc to a Fix or defines a track over ground a specified constant distance from a database DME Navaid.</p>
Course to Altitude (Course is flown making adjustment for wind)	<b>CA</b>	<p>Course is flown making adjustment for wind</p>
Course to DME Distance	<b>CD</b>	<p>Course to DME Distance Leg defines a specified course to a specific DM Distance which is from a specific database DME Navaid.</p>

**Table 9-5: Path Terminators**




Type ARINC 424 Leg	Abbreviation	Example
Course to Fix	<b>CF</b>	
Course to Intercept	<b>CI</b>	<p>Course to an Intercept Leg defines a specified course to intercept a subsequent leg.</p>
Course to Radial	<b>CR</b>	<p>Course to a Radial termination Leg defines a course to a specified Radial from a specific database VOR Navaid.</p>
Direct to Fix	<b>DF</b>	
Course from Fix to Altitude	<b>FA</b>	<p>FA leg is flown making adjustment for wind</p>



**Table 9-5: Path Terminators**

Type ARINC 424 Leg	Abbreviation	Example
Course Fix to a Track Distance	<b>FC</b>	Track from a Fix to a Distance Leg defines a specified track over ground from a database fix for a specific distance. 
Course from Fix to DME Distance (Different Fix)	<b>FD</b>	Track from a Fix to a DME Distance Leg defines a specific track from a database fix to a specific DME Distance from a DME Navaid. 
Course from Fix to Manual termination	<b>FM</b>	FM leg is flown making adjustment for wind 
Terminates at an altitude  Holding, Pattern to Fix  Altitude or Manual Termination	<b>HA</b>  <b>HF</b>  <b>HM</b>	HA - Terminates at an altitude HF - Terminates at the fix after one orbit HM - Manually terminated 

**Table 9-5: Path Terminators**

Type ARINC 424 Leg	Abbreviation	Example
Initial Fix leg	<b>IF</b>	<p>The initial Fix Leg defines a database fix as a point in space.</p> <p>It is only required to define the beginning of a route or procedure.</p> 
Procedure Turn	<b>PI</b>	<p>Procedure Turn Leg defines a course reversal starting at a specific fix, includes Outbound Leg followed by 180 degree turn to intercept the next leg.</p> 
Precision Arc to Fix	<b>RF</b>	

**Table 9-5: Path Terminators**








Type ARINC 424 Leg	Abbreviation	Example
Track from Fix to New Fix	<b>TF</b>	Track to a Fix defines a great circle track over ground between two known database fixes.  Preferred type for straight legs.  
Track to a Fix	<b>TF</b>	
Heading to Altitude	<b>VA</b>	No correction made for wind  
Heading to DME Distance	<b>VD</b>	Heading to a DME Distance termination Leg defines a specified heading terminating at a specified DME Distance from a specific database DME Navaid.  

Table 9-5: Path Terminators

Type ARINC 424 Leg	Abbreviation	Example
Heading to Intercept	<b>VI</b>	<p>Heading to an Intercept Leg defines a specified heading to intercept the subsequent leg at an unspecified position.</p> 
Heading to Manual Termination	<b>VM</b>	<p>Heading to a Manual Termination Leg defines a specified heading to a specified radial from a specific database VOR Navaid.</p> 
Heading to Radial	<b>VR</b>	<p>Heading to a Radial termination Leg defines a specified heading to a specified radial from a specific database VOR Navaid.</p> 

## 9.9. Data Logging and Retrieval

The Genesys Aerosystems EFIS logs all data associated with a flight, including all flight instrument and navigation data. This data may be downloaded for review after flight. Data from the last five flights or 20 hours are logged at a one-second interval.

Selecting the “Download LOG Files” option on the IDU creates a “log” directory on the USB Memory and copy the data logging files into the “log” directory of the USB Memory. The data logging files contain recordings of flight and engine parameters of up to five hours

each from the previous five operations of the system. During system operation, flight and engine parameters are recorded every one second. Each time the parameters are recorded, a Zulu time stamp followed by three lines of comma delimited ASCII text data are written where the first line contains flight parameters, the second line contains engine parameters.

## 9.10. Log Files


### 9.10.1. Delete LOG Files

- 1) Select “Delete LOG Files” option to delete all log files contained in the log directory. This option may be performed if there are problems updating a navigation database or application software due to an excessively large log file.
- 2) The files deleted are named “LOG00.dat” thru “LOG04.DAT” and “MSGLOG.DAT”. Performing this option does not affect operations of the EFIS, as the EFIS automatically generates new “LOG00.DAT” and “MSGLOG.DAT” files once a flight has started.
- 3) Press any button on the IDU or push **1** to return to the Ground Maintenance menu.

## 9.11. Routes and Waypoints

### 9.11.1. VFR Flight Planning

The navigation database includes VFR waypoints which consist of five digits beginning with the letters “VP”. These may be found on VFR charts and should be loaded in the FMS prior to flight to ensure they are available in the database and the INFO checked for proper location.



**Figure 9-2: VFR Waypoint**

### 9.11.2. Download Routes and User Waypoints

- 1) To download all routes and user waypoints stored in the IDU to the USB External Memory Drive, selecting “Download Routes and User Waypoints” option from the Ground Maintenance Page. This option is useful for fleet operations where multiple aircraft fly the same routes.
- 2) Routes are stored on the USB Memory external drive as NAME1-NAME2.RTE where NAME1 is the 1 to 5 character designation of the origin waypoint and NAME2 is the 1 to 5 character designation of the destination waypoint. User waypoints are stored on the USB External Memory Drive as USER.DAT.

### 9.12. EFIS Training Tool (ETT)

#### NOTE:

For installation directions and directions for using the features of the EFIS Training Tool (ETT), refer the Installation and User Manual distributed with the ETT install files.

### 9.13. Upload Routes and User Waypoints

Select “Upload Routes and User Waypoints” on the Ground Maintenance page option to copy all routes and user waypoints stored on a USB external memory drive to the IDU. This option used in conjunction with the “Download Routes and User Waypoints” option enables the operator to store the same routes and user waypoints in multiple aircraft.

#### 9.13.1. Delete Routes

Select “Delete Routes” on the Ground Maintenance page option to remove all routes and the user waypoint file USER.DAT from the IDU. This option is used to delete the contents of the route directory when corrupted routes cause the IDU to continually reboot.

#### 9.13.2. Upload Routes and User Waypoints

To copy all routes and user waypoints stored on a USB external memory drive to the IDU, select “Upload Routes and User Waypoints” on the Ground Maintenance page option. This option used in conjunction with the “Download Routes and User Waypoints”

option enables the operator to store the same routes and user waypoints in multiple aircraft.

### 9.13.3. Delete Routes

Select “Delete Routes” on the Ground Maintenance page option to remove all routes and the user waypoint file USER.DAT from the IDU. Use this option to delete the contents of the route directory when corrupted routes cause the IDU to continually reboot.

## 9.14. USB External Drive Memory Limitations

### NOTE:

Maximum USB memory is not a factor, but the following should be considered:

USB must be formatted as FAT.

FAT-16 for USB Drives 2 GB or smaller

FAT-32 for any larger sized drive. If the drive is not recognized try another source.

When powering up the IDU with a USB inserted and the following message displays, the USB external drive is likely too large and is not accepted for loading or transferring data.

- 1) Error: No updater files found on USB drive.
- 2) Ensure that USB, with required files is properly connected.
- 3) Try again after reboot.
- 4) Press any key to continue.

**9.15. Service Difficulty Report**

Print, complete, then fax to 940-325-3904

Name:	Phone:
Flight No:	Date:
Aircraft:	Registration#:
Software Version:	Error Code:
Route:	Duration of Flight:
Conditions:	
Remarks: (Include time, altimeter Setting, OAT, ALT, TAS, GS, Heading, track, position, flight segment, pilot action, system response, is problem repeatable?).	



## 9.16. Certification Basis

The following TSOs are considered applicable to the IDU-680 (depending upon the features of the installed software).

<b>Document Number</b>	<b>Document Title</b>
ARINC 429-16	Mark 33 Digital Information Transfer System (DITS)
ARINC 735A-1	Traffic Alert and Collision Avoidance System
EIA-232D	Interface between Data Terminal Equipment and Data
EIA-422A	Electrical Characteristics of Balanced Voltage Digital Interface Circuits
FAA AC 23.1311-1B	Installation of Electronic Display in Part 23 Airplanes
RTCA/DO-155	Minimum Performance Standards - Airborne Low-Range Radio Altimeters
RTCA/DO-229D	Minimum Operational Performance Standards for Global Positioning System/Wide Area Augmentation System Airborne Equipment
RTCA/DO-283A	Minimum Operational Performance Standards for Required Navigation Performance for Area Navigation
SAE AS396B	Bank and Pitch Instruments (Indicating Stabilized Type)
SAE AS8002A	Air Data Computer - Minimum Performance Standard
TSO-C4c	Bank and Pitch Instruments
TSO-C87	Airborne Low-Range Radio Altimeter
TSO-C106	Air Data Computer

<b>Document Number</b>	<b>Document Title</b>	
TSO-C194	Terrain Awareness and Warning System	
TSO-C113	Airborne Multipurpose Electronic Displays	SAE AS8034
TSO-C52b	Flight Director Equipment	SAE AS8008
TSO-C146a	Stand-Alone airborne navigation equipment using the Global Positioning System (GPS) Augmented by the Wide Area Augmentation System (WAAS)	
N/A	Airplane Aerodynamics and Performance, Lan and Roskam, 1981.	

## 9.17. Environmental Requirements

The IDU-680 meets the requirements of RTCA/DO-160F as defined below:

Sec.	Condition	Cat.	Test Category Description	Notes
4.0	Temperature and Altitude	F2	Equipment intended for installation in non-pressurized and non-controlled temperature location in an aircraft that is operated at altitudes up to 55,000 ft. (16,800 m) MSL. Operating Low Temp: -55 deg C Operating High temp: +70 deg C Ground Survival Low Temp: -55 deg C Ground Survival High Temp: +85 deg C Altitude: +55,000 feet	+75°C for Short-Time Operating High Temp. Cat. V (30 minutes) for loss of cooling.
5.0	Temperature Variation	B	Equipment in a non-temperature-controlled or partially temperature controlled internal section of the aircraft.	
6.0	Humidity	B	Equipment intended for installation in civil aircraft, non-civil transport aircraft and other classes, installed under conditions in which a more severe humidity environment than standard conditions may be encountered.	

Sec.	Condition	Cat.	Test Category Description	Notes
7.0	Operational Shocks & Crash Safety	B	Equipment generally installed in fixed-wing aircraft or helicopters and tested for standard operational shock and crash safety.	Aircraft Type 5, Test Type R for Crash Safety Sustained Test
8.0	Vibration	H + R + U	<p>H – Demonstrates performance at high-level, short duration transient vibration levels</p> <p>R - (Fixed-Wing) Demonstrates performance at higher, robust vibration levels and after long term vibration exposure.</p> <p>U - (Helicopter w/Unknown Frequencies) Demonstrates performance at higher vibration levels and after long term vibration exposure for fuselage and instrument panel equipment when the specific rotor frequencies are unknown.</p>	<p>Cat. H, curve R</p> <p>Cat. R, curves B, B1</p> <p>Cat. U, curve G</p>
9.0	Explosive Atmosphere	X	Not Applicable	
10.0	Waterproofness	W	Equipment is installed in locations where it may be subjected to falling water, such as condensation	Drip proof test
11.0	Fluids Susceptibility	X	Not Applicable	

Sec.	Condition	Cat.	Test Category Description	Notes
12.0	Sand and Dust	S	Equipment is installed in locations subject to blowing sand and dust.	
13.0	Fungus Resistance	F	Demonstrate whether equipment material is adversely affected by fungi growth.	By Analysis
14.0	Salt Fog	S	Equipment is subjected to a corrosive atmosphere	
15.0	Magnetic Effect	Z	Magnetic deflection distance less than 0.3m.	
16.0	Power Input	Z	Equipment intended for use on aircraft DC electrical systems where the DC supply has a battery whose capacity is small compared with the capacity of the DC generators.	200 ms power interruption capacity
17.0	Voltage Spike	A	Equipment intended primarily for installation where a high degree of protection against damage by voltage spikes is required.	
18.0	Audio Frequency Conducted Susceptibility-Power Inputs	Z	Equipment intended for use on aircraft DC electrical systems where the DC supply may not have a battery of significant capacity floating on the dc bus at all times.	

Sec.	Condition	Cat.	Test Category Description	Notes
19.0	Induced Signal Susceptibility	ZC	Equipment intended primarily for operation in systems where interference-free operation is required on aircraft whose primary power is constant frequency or DC.	
20.0	Radio Frequency Susceptibility (Radiated and Conducted)	Y	Equipment and interconnecting wiring installed in severe electromagnetic environments and to show compliance with the interim HIRF rules.	Radiated: K  Minimum level at all frequencies to be 100V/m
21.0	Emission of Radio Frequency Energy	M	Equipment in areas where apertures are EM significant but not in direct view of aircraft antennas, such as passenger cabin or cockpit	
22.0	Lightning Induced Transient Susceptibility	A3J 33	Equipment interconnected with wiring installed within any airframe or airframe section when structural resistance is also a significant source of induced transients, (i.e., carbon fiber composite structures). Level 3 designates equipment and interconnecting wiring installed in a moderately exposed environment.	Level 4 for MSU and OAT Probe pins.
23.0	Lightning Direct Effects	X	Not Applicable	

Sec.	Condition	Cat.	Test Category Description	Notes
24.0	Icing	X	Not Applicable	
25.0	Electrostatic Discharge (ESD)	A	Electronic equipment that is installed, repaired, or operated in an aerospace environment.	
26.0	Fire, Flammability	C	Non-metallic equipment, component parts, sub-assemblies installed in pressurized or non-pressurized zones and non-fire zones with largest dimension greater than 50 mm.	By Analysis

## INDEX

500 Foot.....	8-5 to 6, 8-24
Abbreviations and Acronyms.....	2-4
ACTV .....	5-16, 5-58, 5-63 to 64, 5-68 to 71, 6-7 to 9, 7-9
ADAHRS.....	2-4, 2-19, 3-75, 9-7 to 8
ADD .....	5-64, 6-6
AGL Indication .....	3-28 to 29
Air Data.....	2-4, 3-90, 3-99, 3-112, 5-105, 8-24, 8-33, 9-22
Airports .....	2-57, 3-89, 5-72, 5-78, 5-123 to 124
Airspace.....	2-10, 2-13, 4-9 to 58, 7-6
Depiction .....	3-88 to 89
Airspeed	
Bug.....	3-32, 5-11, 5-94 to 95
Display .....	3-31, 3-36
Miscompare Threshold .....	9-9
True.....	2-8, 2-13, 3-91, 4-9 to 58, 7-14 to 15
ALT SEL .....	5-17 to 18
Altimeter	
Menu .....	5-101 to 102
Setting.....	3-20, 9-6
Altitude	
Capture Predictor.....	3-84
Display .....	3-23 to 24
Minimum.....	3-25 to 26, 5-11, 5-95
Miscompare Threshold .....	9-8 to 9
Analog AGL Indication.....	3-29



Analog Navigation Symbolology .....	3-95
APP .....	3-81, 5-61
Appendix .....	1-11, 1-14, 7-22, 9-5
APPR.....	6-9, 7-25 to 26, 7-31
Approach.....	2-4 to 10, 2-33, 2-47, 2-50, 2-57 to 58, 3-54, 3-72, ..... 3-81 to 82, 3-109, 5-20 to 21, 5-59, 6-9, 7-6 to 7, 7-12 to 15, ..... 7-23 to 35, 7-39 to 57, 8-5, 8-8 to 11, 8-19, 8-31
APV .....	2-4, 7-7
ARM .....	5-21, 7-8
ASEL .....	2-4
Atmospheric perspective .....	3-15, 3-42 to 43
AUTO .....	3-65, 3-79, 3-128, 5-60, 5-75 to 76, 5-116, 6-8
Automatic RNP.....	7-34
BACK.....	3-19, 5-13
Bank Scale .....	3-15, 3-42, 3-50, 4-8, 4-16 to 58, 5-12
Baro.....	2-17
BARO .....	3-19 to 20, 5-17, 5-101, 7-7
BARO-VNAV .....	7-7
Basic Mode	3-15, 3-39 to 43, 3-49, 3-52 to 53, 5-12, 5-97 to 98, 7-9
Basic Moving Map.....	3-71
Blue .....	2-25, 3-61, 3-81, 3-91 to 92, 3-97, 3-109 to 110
Borders.....	3-92, 3-119
Brown .....	2-25, 3-92
BUGS .....	1-10, 5-28, 5-88 to 92, 7-6
Button/Menu Functions .....	1-7, 3-18 to 19, 5-10, 5-13, 8-6
CALC.....	5-57
CDI Scale .....	7-28

CENTER/ARC .....	5-113, 5-123
Clock/Timers.....	3-78, 3-100 to 112, 3-126
Color Conventions .....	2-23
Compass Rose .....	3-75, 3-105, 4-9 to 58
CONFIRM ACTIVATE ILS.....	5-79
CONFIRM DEL WPT.....	6-7
CONT.....	2-49, 5-20, 7-8
COUNT DN.....	3-78
Course Deviation Indicator .....	2-5, 3-28, 3-53
CREATE-EDIT.....	6-6 to 7
CRS SYNC .....	5-73, 5-79
Data Logging and Retrieval .....	9-17
Database	
Jeppesen.....	1-9 to 10, 1-13 to 14, 2-8, 2-54 to 55, 3-48, 9-11
NavData .....	1-11, 2-17, 2-54 to 56, 3-59, 5-13, 5-59, 7-6, 7-15, ..... 7-34, 9-11
Navigation .....	1-9 to 10, 1-13 to 14, 2-48, 2-54 to 57, 3-62 to 63, .... 3-82, 5-59, 7-6 to 9, 7-16, 7-20 to 21, 7-31, 8-14, 8-30, 9-18
Obstruction.....	2-19, 2-54 to 56, 8-5
Datalink.....	2-17, 2-29, 3-70, 3-89, 3-107 to 113, 3-117 to 118, ..... 5-17 to 25, 5-108
DCLTR..	3-78, 5-28, 5-97 to 100, 5-113 to 114, 5-120, 5-123 to 124
Dead Reckoning .....	2-6, 2-36, 4-13, 7-23
Decision Height .....	2-5, 2-46, 3-30 to 31, 5-11 to 12, 5-95
Default GPS/SBAS Navigation Modes .....	7-25

Delete, DELETE .....	5-66, 6-7
Flight Plan .....	5-48
User Waypoint .....	5-54
Demonstrator.....	1-9 to 10
Density Altitude .....	3-91, 4-9 to 58
Departure .....	2-6, 2-10, 2-33, 3-54, 3-81, 7-6, 7-25 to 28, 7-33, ..... 8-8 to 11, 8-31, 9-6
DESIG .....	5-28, 5-32, 5-41, 5-51, 6-7
Direct.....	5-17, 5-67, 5-71, 7-15 to 16, 7-21, 7-24 to 25, 9-13
Menu .....	5-82 to 84
Direct-To.....	3-82 to 84, 7-15 to 16, 7-21, 7-24 to 25
DISCONT .....	3-82
Discontinuity .....	3-83, 5-67, 5-83, 7-16 to 17, 7-21, 7-24, 7-32 to 34
Display Symbology.....	3-1, 3-70, 8-6
DME .....	2-4 to 6, 2-14, 3-91, 3-97 to 98, 5-24, 5-129, 7-14 to 18, ..... 7-35, 7-53 to 57, 9-12 to 16
DMEs.....	2-57
DP .....	2-6, 3-62, 3-81 to 82, 3-86, 5-60 to 62, 7-14 to 17, 7-24, ..... 7-33 to 34, 8-8
EFIS Training Tool (ETT).....	1-11, 2-6, 9-19
EICAS.....	2-6, 2-15, 2-18 to 22, 2-41, 2-54, 3-14, 3-17 to 18, 3-70, ..... 4-12, 5-12, 5-17 to 19, 5-29, 5-32 to 36, 5-39, 5-109, 6-4 to 5, ..... 8-13
Display .....	2-20
Exceedance Menu .....	5-36
Encoder Functions .....	3-19
Enroute.....	2-6, 2-33, 3-54, 3-83, 3-90, 7-25 to 28, 8-8 to 11
Estimated Time of Arrival (ETA).....	2-6, 3-83 to 84

EXIT .....	3-19, 5-13, 5-57, 6-6 to 7
EXPAND CAS .....	2-48, 5-28, 5-32, 5-36
FAF .....	2-6, 3-81, 5-60, 7-17, 8-14
FAULTS .....	2-29, 4-13, 5-32, 5-56, 5-103, 5-106, 7-34
FAWP .....	2-6, 2-50, 2-57 to 58, 3-54, 4-14, 5-60, 7-17, 7-26 to 28, ..... 7-32 to 34
Fixes .....	3-90, 5-78, 5-123 to 124
Flight Path Marker .....	2-7, 2-47, 3-15, 3-39, 3-42 to 43, 3-48 to 49, ..... 4-8 to 10, 4-16 to 58
<b>Flight Plan</b>	
Activate .....	5-45, 6-6
Active .....	3-86, 3-103, 3-106, 3-119, 3-123 to 124, 4-9 to 58, ..... 5-11, 5-58, 5-63, 5-68 to 70
Create .....	6-6
Edit .....	5-46
Path .....	3-86, 3-103, 3-106, 3-119, 3-123, 4-9 to 58
Reverse .....	5-47
Flight Planning .....	9-5, 9-18
FLT TIME .....	3-78
FLTA .....	2-6, 2-26 to 27, 2-37, 2-43, 2-47, 2-53, 3-46, 3-92, 3-120, ..... 5-19, 8-5 to 12, 8-31, 8-34 to 39
FMS .....	1-6, 1-11, 2-7, 2-16 to 17, 3-51, 3-54 to 57, 3-69, 3-74, ..... 3-82, 3-96 to 97, 5-11, 5-60, 5-75, 5-108, 6-4 to 8, 7-9, 9-18
FORMAT .....	5-32, 5-112, 5-116 to 122, 5-125
FOV Indication .....	3-87
FPL .....	5-16, 5-39 to 42, 6-6 to 7
FROM Operation .....	7-14
General Arrangement .....	2-19

Geodesic Path.....	7-23
Geo-Referenced Backward/Forward .....	7-11
Glideslope . 2-26, 2-32, 3-55 to 58, 3-97, 8-5, 8-22 to 25, 8-33 to 34	
GPS.....2-7, 2-18 to 19, 3-38, 3-49, 3-57 to 60, 3-75 to 3-77, 3-81, ..... 5-56 to 59, 5-94 to 95, 7-6 to 8, 7-28 to 31, 7-47 to 49, 7-58, ..... 9-7 to 8, 9-11, 9-23	
ALMANAC .....	5-104
Altitude.....	7-23
FDE.....	5-104
HPL.....	5-104
LOI.....	5-104
PWR .....	5-103
SATLT.....	5-104
VPL.....	5-104
GPS/SBAS .....	2-19, 2-32 to 36, 2-41 to 42, 2-46 to 50, 3-28, ..... 3-54 to 55, 3-58, 3-61, 3-78, 3-86, 3-94 to 96, 3-103, 3-106, ..... 3-119, 4-7 to 58, 5-56 to 57, 5-103 to 104, 7-7 to 8, 7-14, ..... 7-23 to 25, 7-28 to 30, 7-35, 8-8 to 11, 8-14, 8-19, 8-24 to 33
GPWS .....	1-13, 2-7, 2-26 to 27, 2-32, 2-42 to 43, 2-49, 2-53, ..... 8-5 to 6, 8-15 to 25, 8-31, 8-34
Gray.....	2-24, 3-108 to 110
Groundspeed....	2-33, 3-80, 3-90 to 91, 3-99, 3-112, 4-9 to 58, 8-11
HDG UP/N UP.....	5-113, 5-123
Heading Display .....	3-36 to 37
Heading Bug.....	3-38, 3-55, 5-11, 5-94
(HDG) Menu .....	5-77
Hidden Surface Removal Technique .....	3-43, 3-60 to 62, 7-9
Highway in the Sky.....	3-43, 3-59, 4-8 to 10, 4-16 to 58, 7-7 to 13

HOLD .....	3-97 to 98, 5-24, 5-60
Holding Pattern .....	7-15 to 16, 7-20
IAP .....	2-8, 7-14, 7-31
IAS .....	1-10, 2-8, 3-68, 4-9, 5-89
IDU-680 .....	1-6 to 9, 1-12, 2-15, 2-19 to 20, 2-56 to 58, 3-12 to 18, 4-7, 4-11 to 14, 5-10, 5-14 to 16, 5-19, 5-22 to 28, 5-33, 5-38 to 39, 5-93, 5-109, 8-13, 9-22 to 24
IFR	
APP .....	5-61, 8-27
Procedures .....	3-75, 7-6
ILS ....	2-8, 5-73, 5-79 to 82, 7-7, 7-30, 7-35, 7-39 to 42, 7-50 to 52, 8-5, 8-22 to 25, 8-32 to 33
INFO .....	3-110 to 111, 5-16, 5-23, 5-52, 5-57, 5-64 to 66, 5-71 to 74, 5-79, 5-83, 9-18
inHg/mbar .....	2-46, 3-19 to 20, 5-101 to 102, 8-28, 9-6
Initialization .....	2-15 to 16
INSERT .....	5-64, 5-79, 6-7
International Standard Atmosphere .....	3-91
Introduction .....	1-5, 3-12
Latitude/Longitude .....	5-72
LNAV .....	2-9, 2-57 to 58, 3-55 to 57, 3-82, 4-13 to 14, 5-19 to 20, 5-96, 7-6 to 9, 7-25 to 31, 7-58
Approach .....	2-47, 7-25
LNAV/VNAV .....	2-58, 3-57, 4-13 to 14, 7-6 to 8, 7-25 to 29
Approach .....	2-47, 7-25
Log Files .....	9-18
LON .....	2-9, 3-45, 3-58, 3-61, 4-13, 5-49 to 50, 8-24

LP .....	2-9, 2-58, 3-57, 7-6 to 7, 7-25 to 29, 7-58
Approach .....	2-47, 7-25
LPV.....	2-9, 2-58, 3-56 to 57, 7-6 to 8, 7-25 to 29, 7-35, 7-47 to 49
Approach .....	2-47, 7-25 to 26
MA.....	3-81
Magnetic Course .....	7-22
MAHWP.....	2-9, 2-57
Map .....	3-18, 3-30, 3-127 to 129, 4-8, 4-16 to 58, 5-13
Mini .....	3-43, 3-60 to 61, 6-3
Moving .....	3-70 to 72, 3-120
Page .....	5-13
MAP.....	3-125
Marker Beacon.....	3-51, 3-99, 5-129
MAWP .....	2-9, 2-57 to 58, 7-26 to 27, 7-33
Menu	
Function Types .....	5-13
Synchronization .....	5-10 to 11
MENU.....	1-12, 5-16, 5-41, 6-7, 6-10
METERS .....	5-133
MFD.....	1-9, 1-12, 2-9, 2-15, 2-18 to 20, 2-23 to 25, 2-36, 3-12, ..... 3-16 to 18, 4-11, 4-14, 4-17 to 58, 5-10 to 18, 5-29 to 32, ..... 5-35, 5-41, 5-106 to 126, 6-5 to 7
Essential Mode .....	5-16
Fault Display .....	5-103, 5-106
ND Page Format.....	5-112, 5-122, 5-125
Normal Mode .....	5-15
Page .....	5-32, 5-108 to 109





NO RESULTS .....	5-65 to 66, 5-78
North Up .....	3-120
NRST ILS .....	5-79, 7-35, 7-50
OBS .....	2-10, 2-16, 2-49, 3-55, 3-86, 3-103, 3-106, 3-119, 5-11, 5-16, 5-75 to 76, 5-79 to 80, 5-95, 7-7 to 8
AUTO .....	5-75
Manual .....	6-8
SYNC .....	5-75, 6-8
Obstruction .....	3-15, 3-42 to 44, 3-47, 3-92 to 94, 4-8 to 58, 8-37
Rendering .....	3-43
OFF ....	5-19 to 20, 5-28, 5-32, 5-64, 5-80, 5-85, 5-98, 5-105, 5-113, 5-116, 5-123
OFLY/AUTO .....	5-60
Olive .....	2-25, 3-92
Omnibearing Selector (OBS) Menu .....	5-75 to 76
Outside Air Temperature .....	2-10, 3-91
OVERFLY .....	5-60
Overfly User Waypoint .....	5-41
Ownship symbol .....	3-65, 3-87
PAGE .....	5-32, 5-35, 5-108 to 109
Pan Mode .....	3-95, 3-120, 3-130, 5-19, 5-22 to 25
PAN ON/PAN OFF .....	5-113, 5-123
Parallel Offsets .....	7-23
PDA .....	2-10, 2-43, 2-53, 8-5 to 6, 8-14 to 15, 8-31

PFD.....	1-8, 1-12, 2-10, 2-15 to 18, 2-25, 2-36, 3-12 to 15, 3-29, .....3-36 to 87, 3-96, 3-103, 3-106, 3-119, 4-8, 4-11 to 58, .....5-12 to 18, 5-27 to 34, 5-40 to 41, 5-87 to 92, 5-97 to 102, .....5-109, 6-3 to 10, 7-6 to 8, 8-5 to 6, 8-12, 8-24, 8-33 to 39, .....9-7 to 8
Background.....	3-43
Declutter.....	3-50, 5-97 to 100, 8-34
Normal Mode .....	2-18, 5-14
Symbology .....	3-24 to 25
with EICAS.....	2-22
Pitch Scale.....	3-38 to 39, 4-8, 4-16 to 58
Popup .....	5-19, 8-12 to 13
Procedure Turn.....	7-19, 9-15
Projected Path .....	3-85, 4-9 to 58
PTK.....	2-48, 3-82, 5-58, 5-64, 7-24
PTR.....	3-74
QFE .....	2-11, 2-46, 3-20 to 21, 5-101, 8-28
QNE .....	2-11, 3-20, 5-101 to 102, 8-28
QNH.....	2-11, 3-19 to 20, 5-101 to 102, 6-3, 8-26 to 28
QUICK START .....	2-18
Quick Start Tutorial.....	1-13, 6-1
RAIM.....	2-11, 5-39
Prediction .....	5-56 to 57
Range .....	2-31, 2-53, 3-45, 3-77, 3-87 to 88, 3-102, 3-105, 3-109, ...3-118, 3-122, 3-125 to 127, 4-9 to 58, 5-104 to 105, 8-10, 9-22
Remote Bugs Panel (RBP).....	2-11, 5-93 to 96
Reversionary Modes.....	4-7 to 8

RNAV .....	2-11, 7-6, 7-16, 7-35, 7-47 to 49	
DPs .....	2-57	
RNP.....	2-11, 2-57, 3-57, 5-75 to 76, 5-104, 7-28	
AUTO.....	5-76	
MAN.....	5-76	
Manual .....	2-17, 5-76, 7-34	
Runways.....	3-15, 3-43, 3-62, 3-86, 3-103, 3-106, 3-119, 3-123	
RW .....	6-9	
SAVE EXIT .....	6-6	
SBAS.....	2-12, 2-32 to 41, 4-7, 4-10 to 58, 7-6 to 8,	
SBAS HLTH .....	5-104	
SBAS MSG.....	5-104	
Search Envelope .....	8-10	
Skyway .....	2-24, 3-59, 5-12, 5-97, 7-8 to 9, 9-5	
Slip Indicator.....	3-37	
STAR.....	2-13, 3-62, 3-81 to 82, 3-86, 5-60 to 61, 7-14, 7-35 to 38, .....	8-8
Start Point.....	3-84	
STD .....	5-102	
STORE .....	5-85	
Strikes .....	3-70, 3-101, 3-104, 3-116 to 117	
SYMB DCLTR .....	5-113, 5-123	
SYNC .....	3-130, 5-21, 5-28, 5-73 to 75, 5-79, 6-8 to 10	
System Overview .....	2-15, 3-12, 9-6	
Target Altitude .....	3-21 to 22, 5-11	
Terminal .....	2-13, 2-33, 2-50, 3-54, 3-81, 3-90, 5-124, 7-25 to 28, .....	7-36, 8-8 to 11, 8-31, 9-22

Terrain .....	2-6, 2-13, 2-27, 2-43, 3-43 to 47, 3-60, 3-78, 3-92 to 94, ..... 4-8 to 58, 5-12, 8-5 to 7, 8-10 to 12, 8-17 to 21, 8-29 to 36, ..... 9-5, 9-23
Database.....	2-55, 2-58, 8-29
Rendering .....	3-15, 3-42, 8-12
TIMER.....	5-28, 5-32, 5-85 to 86
Timer Indication .....	3-51
Too Low .....	2-43, 8-21
Top of Descent (TOD) .....	3-56, 3-84
Top-Level Menu.....	5-14 to 19
Traffic.....	2-4 to 5, 2-10 to 11, 2-13, 2-27, 2-44, 2-53, 3-27, 3-30, ..... 3-43, 3-61 to 66, 3-70, 3-79, 3-104 to 105, 4-8 to 58, ..... 5-11 to 13, 5-17 to 18, 5-108, 5-116 to 117, 9-22
TRANS.....	5-102
TRANS ALT .....	5-102
Transmit Enabled .....	2-15, 4-9, 5-26
TSO .....	1-13, 2-14, 3-55, 3-96, 7-6 to 8, 8-5, 8-8, 9-22 to 23
Unusual Attitude Mode .....	3-15, 3-39, 3-42 to 43, 3-49 to 50, 3-57, ..... 3-60 to 61, 3-64, 7-9
Upload .....	9-19
USB.....	1-7 to 9, 2-54 to 56, 9-17 to 20
USER WPT .....	5-41, 6-7
VDI.....	3-43, 3-55, 3-96, 7-7 to 8
Vertical Deviation Indicator.....	3-55 to 58, 7-8
Vertical Speed Indicator .....	2-8, 2-14, 3-26
VFR.....	1-5, 2-14, 2-24, 2-33, 3-62, 3-81, 3-86, 3-89, 3-109, 5-24, ..... 5-59 to 61, 5-113 to 114, 5-123 to 124, 5-133, 7-12 to 14, ..... 7-23 to 27, 7-32, 8-8, 8-27, 8-31, 9-18
APR.....	6-9

VNAV.....	2-14, 2-24, 2-45 to 47, 2-50 to 51, 2-58, 3-22 to 25, ..... 3-56 to 60, 3-82 to 86, 3-96 to 97, 3-106, 3-118, 4-13 to 14, ..... 5-11, 5-21 to 22, 5-59 to 60, 5-89 to 90, 5-96, 7-6 to 14, .....7-25 to 30, 9-5
CDA.....	5-89
Sub-Mode.....	3-22 to 23
VOR DME.....	7-35
VORs.....	2-24, 2-57, 3-89, 5-66, 5-78 to 79, 5-113, 5-123 to 124
VSI.....	2-14, 2-23, 2-27 to 28, 2-51, 3-26 to 28, 3-65, 3-106, 3-118, ..... 4-8, 4-16 to 58, 5-11, 5-89 to 90, 5-94 to 96, 6-4, 8-11, .....8-32 to 33
VTF.....	2-14, 3-54, 7-26 to 28, 7-32
WAAS.....	2-14, 7-6 to 7, 9-23
Water.....	3-92
Waypoint.....	2-6 to 9, 2-57 to 59, 3-76 to 77, 3-81 to 82, 3-96, ..... 3-101, 3-129, 4-8 to 58, 5-49 to 54, 5-57, 6-7, 7-12 to 19, .....7-24, 9-18
Active.....	3-43, 3-59, 6-3
Create User.....	5-49 to 52
Create User (RAD-DST).....	5-52
Edit User.....	5-52 to 53
Identifier.....	3-59, 3-80 to 84
Overfly User.....	5-41
Phantom.....	7-15
Pointer.....	4-8 to 58
Routes and User.....	9-19
Sequencing.....	7-14
Waypoints Fly-By/Fly-Over.....	7-15
WGS-84.....	2-57, 7-18 to 21, 7-23

---

Wind.....	3-90, 3-110, 4-9 to 58
WX-RDR .....	5-109
XFILL SYNC .....	5-28, 6-10
Zoom Mode .....	5-12
ZOOM ON/ZOOM OFF .....	5-28
Zulu time .....	9-18

## Glossary

**AGL Indication (Rad Alt, GPS Alt, Baro Alt)** – Display of altitude above the ground, with designation of the altitude source as R (radio altitude), G (GPS WAAS geodetic altitude less local ground elevation), or B (barometric altitude less local ground elevation).

**Air Data and Groundspeed** – Display of density altitude, outside air temperature, ISA temperature deviation, true airspeed, and ground speed.

**Airspeed Information** – Display of airspeed is the indicated airspeed tape and airspeed readout with associated data. The airspeed function includes color-coded caution bands for minimum and maximum speeds based on V-speeds set in the EFIS limits.

**Altitude Information** – Display of altitude information is the altitude tape and altitude readout.

**Approach Mode Signal Output** – Conventional autopilot approach mode signals are course error output, the left/right deviation signal (localizer output) and the up/down deviation signal (glideslope output). Signals are based on the selected ILS source.

**Attitude Information** – Display of attitude information includes pitch and roll. The bank angle scale may be set to auto-declutter by the pilot when the bank angle is less than 2.8°. The pitch ladder is limited to  $\pm 10^\circ$  from the flight path marker or aircraft waterline, whichever is greater. The unusual attitude display appears when the aircraft pitch exceeds  $\pm 30^\circ$  or bank angle exceeds  $65^\circ$  (fixed wing) or  $50^\circ$  (rotorcraft).

**Autoset** – Automatically selects features or settings.

**Azimuth** – Angle between the north vector and the perpendicular projection of the star down onto the horizon. Usually measured in degrees ( $^\circ$ ).

**Barometric Altimetry** – Measurement of altitude based on the atmosphere (pressure and temperature).

**Barometric Correction** – Display and altitude correction for local barometric pressure.

**Bezel** – Faceplate of the IDU comprised of pushbuttons along the pushbuttons along the sides and rotary encoders along the bottom.

**Chroma** – Colorfulness relative to the brightness.

**Conformally** – Angle-preserving. Example: Traffic appears conformally on the PFD.

**Course Deviation Indicator** – Display of course deviation from selected course, including a To-From indicator.

**Critical Flight Phase** – Phase(s) of flight where the failure mode would result in a hazard condition using flight phases. For example, failure of ILS would only be a hazard condition during approach and landing.

**Crossfill** – Transfer of data and information between IDUs in a dual system with two PFDs configured.

**Cross-linked** – Synchronized across both EFIS systems.

**Datalinked** – Display of received data such as weather or traffic from peripheral systems such as WSI or ADS-B.

**dBZ** – Decibel relative to radar reflectivity (Z). Composite reflectivity shows the highest dBZ (strongest reflected energy) at all elevations. Unlike base reflectivity, which only shows reflected energy at a single elevation scan of the radar, composite reflectivity displays the highest reflectivity of ALL elevations scans. If there is heavier precipitation in the atmosphere over an area of lighter precipitation (i.e. rain has yet to reach the ground), the composite reflectivity displays the stronger dBZ level.

**Deadband** – Neutral zone where no action or changes are made.

**Directional Scale (Compass Rose or Arc) and Ownship Symbol** – Display of general directional information. All MFD pages include a form of the compass rose with current heading pointer and aircraft “ownship” symbol.

**Discrete** – A logic input or output that identifies a condition or status of or for an ancillary system. Discretes are defined by the operating software or settings programmed specifically for the aircraft.



**Display of ADF** – Display of single ADF bearing information in the form of an RMI needle.

**Display of Glideslope** – Display of Glideslope 1 or Glideslope 2 in the form of vertical deviation dots and deviation on PFD or MFD HSI page.

**Display of Lightning Cell Information** – Display of lightning information from a WX-500 system and shown in the form of lightning cells. The pilot may show individual lightning strike data by selecting the dedicated WX-500 page.

**Display of Localizer** – Display of Localizer 1 or Localizer 2 in the form of horizontal deviation dots and deviation.

**Display of Marker Beacon** – Display of outer, middle, and inner marker beacons in the form of a color-coded circle with the corresponding letter (O, M, I).

**Display of Traffic Information** – When integrated with an appropriate traffic system, the PFD and MFD display traffic information in two formats. One format is via traffic symbols as shown on the PFD and MFD Map page and Traffic page. The second format is with the traffic pop-up thumbnail display showing traffic position in a full 360° format on the PFD.

**Display of VOR RMI** – Display of VOR1 and VOR2 bearing in the form of RMI needles.

**Dot** – (CDI scale referenced) represents an additional 2° for VOR and 1.25° for Localizer.

**Failure Condition Hazard Description** – A description of the failure mode to be analyzed.

**Flight Director (Selectable Function)** – Display of flight director in a single or dual cue format when selected for display on the PFD.

**Flight Path Marker (Velocity Vector)** – Display of aircraft's actual flight path, showing where the aircraft is going as opposed to where the aircraft is pointed.

**Flight Plan and Navigation Display** – Display of the active GPS WAAS/SBAS-based flight plan, including course line, waypoints, ground track, glide range, projected path, altitude

capture predictor, approach procedure, missed approach procedure, and the aircraft present position on the active leg.

**Geodetic** – Set of reference points used to locate places on the earth.

**Geoid** – Global mean sea level.

**G-Force and Fast/Slow Indicator** – Indications to show the G-force on the aircraft or, for aircraft equipped with a compatible angle of attack computer, the deviation from the reference speed while in the landing configuration.

**Glideslope Sidelobes** – False glideslope signals.

**GPS WAAS Course Deviation Indicator (CDI)** – Display of CDI relative to selected course, either automatic based on active flight plan or manual based on pilot-selected OBS.

**GPS WAAS Functions** – The EFIS meets the GPS WAAS navigation and flight planning/management requirements of TSO-C146a (RTCA/DO-229D) for Class Gamma 3 equipment. These functions include navigation, flight planning (function select, flight plan generation and editing, selected waypoints, user waypoints, etc.), path definition including approach and departure paths, GPS altitude, dead reckoning, navigation modes with automatic mode switching, loss of navigation monitoring, loss of integrity monitoring, etc. The database used with the GPS WAAS functions meets the integrity requirements of RTCA/DO-200A.

**Heading Bug** – Display and control of selected heading using a bug. May be used to drive heading bug output to autopilot for HSI-based heading mode.

**Heading Display** – Display of heading with directional scale is provided at the top of the PFD. This is the same heading information provided on the MFD.

**Heading Mode Signal Output** – Conventional autopilot heading mode signal is a heading error output based on the difference between the EFIS desired heading and the actual aircraft heading. The EFIS desired heading is either the pilot-selected heading bug or a heading designed to achieve and maintain the active GPS-based flight plan.

**Hectopascal (hPa)** – International System of Units (SI) unit measure of pressure, equals one millibar (mbar).

**HeliSAS** – Genesys Aerosystems' helicopter autopilot and stability augmentation system.

**Horizontal Situation Indicator (Selectable Function)** – Display of VOR or localizer and glideslope deviation when selected for display on the PFD.

**Hover Vector Display (Rotorcraft Only)** – Display of hover drift in a rotorcraft installation when the helicopter is traveling less than 30 knots airspeed.

**Inches of Mercury (inHg)** – Unit of atmospheric pressure used in the United States. Named for the use of mercurial barometers which equate height of a column of mercury with air pressure.



**Inhibit** – Prevention of activity or occurrence. Examples are: **XFILL INHBT**, **TAWS INHBT**, and **TAS INHBT**.

**Integrated Peripherals** – Internal devices of the essential unit.

**Intelliflight** – Genesys Aerosystems' digital autopilot.

**Ionosphere** – Region of the atmosphere between the stratosphere and exosphere, 50 to 250 miles (80 to 400 km) above the surface of the earth.

**International Standard Atmosphere (ISA)** – Standard model of the change of pressure, temperature, density, and viscosity over a wide range of altitudes or elevations.

**Landing Gear Indication** – When enabled on retractable landing gear aircraft, PFD shows indication of landing gear extended.

**Lubber Line** – Line marked on the compass showing the direction straight ahead.

**Mach Display** – Display of Mach number when the aircraft is traveling at or above 0.35 Mach. This function may be deselected by a setting in the IDU configuration (limits) file.

**Magnetic Declination (MAGVAR)** – Sometimes called magnetic variation; the angle between magnetic north and true north.

**Map Data** – Display of map data, including airspace, VFR/IFR airports, VHF nav aids such as VOR/NDB/DME, jet/victor airways, and display range rings.

**Menu Functions** – The EFIS includes menus to access functions on both the PFD and the MFD.

**Mesocyclonic** – Contains a vortex of air within a convective; air rises and rotates around a vertical axis, often in the same direction as low pressure systems.

**Millibar (mbar)** – Metric (not SI) unit of pressure, one thousandth of a bar (which is about equal to the atmospheric pressure on Earth at sea level - 1013 millibars).



**Miscompare** – Disparity of data or information. Examples are:

<b>ALT MISCOMP</b>	<b>ATT MISCOMP</b>	<b>GPS MISCOMP</b>
<b>GS MISCOMP</b>	<b>HDG MISCOMP</b>	<b>IAS MISCOMP</b>
<b>LOC MISCOMP</b>	<b>PLT MISCOMP</b>	<b>RALT MISCOMP</b>
	<b>CPLT MISCOMP</b>	<b>BARO MISCOMP</b>

and

**NavData** – Jeppesen's aeronautical database to navigate the global airspace system.

**Navigation Data Display** – Display of active waypoint, bearing to waypoint, and ground track based on active flight plan. The pilot may also select flight plan information as a mini-map (thumbnail map). These functions are analyzed as part of the GPS WAAS functions not the PFD functions.

**Navigation Log** – Display of navigation information based on active flight plan, including next waypoint, destination, estimated time remaining, and fuel totalizer-based range and endurance. This function may be deselected by a setting in the IDU configuration (limits) file. These functions are analyzed as part of the GPS WAAS functions not the MFD functions.

**Navigation Mode Signal Output** – Conventional autopilot Navigation mode signals are the course error output and the left-right deviation signals. Course error output is based on the difference between the EFIS selected course (OBS) and the actual aircraft heading. These signals are based on the selected navigation signal (VOR, GPS).

**Nondirectional** – Functions in all directions.

**Noodle** – Navigation Display (ND) Projected path; curving path based upon the aircraft bank angle and ground speed used effectively to assist in course interception and making small adjustments to bank angle for proper roll out.

**Nanoteslas (nT)** – A unit of measurement of the strength of the magnetic field. Earth's strongest magnetic field is located at the poles, and the weakest field is near the equator.

**Obstructions Display** – Display of obstructions identified in the embedded obstruction database which are within 8.5 NM of the aircraft present position. Non-threatening obstructions are displayed by color to identify altitude relative to the aircraft's current altitude (amber [yellow] < 2000' below, light red < 500' below, bright red = at or above aircraft). Threatening obstructions, defined as those that pierce the TAWS envelope, are identified by highlight when producing a caution and identified by flashing highlight when producing a warning. The database used with the obstruction functions meets the integrity requirements of RTCA/DO-200A.

**Omnibearing** – Magnetic bearing of an omni-range station.

**Ownship** – Principal eye-point; referring to icon of aircraft represented on display.

**Pitch Limit Indicator** – Appears when the aircraft (fixed wing only) is within 10 knots of stall speed, based on the VSI setting in the EFIS limits. The intent is to notify the pilot of a possible stall condition so corrective action is taken before the stall occurs. This function may be deselected by a setting in the IDU configuration (limits) file.

**Q-Routes** – Published RNAV routes, including Q-Routes and T-Routes, can be flight planned for use by the Genesys EFIS, subject to any limitations or requirements noted on enroute charts, in applicable Advisory Circulars, or by NOTAM. RNAV routes are depicted in blue on aeronautical charts and are identified by the letter "Q" or "T" followed by the airway number. E.g., Q35, T-205. Published RNAV routes are RNAV-2 except when specifically charted as RNAV-1.

**QFE** – Barometric setting that results in the altimeter displaying height above a reference elevation (e.g., airport or runway threshold).

**QNE** – Standard barometric setting (29.92 inHg or 1013 mbar) used to display pressure attitude for flight above the transition attitude.

**QNH** – Barometric setting that results in the altimeter displaying altitude above mean sea level at the reporting station.

**Recency** – State of occurrence, appearance, or origin.

**Selection and Display of Selected Course** – Omni-Bearing Select (OBS) function for the pilot to select the course for navigation. Selected course is displayed for reference.

**Settable V-Speeds, Targets** – The pilot may set certain V-speeds for reference during flight. In addition, the pilot may set certain information at any time for reference during flight, including target airspeed (with corresponding bug) and target altitude (with corresponding bug).

**Side in Command** – Side of aircraft control responsible for its operation.

**Skipped Waypoint** – A skipped waypoint is a waypoint associated with a dynamic termination leg with a zero length. These are either:

- 1) An altitude termination leg when current aircraft altitude is above the termination altitude; or
- 2) System-created (i.e., not NavData specified) intercept to a “Course to a Fix” leg where there is insufficient distance to calculate an intercept heading.

**Skyway VNAV/LNAV Guidance (Synthetic Vision)** – Display of GPS-based active navigation route, flight plan, procedure, or OBS course in a three-dimensional series of skyway boxes. Also known as Highway in the Sky and HITS.

**Slip Indicator** – Display of aircraft lateral accelerations via an integral slip/skid indicator function. The slip indicator is a rectangle just below the heading pointer that moves left and right to indicate the lateral acceleration sensed by the AHRS in the same manner as the ball in a mechanical slip indicator.

**Strikefinder** – Lightning detector system (WX-500) connected to EFIS and enabled through Factory Program settings.

**Suppressed Waypoint** – A suppressed waypoint (designated by brackets) is an airport associated with an IFR or VFR approach procedure.

**Symbology** – Use of symbols.

**T-Routes** – T-Routes are available for use by GPS or GPS/SBAS equipped aircraft from 1,200 feet above the surface (or in some instances higher) up to but not including 18,000 feet MSL. T-Routes are depicted on Enroute Low Altitude Charts and considered to include the same attributes of Low Altitude Airways in the Genesys Aerosystems EFIS Declutter menus.

**Talker** – IDU providing data to external sensors and generating aural alerts. IDUs depend upon intra-system communications to determine which IDU on a side takes over “Talker” responsibilities. Only one talker (transmit enabled) per side, two talkers in a two sided system, and a master talker PFD when considering aircraft limits. Any IDU may become a talker through auto reversionary means in the event of the PFD failing.

**Terrain Display (PFD Artificial Horizon)** – Conformal display of surrounding terrain presented with the artificial horizon, shown in the correct scale and perspective for the aircraft’s current position and altitude. Includes conformal display of known runway locations, direction, scale, and perspective based on aircraft’s current position and altitude.

**Terrain Display and TAWS/HTAWS** – Display of terrain, including identification and annunciation of threatening terrain in accordance with Terrain Awareness Warning System (TAWS) requirements. Coloring scheme for SVS-TAWS PFD and MAP has been simplified as follows:

Non-alerting Terrain below aircraft – Olive Shades

Non-alerting terrain above aircraft – Brown Shades

TAWS FLTA Caution Terrain – Amber (Yellow)

TAWS FLTA Warning Terrain – Red

Obstacles Below aircraft – Amber (Yellow)

Obstacles above aircraft – Red

When over water – Deep Blue

Threatening terrain is determined by the requirements of TAWS TSO-C151b (fixed wing) and TSO-C194 HTAWS (rotorcraft). Threatening terrain is shaded amber (yellow) for caution situations or shaded red for warning situations per TSO-C151b and TSO-C194. TAWS cautions and warnings are accompanied by an amber (yellow) or red flag and an aural annunciation. TAWS Class A, TAWS Class B, TAWS Class C, Enhanced HTAWS, or HTAWS functions may be activated in the system prior to installation. The database used with the TAWS functions meets the integrity requirements of RTCA/DO-200A.

**Timer Indication** – Pilot-selected function for a count-up or count-down timer.

**Traffic Display** – When integrated with an appropriate traffic system, traffic is shown using standard TCAS symbology showing relative position, altitude, climb/decent, and color. The pilot may also show traffic information by selecting the dedicated traffic display page.

**Vertical Speed Display** – Display of altitude rate of change (vertical speed or climb rate).

**V<sub>PROC</sub> (Procedure Speed)** – The aircraft's normal speed (in Airspeed Units and configured in EFIS Limits) for flying instrument approaches (DPs, IAPs, STARs). This value is used for calculating the turn radius used for instrument procedure legs. This speed is not seen on the airspeed tape and only found in the aircraft speed settings inside the limits.

**Warning, Caution, and Advisory Flags** – Display of, warning, caution, and advisory indications accompanied by aural indications. The flags are stacked in the lower left corner of the PFD. Warnings are always shown at the top of the flag stack, followed by cautions and then advisories. These flags remain in view for as long as the situation exists.

**Waterline** – Indication of the aircraft's longitudinal axis or waterline (attitude).

**Wide Area Augmentation System (WAAS)** – Developed by Federal Aviation Administration to provide accurate positioning part of the Satellite Based Augmentation System (SBAS). Other



countries have similar systems: Europe: European Geostationary Overlay System (EGNOS); Japan: MTSAT Satellite-based Augmentation System (MSAS); India: GPS Aided GEO Augmented Navigation system (GAGAN).

**Wind Information** – Display of wind direction, wind speed, and cross wind component.

**Zulu Clock, Timers** – Display of Zulu time (based on GPS data) and pilot-selected timer.



## IDU-680 Version 8.0D Pilot Guide (Fixed Wing)