

3D SYNTHETIC
VISION EFIS

HIGHWAY-
IN-THE-SKY
NAVIGATION

GRAPHICAL
FLIGHT
MANAGEMENT
SYSTEM

INTEGRATED
AUDIO/RADIO
MANAGEMENT



IDU-450 Version 8.0E Pilot Guide (Fixed Wing)

Pilot Operating Guide and Reference

(Fixed Wing)

EFIS Software Version 8.0E

Document 64-000103-080E

© 2017

Genesys Aerosystems

All Rights Reserved

No part of this document may be reproduced in any form, or by any means, without prior written consent of Genesys Aerosystems.

FlightLogic and Virtual VFR are trademarks of Genesys Aerosystems.

All other brand names and trademarks are the property of their respective holders.

One S-TEC Way, Municipal Airport, Mineral Wells TX. 76067

Phone: (800) 872-7832 Fax: (940) 325-3904

www.genesys-aerosystems.com

Record of Revisions	Retain this record in front of manual. Upon receipt of a revision, insert changes and complete table below.	
Revision Number	Revision Date	Insertion Date/Initials

Revision Record

Rev	Notes	Date	Author

Table of Contents

Section 1	Introduction	1-1
1.1.	Introduction	1-1
1.2.	EFIS/FMS Description	1-1
1.3.	About This Guide	1-2
1.3.1.	Audio and Video Interactive Capabilities	1-4
Section 2	System Overview	2-1
2.1.	Abbreviations and Acronyms	2-1
2.2.	System Overview	2-15
2.2.1.	Functional Integration and Display Redundancy...	2-16
2.2.2.	IDU Initialization	2-17
2.3.	General Arrangement	2-21
2.3.1.	Menu Philosophy	2-21
2.3.2.	IDU Intra-System Communications	2-22
2.4.	Color Conventions	2-22
2.5.	Warning/Caution/Advisory System	2-24
2.6.	Database and Software Updates	2-49
2.6.1.	Navigation and Obstruction Databases	2-49
2.6.2.	Update Requirements	2-50
2.6.3.	Software and Terrain Database Update	2-52
2.7.	Demonstrator	2-52
2.8.	EFIS Training Tool	2-53
2.9.	Application Software Air Mode and Ground Mode	2-53
Section 3	Display Symbology	3-1
3.1.	Introduction	3-1
3.1.1.	IDU-450 PFD Display Basic Mode	3-1
3.2.	Menu Functions	3-2
3.2.1.	Selecting BARO	3-3
3.2.2.	Selected Altitude Sub-Mode (Target Altitude) ..	3-4
3.2.3.	VNAV Sub-Mode	3-5
3.2.4.	Altitude Display (VNAV Tile)	3-6
3.2.5.	Altitude Display (Metric Units)	3-6

3.3.	PFD Symbology	3-6
3.3.1.	Minimum Altitude.....	3-7
3.3.2.	Vertical Speed Indicator	3-7
3.3.3.	Normal AGL Indication	3-8
3.3.4.	Analog AGL Indication.....	3-9
3.3.5.	Decision Height	3-10
3.3.6.	Airspeed Display	3-11
3.3.7.	Airspeed Display (With EFIS-Coupled)	3-15
3.3.8.	Heading Display	3-15
3.3.9.	Pitch Scale	3-17
3.3.10.	Pitch Limit Indicator	3-18
3.3.11.	G-Force and Fast/Slow Indicator	3-19
3.3.12.	Landing Gear Indication	3-20
3.3.13.	Turn Rate Indicator.....	3-20
3.3.14.	Unusual Attitude Mode	3-20
3.3.15.	PFD Background	3-21
3.3.16.	Flight Path Marker (Velocity Vector)	3-26
3.3.17.	Bank Angle Scale	3-28
3.3.18.	Timer Indication.....	3-29
3.3.19.	Marker Beacon Symbology	3-29
3.3.20.	Flight Director Symbology	3-30
3.3.21.	Course Deviation Indicator (CDI)	3-31
3.3.22.	OBS Setting of CDI	3-33
3.3.23.	No Autopilot or Fully-Integrated Autopilot CDI.....	3-33
3.3.24.	Vertical Deviation Indicator (VDI)	3-34
3.3.25.	Vertical Deviation Indicator (EFIS Coupled).....	3-36
3.3.26.	Highway in the Sky/Skyway	3-36
3.3.27.	Active Waypoint and Waypoint Identifier.....	3-37
3.3.28.	Mini Map.....	3-38
3.3.29.	Runways.....	3-39
3.4.	Navigation Display Symbology.....	3-41
3.4.1.	Ownship Symbology.....	3-41
3.4.2.	Moving Map.....	3-41

- 3.4.3. Compass Rose/ND Boundary Circle Symbol .3-43
- 3.4.4. Air Data and Groundspeed3-44
- 3.4.5. Clock/Options3-45
- 3.4.6. Navigation Data3-45
- 3.4.7. Analog Navigation Symbology3-47
- 3.4.8. Borders3-48
- 3.4.9. Terrain/Obstructions3-49
- 3.4.10. Pan Mode3-51
- 3.4.11. Start Point3-52
- 3.4.12. Altitude Capture Predictor/Top of Descent3-52
- 3.4.13. Projected Path3-52
- 3.4.14. Active Flight Plan Path/Manual Course/Runways .
.....3-53
- 3.4.15. FOV Indication3-54
- 3.4.16. Range3-54
- 3.5. HSI Screen3-55
 - 3.5.1. HSI Screen VDI3-56
 - 3.5.2. CDI Scale.....3-56
 - 3.5.3. Analog Navigation Symbology3-57
 - 3.5.4. Compass Rose Symbols3-58
 - 3.5.5. Air Data and Groundspeed3-59
 - 3.5.6. Clock/Options3-60
 - 3.5.7. Fuel Totalizer/Waypoint Bearing and Distance
Functions3-60
- 3.6. Navigation Log.....3-62
 - 3.6.1. Clock and Groundspeed3-62
 - 3.6.2. Fuel Remaining and Fuel Flow Data3-62
 - 3.6.3. Waypoint Identifier Column3-62
 - 3.6.4. VNAV and VNAV Offset Column3-63
 - 3.6.5. Path Column3-63
 - 3.6.6. Distance Column3-64
 - 3.6.7. Estimated Time Enroute Column.....3-64
 - 3.6.8. Estimated Time of Arrival Column3-64

3.6.9.	Fuel Remaining Column.....	3-65
Section 4	Reversionary Modes	4-1
4.1.	Reversionary Modes	4-1
4.2.	System Operation in Reversionary Modes	4-2
4.2.1.	Oat Sensor Failure Mode	4-5
4.2.2.	Heading Failure Mode	4-5
4.2.3.	PFD Screen Auto Reversion	4-5
4.2.4.	GPS Failure	4-6
4.3.	PFD Failure Mode 0	4-9
4.3.1.	MFD Failure Mode 0 (Normal Mode)	4-9
4.4.	PFD Failure Mode 1	4-10
4.4.1.	MFD Failure Mode 1.....	4-10
4.5.	PFD Failure Mode 2 (Normal Mode)	4-11
4.5.1.	MFD Failure Mode 2.....	4-11
4.6.	PFD Failure Mode 3	4-12
4.6.1.	MFD Failure Mode 3.....	4-12
4.7.	PFD Failure Mode 4	4-13
4.7.1.	MFD Failure Mode 4.....	4-13
4.8.	PFD Failure Mode 5	4-14
4.8.1.	MFD Failure Mode 5.....	4-14
4.9.	PFD Failure Mode 6	4-15
4.9.1.	MFD Failure Mode 6.....	4-15
4.10.	PFD Failure Mode 7	4-16
4.10.1.	MFD Failure Mode 7.....	4-16
Section 5	Menu Functions and Step-By-Step Procedures.....	5-1
5.1.	Menu Functions.....	5-1
5.2.	Menu Synchronization.....	5-1
5.3.	Menu Function Types.....	5-3
5.4.	Top-Level Menu	5-4
5.4.1.	Top-Level Menu Option Descriptions.....	5-4
5.4.2.	#1 Encoder (1).....	5-4
5.4.3.	Top-Level Menu Automatic Pop-up Function Descriptions	5-5

- 5.5. First Page (PFD).....5-6
 - 5.5.1. PFD Page First-Level Option Descriptions.....5-7
 - 5.5.2. PFD Screen First Soft Menu Level.....5-8
- 5.6. First-Level (MFD).....5-9
- 5.7. Lower-Level Menus (Below First-Level)5-10
 - 5.7.1. Flight Plan (FPL) Menu.....5-10
 - 5.7.2. Flight Planner Page5-10
 - 5.7.3. MFD Page Shown on IDU5-11
 - 5.7.4. Create an Overfly User Waypoint.....5-11
 - 5.7.5. Flight Plan (FPL) Menu Create-Edit (MFD Only) (Step-By-Step).....5-12
 - 5.7.6. Select/Activate Flight Plan (PFD or MFD) (Step-By-Step)5-13
 - 5.7.7. Edit Flight Plan (MFD Only) (Step-By-Step)...5-14
 - 5.7.8. Reverse Flight Plan (MFD Only) (Step-By-Step)...5-14
 - 5.7.9. Delete Flight Plan (MFD Only) (Step-By-Step).....5-15
 - 5.7.10. Create User Waypoint (LAT-LON) (MFD Only) (Step-By-Step).....5-15
 - 5.7.11. Create User Waypoint (RAD-DST) (MFD Only) (Step-By-Step).....5-16
 - 5.7.12. Edit User Waypoint (MFD Only) (Step-By-Step) ...5-17
 - 5.7.13. Delete User Waypoint (MFD Only) (Step-By-Step)5-18
 - 5.7.14. RAIM Prediction.....5-19
- 5.8. Active Flight Plan (ACTV) Menu.....5-21
 - 5.8.1. Main Menu5-21
 - 5.8.2. Active Flight Plan (ACTV) Menus5-21
 - 5.8.3. Active Flight Plan (ACTV) Menus (Step-By-Step).5-25
 - 5.8.4. Active Flight Plan (ACTV) Menu (Step-By-Step)...5-26

5.8.5.	Active Flight Plan (ACTV) Options NRST Menu (Step-By-Step)	5-27
5.9.	Information (INFO) Menu	5-27
5.9.1.	Information (INFO) Menu (Step-By-Step)	5-30
5.10.	Omnibearing Selector (OBS) Menu	5-30
5.10.1.	Omnibearing Selector (OBS) Menu (Step-By-Step)	5-31
5.11.	Heading Bug (HDG) Menu	5-31
5.11.1.	Heading Bug (HDG) Menu (PFD Only) (Step-By-Step)	5-32
5.12.	Nearest (NRST) Menu	5-32
5.12.1.	Nearest (NRST) Menu (Step-By-Step).....	5-34
5.12.2.	Nearest ILS (NRST) Menu (Step-By-Step)	5-34
5.13.	Direct Menu	5-35
5.13.1.	Direct Menu (Step-By-Step)	5-36
5.14.	Time (TIME) Menu	5-37
5.14.1.	Time (TIME) Menu (Step-By-Step)	5-38
5.15.	PFD Source (SOURCE) Menu.....	5-38
5.15.1.	PFD Page First-Level Source Selection (Step-By-Step)	5-39
5.16.	PFD Bugs (BUGS) Menu	5-40
5.16.1.	PFD Bugs (BUGS) Menu (Step-By-Step)	5-42
5.17.	PFD Declutter (DCLTR) Menu	5-43
5.17.1.	PFD Declutter (DCLTR) Menu (Step-By-Step)	5-45
5.18.	PFD Altimeter Menu.....	5-46
5.18.1.	PFD Altimeter Menu (Step-By-Step)	5-47
5.19.	MFD Fault Display (FAULTS) Menu	5-48
5.19.1.	MFD Fault Display (FAULTS) Menu (Step-By-Step)	5-50
5.20.	MFD Fuel Totalizer Quantity Setting (SET FUEL) Menu	5-50
5.21.	MFD Page (PAGE) Menu.....	5-50
5.21.1.	MFD Page (PAGE) Menu (Step-By-Step).....	5-51

5.22.	MFD NAV Log Page	5-52
5.23.	MFD ND Page Format (FORMAT) Menu	5-52
5.23.1.	MFD ND Page Format (FORMAT) Menu (Step-By-Step)	5-55
5.24.	MFD HSI Page.....	5-55
5.24.1.	MFD HSI Pointer (PTRS) Menu	5-55
Section 6	Quick Start Tutorial.....	6-1
Section 7	IFR Procedures.....	7-1
7.1.	Active Flight Plan.....	7-1
7.2.	IFR Procedures.....	7-4
7.3.	Overview of Procedures and Instrument Approaches..	7-5
7.3.1.	Highway in the Sky (Skyway)	7-7
7.3.2.	Waypoint Sequencing.....	7-11
7.3.3.	Fly-Over Waypoints	7-12
7.3.4.	Fly-By Waypoints.....	7-13
7.3.5.	Direct-To	7-18
7.4.	Magnetic Course	7-18
7.4.1.	AHRS Modes for Heading Source.....	7-19
7.4.2.	GPS Altitude	7-19
7.4.3.	Dead Reckoning	7-20
7.4.4.	Parallel Offsets	7-20
7.5.	Default GPS/SBAS Navigation Modes	7-22
7.6.	GPS/SBAS CDI Scale	7-24
7.7.	Approach Type Selection	7-25
7.8.	VTF IFR Approach.....	7-27
7.9.	VTF VFR Approach	7-27
7.10.	Missed Approach and Departure Path Definition	7-28
7.11.	Loss of Navigation Monitoring	7-29
7.12.	Discontinuities.....	7-29
7.13.	Selection of an Instrument Procedure	7-30
7.13.1.	Standard Instrument Departure (SID) (Step-by-Step)	7-31

7.13.2.	Standard Terminal Arrival Route (STAR) (Step-by-Step)	7-33
7.13.3.	ILS Instrument Approach (Step-by-Step)	7-36
7.13.4.	LOC Back Course Instrument Approach (Step-by-Step)	7-40
7.13.5.	RNAV (GPS) Instrument Approach to LPV Minima (Step-By-Step)	7-44
7.13.6.	NRST ILS Instrument Approach (Step-By-Step)	7-47
7.13.7.	VOR/DME Instrument Approach (Step-By-Step)	7-50
Section 8	Terrain Awareness Warning System	8-1
8.1.	TAWS Functions	8-1
8.1.1.	Terrain Display	8-2
8.2.	Forward Looking Terrain Alert (FLTA) Function	8-3
8.2.1.	FLTA Modes	8-3
8.2.2.	GPS/SBAS Navigation Mode Slaving	8-4
8.2.3.	Default FLTA Mode	8-4
8.3.	FLTA Search Envelope	8-5
8.3.1.	FLTA Alerts and Automatic Popup	8-8
8.4.	Premature Descent Alert (PDA) Function	8-9
8.5.	Excessive Rate of Descent (GPWS Mode 1)	8-10
8.6.	Excessive Closure Rate to Terrain (GPWS Mode 2)	8-11
8.7.	Sink Rate after Takeoff or Missed Approach (GPWS Mode 3)	8-13
8.8.	Flight into Terrain when not in Landing Configuration (GPWS Mode 4)	8-14
8.9.	Excessive Downward Deviation from an ILS Glideslope (GPWS Mode 5)	8-16
8.10.	500-Foot Wake-Up Call	8-17
8.11.	External Sensors and Switches	8-17
8.12.	TAWS Basic Parameter Determination	8-18
8.13.	TAWS Automatic Inhibit Functions (Normal Operation)	8-22

- 8.13.1. TAWS Automatic Inhibit Functions (Abnormal Operation)8-22
- 8.13.2. TAWS Manual Inhibit Functions8-24
- 8.14. TAWS Selections on PFD8-25
- Section 9 Appendix.....9-1
- 9.1. Appendix.....9-1
- 9.2. Operating Tips9-1
- 9.3. Domestic or International Flight Planning.....9-1
- 9.4. Descent Planning9-1
- 9.5. Terrain Clearance9-1
- 9.6. Departure Airport Information9-2
- 9.7. Unique Names for Flight Plans.....9-2
- 9.8. Altimeter Settings9-2
- 9.9. Warnings, Cautions, and Advisories9-2
- 9.10. Magnetic vs. True North Modes of Operation9-2
- 9.11. Altitude Miscompare Threshold9-4
- 9.12. Airspeed Miscompare Threshold.....9-5
- 9.13. Jeppesen NavData Chart Compatibility9-7
- 9.14. ARINC-424 Path Terminator Leg Types9-7
- 9.15. Data Logging and Retrieval9-7
 - 9.15.1. Delete LOG Files9-8
 - 9.15.2. Logged Flags and Custom CAS Messages9-8
 - 9.15.3. Screen Capture from Ground Maintenance Pages9-9
- 9.16. Routes and Waypoints9-9
 - 9.16.1. VFR Flight Planning.....9-9
 - 9.16.2. EFIS Training Tool (ETT)9-9
 - 9.16.3. Download Routes and User Waypoints.....9-10
 - 9.16.4. Upload Routes and User Waypoints9-10
 - 9.16.5. Delete Routes/User Waypoints9-10
- 9.17. USB External Drive Memory Limitations9-11
- 9.18. Service Difficulty Report9-12
- 9.19. Certification Basis9-13

9.20.	Environmental Requirements	9-14
T 1.	Traffic Symbology.....	T-1
T 1.1.	Traffic Display Definitions.....	T-1
T 1.2.	Traffic Rendering Rules.....	T-2
T 2.	Dedicated Traffic Screen.....	T-3
T 2.1.	Traffic Display Format	T-3
T 2.2.	Traffic Screen Range	T-4
T 2.3.	Compass Rose Symbols	T-4
T 2.4.	Active Flight Plan Path/Manual Course/Runways.	T-5
T 2.5.	Clock and Options	T-6
T 2.6.	Fuel Totalizer/Waypoint Bearing and Distance Functions	T-7
T 3.	MFD Page First-Level Option Descriptions.....	T-7
T 3.1.	MFD Traffic Format (FORMAT) Menu	T-7
T 4.	PFD Declutter (DCLTR) Menu	T-8
T 5.	MFD Fault Display (FAULTS) Menu	T-8
T 6.	Menu Synchronization.....	T-8
RBP 1.	Remote BUGs Panel.....	RBP-1
RBP 2.	Menu Synchronization.....	RBP-4
S 1.	WX-500 Data.....	S-1
S 1.1.	Strike Screen Range	S-2
S 1.2.	Air Data and Groundspeed	S-2
S 1.3.	Clock and Options	S-2
S 1.4.	Fuel Totalizer/Waypoint Bearing and Distance Functions	S-3
S 1.5.	Active Flight Plan Path/Manual Course/Runways.	S-3
S 2.	MFD Page First-Level Option Descriptions.....	S-4
S 2.1.	MFD Strike Format (FORMAT) Menu	S-4
S 3.	MFD Page (PAGE) Menu.....	S-5
S 4.	MFD Fault Display (FAULTS) Menu	S-5
S 5.	Menu Synchronization.....	S-5
D 1.	Datalink Symbology	D-1

D 1.1.	Ownship Symbol.....	D-5
D 1.2.	Datalink Screen Legend	D-6
D 1.3.	Air Data and Groundspeed	D-6
D 1.4.	Clock/Options	D-6
D 1.5.	Datalink Screen Orientation.....	D-9
D 1.6.	Boundary Circle Symbols	D-10
D 1.7.	Active Flight Plan Path/Manual Course/Runways	D-11
D 1.8.	Borders	D-11
D 1.9.	Pan Mode	D-12
D 2.	Top-Level Menu Automatic Pop-Up Function Descriptions	D-12
D 3.	MFD Page First-Level Option Descriptions	D-13
D 4.	MFD Datalink Format (FORMAT) Menu.....	D-13
D 4.1.	MFD Datalink Format (Step-By-Step).....	D-14
D 5.	Active Flight Plan (ACTV) Menu Options	D-15
D 6.	MFD Fault Display Menu	D-15
D 7.	MFD Page (PAGE) Menu	D-15
D 8.	Menu Synchronization	D-15
WX 1.	Weather Radar	WX-1
WX 1.1.	Weather Radar Screen	WX-1
WX 1.2.	Weather Screen Range	WX-3
WX 1.3.	Track Line	WX-3
WX 1.4.	Active Flight Plan Path/Manual Course/Runways	WX-4
WX 1.5.	Weather Radar Return Data	WX-4
WX 1.6.	Air Data and Groundspeed	WX-6
WX 1.7.	Clock/Options	WX-6
WX 1.8.	Fuel Totalizer/Waypoint Bearing and Distance Functions	WX-8
WX 2.	MFD WX RDR Format (FORMAT) Menu	WX-9
WX 3.	MFD Fault Display (FAULTS) Menu.....	WX-10
WX 4.	Menu Synchronization	WX-11
V 1.	Video Input Screen	V-1

V 1.1.	ZOOM Level	V-1
V 1.2.	Pan Mode	V-2
V 2.	Top-Level Menu Automatic Pop-Up Functions	V-2
V 3.	Video Input Status Display	V-3
V 4.	MFD Page First-Level Option Descriptions.....	V-3
V 4.1.	MFD Video Input Format (FORMAT) Menu	V-3
V 5.	Menu Synchronization.....	V-5
RD 1.	Display Symbology.....	RD-1
RD 1.1.	IDU-450 PFD Display Basic Mode	RD-1
RD 1.2.	Selecting BARO	RD-1
RD 1.3.	Selected Altitude Sub-Mode (Target Altitude).....	RD-2
RD 1.4.	VNAV Sub-Mode	RD-3
RD 1.5.	Altitude Display.....	RD-4
RD 1.6.	PFD Symbology	RD-5
RD 1.7.	Minimum Altitude.....	RD-6
RD 1.8.	Vertical Speed Indicator	RD-6
RD 1.9.	Normal AGL Indication	RD-7
RD 1.10.	Decision Height	RD-7
RD 1.11.	Airspeed Display	RD-7
RD 1.12.	Heading Display	RD-8
RD 1.13.	G-Force Indicator	RD-9
RD 1.14.	Unusual Attitude Mode	RD-9
RD 1.15.	Turn Rate Indicator.....	RD-10
RD 1.16.	Bank Angle Scale	RD-10
RD 1.17.	Marker Beacon Symbology	RD-10
RD 1.18.	Course Deviation Indicator	RD-10
RD 1.19.	Flight Director Symbology	RD-11
RD 1.20.	Landing Gear Indication	RD-11
RD 2.	Reversionary Modes	RD-11
RD 2.1.	PFD (Round Dials) Failure Mode 0	RD-12
RD 2.2.	PFD (Round Dials) Failure Mode 1	RD-12

RD 2.3.	PFD (Round Dials) Failure Mode 2 (Normal Mode)	RD-13
RD 2.4.	PFD (Round Dials) Failure Mode 3	RD-13
RD 2.5.	PFD (Round Dials) Failure Mode 4	RD-14
RD 2.6.	PFD (Round Dials) Failure Mode 5	RD-14
RD 2.7.	PFD (Round Dials) Failure Mode 6	RD-15
RD 2.8.	PFD (Round Dials) Failure Mode 7	RD-15
RD 3.	PFD Declutter (DCLTR) Menu	RD-16
RD 4.	Quick Reference	RD-16
RD 4.1.	XFILL SYNC Operation	RD-17

INDEX

GLOSSARY

List of Figures and Tables

FIGURE 1-1: IDU-450 INPUT IDENTIFICATION	1-2
FIGURE 1-2: AUDIO AND VIDEO ICONS.....	1-4
FIGURE 2-1: IDU-450 PRIMARY FLIGHT DISPLAY (PFD)	2-15
FIGURE 2-2: IDU-450 MULTIFUNCTION DISPLAY (MFD)	2-15
FIGURE 2-3: SYSTEM DIAGRAM	2-16
FIGURE 2-4: INITIALIZATION SCREEN.....	2-17
TABLE 2-1: IDU INITIALIZATION SOFTWARE VERSION AND PART NUMBERS.....	2-17
TABLE 2-2: CPU NUMBER DESIGNATION.....	2-18
FIGURE 2-5: PRIMARY IDU-450 PFD.....	2-21
TABLE 2-3: WARNINGS, CAUTIONS, AND ADVISORIES	2-24
TABLE 2-4: ANNUNCIATIONS PRIORITY.....	2-48
FIGURE 2-6: GROUND MAINTENANCE PAGE	2-51
FIGURE 3-1: PFD	3-1
FIGURE 3-2: PFD IN BASIC MODE.....	3-2
FIGURE 3-3: MENU FUNCTIONS	3-2
TABLE 3-1: ENCODER FUNCTIONS FOR ALL PAGES.....	3-3
FIGURE 3-4: SELECTING BARO.....	3-3
FIGURE 3-5: ALTIMETER SETTING	3-4
FIGURE 3-6: TARGET ALTITUDE BUG (VERTICALLY INTEGRATED)	3-4
FIGURE 3-7: VNAV SUB-MODE (NOT VERTICALLY INTEGRATED)	3-5
FIGURE 3-8: VNAV SUB-MODE (VERTICALLY INTEGRATED).....	3-5
FIGURE 3-9: ALTITUDE DISPLAY (VNAV TILE)	3-6
FIGURE 3-10: ALTITUDE DISPLAY (METRIC UNITS).....	3-6
FIGURE 3-11: PFD SYMBOLOGY.....	3-6
FIGURE 3-12: MINIMUM ALTITUDE.....	3-7
FIGURE 3-13: VSI.....	3-7
TABLE 3-2: SCALE GRADUATIONS AND DISPLAY	3-8
FIGURE 3-14: VSI BUG	3-8
FIGURE 3-15: VSI BUG (VERTICALLY INTEGRATED)	3-8
FIGURE 3-16: NORMAL AGL INDICATION.....	3-9
TABLE 3-3: AGL INDICATION	3-9
FIGURE 3-17: ANALOG AGL INDICATION	3-9
TABLE 3-4: ANALOG AGL INDICATOR.....	3-9
TABLE 3-5: ANALOG AGL INDICATOR MARKINGS	3-10
FIGURE 3-18: DECISION HEIGHT.....	3-10
FIGURE 3-19: AIRSPEED DISPLAY.....	3-11
FIGURE 3-20: AIRSPEED TREND	3-11
FIGURE 3-21: AIRSPEED SCALE BUG	3-11
TABLE 3-6: AIRSPEED BUG LIMITS	3-11
TABLE 3-7: AIRSPEED BUG SETTING ANNUNCIATION AND BUG COLORS	3-12

FIGURE 3-22: AIRSPEED SCALE FAR PART 23	3-12
FIGURE 3-23: AIRSPEED SCALE FAR PART 25	3-14
FIGURE 3-24: AIRSPEED DISPLAY (WITH EFIS-COUPLED)	3-15
FIGURE 3-25: HEADING DISPLAY	3-15
FIGURE 3-26: DG INDICATED WHEN AHRS IN DG MODE.....	3-16
FIGURE 3-27: SLIP/SKID INDICATOR	3-16
FIGURE 3-28: DISPLACED HEADING BUG	3-16
FIGURE 3-29: PITCH SCALE	3-17
FIGURE 3-30: PITCH SCALE ZENITH AND NADIR SYMBOLS	3-17
FIGURE 3-31: PITCH LIMIT INDICATOR	3-18
TABLE 3-8: PITCH LIMIT INDICATOR APPEARANCE LIMITS.....	3-18
FIGURE 3-32: G-FORCE INDICATOR.....	3-19
FIGURE 3-33: G-FORCE INDICATOR TELLTALE INDICATIONS.....	3-19
FIGURE 3-34: RESET G.....	3-19
FIGURE 3-35: FAST SLOW INDICATOR.....	3-19
FIGURE 3-36: LANDING GEAR INDICATION.....	3-20
FIGURE 3-37: TURN RATE INDICATOR.....	3-20
FIGURE 3-38: UNUSUAL ATTITUDE MODE	3-21
FIGURE 3-39: PFD TERRAIN AND OBSTRUCTIONS.....	3-22
TABLE 3-9: LAT-LON RESOLUTION BOUNDARIES	3-23
TABLE 3-10: TERRAIN AND OBSTRUCTION RENDERING LEVELS.....	3-23
FIGURE 3-40: PFD WITH TERRAIN DESELECTED	3-24
FIGURE 3-41: MFD WITH TERRAIN SELECTED.....	3-24
FIGURE 3-42: PFD WITH OBSTRUCTIONS	3-25
FIGURE 3-43: FLIGHT PATH MARKER.....	3-26
FIGURE 3-44: FLIGHT PATH MARKER VIEWS	3-26
FIGURE 3-45: FLIGHT PATH MARKER GHOST	3-27
TABLE 3-11: FLIGHT PATH MARKER BEHAVIOR	3-27
FIGURE 3-46: FLIGHT PATH MARKER ABSENT (UNUSUAL ATTITUDE MODE)	3-27
FIGURE 3-47: PFD WITH GPS FAILURE AFTER 1 MINUTE	3-28
FIGURE 3-48: PFD BANK SCALE	3-28
FIGURE 3-49: BANK ANGLE	3-29
FIGURE 3-50: TIMER.....	3-29
FIGURE 3-51: MARKER BEACONS	3-29
FIGURE 3-52: FLIGHT DIRECTOR	3-30
FIGURE 3-53: FLIGHT DIRECTOR (BASIC MODE).....	3-30
FIGURE 3-54: COURSE DEVIATION INDICATOR	3-31
TABLE 3-12: CDI BEHAVIOR AND COLOR	3-31
FIGURE 3-55: CDI NO AUTOPILOT OR FULLY-INTEGRATED AUTOPILOT	3-33
FIGURE 3-56: VERTICAL DEVIATION INDICATOR.....	3-34
TABLE 3-13: VERTICAL DEVIATION INDICATOR BEHAVIOR	3-34

FIGURE 3-57: VERTICAL DEVIATION INDICATOR COLOR DURING GPS/SBAS LON or VLON3-36

FIGURE 3-58: EFIS COUPLED VERTICALLY WITH GLIDESLOPE MODE ENGAGED3-36

FIGURE 3-59: HIGHWAY IN THE SKY3-37

FIGURE 3-60: ACTIVE WAYPOINT3-37

FIGURE 3-61: MINI MAP3-38

TABLE 3-14: MINI-MAP BEHAVIOR (WHEN NOT DECLUTTERED)3-39

FIGURE 3-62: MINI MAP VOR SYMBOLOGY3-39

FIGURE 3-63: RUNWAYS3-39

TABLE 3-15: RUNWAY DRAWING CRITERIA3-40

FIGURE 3-64: OWNERSHIP SYMBOLOGY3-41

FIGURE 3-65: BASIC MOVING MAP3-41

FIGURE 3-66: LATITUDE/LONGITUDE DISPLAY3-42

FIGURE 3-67: MOVING MAP WITH INSTRUMENT APPROACH3-42

FIGURE 3-68: NORTH-UP ARC MODE3-42

FIGURE 3-69: NORTH-UP CENTERED MODE3-43

FIGURE 3-70: HEADING-UP CENTERED MODE3-43

FIGURE 3-71: COMPASS ROSE/ND BOUNDARY CIRCLE SYMBOL3-43

FIGURE 3-72: AIR DATA AND GROUND SPEED3-44

FIGURE 3-73: CLOCK/OPTIONS3-45

TABLE 3-16: CLOCK/OPTIONS3-45

FIGURE 3-74: NAVIGATION DATA AND AIRSPACE DEPICTION3-45

TABLE 3-17: NAVIGATION SYMBOLOGY3-46

TABLE 3-18: AIRSPACE DEPICTION3-47

FIGURE 3-75: HSI IN ARC AND CENTER MODES3-48

FIGURE 3-76: BORDERS3-49

FIGURE 3-77: TERRAIN/OBSTRUCTIONS3-49

TABLE 3-19: TERRAIN COLOR3-49

FIGURE 3-78: OBSTRUCTIONS3-50

TABLE 3-20: OBSTRUCTIONS3-50

FIGURE 3-79: PAN MODE3-51

FIGURE 3-80: START POINT3-52

FIGURE 3-81: TOP-OF-DESCENT OR TOP-OF-CLIMB3-52

FIGURE 3-82: PROJECTED PATH3-53

FIGURE 3-83: FIELD OF VIEW3-54

FIGURE 3-84: RANGE3-54

FIGURE 3-85: HSI POINTER COLOR3-55

FIGURE 3-86: HSI WITH VDI AND GLIDESLOPE3-56

FIGURE 3-87: HSI CDI SCALE3-56

FIGURE 3-88: HSI CDI SCALE (WITH LON CONDITION)3-57

FIGURE 3-89: ANALOG NAVIGATION DISPLAY VOR1 AND VOR23-57

FIGURE 3-90: HSI BEARING DISTANCE READOUT WITH DME IN HOLD3-58

FIGURE 3-91: HSI WITH MARKER BEACON DISPLAYED	3-58
FIGURE 3-92: COMPASS ROSE.....	3-58
FIGURE 3-93: HSI DISPLAY AIR DATA AND GROUNDSPED WITH MARKER BEACON.....	3-59
FIGURE 3-94: HSI CLOCK.....	3-60
FIGURE 3-95: FUEL TOTALIZER/WAYPOINT BEARING AND DISTANCE FUNCTIONS	3-60
TABLE 3-21: FUEL TOTALIZER/WAYPOINT BEARING AND DISTANCE FUNCTIONS	3-61
FIGURE 3-96: NAVIGATION LOG	3-62
TABLE 4-1: PFD FUNCTIONS.....	4-2
TABLE 4-2: ND FUNCTIONS.....	4-3
TABLE 4-3: OUTPUT FUNCTIONS	4-3
FIGURE 4-1: FAULTS PAGE ON MFD	4-7
FIGURE 4-2: PFD FAILURE MODE 0 GPS/SBAS, ADC AND AHRS NORMAL.....	4-9
FIGURE 4-3: MFD FAILURE MODE 0 (NORMAL MODE) GPS/SBAS, ADC AND AHRS NORMAL.....	4-9
FIGURE 4-4: PFD FAILURE MODE 1 GPS/SBAS FAILED; ADC AND AHRS NORMAL.....	4-10
FIGURE 4-5: MFD FAILURE MODE 1 GPS/SBAS FAILED; ADC AND AHRS NORMAL.....	4-10
FIGURE 4-6: PFD FAILURE MODE 2 (NORMAL MODE) ADC FAILED; GPS/SBAS AND AHRS NORMAL.....	4-11
FIGURE 4-7: MFD FAILURE MODE 2 ADC FAILED; GPS/SBAS AND AHRS NORMAL.....	4-11
FIGURE 4-8: PFD FAILURE MODE 3 AHRS FAILED; GPS/SBAS AND ADC NORMAL	4-12
FIGURE 4-9: MFD FAILURE MODE 3 AHRS FAILED; GPS/SBAS AND ADC NORMAL	4-12
FIGURE 4-10: PFD FAILURE MODE 4 GPS/SBAS AND ADC FAILED; AHRS NORMAL.....	4-13
FIGURE 4-11: MFD FAILURE MODE 4 GPS/SBAS AND ADC FAILED; AHRS NORMAL.....	4-13
FIGURE 4-12: PFD FAILURE MODE 5 GPS/SBAS AND AHRS FAILED; ADC NORMAL	4-14
FIGURE 4-13: MFD FAILURE MODE 5 GPS/SBAS AND AHRS FAILED; ADC NORMAL	4-14
FIGURE 4-14: PFD FAILURE MODE 6 ADC AND AHRS FAILED; GPS/SBAS NORMAL	4-15
FIGURE 4-15: MFD FAILURE MODE 6 ADC AND AHRS FAILED; GPS/SBAS NORMAL	4-15
FIGURE 4-16: PFD FAILURE MODE 7 GPS/SBAS, ADC AND AHRS FAILED	4-16

FIGURE 4-17: MFD FAILURE MODE 7 GPS/SBAS, ADC AND AHRS FAILED4-16

FIGURE 5-1: IDU-450 INPUT CONTROLS5-1

TABLE 5-1: MENU SYNCHRONIZATION5-1

FIGURE 5-2: PFD TOP-LEVEL MENU.....5-4

TABLE 5-2: TOP-LEVEL MENU AUTOMATIC FUNCTION DESCRIPTIONS TILE LEGEND AND ACTION IN ORDER OF PRECEDENCE5-5

FIGURE 5-3: FIRST PAGE PFD5-6

TABLE 5-3: CROSSFILL INHIBIT/ARM/SYNC FUNCTION.....5-7

FIGURE 5-4: FIRST-LEVEL MFD5-9

FIGURE 5-5: FLIGHT PLAN MENU5-10

FIGURE 5-6: CREATION OF OVERFLY USER WAYPOINT5-12

FIGURE 5-7: ACTIVE FLIGHT PLAN MAIN MENU.....5-21

FIGURE 5-8: ACTIVE FLIGHT PLAN MENUS5-22

FIGURE 5-9: INFORMATION MENU5-28

FIGURE 5-10: CRS SYNC5-29

FIGURE 5-11: OMNIBEARING SELECTOR (OBS) MENU.....5-30

FIGURE 5-12: HEADING BUG (HDG) MENU5-32

FIGURE 5-13: NEAREST (NRST) MENU5-33

FIGURE 5-14: DIRECT MENU5-35

FIGURE 5-15: TIME MENU5-37

FIGURE 5-16: PFD SOURCE MENU.....5-39

FIGURE 5-17: PFD BUGS (BUGS) MENU5-41

FIGURE 5-18: PFD BUGS (BUGS) MENU (CONTINUED)5-42

FIGURE 5-19: PFD DECLUTTER (DCLTR) MENU5-44

TABLE 5-4: PFD DECLUTTER OPTIONS AND FEATURES5-44

FIGURE 5-20: PFD ALTIMETER MENU.....5-46

FIGURE 5-21: MFD FAULT DISPLAY MENU.....5-48

FIGURE 5-22: MFD FUEL TOTALIZER QUANTITY MENU5-50

FIGURE 5-23: MFD PAGE (PAGE) MENU5-51

FIGURE 5-24: MFD SYMBOL DECLUTTER.....5-52

FIGURE 5-25: MFD ND PAGE FORMAT MENU5-54

FIGURE 5-26: MFD HSI POINTER (PTRS) MENU5-55

FIGURE 7-1: VERTICAL DEVIATION INDICATOR LINEAR DEVIATION7-6

TABLE 7-1: HIGHWAY IN THE SKY CONFIGURATION7-7

FIGURE 7-2: HIGHWAY IN THE SKY (AIRCRAFT REFERENCED)7-9

FIGURE 7-3: HIGHWAY IN THE SKY (GEO-REFERENCED BACKWARD).....7-9

FIGURE 7-4: HIGHWAY IN THE SKY (GEO-REFERENCED FORWARD).....7-9

TABLE 7-2: FINAL SEGMENT OF IFR APPROACH, DESCENT ANGLE AND VNAV WAYPOINT7-10

FIGURE 7-5: HIGHWAY IN THE SKY FINAL APPROACH SEGMENTS7-11

FIGURE 7-6: FLY-OVER WAYPOINTS7-12

TABLE 7-3: RNAV PATH TERMINATOR LEG TYPE7-13

FIGURE 7-7: FLY-BY WAYPOINTS7-14

TABLE 7-4: LEG SEGMENTS FOR PATHS CONSTRUCTED BY THE IDU	7-15
FIGURE 7-8: PARALLEL OFFSET ENTRY WAYPOINT PTK+	7-21
FIGURE 7-9: PARALLEL OFFSET ENTRY WAYPOINT PTK-	7-21
TABLE 7-5: DEFAULT GPS/SBAS NAVIGATION MODES	7-22
TABLE 7-6: DEFAULT NAVIGATION MODES BASED UPON REGION OF OPERATION	7-23
TABLE 7-7: SUMMARY OF CHANGES IN CROSS-TRACK FSD	7-24
FIGURE 7-10: GPS MODE (LNAV APPR)	7-27
FIGURE 7-11: NAVIGATING TO FAF ON VTF VFR APPROACH	7-28
FIGURE 7-12: MISSED APPROACH AND DEPARTURE PATH	7-29
FIGURE 7-13: STANDARD INSTRUMENT DEPARTURE (SID)	7-31
FIGURE 7-14: STANDARD TERMINAL ARRIVAL ROUTE (STAR)	7-33
FIGURE 7-15: ILS RWY 11 (MSY)	7-36
FIGURE 7-16: LOC BACK COURSE APPROACH	7-40
FIGURE 7-17: RNAV (GPS) INSTRUMENT APPROACH TO LPV MINIMA ..	7-44
FIGURE 7-18: NRST ILS INSTRUMENT APPROACH	7-47
FIGURE 7-19: VOR/DME INSTRUMENT APPROACH	7-50
TABLE 8-1: TAWS FUNCTIONS PROVIDED BY THE EFIS	8-2
FIGURE 8-1: TERRAIN DISPLAY PFD	8-2
FIGURE 8-2: TERRAIN DISPLAY MFD	8-3
FIGURE 8-3: FLTA INHBT	8-3
FIGURE 8-4: DEFAULT FLTA INHBT	8-4
FIGURE 8-5: FLTA INHBT MODE AREAS	8-4
TABLE 8-2: FLTA SEARCH ENVELOPE FOR HTAWS	8-5
FIGURE 8-6: FLTA SEARCH VOLUME	8-7
FIGURE 8-7: ND IN POPUP MODE	8-9
FIGURE 8-8: PDA ALERT THRESHOLD	8-10
TABLE 8-3: GPWS MODE 1 ENVELOPE	8-10
FIGURE 8-9: FIXED WING GPWS MODE 1	8-11
TABLE 8-4: GPWS MODE 2 ENVELOPES	8-12
FIGURE 8-10: FIXED WING GPWS MODE 2	8-12
TABLE 8-5: GPWS MODE 2A ENVELOPES (NOT IN LANDING CONFIGURATION)	8-13
TABLE 8-6: GPWS MODE 2B ENVELOPES (LANDING CONFIGURATION)	8-13
FIGURE 8-11: FIXED WING GPWS MODE 3	8-14
TABLE 8-7: MODE 4 ENVELOPES	8-14
TABLE 8-8: "Too Low" CAUTION WITHIN MODE 4 ENVELOPE	8-15
TABLE 8-9: GPWS MODE 4 PARAMETERS	8-15
FIGURE 8-12: FIXED WING GPWS MODE 4	8-15
TABLE 8-10: GPWS MODE 5 ENVELOPES	8-16
FIGURE 8-13: FIXED WING GPWS MODE 5	8-16

TABLE 8-11: TAWS EXTERNAL SENSORS AND SWITCHES 8-18

TABLE 8-12: AIRPLANE TAWS BASIC PARAMETERS DETERMINATION..... 8-18

TABLE 8-13: TAWS AUTOMATIC INHIBIT FUNCTIONS 8-22

FIGURE 8-14: PFD SVS BASIC OPTION 8-25

FIGURE 8-15: PFD SVS TAWS OPTION 8-25

FIGURE 8-16: PFD SVS TAWS OPTION AND OBSTRUCTIONS 8-26

FIGURE 8-17: PFD OBSTRUCTION CAUTION 8-26

FIGURE 8-18: PFD OBSTRUCTION WARNING 8-27

FIGURE 8-19: AUTOMATIC PFD TERRAIN WARNING 8-27

FIGURE 9-1: US/UK WORLD MAGNETIC MODEL..... 9-3

TABLE 9-1: ALLOWABLE INSTRUMENT ERROR..... 9-4

TABLE 9-2: REGULATORY REFERENCE..... 9-5

TABLE 9-3: AIRSPEED ERROR 9-5

TABLE 9-4: AIRSPEED REGULATORY REFERENCE..... 9-6

TABLE 9-5: LOG FILE VALUES..... 9-8

FIGURE 9-2: VFR WAYPOINT 9-9

FIGURE T-1: TRAFFIC SYMBOLOGY T-1

FIGURE T-2: TRAFFIC THUMBNAIL..... T-1

TABLE T-1: TRAFFIC RENDERING RULES..... T-2

TABLE T-2: TRAFFIC SYMBOLOGY..... T-2

TABLE T-3: PILOT SELECTED OT AND PA TRAFFIC ALTITUDE-FILTER T-2

FIGURE T-3: TRAFFIC DISPLAY FORMAT..... T-3

FIGURE T-4: TRAFFIC SCREEN RANGE COMPASS ROSE SYMBOLS ... T-4

TABLE T-4: ADS-B AND TIS-B TRAFFIC SYMBOLS T-5

FIGURE T-5: CLOCK AND OPTIONS..... T-6

TABLE T-5: CLOCK/OPTIONS T-6

FIGURE T-6: FUEL TOTALIZER/WAYPOINT BEARING AND DISTANCE FUNCTIONS T-7

FIGURE T-7: MFD TRAFFIC FORMAT (FORMAT) MENU T-7

TABLE T-6: PFD DECLUTTER OPTIONS AND FEATURES T-8

TABLE T-7: MENU SYNCHRONIZATION..... T-8

FIGURE RBP-1: REMOTE BUGS PANEL RBP-1

TABLE RBP-1: REMOTE BUGS PANEL (RBP) RBP-1

TABLE RBP-2: MENU SYNCHRONIZATION RBP-4

TABLE S-1: LIGHTNING STRIKES S-1

FIGURE S-1: LIGHTNING SYMBOLS..... S-1

FIGURE S-2: AIR DATA AND GROUNDSPED IN UPPER LEFT CORNER..... S-2

FIGURE S-3: CLOCK AND OPTIONS S-2

TABLE S-2: WX-500 STATUS S-3

FIGURE S-4: FUEL TOTALIZER, WAYPOINT BEARING/DISTANCE IN LOWER RIGHT CORNER S-3

FIGURE S-5: ACTIVE FLIGHT PLAN PATH/MANUAL COURSE/RUNWAYS...	S-4
FIGURE S-6: MFD STRIKE FORMAT (FORMAT) MENU	S-5
TABLE S-3: MENU SYNCHRONIZATION	S-5
FIGURE D-1: DATALINK SYMBOLOGY	D-1
TABLE D-1: WSI INFLIGHT™ DATA PRODUCTS	D-1
TABLE D-2: DATALINK NEXRAD RADAR DATA	D-2
TABLE D-3: DATALINK NEXRAD ECHO TOPS	D-2
TABLE D-4: GRAPHICAL METAR SYMBOLS	D-3
TABLE D-5: GRAPHICAL METARS (GMETARS) SCREEN RANGE ...	D-3
FIGURE D-2: NRST AIRPORT INFO	D-3
TABLE D-6: DATALINK GRAPHICAL METAR PRECIPITATION.....	D-4
FIGURE D-3: DATALINK WINDS AND TEMPERATURE ALOFT	D-5
FIGURE D-4: DATALINK SYMBOLOGY OWNERSHIP SYMBOL.....	D-5
FIGURE D-5: WSI DATALINK SCREEN LEGEND.....	D-6
FIGURE D-6: ADS-B DATALINK SCREEN LEGEND.....	D-6
FIGURE D-7: CLOCK/OPTIONS.....	D-6
TABLE D-7: DATALINK NEXRAD RADAR STATUS.....	D-7
FIGURE D-8: DATALINK SCREEN ORIENTATION	D-9
TABLE D-8: DATALINK SCREEN RANGE VALUES	D-10
FIGURE D-9: DATALINK SCREEN RANGE	D-10
FIGURE D-10: BOUNDARY CIRCLE SYMBOL	D-10
TABLE D-9: TOP-LEVEL AUTO POP-UP FUNCTION DESCRIPTIONS IN ORDER OF PREFERENCE.....	D-12
FIGURE D-11: MFD DATALINK FORMAT (FORMAT) MENU	D-14
TABLE D-10: MENU SYNCHRONIZATION	D-15
FIGURE WX-1: WEATHER RADAR IMAGE ON ND	WX-1
TABLE WX-1: WEATHER RADAR INHIBITED CONDITIONS.....	WX-1
FIGURE WX-2: RADAR IMAGE IN HORIZONTAL DEPICTION.....	WX-2
FIGURE WX-3: RADAR IMAGE IN PROFILE DEPICTION	WX-2
FIGURE WX-4: RADAR TRACK LINE	WX-3
FIGURE WX-5: RADAR ACTIVE FLIGHT PLAN.....	WX-4
TABLE WX-2: WEATHER RADAR RETURN DATA	WX-4
FIGURE WX-6: RADAR RETURN DATA	WX-5
FIGURE WX-7: RADAR CLOCK/OPTIONS	WX-6
TABLE WX-3: RDR 2100 APPLICABILITY	WX-6
TABLE WX-4: RDR 2100 MODE ANNUNCIATION	WX-7
FIGURE WX-8: MFD WX RDR FORMAT MENU	WX-9
TABLE WX-5: MENU SYNCHRONIZATION.....	WX-11
FIGURE V-1: ENCODER FUNCTIONS FOR MFD VIDEO PAGE	V-1
FIGURE V-2: VIDEO PAN VIEW	V-2
TABLE V-1: TOP-LEVEL AUTO POP-UP FUNCTION DESCRIPTIONS....	V-2
FIGURE V-3: VIDEO STATUS.....	V-3
FIGURE V-4: MFD VIDEO INPUT FORMAT (FORMAT) MENU	V-4

TABLE V-2: VIDEO INPUT CONTROLS	V-5
TABLE V-3: MENU SYNCHRONIZATION.....	V-5
FIGURE RD-1: PFD IN BASIC MODE	RD-1
FIGURE RD-2: SELECTING BARO	RD-2
FIGURE RD-3: ALTIMETER SETTING.....	RD-2
FIGURE RD-4: TARGET ALTITUDE BUG (VERTICALLY INTEGRATED) RD-2	
FIGURE RD-5: TARGET ALTITUDE BUG (NOT VERTICALLY INTEGRATED)	
.....	RD-3
FIGURE RD-6: VNAV SUB-MODE.....	RD-3
FIGURE RD-7: VNAV SUB-MODE (NOT VERTICALLY INTEGRATED) RD-3	
FIGURE RD-8: ALTITUDE DISPLAY	RD-4
FIGURE RD-9: METRIC ALTITUDE	RD-5
FIGURE RD-10: PFD SYMBOLOGY	RD-5
FIGURE RD-11: MINIMUM ALTITUDE	RD-6
FIGURE RD-12: VERTICAL SPEED INDICATOR.....	RD-6
TABLE RD-1: SCALE GRADUATIONS AND DISPLAY	RD-6
FIGURE RD-13: NORMAL AGL INDICATION.....	RD-7
FIGURE RD-14: DECISION HEIGHT.....	RD-7
FIGURE RD-15: AIRSPEED DISPLAY.....	RD-7
FIGURE RD-16: ADC SENSOR FAILED.....	RD-8
FIGURE RD-17: HEADING IN BOTTOM AREA	RD-8
FIGURE RD-18: HEADING INDICATOR WHEN AHRS IN DG MODE ..	RD-9
FIGURE RD-19: G-FORCE INDICATOR.....	RD-9
FIGURE RD-20: UNUSUAL ATTITUDE MODE	RD-9
FIGURE RD-21: TURN RATE INDICATOR.....	RD-10
FIGURE RD-22: BANK ANGLE.....	RD-10
FIGURE RD-23: MARKER BEACONS	RD-10
FIGURE RD-24: COURSE DEVIATION INDICATOR.....	RD-10
FIGURE RD-25: FLIGHT DIRECTOR	RD-11
FIGURE RD-26: LANDING GEAR INDICATION.....	RD-11
FIGURE RD-27: PFD (ROUND DIALS) FAILURE MODE 0 GPS, ADC, AND	
AHRS NORMAL	RD-12
FIGURE RD-28: PFD (ROUND DIALS) FAILURE MODE 1 GPS/SBAS	
FAILED; ADC AND AHRS NORMAL	RD-12
FIGURE RD-29: PFD (ROUND DIALS) FAILURE MODE 2 (NORMAL MODE)	
ADC FAILED; GPS/SBAS AND AHRS NORMAL	RD-13
FIGURE RD-30: PFD (ROUND DIALS) FAILURE MODE 3 AHRS FAILED;	
GPS/SBAS AND ADC NORMAL	RD-13
FIGURE RD-31: PFD (ROUND DIALS) FAILURE MODE 4 GPS/SBAS AND	
ADC FAILED; AHRS NORMAL	RD-14
FIGURE RD-32: PFD (ROUND DIALS) FAILURE MODE 5 GPS/SBAS AND	
AHRS FAILED; ADC NORMAL	RD-14
FIGURE RD-33: PFD (ROUND DIALS) FAILURE MODE 6 ADC AND AHRS	
FAILED; GPS/SBAS NORMAL	RD-15

FIGURE RD-34: PFD (ROUND DIALS) FAILURE MODE 7 GPS/SBAS, ADC, AND AHRS FAILED.....	RD-15
TABLE RD-2: PFD DECLUTTER OPTIONS AND FEATURES.....	RD-16

Section 1 Introduction

1.1. Introduction

Aviation has become more complex as cockpit resources have followed the trend toward “automation centered” systems. These sophisticated systems minimize pilot involvement and automate control of the aircraft and its systems, thereby relegating the pilot to the role of manager and emergency backup.

The Genesys Aerosystems Electronic Flight Instrument System (EFIS) was conceived and designed as a “pilot-centered” system. While still highly automated, it presents the pilot with information necessary to make decisions and take appropriate actions. An example is the Highway-In-The-Sky (HITS), which allows for highly automated approaches, but its predictive nature provides the pilot awareness of upcoming maneuvers. Instead of overloading the pilot with information and options, the Genesys Aerosystems EFIS presents only necessary information to reduce pilot workload, decrease task complexity, and minimize confusion. The result is safer flying with less stress and fatigue.

The Genesys Aerosystems EFIS goal is IFR-VFR equivalence with HUD symbology overlaying real-time 3-D virtual view of the outside world. This “synthetic vision” provides the pilot in IMC with simple visual clues for navigation and aircraft control as those used in VFR conditions. The “virtual VFR” eliminates the need to scan multiple instruments for aircraft control or interpret complicated enroute and approach procedures. As experience is gained with this integrated system, the pilot will fly with more precision, awareness, and confidence.

1.2. EFIS/FMS Description

The Integrated Display Unit (IDU) has eight dedicated pushbuttons with imprinted legends along the vertical sides. For reference, these buttons are numbered L1 through L4 starting at the top left and R1 through R4 from the top right. There are two encoders along the bottom with the left encoder only controlling the backlighting intensity.

References throughout this guide refer to the right encoder as “#1 Encoder” (1) to push and or scroll for desired outcomes. On the bezel between the two encoders, a slip indicator or blank housing

acts as the USB memory door. When it is lifted, Ground Maintenance mode is initiated to gain access to a USB port. The maintenance program activates once a USB memory device is inserted.



Figure 1-1: IDU-450 Input Identification

A sensor on the face of the IDU bezel measures ambient light levels. Use the left encoder to control the brightness of the panel lighting or display lighting. Panel lighting refers to the illumination of legends, encoders, and buttons (push and scroll clockwise to increase or counter clockwise to decrease). Display lighting refers to the illumination of the LCD display (without pressing, scroll as described with panel lighting). Lighting may be controlled locally or remotely with a default state being with the local control.

NOTE:

If entering the Ground Maintenance mode with bright light shining or directly on the display, shield the light sensor if necessary.

1.3. About This Guide

Operation of the Genesys Aerosystems EFIS is described in detail and divided into sections as follows:

TABLE OF CONTENTS: Locate areas by topic

INTRODUCTION (Section 1): Basic explanation of the pilot guide.

SYSTEM OVERVIEW (Section 2): Description of system and hardware; Warnings, Cautions, and Advisories annunciations with identified conditions; coloring conventions; system terminology, abbreviations, and acronyms; database updating procedures; and IDU behavior during initialization.

DISPLAY SYMBOLOGY (Section 3): Identification of each screen element of the PFD and MFD, and explanation of what symbology to anticipate.

REVERSIONARY MODES (Section 4): Views of displays with various sensor failed conditions and resulting symbology, as well as, examples of various configurations and display formats used with specific tables showing affected functions. Explanation of what to expect when a particular sensor fails and what changes on the display immediately or after a specified amount of time.

MENU FUNCTIONS AND STEP-BY-STEP PROCEDURES (Section 5): Menu structure of each feature and step-by-step procedures for operation of each task. Basic description of all encoder and button functions with menu tile definitions.

QUICK START TUTORIAL (Section 6): Basics necessary for flying a flight with this system. Includes simple steps to manage displays for existing flight conditions to quickly gain familiarity with where to locate controls to manipulate the system for each operation.

IFR PROCEDURES (Section 7): Detailed information and instruction about selecting and flying instrument procedures found in the navigation database with examples of the most popular published procedures with views of referenced published procedures. Includes descriptions of selection of departure, published instrument approach, standard terminal arrival procedures, as well as, how the active flight plan quickly reflects changes to ATC clearances.

TERRAIN AWARENESS WARNING SYSTEM (Section 8): Description of the TAWS (all classes) functionality for this fixed wing aircraft with all configurations. Defines the various parameters which automatically apply to each mode of flight.

APPENDIX (Section 9): Contains support material and other useful information about system operation, guidance from Jeppesen, and supplemental information such as flight planning; Magnetic vs. True North modes; Airspeed/Altitude Miscompare thresholds; EFIS Training Tool; downloading routes and user waypoints; and the Service Difficulty Report form. Individual sections on equipment and features not installed in every aircraft and may be removed at the discretion of the end-user.

INDEX: Alphabetical listing of terms or keywords with corresponding page numbers.

GLOSSARY: Alphabetical listing of definitions for terms.

1.3.1. Audio and Video Interactive Capabilities

Throughout this guide, references to audio annunciations and video demonstrations are indicated with the following icons. When viewing this guide on a computer or mobile device, click on the icons to hear the respective audio clip or watch a demonstration video via Genesys Aerosystems' YouTube™ channel. Check the YouTube channel for additional videos as they become available.



Audio



Video

Figure 1-2: Audio and Video Icons

Genesys Aerosystems is committed to producing the highest quality product possible and we welcome comments and suggestions concerning this publication. Please e-mail comments and suggestions to:

genesys-support@genesys-aerosystems.com

If you encounter problems with the operation of your Genesys Aerosystems EFIS, please complete and return the Service Difficulty Report in Section 9 Appendix directly to:

Genesys Aerosystems
One S-Tec Way
Mineral Wells Municipal Airport
Mineral Wells, Texas 76067
or Fax: (940) 325-3904

Section 2 System Overview

2.1. Abbreviations and Acronyms

µm Hg	Micrometer of Mercury
0R	No Radius
3-D	Three-Dimensional
AC	Advisory Circular
ACTV	Active
AD	Airworthiness Directive
A-D	Analog to Digital (converter)
ADAHRS	Air Data Attitude Heading Reference System
ADC	Air Data Computer
ADF	Automatic Direction Finder
ADS-B	Automatic Dependent Surveillance-Broadcast
AFCS	Automatic Flight Control System
AFM	Aircraft Flight Manual
AGL	Above Ground Level
AHRS	Attitude Heading Reference System
AIRAC	Aeronautical Information Regulation and Control
AIRMET	Airmen's Meteorological Information
ALT	Pressure Altitude
ALT SEL	Altitude Selection
AMLCD	Active Matrix Liquid Crystal Display
ANP	Actual Navigation Performance
ANSI	American National Standards Institute
ANT	Antenna
APP	Waypoint is part of an Instrument Approach Procedure
APPR	Approach
APT	Airport
APV	Approach with Vertical Guidance
AR	Audio Radio
ARINC	Aeronautical Radio, Inc.

ARP	SAE Aerospace Recommended Practice
AS	SAE Aerospace Standard
ASEL	Aircraft Selected Altitude
ATA	AT Attachment (hard disk storage interface)
ATC	Air Traffic Control
ATT	Attitude
BARO	Barometric setting
BC	Backcourse navigation
BFO	Beat Frequency Oscillator
BRT	Brightness
BTM	Bottom
C	Celsius
CA	Course to Altitude (ARINC-424 Leg)
CALC	as in RAIM (R2)
CAS	Crew Alerting System
CD	Course to DME Distance (ARINC-424 Leg)
CCW	Counter Clockwise
CDA	Continuous Descent Approach
CDI	Course Deviation Indicator
CDR	Critical Design Review
CDTI	Cockpit Display of Traffic Information
CF	Course to Fix (ARINC-424 Leg)
CI	Course to Intercept (ARINC-424 Leg)
CLR	Clear
CM	Configuration Management
CNS	Communications/Navigation/Surveillance
CNX	Cancel
COM	Communication
CONT	Continue
CPLT	Co-Pilot
CPM	Company Project Manager; Computer Processor Module
CPU	Central Processing Unit

CR	Change Request; Course to Radial Termination (ARINC-424 Leg)
CRC	Cyclic Redundancy Check
CRS	Course
CSA	Conflict Situation Awareness (ADS-B)
CTRST	Contrast
CW	Clockwise
DA	Decision Altitude
D-A	Digital to Analog (converter)
DAICD	Digital Aeronautical Information CD
DAR	Designated Airworthiness Representative
dBZ	Decibel relative to radar reflectivity (Z)
DCLTR	Declutter
DCN	Document Change Notice
DCND	Descend
DEC HT	Decision Height Bug
DEL	Delete
DEM	Digital Elevation Model
DER	Designated Engineer Representative
DESIG	Designate
DF	Direct to Fix (ARINC-424 Leg)
DFLT	Default
DG	Directional Gyro
DH	Decision Height
DL	Data Link
DME	Distance Measuring Equipment
DMIR	Designated Manufacturing Inspection Representative
DO	RTCA Document
DOD	Department of Defense
DOF	Digital Obstruction File
DP	Departure Procedure
DR	Dead Reckoning or; Defect Report
DSP	Digital Signal Processing

EFIS	Electronic Flight Instrument System
EGM	Earth Gravity Model
EGNOS	European Geostationary Navigation Overlay Service
EGPWS	Enhanced Ground Proximity Warning System
EIA	Electronics Industry Association
ESSNTL	Essential
ETA	Estimated Time of Arrival
ETE	Estimated Time Enroute
ETT	EFIS Training Tool
EXCD	Exceedance
EXPND	Expand (also EXP)
F	Fahrenheit
FA	Course from a Fix to Altitude (ARINC-424 Leg)
FAA	Federal Aviation Administration
FAF	Final Approach Fix
FAR	Federal Aviation Regulation
FAWP	Final Approach Waypoint (same as FAF)
FC	Course Fix to along Track Distance (ARINC-424 Leg)
FD	Course from a Fix to DME Distance (ARINC-424 Leg); Flight Director
FDE	Fault Detection and Exclusion
FG	Fixed Gear
FG + F	Fixed Gear with Defined Landing Flaps Position
FHA	Functional Hazard Analysis
FIFO	"First in, First out"
FIS	Flight Information Service
FIS-B	Flight Information Service-Broadcast
FL	Flight Level
FLTA	Forward Looking Terrain Awareness
FM	Course from Fix to Manual termination (ARINC-424 Leg)
FMEA	Fault Mode and Effects Analysis
FMS	Flight Management System

FOV	Field of View
FPE	Floating Point Emulation
FPL	Flight Plan
FPM	Feet per Minute; Flight Path Marker
FSD	Full Scale Deflection
FT	Feet
FTE	Flight Technical Error
FTP	Fictitious Threshold Point
FNCT	Function
GAGAN	India's GPS and GEO-Augmented Navigation System
GARP	GNSS Azimuth Reference Point
GBAS	Australia's Ground Based Augmentation System
GLONASS	Russian Global Navigation Satellite System
GLS	GNSS Landing System
GMETAR	Graphical METAR (also GMTR)
GMF	Ground Maintenance Function
GN	Gain
GND	Ground (potential)
GNSS	Global Navigation Satellite System
GPH	Gallons Per Hour
GPI	Glidepath Intercept
GPIP	Glide Path Intercept Point
GPS	Global Positioning System
GPWS	Ground Proximity Warning System
GRD	Grid; Ground
GS	Glideslope
H	Hold
HA	Terminates at an altitude (ARINC-424 Leg)
HF	Holding, Pattern to Fix (ARINC-424 Leg)
HM	Altitude or Manual Termination (ARINC-424 Leg)
HAL	Horizontal Alert Limit
HAT	Height Above Threshold
HDG	Heading

HFOM	Horizontal Figure of Merit
hh:mm:ss	Hours: Minutes: Seconds
HITS	Highway in the Sky
HORIZ	Horizontal
hPa	Hectopascal
HPL	Horizontal Protection Level
HSI	Horizontal Situation Indicator
HUD	Head Up Display
HUL	Horizontal Uncertainty Limit
IAP	Instrument Approach Procedure; Initial Approach Point
IAS	Indicated Airspeed
IAWP	Initial Approach Waypoint (same as IAP)
IC	Integrated Circuit
ICAO	International Civil Aviation Organization
ICD	Interface Control Document
ID	Identity or Identification
IDENT	Identification (Transponder Ident)
IDU	Integrated Display Unit
IF	Initial Fix leg
IFR	Instrument Flight Rules
ILS	Instrument Landing System
IM	Inner Marker
INFO	Information
INHBT	Inhibit
inHg	Inches of Mercury
INIT	Initialize
IO	Input/Output
IP	Initial Point
IPV	Instrument Procedure with Vertical Guidance
ISA	International Standard Atmosphere
ISR	Interrupt Service Routine
IVSI	Instantaneous Vertical Speed Indicator
IWP	Intermediate Approach Waypoint

JAD	Jeppesen Aviation Database
JTAG	Joint Test Action Group (IEEE 1149.1 Standard)
K	Kilo=1000
KB	Kilobyte
kHz	Kilohertz
IAS	Knots Indicated Airspeed
KT	Knot - Nautical Mile per Hour
KTAS	Knots True Airspeed
LAT	Latitude
LCD	Liquid Crystal Display
LCL	Local
LDA	Localizer-type Directional Aid
LED	Light Emitting Diode
LGND	Legend
LIFR	Low IFR conditions (Ceiling < 100' or visibility < 1 mile)
LNAV	Lateral Navigation
LOC	Localizer
LOI	Loss of Integrity
LON	Loss of Navigation; Longitude
LP	Localizer Performance
LPV	Localizer Performance with Vertical Guidance
LRU	Line Replaceable Unit
LSB	Least Significant Bit or Byte
LTP	Landing Threshold Point
LVL	Level
MA	Waypoint is part of the missed approach segment of an Instrument Approach Procedure
MAGVAR	Magnetic Declination (Variation)
MAHP	Missed Approach Holding Point
MAHWP	Missed Approach Holding Waypoint (same as MAHP)
MAN	Manual
MAP	Missed Approach Point; Missed Approach Procedure
MASPS	Minimum Aviation System Performance Standard

MAWP	Missed Approach Waypoint (also MAWPT)
MB	Megabyte
mbar	Millibars
MDA	Minimum Descent Altitude
MEMS	Micro Electro Mechanical System
MESO	Mesocyclonic
METAR	Routine hourly weather report
MFD	Multifunction Display (IDU with software for showing multiple display screens)
MIN	Minimum
MM	Middle Marker
MOA	Military Operations Area
MOPS	Minimum Operational Performance Standard
MOT	Mark On Target
MSAS	Japan's MTSAT-based Satellite Augmentation System
MSB	Most Significant Bit or Byte
MSL	Mean Sea Level
MSU	Magnetic Sensor Unit
MTBF	Mean Time Between Failures
MVFR	Marginal Visual Flight Rules
NACO	National Aeronautical Charting Office
NAS	U.S. National Airspace System
NASA	National Aeronautics and Space Administration
NAV	Navigation
NAVAID	Device or system providing navigational assistance
ND	Navigation Display
NDB	Nondirectional Beacon
NED	National Elevation Dataset
NEXRAD	(Next-Generation Radar) network of weather radars operated by the National Weather Service (NWS) (also NXRDR)
NI	Navigational Information
NIMA	National Imagery and Mapping Agency

NM	Nautical Mile
NPA	Non-Precision Approach
NRST	Nearest
nT	Nanoteslas (ref. World magnetic Model)
NTSC	National Television System Committee standard analog video system (30 frames per second) used in North America and most of South America
NWS	National Weather Service
NXT	Next
OASIS	Open Architecture Systems Integration Symbology
OAT	Outside Air Temperature
OBS	Omnibearing Selector
ODP	Obstacle Departure Procedure
OF	Over-fly
OM	Outer Marker
OT	Other Traffic (Traffic Function)
PA	Proximate Advisory (Traffic Function)
PAL	Predominant analog video system (25 frames per second) used outside North America and South America.
PDA	Premature Descent Alert
PDR	Preliminary Design Review
PDFD	Primary Flight Display (also refers to the primary IDU with software that only shows primary instrumentation)
PFDE	Predictive Fault Detection and Exclusion
PFI	Primary Flight Information
PI	Procedure Turn (ARINC-424 Leg)
PIC	Peripheral Interface Controller
PLI	Pitch Limit Indicator
PLT	Pilot
PM	Personality Module
PN	Part Number; Pan
PRAIM	Predictive Receiver Autonomous Integrity Monitoring
PROC	Procedure

PRV	Previous
PSAC	Plan for Software Aspects of Certification
PSCP	Project Specific Certification Plan
PSP	Partnership for Safety Plan
PTK	Parallel offset (Parallel Track)
PTN	Problem Tracking Number
PTRS	Pointers
QA	Quality Assurance
QFE	Altimeter setting provides height above reference point
QM	Quality Management
QNE	Altimeter setting provides pressure altitude readout
QNH	Altimeter setting provides MSL altitude at a reporting point
RA	Resolution Advisory (Traffic Function)
RADALT	Radar Altimeter (also RALT)
RAD-DST	Radial and Distance
RAIM	Receiver Autonomous Integrity Monitoring
RAM	Random Access Memory
RBP	Remote Bug Panel
RCP	Radar Control Panel
RDR	Radar
REC	ADF receiver in BFO or test mode
RF	Precision Arc to Fix (ARINC-424 Leg)
RFP	Radio Frequency Panel
RG	Retractable Gear
RG + F	Retractable Gear with Defined Landing Flaps Position
RHT	Radar Height
RMI	Radio Magnetic Indicator
RNAV	Area Navigation
RNP	Required Navigation Performance
RS	EIA Recommended Standard
RTC	Real Time Computing
RTCA	Radio Telephone Commission for Aeronautics

RTD	Resistive Thermal Detector
RTL	Run Time Library
RTN	Return
RW	Runway
Rx	Receive
SA	Selective Availability
SAE	Society of Automotive Engineers
SAS	Software Accomplishment Summary
SAT	Saturation
SBAS	Satellite Based Augmentation System
SCC	System Configuration Card (personality module)
SCI	Software Configuration Index
SCMP	Software Configuration Management Plan
SCR	Software Conformity Review
SCS	Software Coding Standards
SDCM	System of Differential Correction and Monitoring
SDD	Software Design Document
SDP	Software Development Plan
SDS	Software Design Standards
SECAM	Analog color television system used in France
SECI	Software Environment Configuration Index
SID	Standard Instrument Departure
SIGMET	Significant Meteorological Advisory
SLCT	Select
SMA	Sub-Miniature version A connector
SN	Serial Number
SNI	Serial Number Information
SOI	Stage of Involvement (FAA software audit)
SPR	Software Problem Report
SQA	Software Quality Assurance
SQAP	Software Quality Assurance Plan
SQAR	Software Quality Assurance Representative
SRD	Software Requirements Document

SRS	Software Requirements Standards
SRTM	Shuttle Radar Topographical Mission
SSA	System Safety Assessment
SSM	Sign Status Matrix
STAB	Stability
STAR	Standard Terminal Arrival Routes
STBY	Stand-by
STC	Supplemental Type Certificate
STP	Software Test Protocol
STRKS	Strikes (Lightning detection)
STS	Software Test Specification
SUA	Special Use Airspace
SV	Service Vehicle
SVCP	Software Verification Cases and Procedures
SVP	Software Verification Plan
SVR	Software Verification Results
SVS	Synthetic Vision System
SYMB	Symbol
SYNC	Synchronize (also SYNCH)
SYRD	System Requirements Document
TA	Traffic Advisory (Traffic Function)
TACAN	Ultra-High Frequency Tactical Air Navigational Aid
TAFs	Terminal Aerodrome Forecasts
TAS	Traffic Advisory System; True Airspeed
TAWS	Terrain Awareness and Warning System
TCA	Terminal Control Areas
TCAD	Traffic Collision Alert Device
TCAS	Traffic Collision Alert System
TCH	Threshold Crossing Height
TD	Traffic Display
T/D	Top of Descent
TERPS	Terminal Instrument Procedures

TF	Track to a Fix; Track from Fix to New Fix (ARINC-424 Leg)
TFR	Temporary Flight Restriction
TGT	Target
THLD	Threshold
TIS	Traffic Information Service
TIS-B	Traffic information Service-Broadcast
TLT	Tilt
TMS	Texas Instruments family of DSP processors
TQP	Tool Qualification Plan
TRANS	Transition
TRK	Track
TRNDO	Tornadic
TSO	Technical Standard Order
TSRA	Terminal Radar Service Area
TTA	Time to Alert
TURB	Turbulence
Tx	Transmit
UART	Universal Asynchronous Receiver-Transmitter
UIM	User Interface Module
USB	Universal Serial Bus, data storage device
USGS	United States Geological Survey
USR	User Waypoint
UTC	Universal Time Coordinated
VA	Heading to Altitude (ARINC-424 Leg)
V _A	Speed above which it is unwise to make full application of any single flight control
VAL	Vertical Alert Limit
V _{APP}	Target approach airspeed
VD	Heading to DME Distance (ARINC-424 Leg)
VDI	Vertical Deviation Indicator
VERT	Vertical
V _{FE}	Maximum flap extended speed

VFOM	Vertical Figure of Merit
VFR	Visual Flight Rules
VHF	Very High Frequency
VI	Heading to Intercept (ARINC-424 Leg)
VLOC	VOR/Localizer
VLON	Vertical Loss of Navigation
VM	Heading to Manual Termination (ARINC-424 Leg)
V _{MO}	Maximum operating limit speed
VNAV	Vertical Navigation (also VNV)
V _{NE}	Never exceed speed
V _{NO}	Maximum structural cruising speed or maximum speed for normal operations
VOR	VHF Omnidirectional Radio
VORTAC	Collocated VOR and TACAN
VOX	Voice
VPL	Vertical Protection Level
V _{PROC}	Procedure Speed
V _R	Rotation speed
VR	Heading to Radial Termination (ARINC-424 Leg)
V _{REF}	Landing reference speed or threshold crossing speed
VSI	Vertical Speed Indicator
VTF	Vectors to Final
V _{TOS}	Minimum speed for a positive rate of climb with one engine inoperative
VUL	Vertical Uncertainty Limit
WAAS	Wide Area Augmentation System
WGS84	World Geodetic System 1984
WPT	Waypoint
WX	Weather
XFILL	Cross-fill

2.2. System Overview




Figure 2-1: IDU-450 Primary Flight Display (PFD)

The IDU-450 EFIS is a complete flight and navigation instrumentation system intuitively providing information via computer-generated displays. The displays include 3-D, enhanced situational awareness Primary Flight Displays (PFD) and Multi-Function Displays (MFD), which may be configured to show a moving map, HSI, terrain, traffic, datalink weather, radar, or video.



Figure 2-2: IDU-450 Multifunction Display (MFD)

At any given time, each system only has one IDU transmit enabled to send RS-232 and RS-422 system transmissions. By default, the PFD is “Transmit Enabled” and, if it subsequently fails, the respective MFD becomes transmit enabled.

2.2.1. Functional Integration and Display Redundancy




Figure 2-3: System Diagram

IDUs incorporate a high-brightness AMLCD screen; bezel pushbuttons; encoders and enter switches; central processing unit; numerous RS-232, RS-422, and ARINC 429 receive and transmit ports; and discrete IO ports. Hardware and software are identical for all IDUs, and functionality is determined by configuration settings setup during installation. The IDUs are independently connected to all external sensors and independently perform all integrated functions (e.g., TAWS, FMS, ADS-B In, Weather, Traffic, Audio/Radio Control, etc.). This provides an exceptional level of redundancy as compared to traditional display architectures where most of these functions were performed by external LRUs. Figure 2-3 depicts a typical architecture used by IDUs.

The IDUs depend upon intra-system (between IDUs on a side – depicted as “Synch” in Figure 2-3) and inter-system (between IDUs

on opposite sides – depicted as “Crosslink” in Figure 2-3) to achieve synchronization of the integrated functions. The IDUs also depend upon intra-system communications to determine which IDU on a side takes over “Talker” responsibilities. The “Talker” IDU is the IDU providing data to external sensors and generating aural alerts.

2.2.2. IDU Initialization




Figure 2-4: Initialization Screen

The hardware, including file system, IO, and graphics, are initialized. Immediately after graphics initialization, a logo screen with “INITIALIZING” is displayed with the Genesys Aerosystems logo, software version number, and part number. The software version number delineates: (1) major revision number (i.e., “8.0”) and (2) minor revision letter (i.e., “E”).

Table 2-1: IDU Initialization Software Version and Part Numbers

Version Number	Part Number
Rev 8.0E	25-EFIS80E-SW-0003

Aircraft configurations are initially read from flash drive storage to provide IDUs with a default configuration setup in the event of personality module failure.

The personality module contains the CPU number (Table 2-2) and system designation (pilot or co-pilot). The CPU number is identified below the part number on the initialization screen (Figure 2-4).

Table 2-2: CPU Number Designation

CPU Number/IDU#	Definition
"0"	Single-screen installation. If no ADC nor AHRS is detected, IDU is MFD-only.
"1"	IDU only shows PFD.
"2"	First MFD in multi-screen installation.
"3"	Second MFD in a multi-screen installation.
"4"	Third MFD in a multi-screen installation.

Pilot IDU #0 or IDU #1 reads aircraft configuration from its personality module. In a multi-screen installation, IDU #1 transmits this configuration to the other IDUs. The other IDUs save the transmitted configurations to flash drive storage.

Aircraft parameters (latitude, longitude, altitude), as they existed prior to the last system shutdown, are read for a good system initialization, even if system sensors are failed or not yet initialized. For future updates (i.e., updating software version 8.0E to 8.0X), all aircraft settings re-initialize to default values. Otherwise, aircraft settings, as they existed prior to the last system shutdown, are used to initialize the system except for the following default values:

- 1) Active flight plan structure and associated values are cleared.
- 2) ADAHRS are set to slaved mode, and the slewing value is initialized to zero.
- 3) Timers are turned off.
- 4) Minimum altitude setting is turned off.
- 5) FMS OBS setting is set to automatic.
- 6) VOR/LOC 1 OBS setting is set to 360°.
- 7) VOR/LOC 2 OBS setting is set to 360°.
- 8) Parallel offset is set to 0 NM.
- 9) Airspeed bug is turned off.
- 10) Target altitude bug is turned off.
- 11) Vertical speed bug is turned off.
- 12) HSI navigation source is set to FMS.

- 13) Datalink and map panning modes are set to off.
- 14) PFD zoom mode is set to off.
- 15) Manual RNP is set to off.
- 16) PFD skyway is set to on.
- 17) RDR-2000/2100 scale is initialized to 80NM.
- 18) Crosslink is initialized to on.

The magnetic variation coefficients database, if configured, is read from the flash drive storage and CRC-32 checked.

The IDU decides whether it is booting on the ground or in flight based on the air/ground mode parameter value from the last system shutdown.

If booting on the ground, the following actions happen:

- 1) A logo screen with “**TESTING**” is displayed for a number of seconds while the various hardware subsystems are initialized.
- 2) CRC-32 values for application executable, limitations files, NavData files, obstruction files, and terrain header files are checked within 1.5 to 3 minutes.

During this action, under “**TESTING**,” the message “**PRESS ANY BUTTON TO QUICK START**” is displayed. Press any button to stop the ground booting and execute the flight booting.

- 3) If the CRC-32 check fails, the program exits with an error message and creates a bit result file indicating failure. The system reboots, and the IDU is inoperable until the anomaly is resolved.
- 4) If the CRC-32 check passes, the program continues to initialize and creates a bit result file indicating passage.
- 5) If “Baro Auto-Setting on Startup Flag” is enabled, the application auto-sets the altimeter based upon the terrain elevation at the startup point.
- 6) A logo screen displaying database versions and validity dates displays the message “**PRESS ANY BUTTON TO CONTINUE.**”
 - a) Software CRC-32;

- b) Aircraft Type;
 - c) Database Versions and Validity Dates
- 7) If all critical sensors (GPS, ADC, and AHRS) are in normal condition, the display screens are shown immediately. IDU #1 initializes to the PFD screen.
- 8) If any critical sensor is not in normal condition, a logo screen with a two-minute countdown timer is shown. The display screen is shown at the earliest of:
- a) When two minutes have elapsed;
 - b) When the pilot presses any button to escape the startup countdown;
 - c) When all critical sensors are in normal condition, the #1 IDU initializes to the PFD screen;
 - d) Other IDUs: IDU #2 initializes to the MFD screen. All other IDUs initialize to the MFD screen;
 - e) On IDU #0 or IDU #2 with fuel totalizer functions enabled, the fuel set menu activates to remind the pilot to set the fuel totalizer quantity.

If booting in the air, the following actions happen:

- 1) A logo screen with **“QUICK START”** is displayed.
- 2) Bit result file created during the last ground boot is checked. If it indicates a failure, the program exits with an error message. If it indicates passage, the program continues.
- 3) The display screens initialize immediately.
- 4) IDU #1 display screen initialize as PFD.

NOTE:

After IDU initialization, if any menu is active, press **EXIT (R1)** on each display and wait at least 20 seconds to allow PFDs to sync with MFDs and pilot and copilot sides to sync (as applicable). If any IDU menu is active, intra-system and inter-system synchronization messages are paused.

2.3. General Arrangement



Figure 2-5: Primary IDU-450 PFD

The IDU-450 is 6.375" W x 5.65" H x 4.75" D and weighs less than 7.5 lbs. It has the capacity to accommodate integrated peripherals mechanically attached to the CPU but have electrical isolation and redundancy. These modules may include:

- 1) Integrated ADAHRS Sensor Module
- 2) Integrated GPS/SBAS Sensor Module
- 3) Serial Protocol Converters
- 4) Video Format Converters

Data storage consists of two compact flash cards sufficiently sized to hold world terrain, navigational, and obstruction databases.

Because the receive ports are connected to the digital sensor modules in parallel, each IDU-450 is independent from all others. In an IFR installation, the software of the primary IDU-450 is configured with only the primary screen (PFD) Figure 2-5.

2.3.1. Menu Philosophy

The menu system is complex due to the integrated functionality of the IDUs. To help the pilot with the complexity, the following rules are in the design of the menu system:

EXIT (R1): When menu system is beyond the top-level **EXIT (R1)** escapes to the top-level with acceptance of changed menu items.

BACK (L1): When soft menu level is deeper than the first-level **BACK (L1)** regresses through the menu system by one level.

Indication of further menu levels: Soft menu function tiles indicate further menu levels with a two-dot trailer, **BUGS..**

2.3.2. IDU Intra-System Communications

Communication between IDUs installed on the same system is referred to as intra-system communications. In a dual system (pilot and co-pilot) configuration, the crosslink system to system communications is referred to as inter-system communications. IDUs on a system side (pilot side and co-pilot side individually) monitor each other using intra-system communications and perform the following checks:

- 1) Intra-system communications freshness
- 2) Screen counter incrementing (i.e., screen not frozen)
- 3) Airspeed agreement
- 4) Altitude agreement
- 5) Attitude agreement
- 6) Barometric setting agreement
- 7) GPS position, track, and groundspeed agreement
- 8) Heading agreement
- 9) Localizer and glideslope deviation agreement
- 10) Radar altitude agreement

2.4. Color Conventions

The EFIS uses a consistent set of colors to display information. Any color representation may not be identical as it appears on the IDU.



WHITE for items set by pilot and held by the EFIS or items where device feedback is not expected; Marker Beacon Receiver High/Low sensitivity modes; scales; associated labels and figures; pilot action; or data entry. Examples:

- Scale markings (airspeed, altitude, heading, VSI, pitch, map ranges, etc.)
- Pilot-selected values (airspeed, heading, altitude)

- Secondary flight data (TAS, wind, OAT, timers, etc.)

When used for an analog bar indication, light gray (low-intensity white) is used instead, as a large white area on the screen may be overwhelming.



CYAN for IFR navigation dataset items (airports with instrument approach procedures, VORs, and intersections) and VOR #1.



MAGENTA (light magenta for visibility) indicates calculated or derived data and certain navigation database items. Examples:

- Active waypoint related symbols
- Course data (desired track, CDI)
- VFR airports, NDBs
- VNAV altitudes



GRAY as background for airspeed and altitude readout and for conformal runway depiction (light gray for usable portion of active runway, dark gray for other runway surfaces).



GREEN (light green for visibility) for VOR #2 and to indicate normal or valid operation (airspeed, altitude tape coloring, status indication, etc.). Examples:

- Aircraft ground track
- Skyway symbology
- Airspeeds in green arc







DARK GREEN for terrain indication on moving map. The slope between adjacent terrain determines the shade used.



AMBER (YELLOW) identifies conditions requiring immediate pilot awareness and possible subsequent action.



OLIVE in various shades shows terrain within 2000' and below aircraft altitude.

- 
BROWN in a variety of shades indicates earth/terrain portion of PFD or when terrain is at or above the aircraft altitude on MFD.
- 
BLUE in a variety of shades indicates sky portion of PFD, bodies of water on moving map, and advisory text on black background.
- 
RED indicates aircraft limitations or conditions, which require immediate pilot action, or a device failure (red “X”).
- 
BLACK for field of view angle lines on moving map, figures on a gray background, and outlining borders and certain figures/elements on backgrounds with minimal contrast, e.g., airspeed, altitude, and menu tiles on the PFD/MFD.

2.5. Warning/Caution/Advisory System

The integrated warning system monitors a wide variety of parameters and provides annunciations for conditions demanding pilot awareness. There are three categories of annunciations: **WARNINGS**, **CAUTIONS**, and **ADVISORIES**. If applicable, the programmed time delay is referenced in seconds prior to the annunciation appearing. Table 2-3 lists the annunciations.

WARNING Red flag and an aural annunciation repeat until the condition goes away or is acknowledged by the pilot.

CAUTION Amber (yellow) flag and single aural annunciation.

ADVISORY Black flag and blue letters with single aural annunciation

Table 2-3: Warnings, Cautions, and Advisories


Display Flag “--” indicates no flag	Aural Annunciation	Condition
GLIDESLOPE	 “Glideslope, Glideslope”	Within GPWS Mode 5 warning envelope. Half second time delay.

Table 2-3: Warnings, Cautions, and Advisories







Display Flag "--" indicates no flag	Aural Annunciation	Condition
LOW FUEL	 "Fuel Low, Fuel Low"	<p>One of the following conditions is true:</p> <ol style="list-style-type: none"> 1) A low fuel warning discrete input is active 2) A sensed fuel tank quantity is below its low fuel warning threshold 3) Total aircraft fuel is below the pilot-set emergency fuel threshold. <p>1-minute time delay.</p>
OBSTRUCTION	 "Warning Obstruction, Warning Obstruction"	Obstruction within TAWS FLTA warning envelope. Half second time delay.
OVERSPEED	 "Overspeed, Overspeed"	Indicated airspeed exceeds redline ($V_{NE}/V_{MO}/M_{MO}$ as appropriate) plus instrument error. No time delay.
PULL UP	 "Terrain, Terrain, Pull Up, Pull Up"	Terrain cell within TAWS FLTA warning envelope. Half second time delay.
	 "Pull Up, Pull Up"	Within GPWS Mode 1 warning envelope. Half second time delay.
	 "Terrain, Terrain, Pull Up, Pull Up"	Within GPWS Mode 2 warning envelope. Half second time delay.

Table 2-3: Warnings, Cautions, and Advisories

Display Flag "--" indicates no flag	Aural Annunciation	Condition
STALL	🔊 "Stall, Stall"	Activated above 100' AGL if indicated airspeed is below the higher of V_{s1} or V_{s1} corrected for G-load + 5 KIAS. Deactivated if stall warning flag set to 0. No time delay.
TRAFFIC	🔊 "Traffic, Traffic"	Resolution advisory. Not given if own aircraft below 400' AGL nor target is below 200' AGL (ground target). Audio not generated with TCAS-II system. No time delay.
CAUTIONS		
ADC1 FAIL	🔊 Alert Tone	Only in dual-ADC installation. Indicates no valid indicated airspeed, pressure altitude, or VSI received from ADC #1 for more than 1 second. No time delay.
ADC2 FAIL	🔊 Alert Tone	Only in dual-ADC installation. Indicates no valid indicated airspeed, pressure altitude, or VSI received from ADC #2 for more than 1 second. No time delay.
ADS-B FAIL	🔊 Alert Tone	Mode-S transponder indicates bad ADS-B out status. 2-second time delay.

Table 2-3: Warnings, Cautions, and Advisories





Display Flag "--" indicates no flag	Aural Annunciation	Condition
AHRS1 FAIL	 Alert Tone	Only in dual-AHRS installation. Indicates no valid bank, pitch, or heading received from AHRS #1 for more than 1 second. No delay. Inhibited during and for 10 seconds after unusual attitude mode.
AHRS2 FAIL	 Alert Tone	Only in dual-AHRS installation. Indicates no valid bank, pitch, or heading received from AHRS #2 for more than 1 second. No delay. Inhibited during and for 10 seconds after unusual attitude mode.
ALT MISCOMP	 Alert Tone	Only in dual-ADC installation with neither failed. Indicates pressure altitude difference between ADCs is beyond limits. 10-second time delay. Inhibit for 5 minutes after startup.
ATT MISCOMP	 Alert Tone	Only in dual-AHRS installation with neither failed. Indicates pitch or roll difference between AHRS is beyond limits (6°). 10-second time delay. Inhibit for 5 minutes after startup.

Table 2-3: Warnings, Cautions, and Advisories

Display Flag "--" indicates no flag	Aural Annunciation	Condition
<p>AUX SENSOR</p>	<p>“Auxiliary Sensor Failure, Auxiliary Sensor Failure”</p>	<p>No valid message or bad status received from installed optional sensors. Sensor status displayed in FAULTS menu.</p> <p>5-second time delay. Inhibited during and for 10 seconds after unusual attitude mode. Applies to the following optional sensors:</p> <ol style="list-style-type: none"> 1) RS-232 TAS System 2) ADS-B System 3) WSI Datalink System 4) WX-500 Lightning System 5) Analog Interface System 6) Weather Radar 7) Weather Radar Control Panel
<p>CHECK GEAR</p>	<p>“Check Gear, Check Gear”</p>	<p>If RG flag is set to 1, activates if aircraft is below 150’ AGL and is descending, but landing gear is not down. 2-second time delay.</p>

Table 2-3: Warnings, Cautions, and Advisories

Display Flag "--" indicates no flag	Aural Annunciation	Condition
<p>CHECK IDU 1</p> <p>CHECK IDU 2</p> <p>CHECK IDU 3</p> <p>CHECK IDU 4</p>	<p>Alert Tone</p>	<p>Indicates either:</p> <ol style="list-style-type: none"> 1) screen counter value has not changed in the last 1 second \pm 0.1 seconds; or 2) intra-system monitor message is not fresh (i.e., no message received for longer than 1 second \pm 0.1 second). <p>"#" indicates which IDU is failing the check (IDU1, IDU2, IDU3, or IDU4.)</p> <p>No time delay.</p>
<p>COOLING FAN</p>	<p>Alert Tone</p>	<p>Cooling fan is not rotating. 1-minute time delay.</p>
<p>CHECK RANGE</p>	<p>"Check Range, Check Range"</p>	<p>Less than 30 minutes buffer (at current groundspeed) between calculated range and distance to:</p> <ol style="list-style-type: none"> 1) last waypoint if it is active; or 2) airport if on a missed approach; or 3) along-route distance to destination. <p>Not activated in climbing flight nor if below 60 knots groundspeed.</p> <p>5-minute time delay.</p>

Table 2-3: Warnings, Cautions, and Advisories





Display Flag "--" indicates no flag	Aural Annunciation	Condition
LOW FUEL	 "Fuel Low, Fuel Low"	Low Fuel warning is not active and one of the following conditions is true: <ol style="list-style-type: none"> 1) A low fuel caution discrete input is active. 2) A sensed fuel tank quantity is below its low fuel caution threshold. 3) Total aircraft fuel is below the pilot-set minimum fuel threshold. 1-minute time delay.
FUEL SPLIT	 Alert Tone	Compares the volume of fuel designated left wing tank fuel vs. right wing tank fuel to the Fuel Split caution threshold. Issued if the difference exceeds Fuel Split caution threshold. Only performed if Fuel Split caution threshold is non-zero and both left and right wing tank fuel are monitored and valid. 1-minute time delay.
GLIDESLOPE	 "Glideslope, Glideslope"	Within GPWS Mode 5 caution envelope. Half second time delay.
GPS LOI	 Alert Tone	GPS/SBAS loss of integrity. No time delay. Inhibited during and for 10 seconds after unusual attitude mode.

Table 2-3: Warnings, Cautions, and Advisories




Display Flag "--" indicates no flag	Aural Annunciation	Condition
GPS LON	 Alert Tone	GPS/SBAS loss of navigation. No time delay. Inhibited during and for 10 seconds after unusual attitude mode.
VERT LON	 Alert Tone	Loss of vertical navigation. No time delay. Inhibited during and for 10 seconds after unusual attitude mode.
GPS MISCOMP	 Alert Tone	<p>Only in dual-GPS/SBAS installation with neither failed. Indicates position, track, or groundspeed difference between GPS/SBAS units is beyond the following:</p> <p>Position: Enroute Mode 4NM Terminal Mode 2NM Departure Mode .6NM IFR Approach Mode .6NM VFR Approach Mode .6NM</p> <p>Track: If groundspeed is greater than 30 kts, miscompare if difference is more than 4°.</p> <p>Groundspeed: If difference between GPS #1 and GPS #2 miscompare is more than 10 kts.</p> <p>10-second time delay. Inhibited during and for 10 seconds after unusual attitude mode.</p>

Table 2-3: Warnings, Cautions, and Advisories





Display Flag "--" indicates no flag	Aural Annunciation	Condition
GPS1 FAIL	 Alert Tone	Only in dual-GPS/SBAS installation. Indicates no valid message received from GPS/SBAS #1 for more than 5 seconds. No time delay. Inhibited during and for 10 seconds after unusual attitude mode.
GPS2 FAIL	 Alert Tone	Only in dual-GPS/SBAS installation. Indicates no valid message received from GPS/SBAS #2 for more than 5 seconds. No time delay. Inhibited during and for 10 seconds after unusual attitude mode.
NO POSITION	 Alert Tone	No valid position data available from selected GPS/SBAS for more than 5 seconds, and dead reckoning not available. No time delay. Inhibited during and for 10 seconds after unusual attitude mode.
GS MISCOMP	 Alert Tone	Only when two valid glideslopes are received. Indicates at least one glideslope is receiving a signal within 1 dot of center and difference between glideslope signals is beyond limits (0.25 Dots). 10-second time delay.

Table 2-3: Warnings, Cautions, and Advisories





Display Flag "--" indicates no flag	Aural Annunciation	Condition
HDG MISCAMP	 Alert Tone	Only in dual-AHRS installation with neither failed nor in DG mode. Indicates heading difference between AHRS is beyond the "Heading Miscompare Threshold" limit. 10-second delay. Inhibited during and for 10 seconds after unusual attitude mode. Inhibit for 5 minutes after startup.
IAS MISCAMP	 Alert Tone	Only in dual-ADC installation with neither failed. Indicates indicated airspeed difference between ADCs is beyond limits. Inhibit for 5 minutes after startup. 10-second time delay.
LOC MISCAMP	 Alert Tone	Only when two valid localizers are received. Indicates at least one localizer is receiving a signal within 1 dot of center and difference between localizer signals is beyond limits (0.25 Dots). 10-second time delay.
NO HEADING	 Alert Tone	No valid heading received from selected AHRS for more than 1 second Inhibited during and for 10 seconds after unusual attitude mode. Disabled if MFD-only. Not shown if PFD heading scale is red-X'd. No time delay.

Table 2-3: Warnings, Cautions, and Advisories





Display Flag "--" indicates no flag	Aural Annunciation	Condition
NO TAWS	 Alert Tone	Indicates aircraft is beyond extent of terrain database or a failure condition exists preventing TAWS FLTA function from operating. Half second time delay. Inhibited during and for 10 seconds after unusual attitude mode.
OAT SENSOR OAT1 SENSOR OAT2 SENSOR	 Alert Tone	Indicates OAT sensor has failed. "OAT SENSOR" applicable to single ADC installation. "OAT# SENSOR" applicable to dual ADC installation. Indicates OAT indication is invalid but other air data parameters are normal (i.e., air data is not red-X'd). Half second time delay.
OBSTRUCTION	 "Caution Obstruction, Caution Obstruction"	Obstruction within TAWS FLTA caution envelope. Half second time delay.
PLT MISCOMP CPLT MISCOMP	 Alert Tone	Only active when fresh intra-system monitor messages are received. Indicates a critical parameter used by another display exceeds the miscompare thresholds when compared to the monitoring display with the following critical parameters:

Table 2-3: Warnings, Cautions, and Advisories

Display Flag "--" indicates no flag	Aural Annunciation	Condition
		<ol style="list-style-type: none"> 1) Attitude (Pitch and Roll) (Attitude Miscompare logic) 2) Heading (Heading Miscompare logic) 3) Pressure Altitude (Altitude Miscompare logic) 4) Indicated Airspeed (Airspeed Miscompare logic) 5) Localizer (both inputs) (Localizer Miscompare logic) 6) Glideslope (both inputs) (Glideslope Miscompare logic) 7) Radar Altitude (Radar Altitude Miscompare logic) 8) Latitude (GPS/SBAS Miscompare logic) 9) Longitude (GPS/SBAS Miscompare logic) 10) Track (GPS/SBAS Miscompare logic) 11) Groundspeed (GPS/SBAS Miscompare logic) <p>1-second time delay. Inhibited during and for 10 seconds after unusual attitude mode.</p>

Table 2-3: Warnings, Cautions, and Advisories





Display Flag "--" indicates no flag	Aural Annunciation	Condition
PLT1 OVRTMP PLT2 OVRTMP PLT3 OVRTMP PLT4 OVRTMP CPLT1 OVRTMP CPLT2 OVRTMP CPLT3 OVRTMP CPLT4 OVRTMP	 Alert Tone	IDU core temperature greater than 95°C. 2-second time delay.
PLT1 SCC PLT2 SCC PLT3 SCC PLT4 SCC CPLT1 SCC CPLT2 SCC CPLT3 SCC CPLT4 SCC	 Alert Tone	Indicates SCC card (Personality Module) could not be read upon power-up. Internal limits are in use by the system. Only active on the ground.
RADALT FAIL	 Alert Tone	Only in single-Radar Altimeter installation. For analog radar altimeter, indicates below 2000' AGL in Air Mode without a valid radar altimeter reading. For ARINC 429 radar, altimeter indicates an SSM of failure warning is transmitting. 2-second time delay.
RADALT1 FAIL	 Alert Tone	Only in dual-Radar Altimeter installation. Indicates no radar altimeter reading received from Radar Altimeter #1 for more than 1 second. Also displayed in Ground Mode. Inhibited when radar altimeter value received from ARINC 429, except when SSM of radar altimeter message indicates failure warning. 2-second time delay.

Table 2-3: Warnings, Cautions, and Advisories




Display Flag "--" indicates no flag	Aural Annunciation	Condition
RADALT2 FAIL	 Alert Tone	Only in dual-Radar Altimeter installation. Indicates no radar altimeter reading received from Radar Altimeter #2 for more than 1 second. Also displayed in Ground Mode. Inhibited when radar altimeter value indicates failure warning. 2-second time delay.
RALT MISCOMP	 Alert Tone	Only in dual-Radar Altimeter installation with neither failed. Indicates difference between radar altimeters is beyond limits: $\geq 500' \text{AGL} \quad \Delta 14\%$ $100 - 500' \text{AGL} \quad \Delta 10\%$ $< 100' \text{AGL} \quad \Delta 10'$ 10-second time delay.
SSEC FAIL SSEC1 FAIL SSEC2 FAIL	 Alert Tone	Indicates either: 1) ADC is not transmitting SSEC-corrected data on an airframe requiring SSEC; or 2) there is a mismatch greater than or equal to 50 $\mu\text{m Hg}$ between the SSEC being calculated by the IDU and the SSEC being used by the ADC. "SSEC1 FAIL" and "SSEC2 FAIL" used in

Table 2-3: Warnings, Cautions, and Advisories




Display Flag "--" indicates no flag	Aural Annunciation	Condition
		dual ADC installations. "SSEC FAIL" used in a single ADC installation. Inhibited if the related ADC is failed. 1-minute time delay.
SAME ADC	 Alert Tone	Only in dual-system, dual- ADC installation with good inter-system communica- tions and neither failed. Indicates both systems are operating from same ADC source. No time delay.
SAME AHRS	 Alert Tone	Only in dual-system, dual- AHRS installation with good inter-system communications and nei- ther failed. Indicates both systems are operating from same AHRS source. No time delay.
SAME GPS	 Alert Tone	Only in dual-system, dual- GPS/SBAS installation with good inter-system communications and neither failed. Indicates both systems are oper- ating from same GPS/SBAS source. No time delay.

Table 2-3: Warnings, Cautions, and Advisories






Display Flag "--" indicates no flag	Aural Annunciation	Condition
SAME NAV	 Alert Tone	Only in dual-system with good inter-system communications. Indicates both systems are operating from same navigation source. Inhibited if both systems are operating from GPS/SBAS in a single-GPS/SBAS installation. No time delay.
SAME RADALT	 Alert Tone	Only dual-system, dual-radar altimeter installation with good inter-system communications, and neither failed. Indicates both systems are operating from same radar altimeter source. No time delay.
SINK RATE	 "Sink Rate, Sink Rate"	Within GPWS Mode 1 caution envelope. Half second time delay.
TRAFFIC	 "Traffic, Traffic"	Traffic advisory. Not given if own aircraft below 400' AGL nor if target is below 200' AGL (ground target). Audio not generated with TCAS-II system. No time delay.
TCAS FAIL	 Alert Tone	Only active with ARINC 735A-1 TCAS-II, TCAS-I, or TAS system. Indicates lack of communications with system or failure indication from system. No time delay.

Table 2-3: Warnings, Cautions, and Advisories






Display Flag "--" indicates no flag	Aural Annunciation	Condition
TERRAIN	 "Caution Terrain, Caution Terrain"	Terrain cell within TAWS FLTA caution envelope. Half second time delay.
TOO LOW	 "Too Low Terrain, Too Low Terrain"	Within GPWS Mode 3 envelope. Half second time delay.
		Within GPWS Mode 4 "Too Low Terrain" envelope. Half second time delay.
	 "Too Low Gear, Too Low Gear"	Within TAWS PDA envelope. Half second time delay.
		Within GPWS Mode 4-2 "Too Low Gear" envelope. Half second time delay.
 "Too Low Flaps, Too Low Flaps"	Within GPWS Mode 4-3 "Too Low Flaps" envelope. Half second time delay.	
TOTALZR QTY	 Alert Tone	Compares volume of sensed fuel to fuel totalizer calculation. Issued if difference exceeds Totalizer Mismatch caution threshold. Only performed if: <ol style="list-style-type: none"> 1) totalizer mismatch caution threshold is non-zero; 2) fuel totalizer is enabled; 3) unmonitored fuel flag is false; 4) fuel totalizer has a valid value; and

Table 2-3: Warnings, Cautions, and Advisories







Display Flag "--" indicates no flag	Aural Annunciation	Condition
		5) fuel levels are valid. 1-minute time delay.
TRIM MOTION↓	 "Trim in Motion, Trim in Motion"	Only with Intelliflight 1950. Pitch trim running in DOWN direction for more than amount of time set in aircraft limits.
TRIM MOTION↑	 "Trim in Motion, Trim in Motion"	Only with Intelliflight 1950. Pitch trim running in UP direction for more than amount of time set in aircraft limits.
CHECK TRIM↓	 "Check Pitch Trim"	Only with Intelliflight 1950. Pitch is mistrimmed for more than 3 continuous seconds. DOWN trim needed.
CHECK TRIM↑	 "Check Pitch Trim"	Only with Intelliflight 1950. Pitch is mistrimmed for more than 3 continuous seconds. UP trim needed.
XFILL FAIL	 Alert Tone	Only in dual-system. Indicates lack of inter-system communications. 2-second time delay. Inhibit for 30 seconds after startup.
--	 "Altitude, Altitude"	Deviation greater than 150' from selected altitude after capture (within 100' of altitude). 2-second time delay.

Table 2-3: Warnings, Cautions, and Advisories











Display Flag "--" indicates no flag	Aural Annunciation	Condition
		If not on descending VNAV profile, deviation greater than 150' from altitude of current or prior VNAV waypoint after capture (within 100' of altitude). 2-second time delay.
--	 "Decision Height"	Deviation from above to below decision height bug. Decision height readout turns amber (yellow) and flashes. No time delay.
--	 "Minimums, Minimums"	Deviation from above to below minimum altitude bug. Minimum altitude readout turns amber (yellow) and flashes. No time delay.
ADVISORIES		
	 Chime	Only in dual-AHRS installation. Indicates AHRS 1 in DG mode. No time delay.
	 Chime	Only in dual-AHRS installation. Indicates AHRS 2 in DG mode. No time delay.
	 Chime	ADC not at full accuracy during warm-up. No time delay.
	 Chime	GPS/SBAS Actual Navigation Performance based on current GPS/SBAS HPL.

Table 2-3: Warnings, Cautions, and Advisories





Display Flag "--" indicates no flag	Aural Annunciation	Condition
BARO MISCOMP	 Chime	Only in dual-system installation. Indicates mismatch of altimeter settings or altimeter modes between systems. 10-second time delay.
CHK BARO	 Chime	Ascending through transition level: Altimeter not set to 29.92 inHg or 1013 mbar. Descending through transition level: Altimeter set to 29.92 inHg or 1013 mbar. Times out in 10 seconds. Disabled during QFE operation. 2-second time delay.
CREW CALL	 Chime	Only with EFIS control of audio controller with pilot isolate function, and call notice is received from the controller.
DR 00:00 DR 01:23	 Chime	GPS/SBAS in Dead Reckoning Mode with valid ADC and AHRS data. Timer shows time since loss of position to indicate quality of DR solution. No time delay. Inhibited during and for 10 seconds after unusual attitude mode.

Table 2-3: Warnings, Cautions, and Advisories








Display Flag "--" indicates no flag	Aural Annunciation	Condition
FLTA INHBT	 Chime	Shown when FLTA function is automatically inhibited during normal operation. "NO TAWS" caution and "TAWS INHBT" advisory have priority. No time delay.
FPM INHBT	 Chime	Flight Path Marker inhibit function activated through momentary discrete input. No time delay.
LNAV APPR	 Chime	GPS/SBAS in LNAV Approach Mode. No time delay.
LNU/UNU APPR	 Chime	GPS/SBAS in LNAV/VNAV Approach Mode. No time delay.
LP APPR	 Chime	GPS/SBAS in LP Approach Mode. No time delay.
LPV APPR	 Chime	GPS/SBAS in LPV Approach Mode. No time delay.
MORE-PRS MENU	None	Number of active messages exceeds 11. Guides pilot in accessing the EXPAND CAS menu. No time delay.
PLT1 PWR PLT2 PWR PLT3 PWR PLT4 PWR CPLT1 PWR CPLT2 PWR CPLT3 PWR CPLT4 PWR	 Chime	Indicates one of the dual redundant power supplies within an IDU is not functioning correctly. 1-minute time delay.

Table 2-3: Warnings, Cautions, and Advisories









Display Flag "--" indicates no flag	Aural Annunciation	Condition
PTK = L 1NM PTK = L 20NM PTK = R 1NM PTK = R 20NM PTK ENDING	 Chime	GPS/SBAS Parallel Offset path advisory. ## is nautical miles left (L) or right (R) of main path. No time delay.
RNP: 0.10A RNP: 15.0A	 Chime	GPS/SBAS Automatic Required Navigation Performance as acquired from navigation database
RNP: 0.10M RNP: 15.0M	 Chime	GPS/SBAS Manual Required Navigation Performance as set by pilot.
SUSPEND	 Chime	GPS/SBAS automatic waypoint sequencing is suspended by being on final approach segment prior to arming missed approach, selecting manual GPS/SBAS OBS, or holding prior to activating CONTINUE tile. No time delay.
TA ONLY	 Chime	Only active with TCAS-II system. Indicates system is unable to display resolution advisories. No time delay.
TAS INHBT	 Chime	TAS aural inhibited through TCAS/TAS Audio inhibit discrete input. No time delay.
TAWS GS CNX	 Chime	Class A TAWS only. TAWS glideslope cancel (GPWS Mode 5) through discrete input. No time delay.
TAWS INHBT	 Chime	TAWS inhibited through discrete input. No time delay.

Table 2-3: Warnings, Cautions, and Advisories















Display Flag "--" indicates no flag	Aural Annunciation	Condition
TCAS STBY	 Chime	Only with TCAS-II system. Indicates system is in standby or executing functional test in flight. No time delay.
TCAS TEST	 Chime	Only with TCAS-II system. Indicates system is in functional test on ground. No time delay.
TERMINAL	 Chime	GPS/SBAS in Terminal Mode. No time delay.
TRUE NORTH	 Chime	System is operating in True North Mode. No time delay.
VECTORS	 Chime	GPS/SBAS in Vectors to Final Approach Mode prior to sequencing FAWP. No time delay.
VFR APPR	 Chime	GPS/SBAS in VFR Approach Mode. No time delay.
VNAV AVAIL	 Chime	Only with Intelliflight 1950. Indicates VNAV guidance is available but not in use by the autopilot. Press "VNV" button on the Mode Control Panel to engage VNAV mode.
XFILL ARM	 Chime	Only in dual-system with good inter-system communications and crossfill not inhibited. Indicates systems are not synchronized but synchronization function is available. No time delay.

Table 2-3: Warnings, Cautions, and Advisories

Display Flag "--" indicates no flag	Aural Annunciation	Condition
XFILL INHBT	 Chime	Only in dual-system with good inter-system communications. Indicates crossfill is inhibited through discrete input. No time delay.
--	 "Autopilot Disconnect"	Only with Intelliflight 1950. Sounds when autopilot servos disengage for any reason.
--	 "Autopilot Failure"	Only with Intelliflight 1950. Sounds when an autopilot failure is detected.
--	 "Five Hundred"	Descending through 500' AGL advisory. Armed upon climbing through deadband value above 500' AGL. Half second time delay.
--	 Altitude Alert Tone	Within the greater of 1000' or 50% of VSI from uncaptured selected or VNAV waypoint altitude. Inhibited in approach procedures. No time delay.
--	 Chime	Sounds when countdown timer reaches 00:00:00. No time delay.

Volume of aural annunciations is adjusted according to severity:

WARNING	= Full volume set into aircraft limits
CAUTION	= 80% of volume set into aircraft limits
ADVISORY	= 60% of volume set into aircraft limits

Press the audio mute switch to mute the active aural annunciation.

Flags are prioritized so warning flags are displayed above caution flags, which are displayed above advisory flags. Within categories, active flags are stacked in chronological order with the most recent annunciation on top. Warning flags flash twice per second and caution flags flash once per second until acknowledged by pressing the audio mute switch.

Only the highest priority (in criticality and recency), unacknowledged aural annunciation is played at a time. To further minimize cockpit confusion, annunciations are grouped and prioritized so only one annunciation is active. Annunciations are prioritized in this manner as follows (higher in list = higher priority).

Table 2-4: Annunciations Priority

1)	GPWS Mode 1 Warning
2)	GPWS Mode 2 Warning
3)	TAWS FLTA Warning
4)	Obstruction Warning
5)	TAWS FLTA Caution
6)	Obstruction Caution
7)	GPWS Mode 4-1
8)	GPWS Mode 4-2
9)	GPWS Mode 4-3
10)	GPWS Mode 1 Caution
11)	GPWS Mode 2 Caution
12)	GPWS Mode 3
13)	GPWS Mode 5 Warning
14)	GPWS Mode 5 Caution
15)	Check Gear
16)	Traffic Warning (Resolution Advisory)
17)	Traffic Caution (Traffic Advisory)
18)	Low Fuel Warning
19)	Low Fuel Caution
20)	Fuel Split Caution
21)	Fuel Totalizer Mismatch Caution
22)	Check Range

In addition, flags are decluttered from all IDUs, which are not “transmit enabled.” Flags only appear on these IDUs if they are IDU-specific (i.e., CHECK IDU #). See Section 9 Appendix for information on logged flags and CAS messages.

2.6. Database and Software Updates

2.6.1. Navigation and Obstruction Databases

The EFIS uses Jeppesen NavData® for the navigation database and Jeppesen data for the obstruction database, which are both secured directly through the Jeppesen Company.

Visit www.jeppesen.com to place the order for the correct database.

Three types of navigation databases may be used on this EFIS.

Americas - Major airports and navigation for Alaska, Canada, Continental U.S., Hawaii, Puerto Rico, Bahamas, Bermuda, Mexico, Central, and South America.

International - All available coverage except North and South America.

World - Major airports and navigation with the Americas.

The updateable navigation database contains at least the following location and path information, referenced to WGS-84, with a resolution of 0.01 minute (latitude/longitude) and 0.1° (for course information) or better at all of the following for the area(s) in which IFR operations are intended:

- 1) Airports.
- 2) VORs, DMEs (including DMEs collocated with localizers), collocated VOR/DMEs, VORTACs, and NDBs (including NDBs used as locator outer marker).
- 3) All named waypoints and intersections shown on enroute and terminal area charts.
- 4) All airways shown on enroute charts, including all waypoints, intersections, and associated RNP values (if applicable). Airways are retrievable as a group of waypoints (select the airway by name to load the appropriate waypoints and legs between desired entry and exit points into the flight plan).
- 5) RNAV DPs and STARs, including all waypoints, intersections, and associated RNP values (if applicable). DPs and STARs are retrievable as a procedure (select the procedure by name to load the appropriate waypoints and legs into the flight plan).

- 6) LNAV approach procedures in the area(s) in which IFR operation is intended consist of:
- a) Runway number and label (required for approach identification);
 - b) Initial approach waypoint (IAWP);
 - c) Intermediate approach waypoint(s) (IWP), when applicable;
 - d) Final approach waypoint (FAWP);
 - e) Missed approach waypoint (MAWP);
 - f) Additional missed approach waypoints, when applicable; and
 - g) Missed approach holding waypoint (MAHWP).

The complete sequence of waypoints and associated RNP values (if applicable), in the correct order for each approach, is retrievable as a procedure (select the procedure by name to load the appropriate waypoints and legs into the flight plan). Waypoints utilized as a final approach waypoint (FAWP) or missed approach waypoint (MAWP) in an LNAV approach procedure are uniquely identified as such (when appropriate) to provide proper approach mode operation.

- 7) LNAV/VNAV procedures in the area(s) where IFR operation is intended. LPV, LP, and/or LNAV/VNAV published procedures are available. Select a procedure by name to load the appropriate waypoints and legs into the active flight plan. Waypoints used as a final approach waypoint (FAWP) and LTP/FTP/MAWP in an LNAV/VNAV procedure are uniquely identified as such to provide proper approach mode operation.

The obstruction database is distributed by a government agency in each country. Not all countries have obstruction databases available.

2.6.2. Update Requirements

Scheduled updates for databases are as follows:

Navigation Database - Every 28 days

Obstruction Database - Every 28 days

MAGVAR Database - Every 5 years (updated as described in a Genesys Aerosystems Service Bulletin)

CAUTION:

Failure to update the EFIS with the correct NavData causes the IDU to remain in continual reboot mode and does not allow any display page to appear.

The EFIS is updated through the Ground Maintenance Function (GMF). To gain access to the GMF, prior to applying power, slide the slip indicator or non-slip blank door cover at the bottom-center of the IDU bezel upward to the first detent position to expose the USB port.



Figure 2-6: Ground Maintenance Page

When an update is performed, the following procedures must be performed separately on every IDU installed in the aircraft.

To update the databases:

- 1) Load the NavData (navdata.exe) and obstruction database (obst.exe) on USB memory.
- 2) Insert the USB into USB port with the power off.

CAUTION:

Always install a valid USB memory device in the IDU prior to activating any Ground Maintenance Function. Operation of the GMF without a valid USB memory device installed may cause erroneous failure indications or corruption of the IDU.

- 3) Turn on power to gain access to the GMF page.
- 4) Scroll **⬇** to highlight “**Update Databases**” and push to enter.

- 5) Once each database is loaded, press any button to continue to complete the process.
- 6) Once both databases have been uploaded, power down the IDU, remove the USB memory device, and lower the USB door.
- 7) Once each IDU has been updated, power up the entire EFIS in normal flight mode and verify each IDU successfully updated with the latest database by noting the new NavData cycle expiration dates before acknowledging the Initialization screen (Figure 2-4). There is no expiration for the obstruction database.

A Cyclic Redundancy Check (CRC) self-test verifies the data at every step of the process, thereby ensuring the data installed into the system has not been corrupted at any point during the process.

2.6.3. Software and Terrain Database Update

Software and terrain databases are updated on an as-needed basis and performed as required as described in a service bulletin.

2.7. Demonstrator

The EFIS has a built-in demonstration application to fly anywhere in the world while performing any procedure (except takeoff and landing) based on the current Jeppesen navigation database. Use this feature on the ground in the Ground Mode as follows:

- 1) With power off, lift the USB memory flash door. Insert a USB flash memory storage device in the IDU lower bezel.
- 2) Power the system on and use **1** (scroll and push to enter) to select **RUN DEMONSTRATION/TRAINING APPLICATION**.

Use the demonstrator to gain familiarity of the EFIS menu structure and location of button tiles for each operation. Load an instrument procedure prior to take off to view the sequence of events to expect with the aircraft flying the same speeds normally flown.

The demonstrator begins flying over Reno, Nevada, USA at an altitude of approximately 7900' MSL but may be changed with the menu and target altitude control. Airspeed remains relatively constant but may be controlled with the Airspeed IAS bug in the BUGS menu. The simulated aircraft may be positioned anywhere in the world, as long as the worldwide terrain database is loaded in the system, by activating a flight plan stored in the memory.

All appropriate navigation signals are simulated, allowing for precision and non-precision instrument approaches found within the current navigation database. All obstructions in the latest obstruction database and all warning, caution, and advisory aural and flag annunciations are presented as appropriate during simulated flights.

2.8. EFIS Training Tool

In addition to the demonstrator program, the EFIS Training Tool (ETT) is available to load on a personal computer for flying like the aircraft. The ETT is compatible with 32- or 64-bit versions of Microsoft Windows®. It serves as a multi-purpose tool for training pilots and provides features to record and capture images. See user guide distributed with the ETT install files for further details.

2.9. Application Software Air Mode and Ground Mode

Numerous symbology elements change behavior depending upon whether the aircraft is on the ground (Ground Mode) or in flight (Air Mode). Mode is determined separately from the system initialization modes. This parameter is continuously calculated as follows:

- 1) If Weight on Wheels/Weight on Ground discrete input is configured, Air or Ground Modes are determined solely from the discrete input position.
- 2) Otherwise, mode is determined as follows:
 - a) If airspeed is valid and AGL altitude is valid, Ground Mode is set when indicated airspeed is less than 30 knots, and AGL altitude is less than 75 feet.
 - b) If airspeed is invalid but AGL altitude is valid, Ground Mode is set when AGL altitude is less than 75 feet.
 - c) Under any other circumstance, Air Mode is set by default.

Section 3 Display Symbology

3.1. Introduction

This section details the symbology used on the Primary Flight Display (PFD) and Multi-Function Display (MFD). In an IFR installation, software of the primary IDU-450 is configured so only the PFD is displayed. On all other IDU-450 displays, software is configured so any screen display is shown at any time.




Figure 3-1: PFD



3.1.1. IDU-450 PFD Display Basic Mode

The following are no longer present when Basic mode is displayed:

- 1) Atmospheric perspective
- 2) Terrain rendering
- 3) Obstructions rendering
- 4) Flight Path Marker
- 5) Roll Pointer option
- 6) Bank Scale option
- 7) Airport runways




Figure 3-2: PFD in Basic Mode

3.2. Menu Functions

The top-level menu level corresponds to the permanent labeling of the IDU pushbuttons and is active when no soft menu tiles appear next to the appropriate IDU button or encoder (❶).






Figure 3-3: Menu Functions

On the PFD, scroll ❶ to activate the heading menu. On MFD pages with an adjustable display (e.g., ND, Strike, Traffic, Datalink, or Weather Radar) scroll ❶ CW to increase scale or CCW to decrease scale.

With the exception of IDU #1 (always configured to the PFD page), push **1** to swap between the PFD and MFD, unless the IDU is in MFD-only mode.

Table 3-1: Encoder Functions for All Pages	
	PFD page
	MFD MAP page

Selection lists too long to be presented in the available space indicate the location within the list. When the menu system is beyond the top-level, **EXIT (R1)** escapes to the top-level. When a menu level is deeper than the first level, **BACK (L1)** regresses one level through the menu system.



3.2.1. Selecting BARO

Press **BARO (R2)** to enter BARO mode and view the inches of mercury (inHg) or millibars (mbar) value in the lower right corner. Scroll **1** CW to increase or CCW to decrease the QNH. Push **1** or **EXIT (R1)** to enter the new value. See Section 5 Menu Functions and Procedures for additional information.



Figure 3-4: Selecting BARO

The altimeter setting is immediately below the altitude readout box and digitally displays the altimeter setting in either inches of mercury (inHg) or millibars (mbar) according to the pilot-selected units. Immediately below the altimeter setting, the mode is announced as QFE operations otherwise, no mode is announced.

QFE: Barometric setting resulting in the altimeter displaying height above a reference elevation (e.g., airport or runway threshold).

QNE: Standard barometric setting (29.92 inHg or 1013 mbar) used to display pressure altitude for flight above the transition altitude.

QNH: Barometric setting resulting in the altimeter displaying altitude above mean sea level at the reporting station.




Figure 3-5: Altimeter Setting

3.2.2. Selected Altitude Sub-Mode (Target Altitude)

When in selected altitude sub-mode, the altitude scale has a pilot-settable target altitude bug geometrically interacting with the altitude box pointer. The target altitude bug setting is limited to -1000 feet at the low end, 50,000 feet at the high end, and is annunciated above the altitude scale as seen above with a resolution of 100 feet.



When in altitude hold mode, the target altitude bug setting annunciation is green, while the target altitude bug is filled-white.

When in a climb or descent mode, the target altitude bug setting annunciation is white, and the target altitude bug is hollow-white.



During altitude hold capture, the target altitude bug setting annunciation is green and flashes, while the target altitude bug is filled-white.

Figure 3-6: Target Altitude Bug (Vertically Integrated)

When not vertically integrated with an autopilot, the target altitude bug setting annunciation is white, and the target altitude bug is filled-white at all times.

3.2.3. VNAV Sub-Mode

When in VNAV sub-mode, the altitude scale shows the active waypoint VNAV altitude (if it exists) with a bug symbol geometrically interacting with the altitude box pointer. The VNAV altitude bug setting is annunciated above the altitude scale with a resolution of 100 feet.




When not vertically integrated with a fully-integrated digital autopilot, the VNAV altitude bug setting includes “VNAV” indicating VNAV altitude sub-mode. When vertically integrated with a fully-integrated digital autopilot, it is not needed because an indication appears in the autopilot mode annunciation area.

Figure 3-7: VNAV Sub-Mode (Not Vertically Integrated)

The VNAV altitude bug is a visual reference or, when vertically integrated with an autopilot either fully or partially integrated through the vertical mode discrete input, as a control parameter for climbs or descents.

When the VNAV altitude or target altitude differs from aircraft altitude to the extent the associated bug is off-scale, the associated bug is “parked” in the direction of the difference with half of the associated bug visible as seen in Figure 3-8.



When vertically integrated with an autopilot:

When in altitude hold mode, the VNAV altitude bug setting is green, and the VNAV altitude bug is filled-magenta. During altitude hold capture, VNAV altitude bug setting is green and flashes, while the VNAV altitude bug is filled-magenta.

When in a climb or descent mode, the VNAV altitude bug setting is white, and the VNAV altitude bug is hollow-magenta.

Figure 3-8: VNAV Sub-Mode (Vertically Integrated)

3.2.4. Altitude Display (VNAV Tile)

When enabled for performing VNAV with a selected altitude entered, **VNAV (L2)** appears for “one-touch” engagement of VNAV.




Figure 3-9: Altitude Display (VNAV Tile)

3.2.5. Altitude Display (Metric Units)

Pilot-selectable altitude values are in metric units with a resolution of 10 meters as depicted.



Figure 3-10: Altitude Display (Metric Units)

3.3. PFD Symbology



Figure 3-11: PFD Symbology

The PFD combines pitot-static information, heading, attitude, 3-D navigation data, and more overlaid on a virtual background of the outside world. Other objects in the background, including terrain, obstructions, traffic, and runways are presented conformally as if seen directly in front of the aircraft while looking outside.

3.3.1. Minimum Altitude




When a minimum altitude is selected (in 10-foot increments), a bug in the form of a bold amber (yellow) bar is displayed in the appropriate position on the altitude tape and below in amber (yellow). The minimum altitude setting is indicated above the altitude tape with a line drawn below. In this example, 1440' MSL is set. Minimum and target altitude/VNAV altitude bugs may be used simultaneously.

Figure 3-12: Minimum Altitude



When a minimum altitude is set, descending from above to below causes an aural annunciation of "Minimums, Minimums," and minimum altitude turns amber (yellow) and flashes.

3.3.2. Vertical Speed Indicator




A vertical speed indicator (VSI) is located to the right of the altitude box in a "worm" format and provides analog and digital representation of VSI in feet per minute.

The VSI worm grows in proportion to the square root of the vertical speed so a change near 0 feet per minute displaces the worm to a much greater degree than an equivalent change at a larger feet-per-minute value. Readouts of vertical speed rounded to the nearest 100 feet per minute appear above the VSI scale (for climbs) or below the VSI scale (for descents).


Figure 3-13: VSI

Table 3-2: Scale Graduations and Display

Type Traffic Installed	Scale Limit	Scale Graduations and Display
With TCAS-II	$\pm 2,000$ FPM	± 500 , $\pm 1,000$, and $\pm 2,000$ Background of the VSI functions as an RA display with green and red colored regions to provide RA maneuver guidance.
Without TCAS-II	$\pm 2,000$ FPM	± 500 , $\pm 1,000$, and $\pm 2,000$ FPM



The pilot-selectable VSI bug setting (100' FPM resolution) in this example is set to 3000 FPM descent rate. The vertical speed bug is used either as a visual reference or, when vertically integrated with an autopilot (either fully integrated or partially integrated through the vertical mode discrete input), as a control parameter for climbs or descents. It is mutually exclusive with the airspeed bug.

Figure 3-14: VSI Bug


When vertically integrated with an autopilot, the VSI bug setting is green with the speed bug filled-white when in VSI climb or descent mode. Otherwise, the VSI bug setting is white, and VSI bug is hollow-white.

Figure 3-15: VSI Bug (Vertically Integrated)

3.3.3. Normal AGL Indication

AGL altitude is displayed in two formats, at the bottom-center of the display above the Course Deviation Indicator (Normal) and as the (Analog) AGL Indicator. These are mutually exclusive of each other and driven by the AGL altitude source used for TAWS but not displayed when the source is invalid. Source designated as follows:

R = Radar altitude.

G = GPS/SBAS geodetic height less database ground elevation.

B = Barometric altitude less database ground elevation.



(SVS Basic) AGL Based on GPS Altitude



(SVS TAWS) AGL Based on Radar Altimeter

Figure 3-16: Normal AGL Indication

Table 3-3: AGL Indication			
Altitude	≥300 Feet	≥100 Feet < 300 Feet	<100 Feet
AGL Indication resolution	10 Feet	5 Feet	1 Foot

AGL altitude is not displayed in either format when it is greater than the maximum AGL Display valid altitude nor when it is invalid. Additionally, AGL indication includes the set decision height (see § 3.3.5).

3.3.4. Analog AGL Indication



Pilot-selectable analog AGL indication is displayed in the lower right corner of the PFD above the active waypoint identifier with a green circular tape and digital readout in the center. The circular tape has a radial line at its end and disappears above 1000' AGL.

Figure 3-17: Analog AGL Indication

Table 3-4: Analog AGL Indicator			
Analog AGL Indicator Markings 0-1000 Feet		AGL	Scaling (at clock position)
0-100 Feet	100 Feet-1000 Feet	0'	6:00
Linear	Logarithmic	50'	9:00
		100'	12:00
		200'	1:30
		500'	3:00

The analog AGL indicator disappears in Unusual Attitude mode and is mutually exclusive with the mini-map and traffic thumbnail. Likewise, when the analog AGL altitude display is shown, the normal AGL display is removed.

	Major Tick Marks	Minor Tick Marks
0'	✓	
10'		✓
20'		✓
30'		✓
40'		✓
50'	✓	
60'		✓
70'		✓
80'		✓
90'		✓
100'	✓	
200'		✓
300'		✓
400'		✓
500'	✓	
1000'	✓	

3.3.5. Decision Height



Analog AGL indication includes the set decision height to the left of the indication along with an amber (yellow) radial line on the circular tape. When below decision height, the circular tape and digital readout are amber (yellow).


Figure 3-18: Decision Height



Descending below decision height is accompanied by “Decision Height” aural annunciation, and decision height readout turning amber (yellow) and flashing.

3.3.6. Airspeed Display


Airspeed is digitally displayed in same color as airspeed scale in knots, miles per hour, or kilometers per hour with interactive pointer. The airspeed scale is commensurate with the certification category of the aircraft.



The airspeed box pointer interacts with the airspeed scale and has graduations every 10 measurement units with labels every 20 measurement units with high numbers at the top. The airspeed scale range is 80-130 measurement units. During an ADC failure, a red “X” is displayed in place of the airspeed scale.

Figure 3-19: Airspeed Display

The airspeed trend vector is calculated along the aircraft longitudinal axis in a “worm” format to provide analog representation of IAS achieved in ten seconds assuming the instantaneous longitudinal acceleration is maintained.



The pilot-settable airspeed bug is filled-white at all times and geometrically interacts with the white airspeed box pointer. The airspeed bug is annunciated above the airspeed scale with a resolution of one knot indicated airspeed used only as a visual reference and is mutually exclusive with the vertical speed bug.

Figure 3-20: Airspeed Trend

When the airspeed bug setting differs from aircraft airspeed to the extent the bug is off-scale, the bug appears to be “parked” in the direction of the difference with half of the airspeed bug visible.



Airspeed bug is parked in the direction of the difference if airspeed off scale.

Figure 3-21: Airspeed Scale Bug

Table 3-6: Airspeed Bug Limits

Low end	High end
Higher of $1.2 \times V_s$ or 60KIAS	Red-line (V_{NE} , V_{MO} , or M_{MO})

Table 3-7: Airspeed Bug Setting Annunciation and Bug Colors		
	Vertically Integrated Autopilot	
	Without	With
Airspeed bug setting annunciation	White at all times	Green when in airspeed climb or descent mode otherwise white
Airspeed bug	Filled-white at all times	Filled-white when in airspeed climb or descent mode otherwise hollow-white

The airspeed scale background and readout for Part 23 airplanes has coloration as follows.




Figure 3-22: Airspeed Scale FAR Part 23

If in Air Mode, a red low-speed awareness area from the bottom of the scale to V_{S0} . The airspeed readout is red in this area.

- 1) If in Ground Mode, a gray area from the bottom of the scale to V_{S0} . The airspeed readout is gray at 0 (indicating “dead” airspeed) but otherwise white in this area.

- 2) If a valid V_{FE} exists, a white flap-operating area from V_{S0} to V_{FE} . The airspeed readout is white in this area.
- 3) For aircraft without a V_{MO}/M_{MO} :
 - a) A green safe-operating area from V_{S1} to V_{NO} . The airspeed readout is green in this area.
 - b) An amber (yellow) caution area from V_{NO} to V_{NE} . The airspeed readout is amber (yellow) in this area.
 - c) A red high-speed awareness area from V_{NE} to the top of the scale. The airspeed readout is red in this area.
- 4) For aircraft with a V_{MO}/M_{MO} :
 - a) A gray safe-operating area from V_{FE} (if it exists) or V_{S0} to V_{MO}/M_{MO} . The airspeed readout is green in this area.
 - b) A red high-speed awareness area from the lower of V_{MO} or M_{MO} to the top of the scale. The airspeed readout is red in this area.

The airspeed scale background for Part 25 airplanes (Part 25 “Airspeed Scale Type”) has colored regions and readout coloration as follows:

- 1) If in Air Mode with a pilot-input V_{REF} value:
 - a) A red low-speed awareness area from the bottom of the scale to G-compensated $1.1 \times V_{S0}$. V_{S0} is calculated by dividing the pilot-input V_{REF} by 1.23. The airspeed readout is red in this area.
 - b) An amber (yellow) low-speed awareness area from G-compensated $1.1 \times V_{S0}$ to G-compensated $1.2 \times V_{S0}$. The airspeed readout is amber (yellow) in this area.
 - c) If a valid V_{FE} exists, a white flap-operating area from G-compensated $1.2 \times V_{S0}$ to V_{FE} and a gray normal-operating area from V_{FE} to the lower of V_{MO} or M_{MO} . The airspeed readout is white in the flap-operating area and green in the normal-operating area.
 - d) If a valid V_{FE} does not exist, a gray normal-operating area from G-compensated $1.2 \times V_{S0}$ to the lower of V_{MO} or M_{MO} . The airspeed readout is green in this area.

- 2) If in Ground Mode or without a pilot-input V_{REF} value:
 - a) If a valid V_{FE} exists, a white flap-operating area from the bottom of the scale to V_{FE} and a gray normal-operating area from V_{FE} to the lower of V_{MO} or M_{MO} . The airspeed readout is gray at 0 (indicating “dead” airspeed) otherwise white in the flap-operating area and green in the normal-operating area.
 - b) If a valid V_{FE} does not exist, a gray normal-operating area from the bottom of the scale to the lower of V_{MO} or M_{MO} . The airspeed readout is gray at 0 (indicating “dead” airspeed) otherwise white below 60 and green at or above 60 in this area.
- 3) A red high-speed awareness area from the lower of V_{MO} or M_{MO} to the top of the scale. The airspeed readout is red in this area.

The airspeed scale for Part 25 airplanes have additional specific airspeed markings as follows.





Figure 3-23: Airspeed Scale FAR Part 25

- 1) If pilot-input V_{REF} is valid, a white V_S marking at the aircraft’s 1-G V_{S0} or an amber (yellow) V_S marking at V_{S0} corrected for G-

loading, whichever is higher. V_{S0} is calculated by dividing the pilot-input V_{REF} by 1.23

- 2) If enabled (V_{GL} not 0), a “green dot” best glide speed marker at V_{GL} .
- 3) If enabled (V_X not 0), a V_X marking at V_X .
- 4) If enabled (V_Y not 0), a V_Y marking at V_Y .
- 5) If enabled (V_A not 0), a V_A marking at V_A .
- 8) If enabled (V_{MFE} not 0), a “white triangle” maximum flap extension speed marker at V_{MFE} .

3.3.7. Airspeed Display (With EFIS-Coupled)




Airspeed descent to 7,500' with green color and filled airspeed

Figure 3-24: Airspeed Display (with EFIS-Coupled)

3.3.8. Heading Display



Normal Mode



Basic Mode

Figure 3-25: Heading Display

The PFD heading scale across the top of the display is aligned with magnetic north with graduations every 5° with major graduations and heading labels every 10°. These graduations and digits of the heading scale are equally spaced so, at an aircraft roll angle of zero,

they approximately conform to the 3-D PFD background. The heading scale includes a triangular white heading pointer aligned with the longitudinal axis of the aircraft with a slip indicator, which is under the triangular white heading pointer when in SVS mode only.



When the AHRS is in DG mode, the DG symbol appears as shown here.

Figure 3-26: DG Indicated when AHRS in DG Mode

An integral slip indicator is provided and may replace the mechanical slip indicator mounted in the bezel. The slip indicator is a rectangle just below the heading pointer that moves left and right to indicate the lateral acceleration sensed by the AHRS in the same manner as the ball in a mechanical slip indicator.




Figure 3-27: Slip/Skid Indicator

The heading scale has a green, diamond-shaped track pointer aligned with the aircraft's track across the earth. When the aircraft's track is displaced from aircraft heading beyond the boundaries of the PFD screen, the track pointer is drawn at the limit of the heading scale in the direction of the displacement, and the aircraft track value is displayed in a solid green box above the track pointer. The track pointer is not displayed when indicated airspeed is in the noise range (indicated airspeed or groundspeed is less than 30 KIAS).



Figure 3-28: Displaced Heading Bug

The heading scale has a pilot-settable heading bug symbol geometrically interacting with the heading pointer. When the heading bug is set, the value is displayed in a white bordered black box above the heading bug symbol for a period of five seconds. When the heading bug value is displaced from aircraft heading beyond the boundaries of the PFD screen, the heading bug symbol is drawn halved at the limit of the heading scale in the direction of

the displacement, and the heading bug value is displayed in a white bordered black box above the heading bug symbol (Figure 3-28).

When an active waypoint exists, the heading scale includes a magenta, star-shaped waypoint pointer (see Figure 3-25) at a point corresponding with the active waypoint. When the waypoint pointer is displaced from aircraft heading beyond the boundaries of the PFD screen, the waypoint pointer is replaced by a magenta, triangular arrow at either the far-right or far-left limit of the heading scale to indicate the shortest (not necessarily the safest) direction of turn to the active waypoint (Figure 3-28). The waypoint pointer and shortest direction of turn indications turn amber (yellow) in the event of GPS Loss of Navigation caution.

3.3.9. Pitch Scale



Figure 3-29: Pitch Scale

Rotation of the background, pitch scale, and background oriented display elements occur relative to the location of the waterline symbol or Large Aircraft Reference Marks fixed in the center of the display.




Figure 3-30: Pitch Scale Zenith and Nadir Symbols

The pitch scale and single width horizon line, which rotates in conjunction with the background according to the aircraft's roll angle, have increments every 5° with major increments and pitch scale labels every 10°. Increments are equally spaced to approximately

conform to the 3-D PFD background. Pointer bars at the ends of each major increment indicate the direction to the horizon and automatically declutter to present the fewest possible increments needed to unambiguously display pitch attitude. The pitch scale terminates with a zenith symbol (small white circle) at +90° and a nadir symbol (small white circle with “+”) at -90°.

3.3.10. Pitch Limit Indicator




Figure 3-31: Pitch Limit Indicator

An amber (yellow) feathered pitch limit indicator symbol appears at 20 knots indicated airspeed above stall speed.

Table 3-8: Pitch Limit Indicator Appearance Limits

FAR Part 23 airplanes 1-G V_{S1} or V_{S1} corrected for G-loading	Part 25 airplanes: If pilot-input V_{REF} is valid, the higher of the aircraft's 1-G V_{S0} or V_{S0} corrected for G-loading where V_{S0} is calculated by dividing the pilot-input V_{REF} by 1.23.
--	---


The pitch limit indicator is a “feathered” symbol modified to work with either the Flight Path Marker or the Large Aircraft Symbol Reference Marks (Basic Mode or Unusual Attitude Mode). The pitch limit indicator first appears above the applicable reference symbol (either the Flight Path Marker or the Large Aircraft Symbol Reference Marks) and converges upon the applicable reference symbol as indicated airspeed decreases. At five knots indicated airspeed above stall speed, the pitch limit indicator turns red and merges with the applicable reference symbol at stall speed and continues moving downward as indicated airspeed further decreases.

3.3.11. G-Force and Fast/Slow Indicator



G-Force indicator appears in the Normal Mode as depicted or next to the Large Aircraft Symbol Reference Marks (Basic Mode or Unusual Attitude mode) when difference between G-Force and 1-G is greater than 0.3 Gs.

Figure 3-32: G-Force Indicator



Positive telltales appear whenever G-force exceeds 2.5G. Negative telltales appear whenever negative G-force is less than -0.5G. Telltales appear full-time within G-indication area and are removed when AOA Fast/Slow replaces G-indicator.

Figure 3-33: G-Force Indicator Telltale Indications


NOTE:



Press **RESET G (L2)** to reset telltales to zero, unless the aircraft G-limits have been exceeded. If G-limits have been exceeded, reset exceedance in Ground Maintenance Function.

Figure 3-34: RESET G

When landing gear is down and the EFIS is receiving a valid Flight Director Fast/Slow label, the G-Force indicator is replaced by a Fast/Slow indicator, which is a “worm” format providing an analog representation of deviation from a target angle of attack.



The Fast/Slow indicator worm grows in the “F” direction with angles of attack lower than the target; grows in the “S” direction with angles of attack higher than the target; and is decluttered when on the ground.

Figure 3-35: Fast Slow Indicator

3.3.12. Landing Gear Indication

If configured, PFD displays landing gear position as small “tires” below Flight Path Marker or Large Aircraft Symbol Reference Marks.




Figure 3-36: Landing Gear Indication

3.3.13. Turn Rate Indicator



A turn rate indicator is displayed in the upper center of the PFD just below the heading pointer when selected and has standard rate and half standard rate graduations with a horizontal worm magnitude presentation.

Figure 3-37: Turn Rate Indicator

3.3.14. Unusual Attitude Mode

Unusual Attitude Mode is enabled when the pitch attitude exceeds $+30^\circ$ or -30° or bank angle exceeds 65° . Once enabled, the waterline symbol is replaced by large aircraft symbol and the Unusual Attitude Mode remains engaged until pitch attitude returns to within 5° of the horizon and bank attitude returns to within 10° of the horizon. Recovery chevrons tied to the 30° and higher pitch scale indications (both positive and negative) aid in unusual attitude recovery and are a normal part of the pitch scale and are not necessarily tied to unusual attitude mode.

NOTE:

The recovery chevrons are a normal part of the pitch scale but are not necessarily tied to unusual attitude mode.



Figure 3-38: Unusual Attitude Mode

The following features are disabled in unusual attitude mode:

- | | |
|--------------------------------------|--|
| 1) Terrain and obstruction rendering | 8) Active Waypoint symbology |
| 2) CDI | 9) Mini Map |
| 3) VDI | 10) Traffic thumbnail |
| 4) Flight Path Marker | 11) If in Basic Mode, PFD reverts to Normal Mode |
| 5) Highway in the Sky boxes | 12) If in Zoom mode FOV, PFD reverts to normal FOV |
| 6) Atmospheric perspective | 13) Runways |
| 7) Analog and digital AGL indication | |

3.3.15. PFD Background

The PFD has a 3-D background generated from terrain elevation and obstruction elevation data stored in electronic memory. The “actual horizon” displayed on the PFD is based upon the higher of terrain within 90NM or a horizon calculated using a visible horizon equation. Thus, the relative elevation of terrain and obstructions with respect to aircraft altitude and performance is observed by reference to the primary flight information pitch ladder and flight path marker.

The background has two pilot-selectable field-of-view (FOV) modes, wide FOV mode (approximately 70°) and narrow FOV mode

(approximately 35°). In Unusual Attitude Mode, wide FOV mode is automatically selected.

A blended-tone sky is displayed in conjunction with terrain. The sky fades from light blue at the horizon to dark blue at the top of the display to simulate atmospheric perspective and enhance the 3-D presentation.



Figure 3-39: PFD Terrain and Obstructions

Terrain and obstruction rendering uses hidden surface removal techniques, while terrain/sky rendering uses atmospheric perspective techniques. Terrain with obstruction rendering is collectively pilot-selectable to declutter the display (*independent declutter of obstructions is not possible.*) Terrain and obstruction rendering is disabled in Basic Mode, Unusual Attitude Mode, and during any reversionary mode. In Unusual Attitude Mode, the blue-brown boundary line of the background decouples from the pitch scale at high pitch angles so a sliver of the blue-brown boundary line always remains visible to give guidance to the horizon.

The terrain ahead of the aircraft is shown conformally with the artificial horizon in the correct scale and perspective for the aircraft's current position and altitude. Worldwide terrain coverage is provided in each IDU and is shown with a resolution as in Table 3-9.

Terrain is displayed ahead of the aircraft using a grid and simulates “atmospheric perspective” (terrain lines fade into the background “ground” color as they recede into the distance).

At latitudes greater than 75°, no grid lines are shown. To keep the grid spacing relatively consistent, at latitudes between 45° and 75°, the longitude spacing is increased according as in Table 3-9.

Table 3-9: LAT-LON Resolution Boundaries

Latitude Range	Longitude Grid Spacing	Heading Boundary	
		Pole	Equator
0° to 46°	24 arc-seconds		
46° to 62°	48 arc-seconds	46°	45°
62° to 70°	72 arc-seconds	62°	61°
70° to 74°	96 arc-seconds	70°	69°
74° to 75°	120 arc-seconds	74°	73°

NOTE:

There is a one-degree dead band to prevent grid flicker while flying along one of the boundary latitudes. The grid space switching changes at one degree less latitude when flying towards the Equator than it does when flying toward the Poles.

Table 3-10: Terrain and Obstruction Rendering Levels

Feature	Terrain Rendering Color	Notes
SVS BASIC	Shades of brown for non-water terrain. Deep blue denotes areas of water and takes precedence over the shades of brown.	Amber and red colors not used for normal display of terrain.
SVS TAWS	Shades of olive when at or below 100 feet less than aircraft altitude. Shades of brown when above 100 feet than aircraft altitude. Deep blue denotes areas of water and takes precedence over other colors. TAWS coloring of FLTA alert or warning cells.	Amber and red colors used for normal display of terrain. Amber and red colors used to show terrain areas causing FLTA alerts.
None	No terrain or obstructions are shown. Neither, SVS BASIC or SVS TAWS is selected.	

When terrain and obstruction rendering is deselected or disabled, the PFD background is a conventional blue over brown attitude display presentation without atmospheric perspective. Additionally, terrain may be deselected on the PFD and retained on the ND MAP.



Figure 3-40: PFD with Terrain Deselected




Figure 3-41: MFD with Terrain Selected

WARNING:

DO NOT USE THIS EFIS FOR TERRAIN-FOLLOWING FLIGHT. DO NOT ATTEMPT TO NAVIGATE USING THE TERRAIN DEPICTION. ALWAYS ADHERE TO PUBLISHED NAVIGATIONAL INSTRUMENT PROCEDURES AND NAVIGATIONAL CHARTS IN ALL FLIGHT CONDITIONS.

Towers, antennas, and other obstructions such as buildings and manmade structures are shown on the PFD display as vertical amber (yellow) lines. Obstructions are conformal in location and size and only shown in conjunction with terrain regardless of altitude. Obstructions representing a collision hazard are annunciated aurally and with a caution or warning flag. Obstructions causing TAWS alarm are depicted as a flashing amber and red triangle. All vertical amber (yellow) lines in Figure 3-42 are the obstructions.



Towers, antennas, and obstructions representing a collision hazard cause an annunciation of “Obstruction” and aural annunciation of “Caution, Obstruction.”



Obstructions without Hazardous Condition

Obstructions Creating an OBSTRUCTION Caution

Figure 3-42: PFD with Obstructions

WARNING:

MANY TOWERS, ANTENNAS, STRUCTURES, AND OBSTRUCTIONS ARE NOT IN THE DATABASE.

NOTE:

The obstruction data is provided by Jeppesen and must be updated each 28 days to maintain current database information.

3.3.16. Flight Path Marker (Velocity Vector)






Figure 3-43: Flight Path Marker

The flight path marker appears on the background to coincide with the aircraft's actual flight path as projected on the outside world. The flight path marker is laterally displaced parallel to the horizon with respect to the center of the display to account for the difference between aircraft track and heading, and is vertically displaced perpendicular to the horizon to account for aircraft climb or descent angle. Because the flight path marker is used in conjunction with a HUD, the flight path marker utility normally associated with a HUD is achieved. When the flight path marker is displaced to the extent it would interfere with heading, altitude, or airspeed indications, it is removed from the display as seen in Figure 3-44.



Flight Path Marker nearing Airspeed tape due to strong crosswind



Flight Path Marker removed due to excessive crosswinds from the right

Figure 3-44: Flight Path Marker Views

When caged, a flight path marker “ghost” is displayed at the flight path marker’s proper lateral location. When the ghost is displaced to the extent it interferes with heading, altitude, or airspeed indications, the ghost is removed from the display.




Figure 3-45: Flight Path Marker Ghost

Table 3-11: Flight Path Marker Behavior

Table 3-11: Flight Path Marker Behavior	
	Crab Angle
Cage (Become laterally centered on the display)	When exceeding 15° (wide FOV) or 7.5° (narrow FOV mode)
Uncage (Resume lateral floating)	When returning below 13° (wide FOV mode) or 6.5° (narrow FOV mode)
Flight path marker movement is dampened by reference to aircraft pitch and heading so not to deviate from pitch or heading at a rate greater than 1°/sec.	



Figure 3-46: Flight Path Marker Absent (Unusual Attitude Mode)

The flight path marker is not shown in Basic Mode. In Unusual Attitude Mode, it disappears to allow the pilot to concentrate on the

Large Aircraft Symbol Reference Marks for unusual attitude recovery. In Unusual Attitude Mode, the flight path marker disappears to allow the pilot to concentrate on the Large Aircraft Symbol Reference Marks for unusual attitude recovery. In reversionary mode 1 (GPS failure), the flight path marker changes to a light gray color after one minute to indicate degraded performance (Figure 3-47). Flight path marker at low speed (indicated airspeed < 45 KIAS) behavior further depends upon whether the aircraft is in flight or on the ground.




Figure 3-47: PFD with GPS Failure after 1 Minute

3.3.17. Bank Angle Scale



With Bank Scale




Without Bank Scale

Figure 3-48: PFD Bank Scale

The Bank Scale and Roll Pointer are centered on the Large Aircraft Symbol Reference Marks in Basic or Unusual Attitude Modes.

When bank angle scale decluttering is selected, a bank angle scale and sky pointer are displayed when the bank angle exceeds 2.8°. With decluttering selected, appearance of the bank angle scale and roll pointer are dampened based upon magnitude and time to prevent nuisance appearances.



When decluttering is not selected, the bank angle scale and sky pointer appear full time with level, 10°, 20°, 30°, 45°, and 60° marks on left and right sides. The bank angle scale and roll pointer are centered upon the Large Aircraft Symbol Reference Marks (Basic Mode or Unusual Attitude Mode).


Figure 3-49: Bank Angle

3.3.18. Timer Indication

When selected, a countdown or count-up timer is only displayed above Fight Path Marker or Large Aircraft Symbol Reference Marks.




Normal Mode



Basic Mode

Figure 3-50: Timer

3.3.19. Marker Beacon Symbolology



Normal Mode

Basic Mode

Figure 3-51: Marker Beacons

3.3.21. Course Deviation Indicator (CDI)










Figure 3-54: Course Deviation Indicator

Table 3-12: CDI Behavior and Color

CDI Pointer and Condition	Color or Behavior
Full Scale Deflection	Flash
When Slaved to GPS/SBAS	<p>Scale is appropriate FSD value for mode of flight:</p> <p>Enroute: ± 2NM</p> <p>From Enroute to Terminal: Change from ± 2 NM FSD to ± 1 NM FSD over distance of 1 NM; start transition when entering terminal mode.</p> <p>From Terminal to Enroute: Change from ± 1 NM FSD to ± 2 NM FSD over distance of 1 NM; start transition when entering enroute mode.</p> <p>From Terminal to Approach: If VTF, switch immediately.</p> <p>Otherwise, change from ± 1 NM FSD to approach FSD over distance of 2 NM; start transition at 2 NM from FAWP.</p> <p>From Approach to Terminal: Change to ± 1 NM.</p>

Table 3-12: CDI Behavior and Color

CDI Pointer and Condition	Color or Behavior
	From Departure to Terminal: If initial leg is aligned with runway, change from ± 0.3 NM FSD to ± 1 NM FSD at the turn initiation point of the first fix in the departure procedure.
When Slaved to GPS/SBAS (with GPS Loss of Navigation)	Amber (Yellow)
Normal conditions	Magenta
In sources other than FMS	Angular scale annunciation
Navigation source is Localizer (Course error exceeds 105°)	Reverse sensing
When lateral deviations are in a failed state	Red "X" displayed over CDI
EFIS not coupled with autopilot	
	Selected NAV source FMS2
	Selected NAV source VOR1
	Selected NAV source VOR2
EFIS coupled system with autopilot	
	Holding the wings level*
	Tracking HDG BUG**
	LNAV in ARM mode**
	LNAV captured**

Notes: *No positive autopilot feedback

**Positive autopilot feedback

3.3.22. OBS Setting of CDI

In automatic mode, the system controls the scale and OBS setting according to the requirements of GPS/SBAS (TSO-C-146C). The selected navigation source is annunciated below the CDI as follows:

- 1) NAV: **FMS1 / FMS2**
- 2) NAV: **VOR1 / LOC1**
- 3) NAV: **BC1 /BC2** (annunciated instead of LOC1/2 when course error exceeds 105°)
- 4) NAV: **VOR2 / LOC2**
- 5) Heading/Roll-Steering Sub-Mode

Heading/roll-steering sub-mode annunciation appears immediately right of the selected navigation source annunciation and displays:

- 1) HDG: **LVL** (Wing-Leveling Sub-Mode Guidance)
- 2) HDG: **LNAV** (LNAV Sub-Mode Guidance)
- 3) HDG: **BUG** (Heading Bug Sub-Mode Guidance)
- 4) HDG: **---** (Failure Sub-Mode)

3.3.23. No Autopilot or Fully-Integrated Autopilot CDI



Figure 3-55: CDI No Autopilot or Fully-Integrated Autopilot

In an installation without an autopilot or with a fully-integrated autopilot, the heading/roll-steering sub-mode annunciation is decluttered from the CDI. Therefore, the shaded background of the CDI only falls behind the CDI scale. An abbreviated navigation source annunciation (without “NAV:”) appears above the top left corner of the CDI scale. The heading/roll-steering sub-mode annunciation does not appear, as it is not required with autopilot mode annunciations or when no autopilot is installed.

3.3.24. Vertical Deviation Indicator (VDI)

The vertical deviation indicator (VDI) on the right side displays vertical deviation for the selected vertical navigation source for displaying descent profile but disappears in Unusual Attitude Mode.




Figure 3-56: Vertical Deviation Indicator

- 1) **LPV Mode and LPV1 or LPV2:** When descending on final approach segment in LPV mode. GPS Altitude used to generate VDI; pilot may follow guidance to LPV minima regardless of temperature.
- 2) **LNAV Mode and VNAV1-G or VNAV2-G:** When descending on final approach segment in LP, LNAV/VNAV, and LNAV or RNP modes when using GPS VNAV. GPS Altitude used to generate VDI; pilot may follow guidance to LNAV minima regardless of temperature.
- 3) **LNAV Mode and VNV1-B or VNV2-B:** Default FMS barometric VNAV mode. Using barometric altitude to generate the VDI, pilot may follow guidance to LNAV minima as long as the specified temperature is within limits.
- 4) **GS1 or GS2:** Glideslope receiver #1 or #2 as indicated. Pilot follows guidance to published Barometric DH.

Table 3-13: Vertical Deviation Indicator Behavior

Source (Below VDI)	Behavior/Condition	Pointer Color
FMS	Conforms to the VDI display	Magenta
Glideslope	Source must be valid when a valid glideslope is received.	Magenta
LPV or VNAV mode	Source is valid if:	Magenta

Table 3-13: Vertical Deviation Indicator Behavior

Source (Below VDI)	Behavior/Condition	Pointer Color
	<p>On VNAV descent segments when approaching Top of Descent point to provide descent anticipation as long as the following are true:</p> <ol style="list-style-type: none"> 1) On VNAV descent segments; OR 2) If vertical deviations on VNAV level segments option is enabled, on VNAV level segments; OR 3) If vertical deviations on VNAV level segments option is disabled, when approaching the Top of Descent point to provide descent anticipation; <p>Providing:</p> <ol style="list-style-type: none"> 1) Aircraft is within 2NM or twice the full scale deflection for the mode of flight (whichever is greater) of the lateral navigation route; AND 2) Aircraft is in TO operation relative to the active VNAV waypoint (i.e., taking into account VNAV offsets); AND 3) If on final approach segment, aircraft is within a 35° lateral wedge of the azimuth reference point (either GARP or MAWPT + 10,000 ft.). 	
LPV,VNV-G	During GPS Loss of Navigation or GPS Vertical Loss of Navigation	Pointer and Text Color Amber (Yellow)



Figure 3-57: Vertical Deviation Indicator Color during GPS/SBAS LON or VLON

3.3.25. Vertical Deviation Indicator (EFIS Coupled)

When vertically integrated with an autopilot (either fully integrated or partially integrated) through glideslope mode discrete input with the glideslope mode engaged, the selected vertical navigation source is green indicating the autopilot is vertically coupled to the selected vertical navigation source. Otherwise, the selected vertical navigation source is white.



Figure 3-58: EFIS Coupled Vertically with Glideslope Mode Engaged

3.3.26. Highway in the Sky/Skyway

When not decluttered, the PFD displays the active navigation route or manual OBS course in 3-D with a series of skyway boxes, which overly the flight plan route at a desired altitude and provide lateral and vertical guidance. See Section 7 IFR Procedures for details.



Coupled to Skyway



Uncoupled to Skyway

Figure 3-59: Highway in the Sky

3.3.27. Active Waypoint and Waypoint Identifier




Figure 3-60: Active Waypoint

The PFD displays the active waypoint symbol as a magenta “tethered balloon” consisting of:

- 1) an “X” depicted at the ground location of the active waypoint;
- 2) a hoop or “tethered balloon” (for fly-over waypoints) or “tethered diamond” (for fly-by waypoints) depicted at the VNAV altitude or at aircraft altitude (if there is no VNAV altitude), and
- 3) a line connecting the “X” and the hoop.

The “X” and the connecting line are not shown if no ground elevation information is encoded with the NavData waypoint information (e.g.,

terminal and enroute fixes). The active waypoint symbol is drawn using the hidden surface removal techniques of the terrain and obstruction rendering so an active waypoint behind terrain appears to be so. The active waypoint symbol disappears in Unusual Attitude Mode but turns amber (yellow) in the event of GPS Loss of Navigation caution.

The identifier of the waypoint along with the bearing and distance to the waypoint is displayed in the lower right corner of the PFD in magenta. If a target altitude is not set and the active waypoint has a VNAV altitude associated as the example above, the identifier includes a display of the VNAV altitude.

NOTE:

Only the active waypoint is shown on the PFD display. Subsequent waypoints in a route are displayed sequentially as the current active waypoint is passed. With terrain turned off, the active waypoint is always visible regardless of distance.

If the active waypoint is beyond the lateral limits of the screen, the magenta waypoint direction pointer (i.e., magenta triangle) on the directional scale indicates shortest direction of turn to the waypoint.

If the waypoint is only a hoop hanging in space, it is a fix and not directly associated with a NAVAID on the ground (e.g. VOR, NDB, user waypoint, or airport).

If the waypoint X disappears behind terrain on the PFD, there is terrain between the aircraft present position and the waypoint.

3.3.28. Mini Map



Figure 3-61: Mini Map

Table 3-14: Mini-Map Behavior (When not Decluttered)		
VOR Pointer, Active Leg, Ownship Symbol	Color	Condition
VOR 1	Cyan	When Valid
VOR 2	Green	When Valid
Active Leg (GPS/SBAS normal)	Magenta	
Active Leg (GPS/SBAS LON condition)	Amber (Yellow)	
Ownship Symbol (Figure 3-64)	White	
Mutually exclusive with the Analog AGL Indicator		
Mini-Map disappears in Unusual Attitude Mode		
Mutually exclusive with Traffic Thumbnail		



Cyan VOR #1



Green VOR #2

Figure 3-62: Mini Map VOR Symbology




3.3.29. Runways



Figure 3-63: Runways

The PFD displays airport runways in a 3-D manner. Upon activation of a DP, VFR approach, IFR approach, or STAR procedure, runways for the airport associated with the procedure, as well as, runways associated with the three nearest airports (computed by TAWS algorithms) are displayed. Runways are displayed with hidden surface removal techniques of the terrain and obstruction rendering, so runways behind terrain appear to be so. Runways are based on characteristics in the navigation database, including elevation, position, orientation, length, and width, and displayed as defined in Table 3-15.

Table 3-15: Runway Drawing Criteria

Feature	Color	Notes
Runway markings, aiming point markings, centerline, designation, and displaced threshold arrows	Dark gray 	According to characteristics from navigation database, e.g., including position, orientation, length, and width.
Runway markings	Medium gray 	
Landing portion of selected runway.	Light gray 	Taking into account displaced threshold data.
Runway markings for selected runway	Lighter gray than light gray.	

3.4. Navigation Display Symbolology

Navigation Display is presented in a variety of formats, including:

- | | |
|--|--|
| 1) Moving Map | 6) Datalink (See Datalink Appendix) |
| 2) Conventional HSI | 7) WX RDR (See Weather Radar Appendix) |
| 3) Navigation Log | 8) Video (See Video Appendix) |
| 4) Strikes (See WX-500 Lightning Strikes Appendix) | |
| 5) Traffic (See Traffic Appendix) | |

3.4.1. Ownship Symbolology



Figure 3-64: Ownship Symbolology

3.4.2. Moving Map



Figure 3-65: Basic Moving Map



NOTE:

When selected, latitude/longitude is displayed below the ownship symbol.

Figure 3-66: Latitude/Longitude Display



Figure 3-67: Moving Map with Instrument Approach



Figure 3-68: North-Up Arc Mode



Figure 3-69: North-Up Centered Mode



Figure 3-70: Heading-Up Centered Mode

3.4.3. Compass Rose/ND Boundary Circle Symbol

In Heading Up mode, the magnetic digital heading readout and pointer are aligned with the longitudinal axis of the ownship symbol.



Figure 3-71: Compass Rose/ND Boundary Circle Symbol

3.4.4. Air Data and Groundspeed



Figure 3-72: Air Data and Groundspeed

The following are displayed in the upper left corner of the ND:

- 1) **Wind:** Information consists of the following readouts:
 - a) Direction in degrees;
 - b) Speed in knots;
 - c) Crosswind component in knots; and
 - d) Graphical wind vector arrow oriented to correspond to the ND orientation.

NOTE:

Wind information is not shown when indicated airspeed is in the noise range of less than 30 knots, when the aircraft is in ground mode, nor when the AHRS is in DG mode.

- 2) **Outside Air Temperature:** Digitally in degrees C or F (as configured).
- 3) **International Standard Atmosphere (ISA):** Difference between ISA temperature and current outside air temperature is displayed digitally in Degrees C or F (Negative values = less than Standard OAT). Decluttered if the "Show ISA Temperature Flag" is disabled in EFIS limits.
- 4) **Density Altitude:** Digitally in feet. Decluttered if "Show Density altitude Flag" is disabled in EFIS limits.

- 5) **True Airspeed:** Digitally in knots. Decluttered if “True Airspeed Flag” is disabled in EFIS limits.
- 6) **Groundspeed:** Digitally in knots.

3.4.5. Clock/Options

The following are displayed in the upper right corner of the ND.



Figure 3-73: Clock/Options

Table 3-16: Clock/Options		
Feature	Options	Notes
Zulu Time or Local Offset	hh:mm:ssZ hh:mm:ssL	Synchronized with GPS/SBAS constellation
Declutter Mode	DCLTR A DCLTR M	= Automatic declutter mode = Manual declutter mode
Terrain Status	Enabled or Disabled	Indicated by absence or presence of terrain











3.4.6. Navigation Data



Figure 3-74: Navigation Data and Airspace Depiction

The ND displays navigation data in correct relationship to the ownship symbol with navigation data symbols, which include airport symbols, NDBs, and user waypoints. High altitude and low altitude airways may be shown.

Table 3-17: Navigation Symbology

	IFR Airport		NDB
	VFR Airport		FIX
	VORTAC		High Altitude Airway
	DME only or TACAN		Low Altitude Airway
	VOR		User Waypoint








The ND has manual and automatic decluttering of navigation data. The following six levels of automatic declutter are based on the number of navigation data symbols drawn in the current ND format and range:

- 1) **Airports:** Manually or automatically decluttered. In automatic declutter mode, large airports (IFR procedure and longest runway and automatically adjusted threshold needed to achieve desired symbol count) are always shown; IFR airports that are not large airports are shown in levels 1, 2, 3, and 4; and VFR airports are shown in levels 1, 2, and 3.
- 2) **VORs:** Manually or automatically decluttered. In automatic declutter mode, VORs are shown in levels 1, 2, 3, 4, and 5.
- 3) **NDBs:** Manually or automatically decluttered. In automatic declutter mode, NDBs are shown in levels 1 and 2. Both enroute and terminal NDBs are shown.
- 4) **FIXES** (including user waypoints): Manually or automatically decluttered. In automatic declutter mode, enroute fixes are shown in level 1. Terminal fixes are manually selected and not

shown in automatic declutter mode. Enroute fixes, terminal fixes, and user waypoints may be manually decluttered separately from each other.

- 5) **High Altitude Airways:** Manually selected.
- 6) **Low Altitude Airways:** Manually selected.

Table 3-18: Airspace Depiction

Table 3-18: Airspace Depiction		
Type of ARINC 424 Airspace		Vertical Limits
	Single pixel, dashed lines	More than $\pm 500'$
	Single pixel solid lines	Within 500'
	Double pixel solid lines	Within airspace vertical limits
Type of ARINC 424 Airspace		Color of Airspace
	Class C, Control Area, TRSAs, Class D	Green
	Class B, TCAs (where applicable)	Blue
	Caution, Danger, MOAs, Training, Warning, and Unknown Areas	Amber (Yellow)
	Prohibited, Restricted, and Temporary Flight Restricted Areas (with Datalink)	Red

3.4.7. Analog Navigation Symbology

When selected, the ND displays analog navigation symbology as described in § 3.4.2. The ND can display a conventional HSI symbology overlay, including a selected course needle, lateral deviation indicator, and “TO FROM” indicator. The size of the HSI depends on Arc or Center modes to ensure a full HSI is always displayed.






Figure 3-75: HSI in Arc and Center Modes

3.4.8. Borders

If selected, national and United States state borders are drawn at all map scales. Borders are white if the background includes terrain.



Without State Borders drawn



With State Borders drawn

Figure 3-76: Borders

3.4.9. Terrain/Obstructions



Figure 3-77: Terrain/Obstructions

Terrain is displayed on the ND in correct relationship to the ownship symbol using color to show relationship to aircraft altitude.

Table 3-19: Terrain Color

Based on Aircraft Altitude	Color	Notes
Terrain at or below 100 feet less than aircraft altitude	Olive shades	Terrain slope determines shade.
Terrain above 100 feet less than aircraft altitude	Brown shades	
FLTA alerts	Amber and Red	See Section 8 TAWS

Table 3-19: Terrain Color

Based on Aircraft Altitude	Color	Notes
Water at all altitudes	Deep Blue	Takes precedence over other colors.


Figure 3-78: Obstructions

Obstructions are displayed on the ND in correct relationship to the ownship symbol using color to show relationship to aircraft altitude.

Table 3-20: Obstructions

Lateral Distance Away	8.5 NM or greater	Not depicted
	8.5 NM or less	See below
Vertical Criteria	More than 2000' below aircraft	Not depicted
	Within 2000' but more than 500' below aircraft	Amber
	Within 500' but below aircraft	Light red
	At or above aircraft altitude	Deep red

Terrain and obstruction rendering is pilot-selectable to declutter the display by deselecting terrain (*independent declutter of obstructions is not possible*). Furthermore, terrain and obstruction rendering is disabled when:

- 1) The GPS/SBAS sensor is failed; OR

- 2) When the ADC is failed; OR
- 3) When the horizontal figure of merit exceeds the greater of 0.3NM or the horizontal alarm limit for the mode of flight.

NOTE:

See Section 8 Terrain Awareness Warning System for obstructions causing TAWS alarms and depiction of separate symbology.

3.4.10. Pan Mode



Figure 3-79: Pan Mode

The ND screen has a pan mode to view map details along the route of flight and at the intended destination or alternate destination while either in flight or on the ground. When pan mode is active, use labeled buttons to move the pan mode location North, South, East, and West in a North-up, centered orientation. Upon entering the pan mode, the heading pointer, track pointer, lubber line, waypoint pointer, analog navigation symbology, and field of view lines are removed from the display.

Figure 3-79 shows the line with bearing and distance from the map center to the aircraft's current position in white. When the aircraft is more than 0.5 NM away. When panning, the nearest displayed airport, VOR, NDB, or fix within the inner range ring is highlighted with a flashing circle. Buttons are labeled to allow for viewing or hiding waypoint information. When exiting the pan mode, all previous settings are restored as before pan mode was enabled.

3.4.11. Start Point

Activation of **NRST** or Direct-To function creates and activates a flight plan from the present position to the selected waypoint. A waypoint named “START” is placed at the current aircraft location when the flight plan is created.




Figure 3-80: Start Point

3.4.12. Altitude Capture Predictor/Top of Descent




Figure 3-81: Top-of-Descent or Top-of-Climb

When a selected altitude or VNAV is specified on the PFD, T/D marks correct point on the flight plan path at which descent must be commenced and contains location on the flight plan path with indication of the glidepath angle used to calculate position. After passing Top of Descent along the lubber line, altitude is captured and shown as a green arc located ahead of the aircraft. The arc marks the bottom-of-descent or top-of-climb point.

3.4.13. Projected Path

When the aircraft is in a bank angle, a projected path emanates from the ownship symbol. This curving path is based upon the aircraft

bank angle and groundspeed as it projects one minute into the future up to a maximum of 180° of turn. The projected path or “noodle” assists in course interception and making small adjustments to bank angle for proper roll out.



Figure 3-82: Projected Path

3.4.14. Active Flight Plan Path/Manual Course/Runways

When there is an active flight plan and the GPS/SBAS OBS setting is automatic, the flight plan path is shown on the ND in its correct relationship to the ownship symbol. The active flight plan path depiction meets all the requirements of GPS/SBAS path definition and matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in automatic OBS mode, skyway boxes, and mini-map). The fly-over waypoint symbol is distinct from fly-by waypoints and consists of the waypoint symbol within a circle. When there is a parallel offset, the active flight plan path depicts the parallel offset path, and the original flight plan path is shown with haloed gray dashed lines. Top of descent symbols with an indication of glidepath angle are shown where VNAV descents are predicted to commence.


When there is an active waypoint and the GPS/SBAS OBS setting is manual, the manual course through the waypoint is shown as a pointer centered on the waypoint. The pointer matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in manual OBS mode, skyway boxes, and mini-map).

The active flight plan path's active leg/manual course and active waypoint are magenta but turn amber (yellow) in the event of a GPS Loss of Navigation caution.


The ND displays airport runways in correct relationship and scale to the ownship symbol. Upon activation of a DP, VFR approach, IFR approach, or STAR procedure, runways for the airport associated with the procedure, as well as runways associated with the three nearest airports, are displayed.

3.4.15. FOV Indication

The ND background indicates the FOV with a set of segmented gray lines leading out from the ownship symbol in either 35° or 70° angles depending on the zoom mode setting on the PFD.



Normal Field of View



Narrow Field of View

Figure 3-83: Field of View



3.4.16. Range




Figure 3-84: Range

The white range ring is centered on the aircraft's position to quickly estimate distances. Distance (in NM) from the aircraft to the ring is a white number overlaying at the 6 o'clock position of the ring. The range ring is half the distance to the directional scale. Consequently, when the range ring shows a distance of 5NM, the directional scale is 10NM. Scroll **1** to set the overall map scale to .5, 1, 2.5, 5, 10, 25, 50, 100, or 200NM.

3.5. HSI Screen



Normal Cyan Pointer



**GPS Loss of Navigation
Amber (Yellow) Pointer**

Figure 3-85: HSI Pointer Color

When selected, the ND displays conventional HSI symbology, including a selected course needle, lateral deviation indicator, and “TO-FROM” indicator. Navigation source indication and OBS setting are displayed in the top center of the HSI in the same color as the course needle. HSI pointer color is:

- 1) Magenta (if FMS is the selected navigation source);
- 2) Cyan (if VLOC1 is the selected navigation source);
- 3) Green (if VLOC2 is the selected navigation source); or
- 4) Yellow when HSI is slaved to GPS/SBAS and there is a GPS Loss of Navigation condition.

The ownship symbol (Figure 3-64) is centered and points straight up on the HSI. The HSI has a compass rose aligned with either magnetic North or True North depending on the True North discrete input. When the HSI NAV source fails (FMS, VOR1, or VOR2), a red “X” is displayed in place of the HSI deviations.

When selected, VOR1, VOR2, and ADF navigation are displayed as seen in Figure 3-86 with the magenta single line FMS1 showing a course of 218°, a cyan single line VOR1 needle showing 277° and 18.2 DME to the station, and a green double line VOR2 needle showing a bearing of 268° and 19.1 DME to the station. The ADF is tuned to an NDB with a bearing of 332° to the station. When the signal is invalid, the associated pointer is not shown.

3.5.1. HSI Screen VDI




Figure 3-86: HSI with VDI and Glideslope

A vertical deviation indicator (VDI) appears when the VDI source is valid to display vertical deviation information for the selected navigation source. When the selected vertical source is FMS, the VDI displayed on the HSI has the same behavior as the VDI displayed on the PFD except of the VDI source displayed on the top of the VDI to avoid clutter with waypoint information below:

- 1) VNV1-B: Default FMS barometric VNAV mode.
- 2) VNV2-B: Default FMS barometric VNAV mode.
- 3) GS1: Glideslope #1
- 4) GS2: Glideslope #2

3.5.2. CDI Scale




Figure 3-87: HSI CDI Scale




Figure 3-88: HSI CDI Scale (with LON Condition)

3.5.3. Analog Navigation Symbolology



Figure 3-89: Analog Navigation Display VOR1 and VOR2

When selected, the HSI displays analog (VOR1 [cyan] and VOR2 [green]) navigation symbolology with an RMI pointer format overlaid upon the HSI. When the signal is invalid, the associated pointer is not shown. When the signal is valid for VOR1 and VOR2, a bearing and distance display for the selected VOR pointers appears at the bottom of the display in the same color of the respective pointer.

If a DME channel is in hold mode, the associated distance readout is displayed in amber (yellow) rather than blue or green, and “H” is above the distance readout.



Figure 3-90: HSI Bearing Distance Readout with DME in HOLD

Valid Marker Beacon discrettes are displayed on the PFD and ND HSI with appropriate coloring markings (Figure 3-91). Only during a built-in-test may more than one marker beacon be active. The display of marker beacons is disabled when the NAV source is FMS.



Figure 3-91: HSI with Marker Beacon Displayed

3.5.4. Compass Rose Symbols



Normal Mode



True North Mode

Figure 3-92: Compass Rose

When selected, a digital heading readout and pointer aligned with the longitudinal axis of the ownship symbol appear on the compass

rose boundary circle. If referenced to magnetic North, the heading readout uses the degree (°) symbol. Otherwise, a stylized True North (T) symbol is used. A green diamond-shaped track pointer aligned with the aircraft's track across the earth appears on the compass rose when groundspeed is less than 30 knots. The pilot-settable heading bug geometrically interacts with the heading pointer on the compass rose. A magenta, star-shaped waypoint pointer is displayed on the heading scale at a point corresponding with the active waypoint but turns amber (yellow) in the event of GPS Loss of Navigation caution.

NOTE:

See Section 7 IFR Procedures for description of the following heading modes with the ADAHRS and EFIS:

- 1) ADAHRS Slaved—EFIS Magnetic North
- 2) ADAHRS Slaved—EFIS True North
- 3) ADAHRS Free/"DG"—EFIS Magnetic North
- 4) ADAHRS Free/"DG"—EFIS True North

3.5.5. Air Data and Groundspeed

Air data and groundspeed are displayed as specified in § 3.4.4.



Figure 3-93: HSI Display Air Data and Groundspeed with Marker Beacon

3.5.6. Clock/Options



Figure 3-94: HSI Clock

The following are displayed in the upper right corner of the HSI:

- 1) **Zulu or LCL Time:** As specified in § 3.4.5.
- 2) **Traffic:** If configured as specified in Traffic Appendix.
- 3) **Datalink:** If configured as specified in Datalink Appendix.
- 4) **Weather Radar:** If configured Weather Radar Appendix.

3.5.7. Fuel Totalizer/Waypoint Bearing and Distance Functions

Fuel totalizer, waypoint bearing, and waypoint distance are displayed in the lower right corner of the HSI.



Figure 3-95: Fuel Totalizer/Waypoint Bearing and Distance Functions

Table 3-21: Fuel Totalizer/Waypoint Bearing and Distance Functions

Function	Conditions	Type Symbols Options
TO Waypoint	<p>If there is an active flight plan, waypoint type, identifier, range, bearing, and ETE/ETA for the active waypoint (“TO” waypoint) are shown.</p> <p>Waypoint information is magenta but turns amber (yellow) with GPS Loss of Navigation caution.</p>	<p>ETA or ETE</p> <p>Degree (°) symbol or True North (T) symbol</p>
DEST Waypoint	<p>If there is an active flight plan, waypoint type, identifier, range, and ETE/ETA for the last waypoint (“DEST” waypoint) are shown.</p> <p>If the active waypoint is not the last waypoint, range and time to destination waypoint are based on the flight plan route. Otherwise, range and time are based on a direct geodetic path.</p> <p>Waypoint information is white but turns amber (yellow) with GPS Loss of Navigation caution.</p>	<p>ETA or ETE</p> <p>Degree (°) symbol or True North (T) symbol</p>
Range	<p>Based on instantaneous fuel flow, fuel remaining and groundspeed are shown immediately below “DEST” waypoint information for easy comparison.</p>	
Endurance	<p>Based on instantaneous fuel flow and fuel remaining is shown.</p>	

3.6. Navigation Log

05:41:21L GS 99		FUEL 91.9GAL FLOW 21.50GPH				
WAYPOINT	UNAV/OFFSET	PATH	DIST	ETE	ETA	FUEL
◆	KLAX				--:--	
◆	*KCPH	B-	099*	8.8mi	0:05	
◆	KLGB	B-	117*	5.8mi	0:03	90
◆	KTDA	B-	251*	9.0mi	0:05	88
◆	KAUX	B-	175*	24.0mi	0:14	87
◆	KCRQ	B-	091*	59.2mi	0:35	81
◆	KRNH	B-	092*	19.1mi	0:11	69
◆	L88	B-	054*	32.5mi	0:19	64
◆	KPSP	B-	332*	35.3mi	0:21	57
◆	KBNG	B-	275*	18.0mi	0:10	50
◆	KONT	B-	268*	38.2mi	0:23	46
◆	KLAX	B-	247*	40.7mi	0:24	38
					08:37	29

05:44:43L GS 103		FLOW 21.8GPH				
WAYPOINT	UNAV/OFFSET	PATH	DIST	ETE	ETA	
◆	KLAX				--:--	
◆	*KCPH	B-	099*	8.8mi	0:05	95:50
◆	KLGB	B-	117*	5.8mi	0:03	95:53
◆	KTDA	B-	251*	9.0mi	0:05	95:58
◆	KAUX	B-	175*	24.0mi	0:14	96:12
◆	KCRQ	B-	091*	59.2mi	0:34	96:47
◆	KRNH	B-	092*	19.1mi	0:11	96:58
◆	L88	B-	054*	32.5mi	0:18	97:17
◆	KPSP	B-	332*	35.3mi	0:20	97:37
◆	KBNG	B-	275*	18.0mi	0:10	97:46
◆	KONT	B-	268*	38.2mi	0:23	98:10
◆	KLAX	B-	247*	40.7mi	0:23	98:34

With Fuel Enabled

Without Fuel Enabled

Figure 3-96: Navigation Log

3.6.1. Clock and Groundspeed

The following are displayed in the upper left corner of the NAV Log:

- 1) **Zulu or LCL Time:** As specified in § 3.4.5.
- 2) **Groundspeed:** Displayed digitally in knots

3.6.2. Fuel Remaining and Fuel Flow Data

The following are displayed in the upper right corner of the NAV Log:

- 1) **Fuel Remaining:** If either fuel level or fuel flow is available, current fuel remaining is displayed digitally in fuel units.
- 2) **Fuel Flow:** If fuel flow is available, current total fuel flow is displayed digitally in fuel units.

3.6.3. Waypoint Identifier Column

The identifier for each waypoint of the active flight plan is displayed in the left-most column of the NAV Log. The active waypoint, indicated with an asterisk, is magenta but turns amber (yellow) in the event of a GPS Loss of Navigation caution. Brackets indicate suppressed waypoints. Navigation data symbols are shown with the waypoint identifier to easily distinguish the waypoint type. When a waypoint is part of a procedure or parallel offset, the following legends are drawn on top of the navigation data symbol:

- 1) **FAF** = Waypoint is a Final Approach Fix


- 2) **MAP** = Waypoint is a Missed Approach Point
- 3) **MA** = Waypoint is part of the missed approach segment of an Instrument Approach Procedure.
- 4) **APP** = Waypoint is part of an Instrument Approach Procedure, but is not a FAF, MAP, or part of the Missed Approach segment.
- 5) **VFR** = Waypoint is part of a VFR Approach.
- 6) **STAR** = Waypoint is part of a Standard Terminal Arrival Procedure.
- 7) **DP** = Waypoint is part of a Departure Procedure.
- 8) **PTK** = Parallel Offset. In case of a STAR or DP waypoint subject to a parallel offset, both STAR/DP and PTK are shown.

3.6.4. VNAV and VNAV Offset Column

The VNAV altitude and associated VNAV Offset (in NM) are displayed immediately to the right of the Waypoint Identifier column. In the case of an approach with a Final Approach Segment data block, the VNAV Offset readout associated with the Missed Approach Point is “GPI” to designate distance to the Glidepath Intercept Point. VNAV altitudes and offsets from the navigation database or manually entered are white. VNAV altitudes and offsets computed automatically are gray. VNAV and VNAV Offset column elements align with Waypoint Identifier column elements to indicate the VNAV information applies to the associated waypoint.

3.6.5. Path Column

The LNAV path between waypoints is displayed immediately to the right of the VNAV and VNAV Offset column. The following paths are displayed:

- 1) Geodetic path between waypoints is displayed with  (R4), followed by the initial geodetic course for the leg.
- 2) Discontinuities (i.e., a leg where FMS is unable to compute a valid path) are shown with the legend -DISCONT-.
- 3) Procedure turns are shown with a pictorial representation of a procedure turn (either left or right turns) as well as the entry and exit course for the procedure turn.

- 4) Holding patterns are shown with a pictorial representation of a holding pattern (either left or right turns) as well as the inbound course for the holding pattern.
- 5) Arcs are shown with a pictorial representation of an arc (either left or right turns) as well as the entry and exit radials for the arc.
- 6) An altitude termination leg is shown by the initial geodetic course for the leg followed by the altitude at which the leg terminates.

Path column elements are offset from Waypoint Identifier column elements to indicate the path information applies to the leg between waypoints.

3.6.6. Distance Column

Distance between waypoints is displayed immediately to the right of the Path column and is calculated taking into account the associated path as well as parallel offsets. In the case of a discontinuity, the distance between waypoints is the direct geodetic distance between the two waypoints. Distance column elements are offset from Waypoint Identifier column elements to indicate the distance information applies to the leg between waypoints.

3.6.7. Estimated Time Enroute Column

ETE between waypoints is displayed immediately to the right of the Distance column and is calculated taking into account the associated distance between waypoints and current groundspeed. ETE column elements are offset from Waypoint Identifier column elements to indicate ETE information applies to the leg between waypoints.

3.6.8. Estimated Time of Arrival Column

ETA at the active waypoint and all subsequent waypoints is displayed immediately to the right of the ETE column. ETA at the active waypoint is calculated taking into account the associated time remaining on the active leg and current time. ETA at subsequent waypoints is calculated taking into account the cumulative ETEs and current time. ETA column elements align with Waypoint Identifier column elements to indicate ETA information applies to the associated waypoint.

3.6.9. Fuel Remaining Column

Fuel remaining at the active waypoint and all subsequent waypoints is displayed immediately to the right of the ETA column. Fuel remaining at the active waypoint is calculated taking into account the associated time remaining on the active leg, current fuel flow, and current fuel quantity. Fuel remaining at subsequent waypoints is calculated taking into account the cumulative ETEs, current fuel flow, and current fuel quantity. Fuel Remaining column elements align with Waypoint Identifier column elements to indicate the fuel remaining information applies to the associated waypoint.

NOTE:

Since a suppressed waypoint is not part of the active flight plan, dashes appear in the absence of the following VNAV data associated with a suppressed waypoint:

- 1) Path data
- 2) Distance data
- 3) ETE data
- 4) ETA data
- 5) Fuel remaining data

Section 4 Reversionary Modes

4.1. Reversionary Modes

The equipment has eight reversionary modes as follows:

Mode 0: GPS/SBAS, ADC, and AHRS normal.

Mode 1: GPS/SBAS failed; ADC and AHRS normal.

Mode 2: ADC failed; GPS/SBAS, and AHRS normal.

Mode 3: AHRS failed; GPS/SBAS, and ADC normal.

Mode 4: GPS/SBAS and ADC failed; and AHRS normal.

Mode 5: GPS/SBAS and AHRS failed; and ADC normal.

Mode 6: ADC and AHRS failed; and GPS/SBAS normal.

Mode 7: GPS, ADC, and AHRS failed.

To use this section, review the following table and notes to determine what feature or function is affected by one or more of the three sensors failed conditions. Examples follow with the IDU-450 displays in various configurations with a table breaking down the affected functions.

Not all possible IDU-450 display configurations and format combinations are represented here. All eight modes of System Operation are represented for description purposes.

4.2. System Operation in Reversionary Modes

Table 4-1: PFD Functions

PFD Function	Mode							
	0	1	2	3	4	5	6	7
Airspeed	OK	OK	19	OK	19	OK	19	19
Altimeter	OK	OK	19	OK	19	OK	19	19
Altimeter Set Display	OK	OK	-	OK	-	OK	-	-
Bank Scale	OK	OK	OK	-	OK	-	-	-
CDI	OK	1 + 20	OK	OK	20	20	OK	20
Runway	OK	1	25	-	-	-	-	-
Waypoint Pointer	7	1	7	7	-	-	7	-
Heading Scale	7	7	7	7	7	-	7	-
AGL Ind.	OK	2	4	OK	11	11	4	-
Flight Path Marker	OK	1 + 14	-	-	-	-	-	-
G-meter	OK	OK	OK	-	OK	-	-	-
Ground Track	7	1	7	7	-	-	7	-
Heading Indicator	7	7	7	-	7	-	-	-
Horizon	OK	OK	OK	-	OK	-	-	-
Mini-Map	7	1	7	7	-	-	7	-
Pitch Limit Indicator	OK	OK	-	8	-	8	-	-
Pitch Scale	OK	OK	OK	-	OK	-	-	-
Highway in the Sky	OK	1 + 15	-	-	-	-	-	-
Terrain/Obstructions	OK	-	25	-	-	-	-	-
Clock Functions	OK	OK	OK	OK	OK	OK	OK	OK
VSI	OK	OK	-	OK	-	OK	-	-
Waterline Symbol	22	22	5	13	5	13	13	13
Waypoint Symbol	OK	1	-	-	-	-	-	-
Waypoint Brg/Dist	OK	1	OK	OK	-	-	OK	-
Traffic	OK	OK	OK	-	-	-	-	-
Traffic Thumbnail	OK	OK	OK	OK	OK	OK	OK	OK
Speed Trend	OK	OK	-	-	-	-	-	-
Dynamic Stall Speed	OK	OK	-	8	-	8	-	-

Table 4-2: ND Functions

ND Functions	Mode							
	0	1	2	3	4	5	6	7
Aircraft Position	OK	1	OK	OK	-	-	OK	-
Special Use Airspace	9	1	6	9	-	-	6+ 9	-
Waypoint Pointer	9	1	9	9	-	-	9	-
Active Flight Plan Path	9	1	9	9	-	-	9	-
Glide Range	9	1	-	10	-	-	-	-
Groundspeed	OK	1	OK	OK	-	-	OK	-
Ground Track	9	1	9	9	-	-	9	-
Heading Indicator	9	9	9	-	9	-	-	-
Navigation Symbols	9	1	9	9	-	-	9	-
Outside Air Temp.	OK	OK	-	OK	-	OK	-	-
Projected Path	OK	1	OK	-	-	-	-	-
Traffic	OK	OK	OK	OK	OK	OK	OK	OK
Terrain/Obstructions	OK	-	25	OK	-	-	25 +9	-
Clock Functions	OK	OK	OK	OK	OK	OK	OK	OK
Waypoint Brg./Dist.	OK	1	OK	OK	-	-	OK	-
Wind	21	3	-	-	-	-	-	-
WX-500 Data	OK	OK	OK	OK	OK	OK	OK	OK
Compass Rose	9	9	9	9	9	-	9	-
Fuel Totalizer Functions	23	24	23	23	12	12	12	12
True Airspeed	OK	OK	-	OK	-	OK	-	-
Density Altitude	OK	OK	-	OK	-	OK	-	-
OAT/ISA Display	OK	OK	-	OK	-	OK	-	-

Table 4-3: Output Functions

Output Functions	Mode							
	0	1	2	3	4	5	6	7
Air/Ground Output	16	16	17	16	17	16	17	17
Autopilot EFIS Valid	16	16	16	-	-	-	-	-
TAWS Alarm Output	16	16	16	16	16	16	16	16
Transmit Enabled	16	16	16	16	16	16	16	16
Warning Light Output	16	16	16	16	16	16	16	16
Caution Light Output	16	16	16	16	16	16	16	16
Mstr. Caut. Light Output	16	16	16	16	16	16	16	16
MDA/DH Output	16	16	18	16	18	16	18	18
Altitude Capture Output	16	16	-	16	-	16	-	-
IAS Switch Output	16	16	-	16	-	16	-	-

- Note 1: Presented using inertial dead-reckoning based on last known wind information. If unable to dead-reckon (e.g., heading is failed or true airspeed cannot be calculated), function is disabled.
- Note 2: Only radar altitude presented when available.
- Note 3: Last known wind is saved during GPS/SBAS failure.
- Note 4: Either radar altitude or geodetic altitude less database elevation.
- Note 5: Waterline symbol expanded to large attitude bars.
- Note 6: Special use airspace boundaries are drawn with bold lines due to lack of aircraft altitude data.
- Note 7: In heading-only failure mode or AHRS failure mode, heading scale aligned with aircraft track and heading indication is removed. In heading-only failure mode or AHRS failure mode combined with GPS failure, heading scale is replaced with a red-X.
- Note 8: Based upon 1G stall speed.
- Note 9: In heading-only failure mode or AHRS failure mode, compass rose aligned with aircraft track and heading indication is removed when in heading up mode. In heading-only failure mode or AHRS failure mode combined with GPS failure, compass rose is removed.
- Note 10: Presenting using last-known wind information and aligned with aircraft track in heading up mode.
- Note 11: Only radar altitude presented when available.
- Note 12: Assuming valid fuel flow information, endurance is presented.
- Note 13: Large attitude bars presented and X'd out.
- Note 14: Flight Path Marker grayed after one minute to indicate degraded operation.
- Note 15: Highway in the Sky removed after one minute.
- Note 16: See IDU SCC Card and Limits Requirements for activation requirements.

- Note 17: Defaults to AIR unless Weight on Wheel/Weight on Ground discrete input is active.
- Note 18: Only DH function (with valid AGL altitude) in this mode.
- Note 19: Red X in place of scale.
- Note 20: VLOC CDI always available if optional VOR symbology enabled.
- Note 21: Function removed during heading-only failure mode.
- Note 23: Assuming valid fuel flow information, both range and endurance are presented.
- Note 24: Assuming valid fuel flow information, both range and endurance are presented using inertial dead-reckoning based on last known wind information. If the pilot is unable to dead-reckon due to loss of heading or true airspeed cannot be calculated, endurance only information is presented.
- Note 25: Inhibited in accordance with the conditions specified in TAWS Automatic Inhibit Function (Abnormal Operation).

4.2.1. Oat Sensor Failure Mode

In addition, the equipment has an OAT sensor failure mode. With the OAT sensor failed, the display of wind, OAT, density altitude, and true airspeed on the ND are disabled.

4.2.2. Heading Failure Mode

In addition, the equipment has a heading failure mode. With heading failed, the PFD heading scale and MFD compass rose align with track (if available) or are removed and replaced with a red-X. In this failure mode, PFD heading scale includes “GPS TRK” around the track marker to clearly delineate the failure mode.

4.2.3. PFD Screen Auto Reversion

For IFR approval in aircraft, flight instrument information essential to safety of flight remains available to the pilot without additional action after a failure. To accommodate this, MFDs have the ability to sense when the PFD has failed and take over the PFD function

automatically. The manner in which this occurs on the IDU-450 is as follows:

When an MFD (IDU #2, 3, or 4) becomes the “transmit-enabled” IDU, the MFD automatically switches to the PFD screen. Push **1** to change the MFD to other screens after the automatic switch.

4.2.4. GPS Failure

GPS degrades or fails as a result of loss of satellite information, or GPS equipment failure. When the integrity is provided by SBAS, the IDU provides a LOI (Loss of Integrity) monitoring caution within two seconds, if the current HPL (Horizontal Protection Level) exceeds the HAL (Horizontal Alert Level). This LOI caution appears when there is no integrity monitoring and disappears when integrity monitoring is restored.

Further GPS degradation causes the EFIS to lose GPS updating of aircraft position, groundspeed, and ground track, and the ability to calculate the wind information.

- 1) **GPS LOI** (Loss of Integrity) displayed with no time delay.
- 2) $HPL > HAL$ for the phase of flight currently in. Position is still presented based upon a GPS navigation solution.
- 3) **GPS LON** (Loss of Navigation) displayed with no time delay of the onset of the following:
 - a) The absence of power;
 - b) Equipment malfunction or failure;
 - c) The presence of a condition lasting five seconds or more where there are an inadequate number of satellites to compute position solution;
 - d) Fault detects a position failure that cannot be excluded within time-to-alert when integrity is provided by FDE;
 - e) $HPL > HAL$ on the final approach segment. Genesys Aerosystems EFIS does not transition to DR Navigation at this stage. A GPS Navigation solution is still presented; and
 - f) Where $HPL > HAL$ on the final approach segment, this position may still be satisfactory for GPS Navigation. For example, an HPL of 0.31NM exists which means as soon

as a transition to TERMINAL mode occurs, all alerts would disappear. This is significantly important during a wind change, if the system had been in a DR mode.

NOTE:

At any time, view HFOM on the FAULTS page to see the system-reported accuracy.




Figure 4-1: FAULTS Page on MFD

- 1) **DR** (Dead Reckoning)
 - a) If a GPS position cannot be calculated, a dead reckoning solution is provided with a timer, **DR 01:23**. This solution is calculated from heading and TAS derived from the AHRS and ADC.
 - b) **NO POSITION**, no position available from the GPS and the EFIS cannot DR due to a second failure.
- 2) **VERT LON** (Loss of Vertical Navigation)

In the event the navigation equipment is no longer adequate to conduct or continue the LNAV/VNAV approach, **VERT LON** appears within one second of the onset of any of the following conditions:


- a) The absence of power;
- b) Equipment malfunction or failure;

- c) The presence of a condition where fault detection detects a position failure that cannot be excluded;
- d) There are an insufficient number of SBAS HEALTHY satellites;
- e) The horizontal protection level exceeds the alert limit as follows for LNAV/VNAV approaches:
 - i) Prior to sequencing the FAWP- HAL should be 0.3 NM with no limit on VAL
 - ii) After sequencing the FAWP- HAL 556m (0.3NM) and VAL 50m

When in LNAV mode, the fault detection function detects positioning failures within 10 seconds after the onset of the positioning failure.


GPS failure results in the EFIS operating in “dead reckoning” mode. The EFIS continues to provide navigational position, groundspeed, and ground track information, based upon the last known wind, current air data, and heading. The IDU-450 PFD and MFD are affected as follows.

4.4. PFD Failure Mode 1




**Figure 4-4: PFD Failure Mode 1
GPS/SBAS Failed; ADC and AHRS Normal**

4.4.1. MFD Failure Mode 1




**Figure 4-5: MFD Failure Mode 1
GPS/SBAS Failed; ADC and AHRS Normal**

4.5. PFD Failure Mode 2 (Normal Mode)



**Figure 4-6: PFD Failure Mode 2 (Normal Mode)
ADC Failed; GPS/SBAS and AHRS Normal**

4.5.1. MFD Failure Mode 2




**Figure 4-7: MFD Failure Mode 2
ADC Failed; GPS/SBAS and AHRS Normal**

4.6. PFD Failure Mode 3




**Figure 4-8: PFD Failure Mode 3
AHRs Failed; GPS/SBAS and ADC Normal**

4.6.1. MFD Failure Mode 3




**Figure 4-9: MFD Failure Mode 3
AHRs Failed; GPS/SBAS and ADC Normal**

4.7. PFD Failure Mode 4




**Figure 4-10: PFD Failure Mode 4
GPS/SBAS and ADC Failed; AHRs Normal**

4.7.1. MFD Failure Mode 4




**Figure 4-11: MFD Failure Mode 4
GPS/SBAS and ADC Failed; AHRs Normal**

4.8. PFD Failure Mode 5




**Figure 4-12: PFD Failure Mode 5
GPS/SBAS and AHRs Failed; ADC Normal**

4.8.1. MFD Failure Mode 5



**Figure 4-13: MFD Failure Mode 5
GPS/SBAS and AHRs Failed; ADC Normal**

4.9. PFD Failure Mode 6




**Figure 4-14: PFD Failure Mode 6
ADC and AHRs Failed; GPS/SBAS Normal**

4.9.1. MFD Failure Mode 6




**Figure 4-15: MFD Failure Mode 6
ADC and AHRs Failed; GPS/SBAS Normal**

4.10. PFD Failure Mode 7



**Figure 4-16: PFD Failure Mode 7
GPS/SBAS, ADC and AHR Failed**

4.10.1. MFD Failure Mode 7



**Figure 4-17: MFD Failure Mode 7
GPS/SBAS, ADC and AHR Failed**

Section 5 Menu Functions and Step-By-Step Procedures

5.1. Menu Functions

Navigate IDU menu functions with the eight peripheral buttons and right encoder (❶). The left encoder is not used for menu functions.



Figure 5-1: IDU-450 Input Controls

5.2. Menu Synchronization

System settings changed by the menu system are synchronized between multiple IDUs in MFD-MFD mode. Each appendix for Datalink, Strikes, RBP, Traffic, Video, Weather Radar, and Round Dials contains specific limitations for menu synchronization for that feature.

Table 5-1: Menu Synchronization

Menu Parameter	Notes
<i>The following menu parameters are synchronized across all displays at all times. These are bugs and fundamental aircraft values that should never have independence.</i>	

Table 5-1: Menu Synchronization

Menu Parameter	Notes
AHRS 1 and 2 mode and slewing values	
Fuel Totalizer Quantity	
VNAV Climb Angle	
Countdown Timer Start Time	
Countdown Timer Default Value	
Remote Tune Frequencies	
VNAV Descent Angle	
Decision Height Setting	Used when “Dual Decision Height Flag” is false.
Emergency and Minimum Fuel Settings	
Heading Bug	
Minimum Altitude Bug Value	
VLOC OBS Settings	
Airspeed Bug Setting	
Target Altitude Bug Setting	
Timer Starting Signal	
True North Mode	
UTC Offset	
Settable V-Speeds	
VSI Bug Setting	
Crosslink Synchronization Status	
Audio-Radio device parameters	
G-Force Limit Parameters	
<p><i>The following menu parameters are synchronized across all displays when crosslink is enabled. Otherwise, they are only synchronized onside. These parameters are FMS parameters and allow the pilot and co-pilot FMSs to be operated independently when crosslink is inhibited.</i></p>	
Active Flight Plan Parameters	
Runway Display Parameters	
<p><i>The following menu parameters are only synchronized onside. These parameters are usually sensor selections or PFD options used to keep the appearance of any pilot's PFD consistent in the case of PFD reversion. The onside characteristic means individual pilots can still adjust their PFD settings to their preference.</i></p>	
Sensor Selections	

Table 5-1: Menu Synchronization

Menu Parameter	Notes
Transition Altitude	
Barometric Setting Units	
Barometric Setting Value	
Barometric Setting Mode	
Decision Height Setting	Used when “Dual Decision Height Flag” is true.
Navigation Source	
PFD Basic Mode	
PFD Zoom Mode	
PFD Analog AGL	
PFD Full-time Bank Scale Flag	
PFD Flight Director Show Flag	
PFD Mini-map Show Flag	
PFD Altitude (meters) Show Flag	
PFD Skyway Show Flag	
PFD Terrain Show Flag	
Rate of turn indication flag	
<i>The following menu parameters are independent between displays. These are used to support non-PFD display options to give the pilot maximum MFD operating flexibility.</i>	
MFD Map and HSI Page Pointer Settings	
MFD Map Function Declutter Settings	
MFD Show ETA Flag	
MFD Map NavData Symbol Declutter Settings	

5.3. Menu Function Types

There are two types of menu functions on the IDU-450, top-level menu functions corresponding to the labeled pushbutton, and soft menu functions indicated by menu tiles, which appear on screen next to the appropriate IDU button or encoder. Soft menu functions take precedence over IDU pushbutton functions and may include indication of further menu levels with a two-dot trailer. When the menu system is beyond the top-level, **EXIT (R1)** escapes to the top-level. When a soft menu level is deeper than the first level, **BACK (L1)** regresses through the menu system by one level.

5.4. Top-Level Menu





Figure 5-2: PFD Top-Level Menu

5.4.1. Top-Level Menu Option Descriptions

- 1) **FPL (L1)**: Flight plan menu
- 2) **ACTV (L2)**: Active flight plan menu
- 3) **INFO (L3)**: Information menu
- 4) **OBS (L4)**: Omnibearing selector menu
- 5) **MENU (R1)**: First-level associated with current display page and times out after 10 seconds if there are no subsequent pilot actions.
- 6) **BARO (R2)**: Altimeter menu
- 7) **NRST (R3)**: Nearest menu
- 8)  **(R4)**: Direct menu

5.4.2. #1 Encoder (1)

- 1) On a PFD, scroll to activate the heading menu.
- 2) On MFD pages with an adjustable display scale (e.g., ND, Strike, Traffic, Datalink, or Weather Radar), scroll CW to increase or CCW to decrease display scale.


- 3) With the exception of IDU #1, push to swap between the PFD and MFD. IDU #1 is always fixed to the PFD page.

5.4.3. Top-Level Menu Automatic Pop-up Function Descriptions

Soft menu tiles appear adjacent to pushbuttons under the specified conditions.

Table 5-2: Top-Level Menu Automatic Function Descriptions Tile Legend and Action in order of Precedence

FPL (L1)	<ol style="list-style-type: none"> 1) When ND Page with Pan Mode enabled, PN OFF appears. Press to disable Pan Mode. 2) When display is “transmit enabled”, LNAV appears. When there is an active flight plan, heading bug sub-mode is active, and the system is integrated with an analog autopilot. Press to deactivate heading bug sub-mode and resume guidance to the active flight plan path. 3) When display is “transmit enabled”, MISS appears upon transitioning the Final Approach Fix. Press to activate the missed approach procedure. 4) When display is “transmit enabled”, CONT appears when in a holding pattern with further active flight plan legs after the holding pattern. Press to re-enable automatic waypoint sequencing to allow normal sequencing to the leg after the holding pattern.
ACTV (L2)	<ol style="list-style-type: none"> 1) When ND Page with: (a) Pan Mode enabled; (b) information for the nearest highlighted waypoint is shown; and (c) airport weather information present in the information block. 2) When display is “transmit enabled”, VNAV appears when VNAV guidance is valid, the selected altitude sub-mode is active, and the system is integrated with an analog autopilot. Press to deactivate selected altitude sub-mode and resume guidance to the VNAV path. 3) When display is “transmit enabled”, ARM appears when on the Final Approach Segment (between

Table 5-2: Top-Level Menu Automatic Function Descriptions Tile Legend and Action in order of Precedence	
	the Final Approach Fix and Missed Approach Point). Press to arm Missed Approach Procedure to automatically activate upon sequencing the Missed Approach Point.
INFO (L3)	When ND Page with Pan Mode enabled, NORTH appears. Press to shift the center of the page in the specified direction.
OBS (L4)	When ND Page with Pan Mode enabled, SOUTH appears. Press to shift the center of the page in the specified direction.
BARO (R2)	When ND Page with Pan Mode enabled, INFO or HIDE appears. Press to toggle display of information for the nearest highlighted waypoint.
NRST (R3)	When ND Page with Pan Mode enabled, EAST appears. Press to shift the center of the page in the specified direction.
 (R4)	When ND Page with Pan Mode enabled, WEST appears. Press to shift the center of the page in the specified direction.

5.5. First Page (PFD)

On the IDU-450, IDU #1 is fixed to the PFD page, and other IDUs may show the PFD page as a backup function. PFD page first-level options are as follows.




Figure 5-3: First Page PFD

5.5.1. PFD Page First-Level Option Descriptions


- 1) **XFILL SYNC (FPL) (L1)**: Appears in dual-system installations where the pilot and co-pilot systems are not synchronized, but crosslink is enabled. Press to synchronize the pilot and co-pilot active flight plan parameters to the system where the button press occurred.

Table 5-3: Crossfill Inhibit/Arm/Sync Function					
Crossfill (1)	Flight Plan	Indication (Pilot and Co-pilot)	Action to Synchronize Flight Plans		Result
			Pilot	Co-pilot	
Enabled (Cond.1)	Synchro- nized	None	None	None	No action required. Pilot and co-pilot sides already synchronized.
Enabled (Cond.2)	Not Synchro- nized (2)	XFILL ARM	MENU (R1) XFILL SYNC (L1)	None	Pilot's flight plan is sent to co-pilot side and both sides are synchronized going forward. XFILL ARM is removed from both sides.
				None	MENU (R1) XFILL SYNC(L1)
Inhibited (Cond.3)	Not Synchro- nized	XFILL INHBT	Enable crossfill (1) (proceed to Cond. 2)		XFILL INHBT removed. XFILL ARM displayed on both sides.

(1) Crossfill is inhibited with the use of a latching (ON) crossfill inhibit switch. Crossfill is enabled by releasing (OFF) this switch. The location and number of crossfill inhibit switches in

Table 5-3: Crossfill Inhibit/Arm/Sync Function

Crossfill (1)	Flight Plan	Indication (Pilot and Co-pilot)	Action to Synchronize Flight Plans		Result
			Pilot	Co-pilot	
a cockpit varies by installation. Usually a single crossfill switch can be centrally located in a side-by-side cockpit within reach of both pilots. If a single switch cannot be installed within reach of both pilots (tandem cockpits or very wide cockpits), two switches can be installed to function in parallel (either switch inhibits or enables crossfill on both the pilot and co-pilot sides).					
(2) Pilot and co-pilot flight plans can become unsynchronized under the following conditions:					
<ul style="list-style-type: none"> • Crossfill is inhibited, and pilot and co-pilot flight plans are separately changed before crossfill is re-enabled. • Either the pilot or co-pilot side is restarted with an active flight plan on the other side and crossfill enabled. 					


- 2) **Source (ACTV) (L2):** Activates PFD source selection menu.
- 3) **DESIG (INFO) (L3):** Creates user waypoint at current aircraft location. In addition, if pressed with an ND page operating in panning mode, creates another user waypoint at phantom panning location. User waypoints are automatically named "OF###", where '###' is the next available over-fly user waypoint number.
- 4) **TIME (OBS) (L4):** Activates timer menu.
- 5) **BUGS (BARO) (R2):** Activates PFD bug set menu.
- 6) **ZOOM ON/ZOOM OFF (NRST) (R3):** Toggles wide and narrow FOV modes. **ZOOM ON** appears when mode is wide FOV. **ZOOM OFF** appears when mode is narrow FOV.
- 7) **DCLTR**  **(R4):** Activates PFD declutter menu.

5.5.2. PFD Screen First Soft Menu Level

XFILL SYNC (L1) appears when all of the following conditions are met:

- 1) Crosslink status is enabled; and
- 2) Crosslink synchronization status is not enabled; and
- 3) Discrete input for Crossfill Inhibit is not enabled; and
- 4) Side in command is valid; and
- 5) AFCS Status is set to invalid.

5.6. First-Level (MFD)




¹ MFD WX RDR Format menu exists (see Weather Radar Appendix).

² When MFD WX RDR Format menu does not exist.

Figure 5-4: First-Level MFD

IDUs other than #1 may show various MFD pages as described in § 5.21. MFD first-level options (tiles) are as follows.

- 1) **FAULTS (FPL) (L1)**: Activates fault display menu.
- 2) **DESIG (INFO) (L3)**: Same function as PFD page first-level.
- 3) **TIME (OBS) (L4)**: Same function as PFD page first-level.
- 4) **SET FUEL (BARO) (R2)**: Activates fuel totalizer set menu.
- 5) **PAGE (NRST) (R3)**: Activates MFD display page select menu.

- 6) **PTRS**  **(R4)**: On HSI page with optional VOR or ADF symbology enabled, activates HSI RMI pointer menu.

5.7. Lower-Level Menus (Below First-Level)

Lower-level menus, and the eight pushbuttons and encoder control them as seen in Figure 5-1.

5.7.1. Flight Plan (FPL) Menu




Figure 5-5: Flight Plan Menu

5.7.2. Flight Planner Page

Use the Flight Planner page for the following functions:

- 1) Manage stored flight plans (activate, create, edit, delete, and reverse);
- 2) Manage user waypoints (create, edit, and delete); and
- 3) Perform RAIM predictions.

These operations demand pilot attention and are not normal operating conditions for the IDU. When the Flight Planner page is in use, it takes over the IDU's controls and disables menu operations described in this document. Normal menu operation and IDU control function are restored upon:

- 1) Exit the Flight Planner page; or
- 2) Because the Flight Planner page takes over the IDU's controls, limitations are placed upon access and display of the Flight Planner page. When accessed, it only appears on the MFD to preserve access to crucial PFD Page controls such as altimeter settings.

Upon activation of the flight plan menu, the application checks for saved flight plans. If there are no saved flight plans, **NO SAVED FPLS** appears. Otherwise, a selection list of saved flight plans is presented. Upon selection of a saved flight plan, the second waypoint in the flight plan is activated.

5.7.3. MFD Page Shown on IDU

Upon activation of the flight plan menu, the application checks for saved flight plans. If there are no saved flight plans, the Flight Planner page is activated. Otherwise, an option list is presented to either select a saved flight plan or enter the flight planning page. Select the saved flight plan option for a list of saved flight plans. Upon selection of a saved flight plan, the second waypoint in the flight plan is activated.

5.7.4. Create an Overfly User Waypoint

When flying over intended waypoint, press **MENU (R1)** then **DESIG (INFO) (L3)** on the PFD or MFD. A user waypoint is created at the present position and automatically named "OF####", where '####' is the next in sequence overfly user waypoint number available. When in Pan Mode and the aircraft position is slewed, a second user waypoint is created at the original position. Use the **EDIT USER WPT** function on the MFD to change the waypoint name.

NOTE:

A maximum of 998 user waypoints may be created and stored.



Figure 5-6: Creation of Overfly User Waypoint


5.7.5. Flight Plan (FPL) Menu Create-Edit (MFD Only) (Step-By-Step)



1) Press **FPL (L1)**.



2) Scroll **1** to **CREATE-EDIT..** and push to enter.



3) Push **1** to enter.




4) Press **ADD (R2)** to begin creating first waypoint.



5) Use **1** to create a new waypoint or press **NRST APT.. (L2)**, **NRST VOR.. (L3)**, **NRST NDB.. (L4)**, **NRST FIX.. (R2)**, or **NRST USR.. (R3)**, and make desired selection. Push **1** to enter.



6) When finished, press **SAVE (R4)** to store new flight plan as one of 100 flight plans in memory.



- 7) Press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit.

NOTE:

When 100 flight plans are stored in memory, the **CREATE FLIGHT PLAN** option is absent.

5.7.6. Select/Activate Flight Plan (PFD or MFD) (Step-By-Step)



- 1) Press **FPL (L1)** on PFD or MFD.




- 2) Scroll **1** to **SELECT..** and push to enter.




- 3) Scroll **1** to desired saved flight plan and push to enter and exit to normal operation.

Or



- 1) Scroll **1** to **CREATE-EDIT..** and push to enter.



- 2) Scroll **1** to **ACTIVATE FLIGHT PLAN** and push to enter.



- 3) Scroll **1** to saved flight plan and push to enter.
- 4) Press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit.




5.7.7. Edit Flight Plan (MFD Only) (Step-By-Step)



- 1) Press **FPL (L1)**.




- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.



- 3) Scroll **1** to **EDIT FLIGHT PLAN** and push to enter.



- 4) Scroll **1** to desired flight plan and push to enter.



- 5) Edit flight plan by adding or deleting waypoints as appropriate.
- 6) Press **SAVE (R4)**.
- 7) Press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit.




5.7.8. Reverse Flight Plan (MFD Only) (Step-By-Step)




- 1) Press **FPL (L1)**.



- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.



- 3) Scroll **1** to **REVERSE FLIGHT PLAN** and push to enter.



- 4) Scroll **1** to desired flight plan and push to enter.
- 5) Press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit.




5.7.9. Delete Flight Plan (MFD Only) (Step-By-Step)



1) Press **FPL (L1)**.



2) Scroll **1** to **CREATE-EDIT..** and push to enter.



3) Scroll **1** to **DELETE FLIGHT PLAN** and push to enter.



4) Scroll **1** to flight plan to be deleted and push to enter.



5) Push **1** to **CONFIRM DELETE FPL**.



6) Next flight plan is highlighted. Press **BACK (L1)** to return to function select page or **EXIT (R1)** to exit the menu.



5.7.10. Create User Waypoint (LAT-LON) (MFD Only) (Step-By-Step)

User waypoints may be created with three methods:

- 1) Latitude and Longitude
- 2) Radial and Distance
- 3) Overfly (§ 5.7.4)


Use the following procedure to create a user waypoint using latitude and longitude.




1) Press **FLP (L1)**.



2) Scroll **1** to **CREATE-EDIT..** and push to enter.



- 3) Scroll **1** to **CREATE USER WPT (LAT-LON)** and push to enter.



- 4) To name new user waypoint, scroll **1** and push to enter all five character spaces. With new name created, use **1** to proceed through all fields as necessary.

Preloading of approach bearing is dependent on mode of flight as follows:




On Ground: Preloaded with current heading



In Flight: Preloaded with **OFF** value

If desired, specify approach bearing to user waypoint in degrees 1°-360°. **OFF** value disables VFR approaches to user waypoint.



- 5) Once all fields are entered, press **SAVE (R4)** to save user waypoint and return to the editing screen.


5.7.11. Create User Waypoint (RAD-DST) (MFD Only) (Step-By-Step)



- 1) Press **FPL (L1)**.



- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.



- 3) Scroll **1** to **CREATE USER WPT (RAD-DST)** and push to enter.



Identifier is automatically named RD### where ### is the next available radial distance waypoint number.*



- 4) After all fields are entered, press **SAVE (R4)** to save and return to editing screen.

* **Reference Waypoint:** On the second line, pilot is prompted to enter identifier for reference waypoint. Use **1** to enter reference waypoint in the same manner a waypoint is entered for a flight plan. If there is a single result, pilot is advanced to the radial entry box. If there is no result, pilot is re-prompted to enter an identifier. If there are multiple results, a list with matching identifiers is displayed, and upon selection, pilot is advanced to the radial entry box. **INFO** provides access to information for the highlighted result.

Radial Entry: The third line is for pilot to specify a radial from the reference waypoint in increments of degrees.


Distance Entry: The fourth line allows the pilot to specify a distance from the reference in increments of tenths of nautical miles.




5.7.12. Edit User Waypoint (MFD Only) (Step-By-Step)




- 1) Press **FPL (L1)**.




- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.



- 3) Scroll **1** to **EDIT USER WPT** and push to enter.






- 4) Scroll **1** to desired waypoint to be edited.



- 5) Use **1** to enter alphanumeric characters. Follow prompts to edit information. Push **1** to step through all character spaces.
- 6) To back up, press **BACK (L1)** and continue to end of all character spaces.
- 7) Select another waypoint or push **SAVE (R4)** to save changes to return to EDIT USER WPT menu.

5.7.13. Delete User Waypoint (MFD Only) (Step-By-Step)



- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **DELETE USER WPT** and push to enter.
- 4) Scroll **1** to waypoint to be deleted.
- 5) Push **1** to **CONFIRM DEL USER WPT**.
- 6) If no other waypoints to delete, press **EXIT (R1)** to exit the menu and return to the MAP.

NOTE:

Pilot alterations of user waypoint parameters while in flight do not automatically update to an active flight plan.

When changes are made to a user waypoint, and those changes are desired in existing flight plans, which use the waypoint, it must be deleted and replaced in the flight plans with the following steps:

- 1) EDIT the user waypoint as described above.
- 2) Open a flight plan that uses the user waypoint.
- 3) Delete the existing waypoint from the flight plan.
- 4) Save and Exit.
- 5) Reload the flight plan if it were in use.



5.7.14. RAIM Prediction


When selected, the RAIM prediction screen is only shown if the GPS/SBAS receiver is capable of performing a RAIM Prediction. There must be no faults along with a current almanac in memory. The **FAULTS** menu may be monitored to determine if the GPS/SBAS receiver is capable of performing a RAIM prediction.



- 1) Press **FPL (L1)**.




- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.



- 3) Scroll **1** to **RAIM PREDICTION** and push to enter.

SEE NOTE BELOW.



- 4) Press **START OVER (R2)** to start the process again or press **EXIT (R1)**.

NOTE:

The pilot may perform RAIM prediction at a designated waypoint.

The screen has various data entry boxes as follows:

- 1) **Designated Waypoint:** Prompted to enter an identifier for the designated waypoint. If there is a single result, advanced to UTC time entry box. If there is no result, re-prompted to enter an identifier. If there are multiple results, a selection list with matching identifiers is presented and, upon selection, is advanced to UTC time entry box. **INFO (L3)** aids in selection and gives access to information for the highlighted results.
- 2) **UTC Time Entry:** Allows entry of the 24-Hour UTC estimated time of arrival at the designated waypoint.
- 3) **UTC Date Entry:** Allows entry of the UTC estimated date of arrival at the designated waypoint.
- 4) **PRN Mask Entry:** Allows specification the PRN number of satellites expected to be unavailable at the destination.
- 5) **EXIT:** Exit of the RAIM prediction screen at any time.
- 6) Once a designated waypoint and UTC estimated time of arrival are entered, **CALC (R2)** appears to initiate the RAIM Prediction. Press **CALC (R2)** to check the UTC estimated time of arrival and ensure it is within the current almanac (i.e., <3.5 days from current date and time). If it is, a Predictive FDE Request message requesting "Detection Availability" with a required HAL of 0.3NM is sent to the GPS/SBAS receiver. In response, the GPS/SBAS receiver replies with a sequence of Predictive FDE Response messages. These messages are parsed and used to fill in the RAIM Prediction result area at the bottom of the screen. The RAIM Prediction result area shows the RAIM Prediction results as "OK" or "XX" for ETA \pm in 5-minute increments. Once a prediction is complete, press **START OVER (R2)** to perform another prediction without exiting the RAIM Prediction screen.

5.8. Active Flight Plan (ACTV) Menu

5.8.1. Main Menu

See Section 7 IFR Procedures for Active Flight Plan description.




Figure 5-7: Active Flight Plan Main Menu

5.8.2. Active Flight Plan (ACTV) Menus

Various options appear at the same menu level as the nav log selection list. These options allow various modifications to be made to the active flight plan as follows.




Figure 5-8: Active Flight Plan Menus

- SAVE (L1):** Saves active flight plan. Stored flight plans are saved without procedures or phantom waypoint (this is a safety item as procedures potentially change every 28 days). Stored flight plans are named by their first and last waypoints. If the new stored flight plan has the same start and end points as a previously saved flight plan but has different routing, a number (0-9) is appended to the name to uniquely identify up to 10 routings with the same start and end points.

- 2) **ACTV OFF (L2)**: Deletes active flight plan. Pilot is prompted to confirm deletion prior to completion of the operation.
- 3) **INFO (L3)**: Activates information menu for highlighted waypoint.
- 4) **PTK (L4)**: Shown if the active leg can be offset allowing the pilot to specify a parallel offset distance that applies to the active and contiguous legs. The range of parallel offsets are from 20NM left of track to 20NM right of track in 1NM increments.
- 5) **INSERT/ADD (R2)**: Inserts or adds a waypoint or airway into the active flight plan. If the highlighted position is one position past the end of the active flight plan, tile reads **ADD**, otherwise it reads **INSERT**. When highlighted waypoint is the second or subsequent waypoint of a procedure, tile does not appear. This prevents corruption of IFR approaches, STARs, and DPs. When activated, pilot is prompted to enter an identifier. To perform a search for waypoints, enter at least two characters. If only one character is entered, only airways are searched.

For waypoints, if there is a single result, it is inserted or added to the active flight plan. If there is no result, pilot is re-prompted to enter an identifier. If there are multiple results, a list with matching identifiers is presented and, upon selection, the selected waypoint is inserted or added to the active flight plan. **INFO (L3)** aids in selection and gives access to information for the highlighted result.

For airways, a search is performed for all airways going through the highlighted waypoint and matching the entered identifier (i.e., for a list of all Victor airways, Q-Routes and T-Routes, enter an identifier string of "V", "Q" or "T"). If there is a single result, a list of airway waypoints is shown to select the desired exit point. If there is no result, pilot is re-prompted to enter an identifier. If there are multiple results, a list with matching airway identifiers is presented and, upon selection, a list of airway waypoints is shown to select the desired exit point. Upon selecting the desired exit point, all airway waypoints from the previous waypoint to the desired exit point are inserted or added to the active flight plan.


- 6) **NRST APT (L2)**: Performs a search for 20 airports within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no airports within 240NM with a runway length greater than or equal to the minimum runway

length setting), **NO RESULTS** is displayed. Otherwise, a list is displayed including identifier, bearing, and distance to each result. Upon selecting a result, the item is inserted or added to the flight plan. **INFO (L3)** aids in selection and gives access to information for the highlighted result.

- 7) **NRST FIX (R2)**: Performs a search for 20 fixes within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no fixes within 240NM), **NO RESULTS** is displayed. Otherwise, a list is displayed including identifier, bearing, and distance to each result. Upon selecting a result, the item is inserted or added to the flight plan. **INFO (L3)** aids in selection and gives access to information for the highlighted result.
- 8) **NRST NDB (L4)**: Performs a search for 20 NDBs within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no NDBs within 240NM), **NO RESULTS** is displayed. Otherwise, a list is displayed including identifier, bearing, and distance to each result. Upon selecting a result, the item is inserted or added to the flight plan. **INFO (L3)** aids in selection and gives access to information for the highlighted result.
- 9) **NRST USR (R3)**: Performs a search for 20 user waypoints within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no user waypoints within 240NM), **NO RESULTS** is displayed. Otherwise, a list is displayed including identifier, bearing, and distance to each result. Upon selecting a result, the item is inserted or added to the flight plan. **INFO (L3)** aids in selection and gives access to information for the highlighted result.
- 10) **NRST VOR (L3)**: Performs a search for 20 VORs within 240NM nearest to the waypoint prior to the insertion point or, if there is no waypoint prior to the insertion point, current aircraft location. If there are no results (i.e., no VORs within 240NM), **NO RESULTS** is displayed. Otherwise, a list is displayed including identifier, bearing, and distance to each result. Upon selecting a result, the item is inserted or added to the flight plan. **INFO (L3)** aids in selection and gives access to information for the highlighted result.

Identifier Entry Box: The pilot may enter an identifier. To perform a search for waypoints enter of at least two characters. If there is a single result, it is inserted or added to the active flight plan. If there is no result, pilot is re-prompted to enter an identifier. If there are multiple results, a list with matching identifiers is presented and, upon selection, the selected waypoint is inserted or added to the active flight plan. **INFO (L3)** aids in selection and gives access to information for the highlighted result.

- 11) **DELETE (R3):** Not shown if the highlighted waypoint is a parallel offset entry or exit waypoint (these types of waypoints are deleted by removing the parallel offset). Otherwise, if the highlighted waypoint is a non-procedure waypoint, the function deletes the highlighted waypoint from the active flight plan. If the highlighted waypoint is part of a procedure, the function deletes the entire procedure from the active flight plan. Pilot is prompted to confirm deletion prior to completion of the operation. Tile does not appear if the highlighted waypoint is a non-procedure waypoint and there are fewer than three non-procedure waypoints in the active flight plan. This is because an active flight plan must always have at least two non-procedure waypoints. Tile also does not appear when the highlighted waypoint is suppressed or when the highlighted position is one position past the end of the active flight plan.

- 12) **Direct  (R4):** Not shown if the highlighted waypoint is a parallel offset entry or exit waypoint. Otherwise, inserts a phantom waypoint at the current aircraft location and makes the highlighted waypoint active. The phantom waypoint is a fly-over defined entry waypoint, and the leg prior to the phantom waypoint is designated a discontinuity. This assures the skyway is “re-centered” to provide guidance to the new active waypoint. Tile does not appear when highlighted waypoint is suppressed or when highlighted position is one position beyond the end of the active flight plan.


5.8.3. Active Flight Plan (ACTV) Menus (Step-By-Step)



- 1) Press **ACTV (L2)** to view active flight plan.



- 2) Scroll **1** to desired waypoint and push to enter.
- 3) Scroll **1** to desired option and push to enter.
- 4) As one option, a VNAV setting is entered.



- 5) As another option, deleting the next waypoint is accomplished.

5.8.4. Active Flight Plan (ACTV) Menu (Step-By-Step)



- 1) With desired flight plan selected and activated, press **ACTV (L2)** on the PFD or MFD to view active flight plan.



- 2) Scroll **1** to desired waypoint and push to enter.



- 3) Scroll **1** to **VNAV..** then to desired altitude and push to enter.
- 4) If no OFFSET is necessary, push **1** to enter.



- View active flight plan for further editing or press **EXIT (R1)** to clear active flight plan from view.

5.8.5. Active Flight Plan (ACTV) Options NRST Menu (Step-By-Step)



- With active flight plan displayed, press **INSERT.. (R2)** to see NRST options.
- Press **NRST APT.. (L2)**, **NRST VOR.. (L3)**, **NRST NDB.. (L4)**, **NRST FIX.. (R2)**, **NRST USR.. (R3)**, or **AIRWAY.. (R4)** to view applicable list. Scroll **1** to desired selection and push to insert into active flight plan.



- Press **SAVE (L1)** to save active flight plan as one of the 100 stored flight plans. (Any procedure within the saved active flight plan is not saved.)

5.9. Information (INFO) Menu

If **INFO** is activated from within the **ACTV**, **NRST**, or **Direct** menu, information on the highlighted waypoint is shown. Otherwise, the function checks for an active waypoint. If there is an active waypoint, it becomes the default entry. If there is no active waypoint, the nearest airport becomes the default entry. If the default entry is accepted, information for the default entry is shown. If the pilot rejects the default entry by entering identifier characters, a search

for matching identifiers is performed. If there is a single result, information for the result is shown. If there is no result, pilot is prompted to enter an identifier. If there are multiple results, a selection list with matching identifiers is presented. The amount and type of information presented depends on the type of waypoint as follows:

- | | |
|-----------------------------|-------------------------------|
| 1) Waypoints | 7) Latitude/Longitude |
| 2) Identifier | 8) Navigation aides |
| 3) Type | 9) Frequency |
| 4) Elevation (if available) | 10) Airports |
| 5) Long name | 11) Communication frequencies |
| 6) Bearing and distance | 12) Runway data |




Figure 5-9: Information Menu

For remote tuning, a single frequency is associated with the waypoint; tiles allow transmission to remote NAV or COM radios. **TO COM1** or **TO NAV1 (R2)** while a **TO COM2** or **TO NAV2 (R3)** is shown. If more than one frequency is associated with the waypoint (i.e., airport waypoint), tiles are shown to allow transmission of a frequency to remote NAV or COM radios when a frequency is highlighted in the **INFO** block. If the frequency is less than 118MHz, the tiles read **TO NAV#**, and the transmission is addressed to NAV radios. If the frequency is greater than or equal to 118MHz, the tiles read **TO COM#**, and the transmission is addressed to COM radios.

NOTE:

Frequencies are only sent to com or nav radios in the standby position. The pilot must swap frequencies to the active position in the applicable radio.

When information is presented for an ILS or localizer waypoint and the current VLOC1 or VLOC2 omnibearing selectors are not synchronized with the localizer course, **CRS SYNC (L4)** synchronizes **VLOC1 (L3)** and **VLOC2 (L4)** omnibearing selectors to the localizer course.



Figure 5-10: CRS SYNC

5.9.1. Information (INFO) Menu (Step-By-Step)



1) Press **INFO.. (L3)** to view active waypoint.



2) Push **1** to view information.

5.10. Omnibearing Selector (OBS) Menu




Figure 5-11: Omnibearing Selector (OBS) Menu


OBS menu allows the pilot to control the omnibearing selector for showing course deviations. Press **FMS (L2)** to specify a manual or automatic OBS setting in which the current active OBS is controlled by the active flight plan. OBS for **VLOC1** allows the pilot to specify the active OBS setting for the **VLOC1** navigation function. OBS for **VLOC2** allows the pilot to specify the active OBS setting for the **VLOC2** navigation function. Manual **FMS**, **VLOC1**, and **VLOC2 OBS** settings are settable in increments of 1°. **OBS SYNC (R3)** synchronizes manual **FMS**, **VLOC1**, or **VLOC2 OBS** settings

(depending on HSI source) to the inbound course or, if the inbound course cannot be determined, to aircraft heading.

When HSI source is **FMS**, **OBS AUTO/OBS MAN**  (**R4**) toggles between automatic and manual OBS settings.

With VOR symbology enabled, the pilot may select **FMS**, **VLOC1**, or **VLOC2** as the HSI source, which selects navigation source used to generate HSI guidance symbology.

If True North mode discrete input is not configured, the pilot may toggle between “TRUE NORTH” and “MAG NORTH” modes.

Upon selecting **RNP.. (R2)**, **RNP AUTO/RNP MAN**  (**R4**) toggles between automatic and manual RNP settings. Manual RNP is selectable between 0.10NM and 15NM as follows:

- 1) 0.01NM increments between RNP 0.10 and RNP 0.3
- 2) 0.1NM increments between RNP 0.3 and RNP 2
- 3) 1NM increments between RNP 2 and RNP 15

5.10.1. Omnibearing Selector (OBS) Menu (Step-By-Step)




- 1) Before pressing **OBS (L4)** to make any OBS changes, view the current setting to see if **FMS** is selected.



- 2) Press **OBS (L4)** and make HSI source selection or change to **OBS MANUAL (R4)**.

5.11. Heading Bug (HDG) Menu

Use the heading bug menu to set the heading bug in increments of 1°, synchronize to current heading, or turn off heading bug.


Figure 5-12: Heading Bug (HDG) Menu

5.11.1. Heading Bug (HDG) Menu (PFD Only) (Step-By-Step)



- 1) Scroll **1** to enter Heading mode.
- 2) Scroll **1** to change heading bug in 1° increments.
- 3) Push **1** or press **EXIT (R1)** to save new heading, or press **SYNC (R3)** to sync current heading then push **1** to enter or press **EXIT (R1)**.

5.12. Nearest (NRST) Menu

Upon selecting a category from the option list, a list of up to 20 items within 240NM matching the category appears. If the list is empty (i.e., no items within 240NM), **NO RESULTS** is displayed. The selection list includes identifier, bearing, and distance to the item. The list of airports contains only airports with runway length greater than or equal to the minimum runway length setting as configured during installation.

The list for airports, VORs, ILSs, NDBs, ARTCCs, and FSSs includes an associated frequency (CTAF for airports). Tiles allow transmission of the associated frequency to remote NAV or COM radios. If the frequency is greater than or equal to 118MHz, tiles read **TO COM#**, and transmission is addressed to COM radios. If the frequency is less than 118MHz, tiles read **TO NAV#**, and transmission is addressed to NAV radios, **TO COM1 (R2)**, or **TO COM2** or **TO NAV2 (R3)** position.




Figure 5-13: Nearest (NRST) Menu

In the case of **NRST ILS** where the current VLOC1 or VLOC2 OBS does not match the localizer course, **CRS SYNC (L4)** synchronizes VLOC1 and VLOC2 OBS to the localizer course.

Upon selecting airport, VOR, NDB, fix, or user waypoint, a new active flight plan is created from present aircraft position to the selected waypoint. Upon selecting ILS, **CONFIRM ACTIVATE ILS** is displayed. When the ILS is confirmed, the following actions occur:

- 1) A direct flight plan to the airport associated with the ILS is created;
- 2) A vectors-to-final ILS approach to the ILS is activated;
- 3) If the heading bug is turned OFF, the heading bug is activated to current heading to act as a starting point for receiving vectors (autopilot enabled systems only);

- 4) VLOC1 and VLOC2 OBS settings are set to the associated localizer course;
- 5) HSI source is switched as follows:
 - a) If only one nav radio is installed, source for the selecting side is changed to VLOC1. Source for the other side does not change.
 - b) If two nav radios are installed, default sensor for the selecting side controls which source is used. Source for the other side does not change.
- 6) Connected nav radios are remote tuned to ILS frequency if Remote Tuning is enabled in EFIS limits.


5.12.1. Nearest (NRST) Menu (Step-By-Step)



- 1) Press **NRST (R3)** to enter Nearest Menu.



- 2) Scroll **1** to **APT..** and push to enter.



- 3) Scroll **1** to desired airport. Select **INFO**, or send frequency to **COMM1** or **COMM2**.

5.12.2. Nearest ILS (NRST) Menu (Step-By-Step)



- 1) Press **NRST (R3)** to enter Nearest menu.

- 2) Scroll **1** to **ILS..** and push to enter.



- 3) Scroll **1** to desired airport and ILS approach then push to enter.



- 4) Push **1** to confirm and activate ILS.

5.13. Direct Menu




Figure 5-14: Direct Menu

Upon activating the direct menu from the top-level menu, the function checks for a current active waypoint and, if found, the active waypoint becomes the default entry. If there is no active waypoint, the nearest airport becomes the default entry.

If the default entry is the active waypoint and accepted by the pilot, a phantom waypoint is inserted at the current aircraft location. The phantom waypoint is a fly-over defined entry waypoint, and the leg prior to the phantom waypoint is designated a discontinuity. This assures the skyway is “re-centered” to provide guidance to the new active waypoint. The rest of the active flight plan remains unchanged.


If the default entry is not the active waypoint and accepted by the pilot, the resulting action depends upon whether the aircraft is in the air or on the ground. If in the air, a new active flight plan is created from present aircraft position to the selected waypoint. If on the ground, a search is conducted for a database airport within 6NM. If an airport is found, a new active flight plan is created from the found airport to the selected waypoint. Otherwise, a new active flight plan is created from present aircraft position to the selected waypoint.


If the pilot rejects the default entry by entering identifier characters, a search for matching identifiers is performed. If there is a single result, the resulting action depends upon whether the aircraft is in the air or on the ground. If in the air, a new active flight plan is created from present aircraft position to the selected waypoint. If on the ground, a search is conducted for a database airport within 6NM. If an airport is found, a new active flight plan is created from the found airport to the selected waypoint. Otherwise, a new active flight plan is created from present aircraft position to the selected waypoint.

If there is no result, pilot is re-prompted to enter an identifier. If there are multiple results, a selection list with matching identifiers is presented. Upon selection, the resulting action depends upon whether the aircraft is in the air or on the ground. If in the air, a new active flight plan is created from present aircraft position to the selected waypoint. If on the ground, a search is conducted for a database airport within 6NM. If an airport is found, a new active flight plan is created from the found airport to the selected waypoint. Otherwise, a new active flight plan is created from present aircraft position to the selected waypoint. **INFO (L3)** aids in selection and gives access to the information function for the highlighted result.

5.13.1. Direct Menu (Step-By-Step)



- 1) Press  (**R4**) to enter the Direct menu.
- 2) Active waypoint or, in absence of active waypoint, nearest airport appears.



- 3) Push **1** to insert phantom waypoint at current aircraft location or scroll **1** to enter new identifier.
- 4) After creating new identifier, scroll **1** to the end and push to enter. New active flight plan is



created from the present aircraft position.

- 5) If necessary, search waypoints for selection. Scroll **1** to desired selection and push to enter.

5.14. Time (TIME) Menu

Upon selecting the timer menu, a list to choose the count up timer, countdown timer, or flight time displays. **OFF (R4)** turns off any active timer functions. If count up timer is selected, it is activated. If the countdown timer is selected, the pilot is prompted to enter a start time from which the countdown begins. Shortcut tiles quickly add or decrement by five minute increments. After entering a start time, start the countdown timer or press **STORE (R4)** to store the start time for later use.

If UTC offset is selected, the pilot is prompted to enter a UTC offset between -12:00 and +14:00 in 15-minute increments. A shortcut button to select Zulu time (UTC offset = 0:00) is provided.




Figure 5-15: Time Menu

If the pilot selects the flight time display option, the elapsed time since the aircraft transitioned from ground to air mode is displayed for ten seconds or until any button is pressed. If the aircraft has not yet transitioned from ground to air mode, upon selecting the flight time display option, elapsed time is displayed as **FLT TM: 00:00:00**.

5.14.1. Time (TIME) Menu (Step-By-Step)



1) Press **MENU (R1)**.



2) Press **TIME.. (L4)** to enter TIME menu.



3) Scroll **1** to **COUNT UP**, **COUNT DN..**, or **FLT TIME**, and push to enter.



4) If **COUNT UP** is desired, push **1** to enter. Timer appears on the PFD above the pitch scale.



5) To turn off timer, press **MENU (R1)**, **TIME.. (L4)**, then **OFF (R4)**.

5.15. PFD Source (SOURCE) Menu

Upon activating the PFD source menu, an option list of sensor sources is shown for the pilot to select/deselect the following items:

- | | |
|-----------|---------------------------|
| 1) ADC1, | 5) GPS1, |
| 2) ADC2, | 6) GPS2, |
| 3) AHRS1, | 7) Radar Altimeter 1, and |
| 4) AHRS2, | 8) Radar Altimeter 2 |

If a Genesys ADAHRS is the selected AHRS and a DG/Slave discrete input is not configured for that AHRS, then “AHRS SLAVE”/“AHRS DG” tile appears to toggle between the two AHRS modes. If in DG mode without slew discrete inputs configured for the selected AHRS, then “AHRS SLEW” tile appears to enter a submenu that allows adjustment of the DG mode slewing value.




Figure 5-16: PFD Source Menu

5.15.1. PFD Page First-Level Source Selection (Step-By- Step)




- 1) Press **MENU (R1)**.
- 2) Press **SOURCE (L2)**.
- 3) Scroll **1** to check desired source, push to check, scroll to **DONE**, and push to enter.



- 4) When dual AHRS are installed with an AHRS offside select discrete in not configured.
- 5) When Genesys AHRS is installed and in DG Mode without discrete inputs for the selected AHRS.

5.16. PFD Bugs (BUGS) Menu

Upon selecting the PFD bugs menu, the following options:

- 1) **MINS (R3)**: Push **1** to select **DEC HT..** then **200 FT (R3)** or **OFF (R4)** , or set DH in increments of 10' or;
- 2) **MINS (R3)**: Scroll **1** to select **MIN ALT..** press **SYNC (R3)** to synch minimums to current altitude or scroll **1** to desired minimum altitude in increments of 10';
- 3) **IAS (L2)**: Set airspeed bug to sync with current airspeed, turn off, or set the bug in increments of 1 knot IAS). (No bug setting less than 1.2 V_s or 60KIAS, whichever is lower. No higher than V_{NE}, V_{MO}, M_{MO});
- 4) **VNAV CDA**  **(R4)**: Set VNAV climb or descent angle (setting either in increments of 0.1° with corresponding feet per nautical mile, or selecting a shortcut for **3° (R4)**);
- 5) **V-SPDS (L3)**: Set V-speeds options for either takeoff V-speed (V_1 , V_R , V_2 , and V_{ENR}) or approach V-speeds (V_{REF} and V_{APP}) or;
- 6) **VSI (L4)**: Set vertical speed by either synchronizing the VSI bug to the current VSI, turning the VSI bug off, or setting the VSI bug in increments of 100 feet per minute.

NOTE:

The airspeed bug and VSI bug are mutually exclusive, and therefore, selecting one turns off the other.




Figure 5-17: PFD Bugs (BUGS) Menu





Figure 5-18: PFD Bugs (BUGS) Menu (Continued)

5.16.1. PFD Bugs (BUGS) Menu (Step-By-Step)



- 1) Press **MENU (R1)** then **BUGS (R2)** to enter Bugs menu.
- 2) Press **IAS (L2)**, **VSI (L4)**, **MINS (R3)**, or **VNAV CDA (R4)**.




- 3) If **IAS (L2)** is entered, press **SYNC (R3)** to accept or **OFF (R4)** to turn off IAS bug.




- 4) If a different **IAS** bug is desired, scroll **1** to select desired airspeed and push to enter new value or press **EXIT (R1)**.




- 5) If **MINS (R3)** is selected, scroll **1** to **DEC HT..** or **MIN ALT..**. Push to enter.



- 6) If **DEC HT..** is selected, scroll **1** to create new decision height. Push to enter or press **EXIT (R1)**.



DH displays below FPM or next to analog AGL display.



- 7) If **VNAV CDA (R4)** is selected, scroll **1** to **DCND ANG..** or **CLIMB ANG...**. Push to enter or press **EXIT (R1)**.



- 8) If **DCND ANG..** is selected, scroll **1** to create descent angle. Push to enter or select default **3° (R4)**.

5.17. PFD Declutter (DCLTR) Menu

Upon activating the PFD declutter menu, an option list of declutter items is shown.




Figure 5-19: PFD Declutter (DCLTR) Menu


Table 5-4: PFD Declutter Options and Features

Declutter Options	Configuration		Notes
	Tapes	Basic	
PFD Analog AGL Indicator	✓	✓	
Full-Time or Auto Decluttered Bank Scale Display	✓		
Basic Mode	✓	✓	
PFD Mini-Map	✓	✓	
Skyway Guidance	✓		
Airspeed Trend	✓		Feature only
Non-TAWS	✓		SVS TAWS is labeled "SVS ADVANCED" when TAWS is not enabled
TAWS	✓		
Turn Rate Indication	✓	✓	

Table 5-4: PFD Declutter Options and Features

Declutter Options	Configuration		Notes
	Tapes	Basic	
Single Cue Flight Director	✓	✓	
Dual Cue Flight Director	✓	✓	
METERS	✓	✓	

5.17.1. PFD Declutter (DCLTR) Menu (Step-By-Step)



- 1) Press **MENU (R1)** then **DCLTR (R4)** to enter the Declutter menu.
- 2) Scroll **1** to select **ANLG AGL**, **BANK SCL**, **BASIC**, **MINI MAP**, **MINI TRFC**, **SKYWAY**, **SVS TAWS**, **SVS BASIC**, **TRAFFIC**, **TURN IND**, **FD1**, **FD2**, or **METERS** and push to enter.
- 3) If **BANK SCL** is unchecked press **EXIT (R1)** or scroll **1** to **DONE** and push to enter.

Bank Scale is removed while in level flight.
- 4) Scroll **1** to **SVS TAWS** and push to enter. Press **EXIT (R1)** or scroll **1** to **DONE** and push to enter.
- 5) For **SVS BASIC**, scroll **1** to **SVS BASIC** and push to enter. Press **EXIT (R1)** or scroll **1** to **DONE** and push to enter.



- 6) In the event of a TAWS warning, the system automatically switches back to **SVS TAWS** mode if terrain were disabled.



5.18. PFD Altimeter Menu





Figure 5-20: PFD Altimeter Menu

Press **BARO (R2)** to activate the altimeter menu. Scroll **1** to increment (CW) or decrement (CCW) the barometric setting and push **1** to accept the new barometric setting. In addition, the following options are available in the altimeter menu:

- 1) **QNH/QFE (L2)**: Toggles between QNH altimeter operation and QFE altimeter operation. When in QNH mode, QNE operation automatically is selected when above the transition altitude with a standard altimeter setting. The following definitions:
 - a) **QFE**: Barometric setting resulting in the altimeter displaying height above a reference elevation (e.g., airport or runway threshold).

- b) **QNE**: Standard barometric setting (29.92 inHg or 1013 mbar [hPa]) used to display pressure altitude for flight above the transition altitude.
 - c) **QNH**: Barometric setting resulting in the altimeter displaying altitude above mean sea level at the reporting station.
- 2) **TRANS ALT (L3)**: Changes transition altitude used by the system in units of 500 feet. Transition altitude is used to generate barometric setting warnings and to determine QNE/QNH operation. If current transition altitude is not 18,000 feet, **18000' (R4)** quickly sets 18,000 feet as the transition altitude.
 - 3) **MBAR/IN HG (L4)**: Sets barometric setting units (inHg or mbar).
 - 4) **STD**  **(R4)**: Sets barometric setting to standard (29.92 inHg or 1013 mbar).

5.18.1. PFD Altimeter Menu (Step-By-Step)



- 1) Press **BARO (R2)** to enter the Altimeter menu.
- 2) Scroll **1** to set proper QNH and push to enter.
- 3) Crosscheck proper QNH under altitude indication.



- 4) Press **BARO (R2)** again and **STD (R4)** to reset QNH to 29.92 and push to enter.

5.19. MFD Fault Display (FAULTS) Menu




Figure 5-21: MFD Fault Display Menu

Upon selecting the MFD faults menu, the status of the following system parameters are displayed:

- 1) GPS/SBAS loss of navigation due to absence of power (GPS PWR)
- 2) GPS/SBAS loss of navigation due to probable equipment failure (GPS EQPMNT)

- 3) GPS/SBAS loss of navigation due to inadequate satellites to compute a position solution (GPS SATLT)
- 4) GPS/SBAS loss of navigation due to a position failure that cannot be excluded within the time to alert (GPS FDE)
- 5) GPS/SBAS loss of integrity and loss of navigation due to loss of integrity (GPS LOI)
- 6) Readout of current GPS/SBAS horizontal protection level (GPS HPL) in nautical miles. This value may be used as the estimate of position uncertainty required in RNP airspace.
- 7) Readout of current GPS/SBAS vertical protection level (GPS VPL) in meters.
- 8) Readout of the current GPS/SBAS horizontal figure of merit (GPS HFOM) in nautical miles. This value is an indication of the 95% confidence horizontal position accuracy.
- 9) Readout of the current GPS/SBAS vertical figure of merit (GPS VFOM) in meters. This value is an indication of the 95% confidence vertical position accuracy.
- 10) An indication of whether the GPS/SBAS receiver has a valid almanac in memory (GPS ALMANAC).
- 11) GPS/SBAS loss of navigation due to no valid SBAS message received for four seconds or more (SBAS MSG).
- 12) GPS/SBAS loss of navigation due to insufficient number of SBAS HEALTHY satellites (SBAS HLTH).
 - a) An Attitude or Range Fault Condition exists.
 - b) A Control Fault Condition exists.
 - c) A T/R Fault Condition exists.
- 13) If the analog interface option is enabled, loss of communications with the analog interface (AIU).

5.19.1. MFD Fault Display (FAULTS) Menu (Step-By-Step)



1) Press **MENU (R1)** then **FAULTS (L1)** to view the Faults menu.



2) View status of GPS and equipment parameters.

5.20. MFD Fuel Totalizer Quantity Setting (SET FUEL) Menu




Figure 5-22: MFD Fuel Totalizer Quantity Menu

The fuel quantity setting menu allows the pilot to:

- 1) Set the fuel totalizer quantity in increments of volume units.
- 2) If either a fuel totalizer or fuel level sensing (with no unmonitored fuel) is configured in the aircraft limits, set emergency and minimum fuel bugs in increments of volume units.

MAINS (R3) sets the quantity to the “fuel tabs” fuel capacity, and

FULL (R4) sets the quantity to the total aircraft fuel capacity. Units of measure and fuel flow are shown in the quantity window when available.

5.21. MFD Page (PAGE) Menu

PAGE menu allows the pilot to select which MFD page to display:

- 1) **MAP:** ND page
- 2) **HSI:** HSI page
- 3) **NAV LOG:** FMS page
- 4) **STRIKES:** Strike page (See Strikes Appendix)
- 5) **TRAFFIC:** Traffic page (See Traffic Appendix)
- 6) **DATALINK:** Datalink page (See Datalink Appendix)
- 7) **WX-RDR:** Weather Radar page (See Weather Appendix)
- 8) **VIDEO:** Video page (See Video Appendix).






Figure 5-23: MFD Page (PAGE) Menu

5.21.1. MFD Page (PAGE) Menu (Step-By-Step)



- 1) Press **MENU (R1)**.
- 2) Press **PAGE.. (R3)** to view page menu.
- 3) Push and scroll **1** to **MAP, HSI, NAV LOG, STRIKES, TRAFFIC, DATALINK, WEATHER RADAR, or VIDEO**. Push to enter.

5.22. MFD NAV Log Page



WAYPOINT UNNU/OFFSET	PATH	DIST	ETE	ETA	FUEL
START	Q120UN1	25.254	0+10	13:00	332
IP	Q 218*	10.04	0+17	13:00	332
LAFFS	Q 218*	5.24	0+02	13:40	321
RH2L	Q 6* 830*	5.6	0+00	13:42	316
RNC	Q 233*	5.7	0+00	13:42	316
IC	Q 26*	15.2	0+18	13:48	315
MICRO	Q 254*	5.8	0+08	14:06	331
MICRO	Q 254*	5.8	0+08	14:16	324
(KLFT)	-----	-----	-----	-----	-----

- 1) Press **MENU (R1)** then **PAGE (R3)**. Scroll **1** to **NAV LOG**. Push to enter.
- 2) **NAV LOG** page cannot be formatted or used to edit the active flight plan.

5.23. MFD ND Page Format (FORMAT) Menu

Upon selecting the MFD format menu when in the ND page, an option list appears with the following:

- 1) **CENTER/ARC**: Toggles between a centered and arced ND display format (if not panning).
- 2) **HDG UP/N UP**: Toggles between a heading up and a North up ND display format (if not panning).
- 3) **PAN ON/PAN OFF**: Toggles ND page pan mode.
- 4) **SYMB DCLTR**: Activates a list to choose either automatic navigation symbol declutter or manual navigation symbol declutter. If the pilot chooses manual navigation symbol declutter, a further list appears to individually select:

- a) large airports;
- b) IFR airports;
- c) VFR airports;
- d) VORs;
- e) NDBs;
- f) fixes;
- g) terminal fixes; and
- h) user waypoints.



Figure 5-24: MFD Symbol Declutter

Turning on VFR airports also turns on large and IFR airports. Turning on IFR airports also turns on large airports. Turning off large airports also turns off IFR and VFR airports. Turning off IFR airports also turns off VFR airports.

- 5) **FNCT DCLTR**: Activates a list to individually toggle display of:
- a) airspace;
 - b) borders;
 - c) datalinked NEXRAD, graphical METARs and lightning ground strikes (if datalink or ADS-B option is enabled);
 - d) estimated time of arrival (ETA);
 - e) high-altitude airways;
 - f) low-altitude airways;
 - g) current latitude and longitude display of ADF #1 pointer (if ADF symbology is enabled);
 - h) ADF #2 pointer (if dual ADF symbology is enabled);
 - i) VOR1 pointer (if VOR symbology is enabled);
 - j) VOR2 pointer (if dual VOR symbology is enabled);
 - k) Strikes (if WX-500 option is enabled);
 - l) Terrain;
 - m) Traffic (if traffic option is enabled); and
 - n) Weather radar (if weather radar option is enabled).





Figure 5-25: MFD ND Page Format Menu

5.23.1. MFD ND Page Format (FORMAT) Menu (Step-By-Step)



1) Press **MENU (R1)** and **FORMAT.. (R4)**.



2) Scroll **1** to **FNCT DCLTR..** Push to enter.



3) Scroll **1** to **LAT/LON** and push to enter. Press **EXIT (R1)** or scroll to **DONE** and push to enter.

5.24. MFD HSI Page



1) Press **MENU (R1)** then **PAGE (R3)**.



2) Scroll **1** to **HSI** and push to enter.

5.24.1. MFD HSI Pointer (PTRS) Menu

Upon selecting the HSI pointers menu when in the HSI page, an option list appears to allow the pilot to individually select display of:

- 1) ADF1 pointer (if ADF symbology is enabled);
- 2) ADF2 pointer (if dual ADF symbology is enabled);
- 3) VOR1 pointer (if VOR symbology is enabled); and
- 4) VOR2 pointer (if dual VOR symbology is enabled).





Figure 5-26: MFD HSI Pointer (PTRS) Menu

Section 6 Quick Start Tutorial

Quick Reference Guide (DOC 64-000101-080E)



Begin by reading the EFIS Aircraft Flight Manual (AFM) or Aircraft Flight Manual Supplement (AFMS).



Power up the EFIS. The system performs a built-in test routine. If all tests pass, the system displays a screen identifying the database coverage. Press any button to acknowledge, and the system begins a two-minute countdown while awaiting sensor initialization. (For purposes of flight planning, etc., press any button to override this countdown.)



The right encoder is numbered #1 (1).

1

PFD




Press **BARO (R2)** and scroll 1 to desired QNH and push to enter or press **EXIT (R1)**.



Press **(R4)** for Direct To menu. If in the air, the nearest airport appears. Scroll **(1)** to alpha or numerical character then push to confirm and advance to the next position. Push to enter, until all five spaces have been entered or viewed.



Magenta star bearing to the waypoint and green diamond ground track symbols are displayed on the directional scale.



A direct route to the active waypoint is activated and appears as magenta tethered balloon on the PFD as shown.



Indicated airspeed is on the left, altitude is on the right, and heading is across the top. An FMS/VLOC CDI is located on the bottom. The VSI appears on the right side of the altitude tape. The active waypoint is in the lower right corner.



On the MFD, press **MENU (R1)** to view soft menu selections for easy access with press of appropriate IDU button.

Flight Plans (Stored Routes)

Activate Flight Plan on PFD or MFD

- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **SELECT..** and push to enter.
- 3) Scroll **1** to select desired flight plan and push to activate.

Create Flight Plan on MFD

- 1) Press **FPL (L1)**.
- 2) Scroll **1** to **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **CREATE FLIGHT PLAN** and push to enter.
- 4) Press **ADD (R2)** to create first waypoint using **1** to enter waypoints from beginning to end or press **NRST APT (L2)**, **NRST VOR (L3)**, **NRST NDB (L4)**, **NRST FIX (R2)**, or **NRST USR (R3)**, select next waypoint, and push to enter.
- 5) Press **SAVE (R4)** to save flight plan.
- 6) Press **EXIT (R1)** to exit Flight Planner.

Waypoints

Create a User Waypoint on PFD or MFD

- 1) Press **MENU (R1)**.
- 2) Press **DESIG (L3)**.

Edit a User Waypoint on MFD

- 1) Press **FPL (L1)**.
- 2) Scroll **1** to highlight **CREATE-EDIT..** and push to enter.
- 3) Scroll **1** to **EDIT USER WPT** and push to enter.
- 4) Scroll **1** to highlight waypoint to edit and push to enter.
- 5) Scroll and push **1** through menu for all changes.
- 6) Press **SAVE (R4)** to save changes. Press **EXIT (R1)** to exit menu.

Add Waypoint to an Active Route on PFD or MFD

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to location in waypoint list where added waypoint is to be inserted above.
- 3) Press **INSERT (R2)**.
- 4) Press **NRST APT (L2)**, **NRST VOR (L3)**, **NRST NDB (L4)**, **NRST FIX (R2)**, **NRST USR (R3)**, or **AIRWAY (R4)** and then
 - a) Scroll **1** to make selection and push to enter, or
 - b) Use **1** to enter waypoint identifier and push to enter.

Delete Waypoint from an Active Route on PFD or MFD

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to waypoint to delete. If part of a published procedure, press **DELETE (R3)** to prompt **CONFIRM DEL PROC**.
- 3) Push **1** to **CONFIRM DEL PROC** and push to enter.

Omnibearing Selector Function

Automatic OBS (FMS OBS Only) on PFD or MFD

- 1) Press **OBS (L4)**.
- 2) Push **1 OBS:AUTO** to enter.

Manual OBS on PFD or MFD

- 1) Press **OBS (L4)**.
- 2) Select desired HSI source, press **NAV VLOC1 (L3)** or **NAV VLOC2 (L4)**.
- 3) If HSI source is NAV FMS, press **OBS MANUAL (R4)** then scroll **1** to desired OBS value and push to enter, or press **OBS SYNC (R3)** and push **1** to enter.
- 4) If HSI source is **NAV VLOC1 (L3)** or **NAV VLOC2 (L4)**, scroll **1** to desired course (OBS:XXX° (XXX°)) and push to enter.

Approaches/Track

Select a VFR Approach on PFD or MFD

(The active flight plan must contain an eligible airport for runway selection and VFR approach creation.)

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to highlight airport or user waypoint, push to enter.
- 3) Scroll **1** to highlight **VFR APPR..** and push to enter.
- 4) Scroll **1** to select desired runway and push to enter.

Change Runway during VFR Approach on PFD or MFD

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to highlight the following and push to enter:
 - a) Eligible airport
 - b) **VFR APPR..**
 - c) Desired runway

(This will delete the previous VFR approach and create a new VFR approach to the selected runway.)

Select an IFR Approach on PFD or MFD

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to desired eligible airport and push to enter.
- 3) Scroll **1** to **IFR APPR..** and push to enter.
- 4) Scroll **1** to desired approach and push to enter.
- 5) Scroll **1** to desired transition and push to enter.
- 6) Scroll **1** to desired runway and push to enter.

Change Runway on IFR Approach on PFD or MFD

- 1) Press **ACTV (L2)**.
- 2) Scroll **1** to destination airport and push to enter.
- 3) Select **APPR**: Scroll **1** to desired approach. Push to enter.
- 4) Select **TRANS**: Scroll **1** to desired transition. Push to enter.
- 5) Select **RW**: Scroll **1** to desired runway. Push to enter.

(This will delete the previous IFR approach and create a new IFR approach to the selected runway.)

XFILL SYNC Operation

XFILL Sync Operation on PFD

(Crossfill is the normal default mode of operation.)

- 1) During crossfill inhibited operation, **XFILL INHBT** appears in the PFD in the lower left corner.
- 2) When the pilot and co-pilot systems are not synchronized, **XFILL ARM** appears in lower left corner of the PFD.
- 3) When the pilot and co-pilot systems are not synchronized, press **MENU (R1)** then **XFILL SYNC (L1)** to synchronize the pilot and co-pilot active flight plan parameters from the system where the button press occurred.



Section 7 IFR Procedures

7.1. Active Flight Plan

Upon activation of the active flight plan menu, the application checks for an active waypoint. If there is no active waypoint, **NO ACTIVE WPT** is issued. Otherwise, a nav log of waypoints in the active flight plan is presented with the following:

- 1) Waypoint identifier and characterization (default, overfly **[OF]**, or no radius **[OR]**)
- 2) Symbol designating waypoint type and what type of procedure (if any) the waypoint is associated
- 3) VNAV altitudes and offsets associated with each waypoint
- 4) Information related to the flight plan path between each waypoint.

In the case of an approach with a Final Approach Segment data block, the VNAV Offset readout associated with the Missed Approach Point is “GPI” to designate distance to the Glidepath Intercept point. When courses are presented as part of the path information, they are displayed referenced to magnetic North with the degree (°) symbol.

VNAV altitudes and offsets from the navigation database or have been manually entered are shown in white, and those computed automatically are shown in gray. The current active waypoint is designated by an asterisk and shown in magenta but turns amber (yellow) in the event of a GPS Loss of Navigation caution.

A suppressed waypoint (designated by brackets) is an airport associated with an IFR or VFR approach procedure. After an approach procedure is activated, the associated airport is no longer part of the active flight plan for guidance purposes. However, the associated airport is still shown in the nav log for it to be highlighted for information or to activate other procedures to the airport. Since only one approach may be active at any given time, only one waypoint may be suppressed at any given time.

A skipped waypoint is a waypoint associated with a dynamic termination leg with a zero length. These are either:

- 1) An altitude termination leg when current aircraft altitude is above the termination altitude; or
- 2) System-created (i.e., not NavData specified) intercept to a “Course to a Fix” leg where there is insufficient distance to calculate an intercept heading.

To add a waypoint to the end of the active flight plan, scroll through each waypoint of the flight plan to one position past the end. If not, the application makes the selected waypoint active. Otherwise, an option list is presented.

Upon selection of a waypoint from the selection list, the EFIS checks whether the selected waypoint meets the criteria for waypoint activation, manual VNAV parameter entry, custom holding pattern entry, manual overfly characterization, VFR approach entry, IFR approach entry, STAR entry, or DP entry. If it does, an option list is presented as follows:

- 1) **WAYPOINT:** If selected waypoint is neither suppressed, skipped, nor a manual termination, make the selected waypoint the active waypoint.
- 2) **VNAV:** If selected waypoint is neither suppressed, skipped, a manual termination, part of an IFR approach, nor part of a VFR approach, enter a manual VNAV altitude and offset for the selected waypoint. This level includes tiles to synchronize the VNAV altitude to current altitude and to remove the manual VNAV altitude and offset entry. VNAV altitudes are settable in increments of 100 feet, and offsets are settable in increments of 1NM.
- 3) **HOLD:** If selected waypoint is neither suppressed, skipped, a manual termination, part of an IFR approach after the FAF/FAWP, part of a VFR approach, a holding waypoint, nor a DP anchor waypoint, enter a manual holding pattern at the selected waypoint. Define the course, turn direction (left or right), and leg length (expressed as either distance or time) for the manual holding pattern. Holding pattern course is settable in increments of 1° and leg length is settable in increments of 1NM or a tenth of a minute.
- 4) **OFLY/AUTO:** If selected waypoint is neither suppressed, skipped nor a manual termination, change the waypoint’s overfly characterization. The choices are:

- a) **AUTO**: Reset automatic overfly characterization by FMS.
- b) **OVERFLY**: Force the overfly characterization to be an overfly adjust-exit waypoint and force the inbound course to go directly to the waypoint regardless of the amount of course change required.
- c) **NO RADIUS**: Force the turn radius at the waypoint to be zero, which forces the inbound course and outbound course to go directly to and from the waypoint regardless of the amount of course change required.

NOTE:

It is not possible to track a “NO RADIUS” path perfectly, but the FMS path guidance quickly recaptures the outbound course after automatic waypoint sequencing. Designating a waypoint as a “NO RADIUS” waypoint affects the turn radius used to calculate procedure turn and holding pattern leg paths.

- 5) **VFR APP**: If selected waypoint is a user waypoint with an approach bearing, a VFR approach to the user waypoint based upon the approach bearing is created, and the user waypoint is suppressed. If the selected waypoint is a VFR airport or an IFR airport with surveyed runways, the pilot is presented with a list of runways. After selecting a runway, a VFR approach to the runway is created, and the airport waypoint is suppressed. Activating a VFR approach deletes any pre-existing IFR or VFR approaches. If a heading bug is not already active, activating a VFR approach activates the heading bug on current aircraft heading and is used to define the course intercept angle.
- 6) **IFR APP**: If selected waypoint is an airport with an IFR approach, the pilot is presented with a list of available approaches (including, if applicable, the five-digit channel number, followed by a selection list of available transitions, if there are more than one) and a list of runways (if there are surveyed runways at the airport). After selection, the appropriate IFR approach is created, and the airport waypoint is suppressed. Activating an IFR approach deletes any pre-existing IFR or VFR approaches. If there is a pre-existing STAR to the airport, the IFR approach waypoints are inserted after the STAR waypoints. If a heading bug is not already active, and the activated transition is “Vectors to Final,” activating an IFR

approach activates the heading bug on current aircraft heading for purposes of defining the course intercept angle.

- 7) **STAR:** If selected waypoint is an airport with a STAR, the pilot is presented with a list of available STARs, followed by a list of available transitions (if there are more than one) and a list of runways (if there are surveyed runways at the airport). After selection, the appropriate STAR is created. Activating a STAR deletes any pre-existing STAR. If there is a pre-existing approach (IFR or VFR) to the airport, the STAR waypoints are inserted prior to the approach waypoints.
- 8) **DP:** If selected waypoint is an airport with a DP, the pilot is presented with a list of DPs, followed by a list of available transitions (if there are more than one) and runways (if there are surveyed runways at the airport and more than one runway is authorized for the DP). After selection, the appropriate DP is created, and upon activation, deletes any pre-existing DPs.

7.2. IFR Procedures

Pilots operating in a radar environment are expected to associate departure headings or an RNAV departure advisory with vectors or the flight path to their planned route or flight. Use of both types of departure procedures; Obstacle Departure Procedures (ODP), which are printed textually or graphically, and Standard Instrument Departure procedures (SIDs), which are always printed graphically. All DPs, either textual or graphic, may be designed using either conventional or RNAV criteria. RNAV procedures have RNAV printed in the title.

ODPs are not found in the navigation database, and therefore the climb angle found in the PFD BUGS menu should be set to comply with the steeper than normal climb gradient during the departure until established on the enroute structure. ODPs are recommended for obstruction clearance and may be flown without ATC clearance, unless an alternate departure procedure (SID or radar vector) has been specifically assigned by ATC.

Approach minima are never coded in NavData. On some approaches, the altitude coded at the MAP for a non-precision approach coincides with an MDA (normally where the final approach course does not align with the runway), but more often the coded altitude is some height above the threshold.

7.3. Overview of Procedures and Instrument Approaches

This Genesys Aerosystems EFIS provides three-dimensional GPS Precision and Non-precision instrument approach guidance using a system integral TSO C146c BETA 3 GPS receiver with GPS and augmented GPS with SBAS (Satellite Based Augmentation System) commonly referred to as WAAS (Wide Area Augmentation System). In order to support full integration of RNAV procedures into the National Airspace System (NAS), a new charting format for Instrument Approach Procedures (IAPs) has been designed to avoid confusion and duplication of Instrument Approach Charts.

Use of this GPS receiver provides a level of certified service supporting RNAV (GPS) approaches to LNAV, LP, LNAV/VNAV, and LPV lines of minima within system coverage. Some locations close to the edge of the coverage may have lower availability of vertical guidance.

Approach with Vertical Guidance (APV) procedures are defined in ICAO Annex 6 and include approaches such as LNAV/VNAV procedures presently being flown with barometric vertical navigation (BARO-VNAV). These approaches provide vertical guidance but do not meet the more stringent standards of a precision approach. With the BETA 3 GPS receiver and updatable navigation database in this system, these approaches may be flown using an electronic glidepath, which eliminates the errors introduced by using barometric altimetry.

In addition to LNAV/VNAV procedures, APV takes advantage of the high accuracy guidance and increased integrity provided by GBS/SBAS. This SBAS (TEROS/ICAO) generated angular guidance allows the use of the same TERPS approach criteria used for ILS approaches. The resulting approach procedure minima, LPV (Localizer Performance with Vertical guidance), may have a decision altitude as low as 200 feet height above touchdown (EASA OPS LPV 250 ft.) with visibility minimums as low as ½ mile (providing the terrain and airport infrastructure and regulations support the lowest minima criteria).


Another non-precision GPS/SBAS Approach is certified as an LP (Localizer Performance) approach where terrain or obstructions prohibit the certification of the LPV vertically guided approach. This approach takes advantage of the angular lateral guidance and smaller position errors (provided by GPS/SBAS) to provide a lateral only procedure similar to an ILS Localizer. LP procedures may

provide lower minima than a LNAV procedure due to the narrower obstacle clearance surface. In the LP approach, vertical guidance is for information only and is based on SBAS or BARO information.

The Genesys Aerosystems EFIS guides the pilot through every step of the approach procedure with Highway in the Sky 3-D symbology. The system defines a desired flight path based upon the active flight plan. The current position of the aircraft is determined relative to the desired path in order to determine lateral deviation for display on the GPS/SBAS CDI and VDI. The IDU auto-sequences from one waypoint to the next in accordance with the flight plan along the flight path with the following exceptions:

- 1) The pilot has selected a manual GPS/SBAS OBS (**SUSPEND** shown).
- 2) The active waypoint is the missed approach waypoint, and the missed approach procedure has not been armed (**ARM**) or initiated (**MISS**) (**SUSPEND** shown).
- 3) The aircraft is in a published or manually created holding pattern, and the pilot has not chosen to continue (**CONT**) out of the holding pattern (**SUSPEND** shown).
- 4) The active waypoint is the last waypoint of the active flight plan (no flag shown).

The linear vertical scale limits of the VDI for LNAV/VNAV and LPV approaches are shown in Figure 7-1.



Note: Offset conical vertical deviation reference surface and hyperboloid surface are not depicted.

Figure 7-1: Vertical Deviation Indicator Linear Deviation

7.3.1. Highway in the Sky (Skyway)

When not decluttered, the PFD displays the active navigation route or manual OBS course in a three-dimensional manner using a series of skyway boxes, which are a series of perspective objects overlying the flight plan route at a desired altitude providing lateral and vertical guidance. The skyway boxes conform to the VNAV requirements of GPS/SBAS receiver requirements (TSO-C-146C). The top and bottom sides of the boxes are parallel to the horizon on straight leg segments and dynamically tilt with respect to the horizon on turning leg segments based upon leg segment turn radius and groundspeed. When the active route is in view, up to five boxes are shown with the dimensions being a constant 400 feet wide (± 200 feet from the desired lateral path) by 320 feet tall (± 160 feet from the desired vertical path) spaced horizontally 2000 feet. The skyway boxes are drawn using the hidden surface removal techniques of the terrain and obstruction rendering so a skyway box behind terrain appears to be so. The skyway boxes disappear in Basic Mode and Unusual Attitude Mode. In reversionary mode 1 (GPS failure), the skyway boxes disappear after one minute to indicate degraded navigation performance.

Table 7-1: Highway in the Sky Configuration

Type HITS Lines	Fully Integrated Autopilot	Partially Integrated Analog Autopilot (HDG Mode and/or NAV/APR mode discrete inputs)	Un-Integrated Autopilot or No Autopilot
Dashed	Not coupled to skyway		
Solid	Coupled to skyway	Coupled to skyway. Autopilot is either in HDG mode with LNAV heading/roll-steering sub-mode engaged or in NAV/APR mode with the FMS, FMS1, or FMS2 as the selected navigation source.	Always Solid

Skyway box altitude is controlled by VNAV altitude, aircraft altitude, aircraft climb performance, and climb/descent angle setting. If no

VNAV altitude is set, the skyway boxes describe the desired lateral flight path of the aircraft at the aircraft's current altitude.

With a VNAV altitude set, the boxes provide both lateral and vertical guidance. Climb and descent angle settings are controlled individually with a resolution of 0.1°. VNAV is guided by VNAV waypoints determined by VNAV altitude and VNAV offset from flight plan waypoints. There are two sources for VNAV altitudes, the navigation database and manual input through the ACTV menu. VNAV altitudes for waypoints without a navigation database or manually input VNAV altitude are automatically computed by the system using "look-ahead" rules. When "look-ahead" finds a further VNAV altitude constraint above the previous VNAV altitude constraint (i.e., climb commanded), an automatic VNAV altitude is continuously calculated for the waypoint based upon an immediate climb to the altitude constraint at the higher of actual climb angle or the climb angle setting (dynamic climb angle). When "look-ahead" finds a further VNAV altitude constraint below the previous VNAV altitude constraint (i.e., descent commanded), an automatic VNAV altitude is calculated for the waypoint based upon a descent to reach the VNAV altitude constraint at the associated waypoint using the descent angle setting. If no further VNAV altitude constraints are found, the automatic VNAV altitude is set to the last valid VNAV altitude constraint.

When a VNAV climb is desired, the boxes are drawn at a vertical position the higher of: (a) the dynamic climb angle emanating from the aircraft's present position (aircraft-referenced); (b) the dynamic climb angle emanating from the next waypoint VNAV altitude (geo-referenced forward); or (c) the climb angle setting emanating from the previous waypoint VNAV altitude (geo-referenced backward). The geo-referenced backward calculation is only considered when the current leg is part of a procedure and is designed to provide pilot awareness, if a specified climb gradient is not being met. Once the boxes intercept the VNAV altitude, further boxes are drawn with a zero angle to show a level off followed by a level flight segment. Because five boxes are shown, the level-off depiction is an anticipatory cue for the pilot. Climb guidance is depicted in Figure 7-2, Figure 7-3, and Figure 7-4.




Figure 7-2: Highway in the Sky (Aircraft Referenced)




Figure 7-3: Highway in the Sky (Geo-Referenced Backward)




Figure 7-4: Highway in the Sky (Geo-Referenced Forward)

When a VNAV descent is desired, boxes are drawn with a zero angle until reaching a descent point. Further boxes are drawn downward at an angle corresponding to the descent angle setting. The descent point is defined by the intercept of a line emanating upward from the subsequent VNAV waypoint at the descent angle setting and a line representing level flight at the previous VNAV altitude. On the final approach segment of an IFR approach, descent angle and VNAV waypoint are defined as follows.

Table 7-2: Final Segment of IFR Approach, Descent Angle and VNAV Waypoint

Condition	VNAV Waypoint	Descent Angle
IFR Approach with valid Final Approach Segment data block	Glidepath Intercept Point as defined in Final Approach Segment data block	Descent Angle as defined in Final Approach Segment data block
No or invalid Final Approach Segment data block No intermediate waypoints exist between Final Approach Fix and Missed Approach Point.	Missed Approach Point location	Straight line from Final Approach Fix to Missed Approach Point location and altitudes.
No or invalid Final Approach Segment data block Intermediate waypoints exist between Final Approach Fix and Missed Approach Point.	Missed Approach Point location	Steepest descent angle based upon straight lines from the Final Approach Fix and subsequent Intermediate Waypoints to Missed Approach Point location and altitudes.

On the final approach segment of a VFR approach procedure, the higher of the descent angle setting or 3° is used.

Because five boxes are shown, the descent point depiction is an anticipatory cue. Figure 7-5 depicts descent guidance and creates

an easily understood, yet safe, VNAV paradigm meeting the VNAV requirements current guidance.

Further, the paradigm is biased towards keeping the aircraft at the highest altitude possible for the longest period of time, The climb paradigm compensates for an aircraft's ability to climb more steeply than specified and warns of being below a desired climb gradient when the aircraft is unable to meet the specified climb angle. The descent paradigm encourages flying stabilized approaches.



Figure 7-5: Highway in the Sky Final Approach Segments

7.3.2. Waypoint Sequencing

Where automatic waypoint sequencing is suspended due to reasons 1, 2, or 4 in § 7.3, the EFIS automatically switches from TO operation to FROM operation when appropriate. If not suspended, automatic waypoint sequencing occurs upon the following conditions:

- 1) Bearing to the transition point (turn bisector for fly-by waypoint, active waypoint for fly-over waypoint) is more than 90° from the current course (i.e., transition from “TO” to “FROM” operation);
- 2) Aircraft location is within two turn diameters (based upon current True Airspeed and 15° angle of bank) of the active waypoint location; and
- 3) Aircraft heading is within 90° of the current course (i.e., generally pointed in the correct direction).

The desired flight path is created from a sequence of straight, left turning, and right turning leg segments designed to provide smooth skyway, GPS/SBAS CDI, and lateral autopilot guidance. Each leg between waypoints is composed of up to nine segments. Radii for turning segments (other than DME arc or Radius to a Fix segments) are calculated with the parameter speed determined as follows:

- 1) If the waypoint is part of a DP and within 30 NM of the departure runway, speed is the preprogrammed Procedure Speed.
- 2) If the waypoint is part of a STAR and within 30 NM of the arrival runway, speed is the preprogrammed Procedure Speed.
- 3) If the waypoint is part of an IAP or VFR Approach Procedure, speed is the preprogrammed Procedure Speed.
- 4) If the waypoint is part of a Holding Pattern, speed is the preprogrammed Procedure Speed.
- 5) Otherwise, speed is the current True Airspeed or preprogrammed Procedure Speed, whichever is higher.

In all cases, if NavData derived speed limit is associated with the waypoint, speed is the lower of the NavData derived speed limit or the speed determined above.

7.3.3. Fly-Over Waypoints

For creating the desired flight path, each waypoint is designated as a fly-by waypoint or a fly-over waypoint. Waypoints are further subdivided into waypoints with a defined entry heading and waypoints with a defined exit heading. Waypoint auto-sequencing for fly-by waypoints occurs at the bisector of the turn. Waypoint auto-sequencing for fly-over waypoints occurs over the waypoint.




Figure 7-6: Fly-Over Waypoints

The following waypoints are Fly-Over with Defined Entry Heading:

- 1) Exit from holding pattern;
- 2) Exit from procedure turn;
- 3) Entry into holding pattern;
- 4) Missed Approach Point;
- 5) Phantom Waypoint (waypoint created by either inserting a waypoint into the active flight plan or performing the Direct-To function within the active flight plan -- avoids S-turns);
- 6) Last waypoint;
- 7) Start waypoint (waypoint created by creating a new active flight plan with the Direct-To function – avoids S-turns);
- 8) Reference (takeoff runway end) waypoint of a DP;
- 9) Waypoint leading into discontinuity; and
- 10) Altitude, DME, or Radial termination legs (ARINC-424 path types CA, FA, VA, CR, VR, CD, FD, and VD).
- 11) Waypoints marked as overfly in the navigation database.

The definitions of leg type designators are as follows.

Table 7-3: RNAV Path Terminator Leg Type





Path	Designator		Terminator
Constant DME arc	A	A	Altitude
Course to	C	C	Distance
Direct Track	D	D	DME Distance
Course from a Fix to	F	F	Fix
Holding Pattern	H	I	Next Leg
Initial	I	M	Manual Termination
Constant Radius	R	R	Radial Termination
Track Between	T	V	Heading To

Examples: **CF**= Course to Fix, and **FM**= Course from a Fix to a Manual Termination, etc. (See Section 9 Appendix for more information.)

7.3.4. Fly-By Waypoints

The following waypoints are Fly-Over with Defined Exit Heading:

- 1) Entry into procedure turn; and
- 2) Waypoint exiting a discontinuity with the exception of phantom waypoints or DP reference waypoints;
- 3) First waypoint with the exception of start waypoints or DP reference waypoints;
- 4) Course to a fix legs that are not to the FAF/FAWP are Fly-By with defined Entry Heading. All other waypoints are Fly-By with the entry adjusted and have a defined Exit Heading.


MFD

PFD

Normal

*Large Turn --
Defined Exit*

*Large Turn --
Defined Entry*
Figure 7-7: Fly-By Waypoints
NOTE:

Entry adjustments should be expected anytime a turn exceeds 120° . Turns greater than 120° should not be used in conjunction with RNP routes. (RNP standards specifically exclude such turns from RNP requirements.)

Leg segments for paths are constructed by the IDU as follows.

Table 7-4: Leg Segments for Paths Constructed by the IDU

Path Type	Entry Waypoint	Exit Waypoint	# of Segments and Description
Straight Leg, DME Arc, or Radius to a Fix	Fly-By	Fly-By	2nd half of fly-by turn at entry waypoint. WGS-84 geodesic or arc path from entry to exit turns. 1st half of fly-by turn at exit waypoint.
	Fly-By	Fly-Over Defined Exit Heading	2nd half of fly-by turn at entry waypoint. WGS-84 geodesic or arc path from entry to exit turns. Turn to exit heading prior to exit waypoint.
	Fly-By	Fly-Over Defined Entry Heading	2nd half of fly-by turn at entry waypoint. WGS-84 geodesic or arc path from entry turn to exit waypoint.
	Fly-Over Defined Exit Heading	Fly-By	WGS-84 geodesic or arc path from entry waypoint to exit turn. 1st half of fly-by turn at exit waypoint.
	Fly-Over Defined Exit Heading	Fly-Over Defined Exit Heading	WGS-84 geodesic or arc path from entry waypoint to exit turn. Turn to exit heading prior to exit waypoint.
	Fly-Over Defined Exit Heading	Fly-Over Defined Entry Heading	WGS-84 geodesic or arc path from entry waypoint to exit waypoint.

Table 7-4: Leg Segments for Paths Constructed by the IDU

Path Type	Entry Waypoint	Exit Waypoint	# of Segments and Description
	Fly-Over Defined Entry Heading	Fly-By	Turn from entry heading after entry waypoint. WGS-84 geodesic or arc path from entry to exit turns. 1st half of fly-by turn at exit waypoint.
	Fly-Over Defined Entry Heading	Fly-Over Defined Exit Heading	Turn from entry heading after entry waypoint. WGS-84 geodesic or arc path from entry to exit turns. Turn to exit heading prior to exit waypoint.
	Fly-Over Defined Entry Heading	Fly-Over Defined Entry Heading	Turn from entry heading after entry waypoint. WGS-84 geodesic or arc path from entry turn to exit waypoint.
Procedure Turn	Fly-Over Defined Exit Heading	Fly-Over Defined Entry Heading	WGS-84 geodesic path from entry waypoint on outbound heading for 30 seconds. Turn to procedure turn heading (45°). Outbound on procedure turn heading for 72 seconds. Turn to inbound heading (135°). WGS-84 geodesic path to exit waypoint. Entry

Table 7-4: Leg Segments for Paths Constructed by the IDU

Path Type	Entry Waypoint	Exit Waypoint	# of Segments and Description
			<p>waypoint and exit waypoint are same point.</p> <p>Turn to proper entry procedure heading. This heading varies. For a parallel entry, it is 180° from the holding course. For direct and teardrop entries, it is the heading required to get to entry of inbound turn.</p>
Holding Pattern	Fly-Over Defined Entry Heading	Fly-Over Defined Entry Heading	<p>WGS-84 geodesic path to entry of inbound turn.</p> <p>Inbound turn. Degree of turn varies depending upon entry procedure and heading.</p> <p>WGS-84 geodesic path to holding fix for direct and teardrop entries. WGS-84 geodesic path to entry of turn to holding pattern heading for parallel entries.</p> <p>Turn to holding pattern heading for parallel entries. This leg is not used for direct and teardrop entries.</p> <p>Turn to holding pattern outbound leg (180°).</p> <p>Holding pattern outbound leg (length based upon either time or distance as specified by navigation database).</p>

Table 7-4: Leg Segments for Paths Constructed by the IDU

Path Type	Entry Waypoint	Exit Waypoint	# of Segments and Description
			Turn to holding pattern inbound leg (180°). Holding pattern inbound leg (length based upon either time or distance as specified by navigation database).

7.3.5. Direct-To

If the IDU generates a WGS-84 geodesic path to a designated “To” fix, the aircraft captures this path without “S-turning” or undue delay. Where the selected “To” fix is in the active flight plan, the required transition is created as follows:

- 1) A phantom waypoint is created at the current aircraft location.
- 2) Leg prior to the phantom waypoint is designated as a discontinuity.
- 3) Phantom waypoint is designated as a Fly-Over Defined Entry Heading waypoint where the entry heading is current aircraft track.

Where the selected “To” fix is not in the active flight plan, the required transition is created as follows:

- 1) A new active flight plan is created from “Start” (current aircraft location) to the “To” fix.
- 2) “Start” waypoint is designated as a Fly-Over Defined Entry Heading waypoint where the entry heading is current aircraft track.

7.4. Magnetic Course

The source of magnetic variation used for paths defined using magnetic course is in accordance with the following:

- 1) If the leg is part of a database terminal area procedure and the magnetic variation is specified by the State for the procedure, the magnetic variation to be used is the value specified.
- 2) If the leg is not part of a procedure and the active fix is a VOR, the magnetic variation to be used is the published station declination for the VOR.
- 3) If the leg is not part of a procedure and the terminating fix is not a VOR, the magnetic variation to be used is defined by the system using an internal model.

The EFIS has the capability of computing magnetic variation at any location within the region where flight operations may be conducted using Magnetic North reference. The assigned magnetic variation is calculated with the NIMA GEOMAG algorithm and World Magnetic Model appropriate to the five-year cycle.

7.4.1. AHRS Modes for Heading Source

AHRS Slaved—EFIS Magnetic North: Standard mode of operation. Everything displayed relative to Magnetic North drift free.

AHRS Slaved—EFIS True North: Everything is displayed relative to True North with drift free heading. The preferred way to operate in areas where navigation is done relative to True North. (See Section 9 Appendix for limitations on Earth's magnetic flux horizontal field)

AHRS Free/"DG"—EFIS Magnetic North: Use when operating around significant magnetic disturbances in areas where navigation is done relative to Magnetic North. Ensure the compass rose is slewed to a Magnetic North value.

AHRS Free/"DG"—EFIS True North: Method of operation in high-latitude areas where navigation is accomplished relative to True North. Heading is not drift free and requires periodic correction. This mode may also be used when operating around significant magnetic disturbances in areas where navigation is done relative to True North. Ensure the compass rose is slewed to a True North Value.

7.4.2. GPS Altitude

WGS-84 ellipsoid altitude received from the GPS/SBAS is converted to geodetic (MSL) altitude using the EGM 2008 geoidal database which is revised on a 12-year cycle.

7.4.3. Dead Reckoning

The EFIS provides a Dead Reckoning capability and is active, whenever the GPS/SBAS sensor is not sending a valid position. The EFIS projects the last known GPS/SBAS position forward using TAS and heading corrected for last known wind as it continues to navigate using this position and the active flight plan. The system provides the capability to determine bearing to an airport based upon the dead reckoning position.

7.4.4. Parallel Offsets

The parallel offset is a route parallel to, but offset from, the original active route. The basis of the offset path is the original flight plan leg(s) and one or more offset reference points as computed by the EFIS. The computed offset reference points are located so that they lie on the intersection of lines drawn parallel to the host route at the desired offset distance and the line that bisects the track change angle. An exception to this occurs where the parallel offset ends. In this case, the offset reference point is located abeam of the original flight plan waypoint at the offset distance.

The parallel offset function does not propagate through route discontinuities, unreasonable path geometries as follows:

- 1) Legs that are parts of approach procedures (IFR and VFR); or
- 2) Legs with complex geometries or that begin or end with dynamically terminations. (ARINC 424 path types other than CF, DF, or TF or any leg where the starting waypoint is not a fixed position); or
- 3) Legs that begin at an aircraft starting position (reference waypoint in a DP or Start/Phantom waypoints created by the Direct-To function.

Parallel offset function does not propagate through the following:

- 1) Any waypoint at the beginning or end of a route discontinuity; or
- 2) Any waypoint at the beginning or end of a prohibited leg type; or
- 3) A waypoint with an unreasonable path geometry (defined as a turn greater than 120°.

When the parallel offset function begins or ends within a flight plan due to the above constraints, parallel offset entry or exit waypoints

are inserted into the flight plan. Discontinuities precede parallel offset entry waypoints and follow parallel offset exit waypoints. This allows the pilot to navigate to and from the parallel offset as required. A parallel offset entry waypoint (“PTK+”) is shown in Figure 7-8.



Figure 7-8: Parallel Offset Entry Waypoint PTK+



Figure 7-9: Parallel Offset Entry Waypoint PTK-

The EFIS provides guidance to parallel tracks at a selected offset distance. When executing a parallel offset, the navigation mode and all performance requirements of the original route in the active flight plan are applicable to the offset route. The EFIS provides for entry of offset distance in increments of 1 NM, left or right of course, and

is capable of offsets of at least 20 NM. When in offset mode, it is indicated with an advisory flag, i.e., **PTK = L 20NM**. When in offset mode, the EFIS provides reference parameters (e.g., cross-track deviation, distance-to-go, time-to-go) relative to the offset path and offset reference points.

Once a parallel offset is activated, the offset remains active for all flight plan route segments until removed automatically (transitioning through a parallel track exit waypoint), until the flight crew enters a “Direct-To” routing or activates a new flight plan route, or until (manual) cancellation.

NOTE:

If a parallel offset is entered in the active flight plan and then cancelled, that active flight plan is no longer eligible for configuring another parallel offset without deleting and reactivating due to the creation of a discontinuity.

7.5. Default GPS/SBAS Navigation Modes

In default GPS/SBAS operating mode, the IDU has Enroute, Terminal, LNAV Approach, LNAV/VNAV Approach, LP Approach, LPV Approach, VFR Approach, and Departure navigation modes. Mode annunciation, alert limits (horizontal and vertical), and CDI FSD (horizontal and vertical) are determined by navigation mode as follows.

Navigation Mode	Annunciation
Enroute	None
Terminal	TERMINAL
LNAV Approach	LNAV APPR
LNAV/VNAV Approach	LNAV/VNAV APPR
LP Approach	LP APPR
LPV Approach	LPV APPR
VFR Approach	VFR APPR
Departure	TERMINAL

The system automatically switches to default navigation modes based upon region of operation as follows.

Table 7-6: Default Navigation Modes Based Upon Region of Operation

Default Navigation Mode	Definition of Region
Departure	Selected when the active waypoint is the first waypoint of a departure or Missed Approach Procedure <u>and</u> the active leg heading is aligned ($\pm 3^\circ$) with the active runway heading. Also set when the active waypoint is the MAWP but a missed approach has been manually activated*.
VTF Approach (LNAV, LNAV/VNAV, LP or LPV)	VTF IFR Approach has been selected; <u>and</u> within 30 NM of the active runway*; <u>and</u> the FAWP is the active waypoint*; <u>and</u> the bearing to the FAWP is within 45° of the final approach segment track (treated as a mode entry criteria)*; <u>and</u> the desired track to FAWP is within 45° of the final approach segment track (treated as a mode entry criteria).
Approach (LNAV, LNAV/VNAV, LP or LPV)	IFR Approach has been selected; <u>and</u> within 30 NM of the active runway*; <u>and</u> the MAWP or the FAWP is the active waypoint; <u>and</u> if the FAWP is the active waypoint: the bearing to the FAWP is within 45° of the final approach segment track (treated as a mode entry criteria)*; <u>and</u> the desired track to FAWP is within 45° of the final approach segment track (treated as a mode entry criteria)*; <u>and</u> either the segment leading into the FAWP is not a holding pattern or the pilot has elected to continue out of holding.
VFR Approach	VFR Approach has been selected*; <u>and</u>

Table 7-6: Default Navigation Modes Based Upon Region of Operation

Default Navigation Mode	Definition of Region
	within 30 NM of the active runway*; <u>and</u> the active runway is the active waypoint.
Terminal	Not in Departure Mode; <u>and</u> Not in Approach Mode; <u>and</u> The active waypoint is part of a departure <u>or</u> the active waypoint and previous waypoint are parts of an arrival or approach <u>or</u> within 30 NM of the departure airport, arrival airport, or runway.
Enroute	Not in Departure, Approach, or Terminal Modes.

NOTE:

During RNP 0.3 Approach (manually or coded) the scale remains in RNP 0.3.

7.6. GPS/SBAS CDI Scale
Table 7-7: Summary of Changes In Cross-Track FSD

	To Enroute	To Terminal	To Approach
From Enroute		Change from ± 2 NM FSD to ± 1 NM FSD over distance of 1 NM; start transition when entering terminal mode.	
From Terminal	Change from ± 1 NM FSD to ± 2 NM FSD over distance of 1 NM; start transition when entering enroute mode.		If VTF, switch immediately. Otherwise, change from ± 1 NM FSD to approach FSD over distance of 2 NM; start

Table 7-7: Summary of Changes In Cross-Track FSD

	To Enroute	To Terminal	To Approach
			transition at 2 NM from FAWP
From Approach		Change to ± 1 NM.	
From Departure		If initial leg is aligned with runway, change from ± 0.3 NM FSD to ± 1 NM FSD at the turn initiation point of the first fix in the departure procedure.	

NOTE:

For RNP 0.3 routes, Time to Alert is the same as for the approach.
 For RNP 0.3, the EFIS uses a 10-second TTA when using GPS-only, and a 2-second TTA when using EGNOS.

7.7. Approach Type Selection

The IDU selects the approach type (LNAV, LNAV/VNAV, LP, or LPV) when entering approach mode with the following order of precedence and prerequisites:

1) LPV:

- a) LPV Enable is enabled;
- b) ARINC-424 “Level of Service” indicates LPV minimums are published;
- c) Valid long-term, fast, and ionospheric SBAS corrections are available and being applied to at least 4 GPS satellites;
- d) Final Approach Segment data block exists and passes CRC; and
- e) Horizontal and vertical alert limits from Final Approach Segment data block are predicted to be supported.

- 2) **LP:**
- a) LPV Enable is enabled;
 - b) ARINC-424 “Level of Service” indicates LP minimums are published;
 - c) Valid long-term, fast, and ionospheric SBAS corrections are available and being applied to at least 4 GPS satellites;
 - d) Final Approach Segment data block exists and passes CRC; and
 - e) Horizontal alert limit from Final Approach Segment data block is predicted to be supported.
- 3) **LNAV/VNAV:**
- a) ARINC-424 “Level of Service” indicates LNAV/VNAV minimums are published;
 - b) If a Final Approach Segment data block exists, LPV Enable is enabled;
 - c) If a Final Approach Segment data block exists, it passes CRC; and
 - d) Horizontal alert limit of 556 m. (.3 NM) is predicted to be supported.

NOTE:

Because the IDU inherently supports barometric VNAV, it is not a prerequisite for the vertical alert limit to be predicted or supported. Nor is it a prerequisite for valid long-term, fast, and ionospheric SBAS corrections be available and applied to at least four GPS satellites. Rather, the vertical alert limit (50 m) and SBAS correction tests are used to determine whether to present guidance based upon GPS altitude or barometric altitude.

- 4) **NAV:** Default approach type selected when none of the above selections are made. There are no prerequisites for selecting LNAV.

The IDU continuously displays the approach type (mode indication) after selection. The IDU does not degrade the approach type after selection unless the approach procedure is reselected or changed.

NOTE:

These GPS/SBAS modes still appear during a ground based approach such as an ILS approach (see Figure 7-10).

Some instrument procedures include notes saying “RNP 0.3 required” and are coded as an RNAV procedure. In these cases, select manual RNP to see the RNP and ANP values on the PFD.




Figure 7-10: GPS Mode (LNAV APPR)

7.8. VTF IFR Approach

In addition, the pilot may select a VTF IFR approach, indicating the pilot does not intend to fly the entire procedure. When a VTF IFR approach is selected, the IDU creates an “IP” waypoint on the extended final approach course to provide deviations relative to the extended final approach course. The “IP” is designated as a fly-over defined exit heading waypoint, and the leg prior to the “IP” is designated as a discontinuity. Until the FAWP has been sequenced, the IDU indicates a VTF IFR approach has been selected (with mode annunciation **VECTORS**) to advise the pilot guidance is not relative to a published approach path and TERPS or ICAO DO 8168 clearances are not assured.

7.9. VTF VFR Approach

The pilot may select a VFR approach to a runway or user waypoint with a defined approach bearing.



When a VFR approach is selected, the IDU creates an “IP” waypoint approximately 12 NM on the extended final approach course to provide deviations relative to the extended final approach course. The “IP” is designated as a fly-over defined exit heading waypoint, and the leg prior to the “IP” is designated as a discontinuity.

During this VTF VFR approach, the aircraft is proceeding towards the IP. Since the IP is designated as a discontinuity, proceeding direct is not possible. When attempting to proceed direct to the IP, only the active leg between the IP and RW01 is activated.

Figure 7-11: Navigating to FAF on VTF VFR Approach

7.10. Missed Approach and Departure Path Definition

The pilot may initiate the missed approach with manual action. Once on the final approach segment (dashed line course similar to instrument approach chart portrayal), the pilot has the option to initiate an immediate missed approach or to arm the system to execute the missed approach at the MAWP. When arming the missed approach, the pilot may take this action before crossing the MAWP, in which case the equipment arms the missed approach for automatic initiation at the MAWP. If a missed approach is not initiated prior to crossing the MAWP, the IDU automatically switches to FROM mode at the MAWP and continue on the same course.

If the pilot initiates the missed approach, the IDU provides guidance relative to the procedure. If a missed approach is armed prior to crossing the MAWP, the desired path, to and after the MAWP, is defined by the procedure. If the first leg in the missed approach procedure is not a straight path aligned within 3° of the final approach course, the FSD changes to terminal mode FSD (± 1 NM) when the missed approach is initiated. Otherwise, the FSD changes to ± 0.3 NM, when the missed approach is initiated (departure mode), and changes to terminal mode FSD (± 1 NM) at the turn initiation point of the first waypoint in the missed approach procedure.



Missed Approach dashed line

Figure 7-12: Missed Approach and Departure Path

The pilot may manually select DP guidance and, if the first leg in the DP is not a straight path aligned within 3° of the runway heading, terminal mode FSD (± 1 NM) is used. Otherwise, the FSD is ± 0.3 NM (departure mode) and changes to terminal mode FSD (± 1 NM) at the turn initiation point of the first waypoint in the DP.

7.11. Loss of Navigation Monitoring

The IDU continuously monitors, independent of any pilot action, for loss of navigation capability. In Manual RNP mode or Automatic RNP mode prior to sequencing the FAWP, the loss of navigation caution is displayed using a 10 second time to alert if the RNP value is less than 2 NM and a 30 second time to alert otherwise. The **FAULTS** menu enables the pilot to distinguish the cause of the loss of navigation caution. The caution returns to its normal state upon termination of the responsible condition.

7.12. Discontinuities

Where the IDU is unable to construct a smooth flight path as described above due to active flight plan waypoint spacing (i.e., spacing too close for turn radius), a discontinuity is placed between the waypoints. When a discontinuity exists, no path nor skyway is drawn between the waypoints. The pilot cannot activate the waypoint exiting the discontinuity, as it is not possible to provide path guidance to this waypoint. Attempts to activate the waypoint exiting

the discontinuity activates the next waypoint or, if there is no next waypoint (i.e., end of active flight plan), activates the waypoint leading into the discontinuity.

7.13. Selection of an Instrument Procedure

When an instrument procedure is selected and active, the receiver notifies the pilot of the most accurate level of service supported by the combination of the GPS/SBAS signal, receiver, and selected approach, using naming conventions on the minima lines of the selected approach procedure. Once the level of service has been given, the EFIS operates in this mode for the duration of the procedure, unless the level of service becomes unavailable. The EFIS cannot change back to a more accurate level of service until the next time an approach is activated.

The following are samples of step-by-step procedures.

- 1) SID (Step-By-Step)
- 2) STAR (Step-By-Step)
- 3) ILS Instrument Approach (Step-By-Step)
- 4) LOC BC Instrument Approach (Step-By-Step)
- 5) RNAV (GPS) Instrument Approach to LPV Minima (Step-By-Step)
- 6) NRST ILS Instrument Approach (Step-By-Step)
- 7) VOR DME Instrument Approach (Step-By-Step)

7.13.1. Standard Instrument Departure (SID) (Step-by-Step)






Figure 7-13: Standard Instrument Departure (SID)



- 1) Press **ACTV (L2)**. Scroll **1** to **KAST** and push to enter.



- 2) Scroll **1** to **DP..** and push to enter.




- 3) Scroll **1** to desired DP and push to enter.




- 4) Scroll **1** RW31 and push to enter. DP is loaded with **RW31** transition and push to enter.



- 5) Scroll **1** to RW31 and push to enter.



- 6) Scroll **1** to airport (KAST) to view DP in active flight plan.



- 7) RW31 is now the next waypoint in the active flight plan.

7.13.2. Standard Terminal Arrival Route (STAR) (Step-by-Step)





Figure 7-14: Standard Terminal Arrival Route (STAR)

If the selected waypoint is an airport with a published STAR, select from a list of available STARS, transitions, and runways. After selection, the appropriate STAR is created and displayed on the MAP page. Activating a STAR deletes any pre-existing STAR and is inserted prior to any approach waypoints if previously entered.

STARS normally terminate at a fix near the airport, then a radar vector or feeder route is used for transition to the approach phase of the arrival. If an instrument approach is activated during the STAR, the approach waypoints are inserted after the STAR.



- 1) With arrival airport in active flight plan highlighted, push **1** to enter.




- 2) Scroll **1** to **STAR..** and push to enter.




- 3) Scroll **1** to desired **STAR:** and push to enter.



- 4) Scroll **1** to desired **TRANS:** and push to enter.



- 5) Scroll **1** to desired **RW:** and push to enter.




- 6) Press **ACTV (L2)** to view STAR in active flight plan and active waypoint.

Assume ATC assigned a clearance to cross SARDI at 3500' 2 NM prior to crossing.

✕	START	----- /	143°	37NM
Step	*DUNEE	----- /	056°	16NM
Step	SARDI	----- /	056°	7NM
Step	RICED	----- /		

- 7) Press **ACTV (L2)** and scroll **1** to the waypoint in the clearance and push to enter.

	WAYPOINT
	UNAV..
	HOLD..
	OFLY/AUTO..

- 8) Scroll **1** to **VNAV..** and push to enter.

	UNAV AT SARDI
	ALTITUDE: 3500'
	OFFSET: ---NM

- 9) Scroll **1** to enter assigned altitude, push to enter, and scroll **1** CCW to enter -2 NM and push to enter to comply with ATC crossing clearance.

	DEST KHPN
	UNAV AT SARDI
	ALTITUDE: 3500'
	OFFSET: -2NM

- 10) Altitude is shown on active flight plan with offset of 2 NM prior to reaching SARDI.

✕	START	1400' /	143°	37NM
Step	*DUNEE	3500' /	056°	16NM
Step	SARDI	3500' / -2	056°	7NM
Step	RICED	3500' /		

7.13.3. ILS Instrument Approach (Step-by-Step)





Figure 7-15: ILS RWY 11 (MSY)

All approach operations typically begin with the same basic steps. The following example selects the ILS RWY 10 at Louis Armstrong New Orleans INTL (KMSY). The PFD BUGS menu may be accessed on the PFD or Remote Bugs Panel if equipped.




- 1) Press **ACTV (L2)**. Scroll **1** to desired airport and push to enter.



- 2) Scroll **1** to **IFR APPR..** and push to enter.



- 3) Scroll **1** to desired approach, transition, and runway. Push to enter for each option.



- 4) ATC clears the flight Direct to MUDBG. With ACTV flight plan displayed, scroll **1** to MUDBG and press **(R4)** and push **1** to enter.



- 5) Inside the FAF with the Missed Approach procedure armed. Barometric minima set to 500' MSL, DH set to 220' AGL, and IAS speed bug set to 150 IAS.



- 6) On the MFD press **MENU (R1)** and **PAGE (R3)** then scroll **1** to HSI and push to enter for this presentation of the approach inside the FAF.



- 7) As an option on the PFD, press **MENU (R1)** and **ZOOM ON (R3)** passing Barometric minima. **FLTA INHBT** appears inside 2.0 NM.





8) Passing the Middle Marker.



9) Passing the MAWP with automatic Nav source switching to FMS with Missed Approach waypoint appearing ahead and at 800'.

7.13.4. LOC Back Course Instrument Approach (Step-by-Step)





Figure 7-16: LOC Back Course Approach



- 1) Press **ACTV (L2)**, scroll **1** to KSMX, and push to enter.



- 2) Scroll **1** to **IFR APPR..** and push to enter.



- 3) Scroll **1** to **LBCA** and push to enter.



- 4) Scroll **1** to transition and push to enter.



- 5) Scroll **1** to runway and push to enter.



- 6) An active waypoint leg is created for direct to RZS.



- 7) ATC provides clearance direct to **KOAKS** maintain 6000'.
- 8) Press **ACTV (L2)**. Scroll **1** to **KOAKS**, press **(R4)**, and then push **1** to enter.



9) Passing the FAF, **ARM (L2)** appears without a suspend advisory due to step-down fix ahead.

10) Press **OBS (L4)**. Scroll **1** to set final approach course 300° then push to enter.



11) Approaching step-down fix **PATER** with fly-by symbol appearing as a point in space.



12) After passing **PATER**, **SUSPEND** appears until **ARM (L2)** is pressed to arm auto waypoint sequencing at the MAWP.



13) Press **MENU (R1)** then **ZOOM OFF (R3)** to return the PFD to normal wide field of view.



- 14) Once established in published holding, **CONT (L1)** is present with **SUSPEND** until pressed.

7.13.5. RNAV (GPS) Instrument Approach to LPV Minima (Step-By-Step)




Figure 7-17: RNAV (GPS) Instrument Approach to LPV Minima


- 1) Select airport and **IFR APPR..** as in previous examples.



- 2) After reviewing the approach chart, scroll **1** to **RNAV32 (99617)** then push to enter.

NOTE:

Verify the WAAS channel 5-digit number is identical to instrument approach chart reference.



- 3) Scroll **1** to desired transition and runway then push to enter as described in previous examples.



TRF	UUDYU	3026' /----	326°	3NM
APC	HOLUS	2012' /----	326°	2NM
NAI	TP RW32	1322' /GPI		
1.0		1572' /----	326°	1572'

- 4) Press **ACTV (L2)**. Scroll **1** to desired waypoint, press **⏪ (R4)** then push **1** to enter.



- 5) Scroll **1** to desired map scale for best view.
- 6) Observe active leg magenta line and next leg in white.



- 7) Inside FAF, press **ARM (L2)** prior to step down FIX, HOLUS.




- 8) Approaching HOLUS on glidepath with Minimums set at 1580'.



- 9) Approaching Minimums on glidepath with runway insight with landing gear down.

NOTE:

When in LPV mode, the altitudes for the FAF, MAP, and any waypoints between the FAF and MAP are calculated based upon the internally protected FAS Data Block. Additionally, in LPV mode, the altitude presented for the MAP is, in fact, the altitude for the GPIP (Glidepath Intercept Point) as contained in the FAS Data Block. The offset field is populated, because the altitude presented is not the altitude for the MAP. The abbreviated "GPI" indicates the vertical navigation offset is to the GPIP.



1) An active flight plan is not necessary. Press **NRST (R3)** and scroll **1** to ILS.. and push to enter.

2) Scroll **1** to desired ILS approach and runway ("ILS" must precede airport) and push to enter.



3) Scroll **1** to desired map scale for best view.


4) Observe active leg magenta line and next leg in white.



5) Inside FAF, press **ARM (L2)** to continue auto waypoint sequencing.



6) Auto waypoint sequencing has resumed. DH set to 200', and Barometric minimums set to 1000'. As an option, press **MENU (R1)** and **ZOOM ON (R3)**.



- 7) Approaching Decision Height on glidepath with runway insight with landing gear down and zoom mode selected.



- 8) Upon passing the MAWP the EFIS automatically switches the NAV source to FMS to allow navigation through the entire missed approach procedure.

NOTE:

The following actions occur when selecting NRST ILS:

- 1) A direct flight plan to the ILS airport is created.
- 2) A Vectors-to-Final ILS approach is activated.
- 3) Heading Bug is activated to the current heading. (Autopilot enabled.)
- 4) VLOC 1 and VLOC 2 OBS are set to the associated localizer course.
- 5) HSI source is switched as follows: ILS frequency is automatically transmitted to NAV1 in standby position. (Auto-tuning enabled.)

7.13.7. VOR/DME Instrument Approach (Step-By-Step)




Figure 7-19: VOR/DME Instrument Approach

- 1) Select airport and **IFR APPR..** as in previous examples.



- 2) After reviewing the approach chart, scroll **1** to **VORDME14** then push to enter.



- 3) Scroll **1** to desired transition and runway then push to enter as described in previous examples.




- 4) Press **ACTV (L2)**. Scroll **1** to desired waypoint, press **DR (R4)** then push **1** to enter.



- 5) Scroll **1** to desired map scale for best view.
- 6) Observe active leg magenta line and next leg in white.



- 7) Inside FAF, press **ARM (L2)** prior to step down FIX, GOLDY.



- 8) Approaching GOLDY on glidepath with Minimums set at 420'.



- 9) Approaching Minimums on glidepath with runway insight and landing gear down.



- 10) On short final with gear down and light gray active runway in sight.



- 11) MFD view of same position described above.



- 12) During the missed approach with Nav source automatically switched to FMS for the Missed Approach Procedure.

NOTE:

Navigation databases are expected to be current for the duration of the flight. If the Aeronautical Information Regulation and Control (AIRAC) cycle is due to change during the flight, operators and pilots should establish procedures to ensure the accuracy of navigation data including suitability of navigation facilities used to define the routes and procedures for flight. Traditionally, this has been accomplished by verifying electronic data against paper products. One acceptable means is to compare aeronautical charts (new and old) to verify navigation fixes prior to departure. If an amended chart is published for the procedure, the database must not be used to conduct the operation.

Pilots may notice a slight difference between the navigation information portrayed on the chart and their primary navigation display heading. Differences of three degrees or less may result from equipment manufacturer's application of magnetic variation and are operationally acceptable.

GPS receivers do not "Fail Down" to lower levels of service once the approach has been activated. If only **VERT LON** appears, the pilot may elect to use the LNAV minima, if the rules under which the flight is operating to allow changing the type of approach being flown after commencing the procedure. If the lateral integrity limit is exceeded on an LP approach, a missed approach is necessary since there is no way to reset the lateral alarm limit while the approach is active.

Section 8 Terrain Awareness Warning System

8.1. TAWS Functions

The IDU provides TSO-C151b TAWS functionality. The following description is for a TAWS Class A, B, and C depending on aircraft configuration and external sensors/switches. Warning functions provided by TAWS are:

- 1) **Terrain Display:** Terrain and obstacles on PFD and ND.
- 2) **Forward Looking Terrain Awareness (FLTA):** Alerts to hazardous terrain or obstructions in front of the aircraft.
- 3) **Premature Descent Alert (PDA):** Alerts when descending well below a normal approach glidepath on the final approach segment of an instrument approach procedure.
- 4) **Excessive Rate of Descent (GPWS Mode 1):** Alerts when rate of descent is hazardously high as compared to height above terrain (i.e., descending into terrain).
- 5) **Excessive Closure Rate to Terrain (GPWS Mode 2):** Alerts when rate of change of height above terrain is hazardously high as compared to height above terrain (i.e., flying level over rising terrain).
- 6) **Sink Rate after Takeoff or Missed Approach (GPWS Mode 3):** Alerts when a sink rate is detected immediately after takeoff or initiation of a missed approach.
- 7) **Flight into Terrain when not in Landing Configuration (GPWS Mode 4):** Alerts when descending into terrain without properly configuring the aircraft for landing.
- 8) **Excessive Downward Deviation from an ILS Glideslope (GPWS Mode 5):** Alerts when an excessive downward glideslope deviation is detected on the final approach segment of an ILS approach.
- 9) **500 foot Wake-up Call:** A single aural callout when descending through 500 feet AGL.

Table 8-1: TAWS Functions Provided by the EFIS

Aircraft Type	Airplane				Airplane
	RG + F	RG	FG + F	FG	
TAWS Class	A	A	A	A	B or C
Terrain Display	✓	✓	✓	✓	✓
FLTA	✓	✓	✓	✓	✓
PDA	✓	✓	✓	✓	✓
GPWS Mode 1	✓	✓	✓	✓	✓
GPWS Mode 2	✓	✓	✓	✓	
GPWS Mode 3	✓	✓	✓	✓	✓
GPWS Mode 4	✓	✓	✓		
GPWS Mode 5	✓	✓	✓	✓	
500' Call	✓	✓	✓	✓	✓

Notes: RG + F = Retractable Gear with Defined Landing Flaps Position
Position

RG = Retractable Gear

FG + F = Fixed Gear with Defined Landing Flaps Position

FG = Fixed Gear

8.1.1. Terrain Display



Figure 8-1: Terrain Display PFD



Figure 8-2: Terrain Display MFD

Display of terrain on the PFD and MFD are described in Sections 3 Display Symbology and 5 Menu Functions and Step-By-Step Procedures where applicable.

8.2. Forward Looking Terrain Alert (FLTA) Function




Figure 8-3: FLTA INHBT

FLTA function uses the following to alert to hazardous terrain or obstructions within a search envelope in front of the aircraft:

- | | |
|--------------------------------|----------------------------|
| 1) Terrain database | 5) Aircraft track |
| 2) Obstruction database | 6) Aircraft groundspeed |
| 3) Airport and runway database | 7) Aircraft bank angle |
| 4) Aircraft position | 8) Aircraft altitude |
| | 9) Aircraft vertical speed |

8.2.1. FLTA Modes

The EFIS FLTA mode is either slaved to the GPS/SBAS navigation mode or set automatically based upon default mode logic.

8.2.2. GPS/SBAS Navigation Mode Slaving

The EFIS performs TSO-C146c GPS/SBAS functions in addition to the TAWS functions. As a result, GPS/SBAS navigation mode is available as an input to the TAWS. The pilot may select an IFR procedure (Approach, DP, or STAR) which changes the GPS/SBAS navigation mode to Enroute, Terminal, Departure, or IFR Approach as appropriate. In addition, the EFIS allows the pilot to select a VFR approach to any runway or user waypoint with a defined approach path. Selection of a VFR approach causes automatic GPS/SBAS navigation mode changes to Enroute, Terminal, or VFR Approach as appropriate. When slaved, the GPS/SBAS active runway threshold or user waypoint is the reference point for automatic FLTA inhibiting. The advantage is the GPS/SBAS navigation modes are a direct indication to the FLTA function of pilot intent.

8.2.3. Default FLTA Mode




Figure 8-4: Default FLTA INHBT

If the default FLTA navigation mode is higher in precedence than the GPS/SBAS navigation mode, FLTA mode is slaved to the default FLTA navigation mode. These modes, in order of precedence, are:




Figure 8-5: FLTA INHBT Mode Areas

- 1) **Departure Mode:** Enabled when in Ground Mode. Reference point for automatic FLTA inhibiting and mode envelope definition is the last point at which the ground definition was satisfied (this is near the liftoff point). Departure Mode ends upon climbing through **1500 feet** above or traveling more than **6NM** from the reference point.
- 2) **Other Modes:** For other default FLTA modes, reference point for automatic FLTA inhibiting and mode envelope is the nearest runway threshold or the nearest user waypoint with a defined approach bearing. TAWS continuously searches all runway thresholds at the nearest three airports to determine the nearest runway threshold. TAWS performs a search for the nearest three airports and nearest user waypoints with a defined approach bearing every 3NM of distance traveled.
 - a) **Approach Mode:** Exists when within 1900 feet and 5NM of the reference point.
 - b) **Terminal Mode:** Exists from 5NM to 15NM from the reference point when below an altitude that varies from 1900 feet (at 5NM) to 3500 feet (at 15NM) above the reference point.
 - c) **Enroute Mode:** Exists when not in any other mode.

8.3. FLTA Search Envelope

The FLTA search envelope is an area in front of and below the aircraft. If terrain or obstructions are found within the FLTA search envelope, a caution or warning is given to the pilot. Dimensions of the search envelope depend upon TAWS type, FLTA mode, aircraft groundspeed, aircraft bank angle, and vertical speed. Basic envelope parameters are as follows.

- 1) **TAWS Type:** Determines value of several parameters used to calculate the search envelope as described in Table 8-2.

Table 8-2: FLTA Search Envelope for HTAWS

Envelope	Parameter	Notes
Level-Off Rule	10% of vertical speed	Used for level off leading
Range	36 seconds of the forward	GPS/SBAS HFOM added to range.

Table 8-2: FLTA Search Envelope for HTAWS

Envelope	Parameter	Notes
	range search envelope	
Enroute Mode Level/Climbing Flight RTC	150 feet	
Terminal Mode Level/Climbing Flight RTC	150 feet	
Approach Mode Level/Climbing Flight RTC	150 feet	
Departure Mode Level/Climbing Flight RTC	100 feet	
Enroute Mode Descending RTC	100 feet	
Terminal Mode Descending RTC	100 feet	
Approach Mode Descending RTC	100 feet	
Departure Mode Descending RTC	100 feet	

- 2) **Aircraft Track:** Terrain search envelope is aligned with aircraft track.
- 3) **Aircraft Groundspeed:** Used in conjunction with range parameter to determine look-ahead distance. In addition, used in conjunction with FLTA mode to determine search volume width as follows:
 - a) **Enroute Mode:** Search volume width is based upon a 30° change in track followed by 30 seconds of flight at aircraft groundspeed. Maximum width is 0.5NM either side of track.
 - b) **Terminal Mode:** Search volume width is based upon a 15° change in track followed by 30 seconds of flight at aircraft groundspeed. Maximum width is 0.5NM either side of track.

- c) **Approach Mode:** Search volume width is based upon a 10° change in track followed by 30 seconds of flight at aircraft groundspeed. Maximum width is 0.3NM either side of track.
- d) **Departure Mode:** Search volume width is based upon a 10° change in track followed by 30 seconds of flight at aircraft groundspeed. Maximum width is 0.3NM either side of track.




Figure 8-6: FLTA Search Volume

After calculating search volume width, GPS/SBAS HFOM is added to search volume width.

- 1) **Aircraft Bank Angle:** Used to expand the search volume in the direction of a turn and requires at least 10° of bank. In addition, search volume expansion is delayed so at 10° of bank, the bank angle must be continuously held for 3.25 seconds. The amount of delay is reduced linearly with increased bank angle so at 30° of bank there is no delay time. Delaying is intended to reduce

nuisance search volume expansions when experiencing bank angle excursions due to turbulence.

- 2) **Aircraft Vertical Speed:** Used to determine which RTC values should be used. At vertical speeds above -500 fpm, level and climbing flight RTC values are used. At vertical speeds less than or equal to -500 fpm, descending flight RTC values are used. In addition, vertical speed is used to increase the descending flight RTC value used by the system. The increase in descending flight RTC is based upon a three-second pilot reaction time and VSI leading according to the level-off rule parameter.

8.3.1. FLTA Alerts and Automatic Popup

When terrain or obstructions fall within the FLTA search envelope, a FLTA warning is generated. Terrain rendering is enabled when a FLTA warning is initiated or upgraded as follows:

- 1) On PFD screen, terrain rendering is enabled;
- 2) On navigation display screen, terrain rendering is enabled only if TAWS Inhibit is not enabled. TAWS Inhibit prevents terrain from being automatically enabled on the navigation display.

In addition, when an FLTA warning is initiated or upgraded, an automatic popup mode is engaged as follows:

- 1) Display switched to navigation display.
- 2) Display switched to aircraft centered and heading up.
- 3) Display panning disabled.
- 4) Display scale set to:
 - a) 10NM (groundspeed > 200 knots);
 - b) 5 NM (groundspeed < = 200 knots and groundspeed > 100 knots); or
 - c) 2NM (groundspeed < = 100 knots).

After popup mode is engaged, the pilot may change any setting automatically changed by the popup mode. In addition, **RESET (L1)** appears for 20 seconds to reset the previous screen configuration with one button press. Popups only occur on IDU #0 or IDU #2 with all TAWS classes configured and do not occur if TAWS Inhibit is enabled.



Figure 8-7: ND in Pop-up Mode

8.4. Premature Descent Alert (PDA) Function


PDA function alerts when descending well below a normal approach glidepath on final approach segment of an instrument approach procedure. PDA function uses the following:

- 1) GPS/SBAS navigation database
- 2) GPS/SBAS navigation mode
- 3) Aircraft position
- 4) Aircraft altitude

PDA function is armed when on final approach segment of an IFR approach procedure and below the FAF crossing altitude. The alerting threshold for the PDA function is 0.5° less than the lower of:

- 1) a straight line from the FAF to approach runway threshold; or
- 2) 3°

When the aircraft descends below the threshold, a PDA warning is generated (Figure 8-8).


Figure 8-8: PDA Alert Threshold

8.5. Excessive Rate of Descent (GPWS Mode 1)

GPWS Mode 1 function uses aircraft vertical speed information and AGL altitude to alert when the rate of descent is hazardously high as compared to height above terrain. GPWS Mode 1 has a caution and a warning threshold. When below the thresholds, a GPWS Mode 1 warning is generated.

Table 8-3: GPWS Mode 1 Envelope

Sink Rate (fpm)	AGL Altitude (ft.)	
	“Sink Rate” Caution Threshold	“Pull Up” Warning Threshold
< 2360	$125\% \times (\text{Sink Rate} - 1416)$	$66\% \times (\text{Caution Threshold})$
2360 to 4900	Lesser of: 2450, or, $50\% \times (\text{Sink Rate})$	




Figure 8-9: Fixed Wing GPWS Mode 1

8.6. Excessive Closure Rate to Terrain (GPWS Mode 2)

GPWS Mode 2 function is present in Class A TAWS and uses filtered AGL rate and AGL altitude to alert when rate of change of height above terrain is hazardously high as compared to height above terrain (i.e., flying level over rising terrain). AGL rate filtering is based upon a 10-second sampling time.

There are two Mode 2 envelopes: Mode 2A which is active when not in landing configuration, and Mode 2B which is active when in landing configuration. Envelope selection is determined as follows.

Configuration	Mode 2A	Mode 2B
Retractable gear with defined landing flaps position	Flaps NOT in landing configuration	Flaps in landing configuration
Retractable gear	Landing gear UP	Landing gear DOWN
Fixed gear with defined landing flaps position	Flaps NOT in landing configuration	Flaps in landing configuration
Fixed gear	AGL Altitude > 500 ft or Airspeed > V_{FE}	AGL Altitude \leq 500 ft or Airspeed \leq V_{FE}

Mode 2 Envelope Depictions are shown in Figure 8-10.




Figure 8-10: Fixed Wing GPWS Mode 2

When GPWS Mode 2 envelope is pierced, a warning is generated.

Table 8-5: GPWS Mode 2A Envelopes (NOT in Landing Configuration)			
AGL Rate (fpm)	AGL Altitude (ft.)		
	“Caution, Terrain” Caution Threshold	“Pull Up” Warning Threshold	
< 3900	$80\% \times (\text{AGL Rate} - 2000)$	$66\% \times (\text{Caution Threshold})$	
> 3900	1520 + 15% of the lesser of:		
	Airspeed (KIAS)		AGL Rate (fpm)
	< 220	6000	
	220 to 300	$6000 + 50 \times (\text{Airspeed} - 220)$	
> 300	10,000		
	or AGL Rate		

Table 8-6: GPWS Mode 2B Envelopes (Landing Configuration)	
AGL Altitude (ft.)	
“Caution, Terrain” Caution Threshold	“Pull Up” Warning Threshold
Lesser of: 800 or $80\% \times (\text{AGL Rate} - 2000)$	$66\% \times (\text{Caution Threshold})$

8.7. Sink Rate after Takeoff or Missed Approach (GPWS Mode 3)

GPWS Mode 3 function uses aircraft vertical speed information and AGL altitude to alert when sink rate is detected immediately after takeoff or initiation of a missed approach. GPWS Mode 3 is armed by either being in Ground Mode or on the first leg of a missed approach procedure (as determined by the GPS/SBAS) with distance to the active runway threshold increasing. GPWS Mode 3 is disarmed upon climbing through **700 feet AGL** traveling more than **6NM** from the last point at which the ground definition was satisfied (this is near the liftoff point), or transitioning to the second leg of a missed approach procedure. GPWS Mode 3 has a caution threshold based upon height above terrain and vertical speed. When

below the caution threshold, a GPWS Mode 3 warning is generated as defined in Figure 8-11.

$$\text{“Don’t Sink” AGL} = 1.4 * \text{sink rate}$$




Figure 8-11: Fixed Wing GPWS Mode 3

8.8. Flight into Terrain when not in Landing Configuration (GPWS Mode 4)

GPWS Mode 4 function is present in Class A TAWS and uses aircraft speed information and AGL altitude to alert when descending into terrain without properly configuring the aircraft for landing. There are two Mode 4 envelopes: Mode 4A gives cautions when landing gear is in other than landing configuration, and Mode 4B gives cautions when landing gear or flaps are in other than landing configuration. Applicability of Mode 4 envelopes to aircraft types are as follows.

Table 8-7: Mode 4 Envelopes

Configuration	Mode 4A	Mode 4B
Retractable gear with defined landing flaps position	Landing gear up	Landing gear up or flaps not in landing configuration
Retractable gear	Landing gear up	Landing gear up
Fixed gear with defined landing flaps position	Not Applicable	Flaps not in landing configuration
Fixed gear	Not Applicable	Not Applicable

Mode 4 alerting criteria requires the Mode 4 envelope be entered from above, so changing aircraft configuration within a Mode 4 envelope does not generate an alert. Mode 4 envelopes consists of a low-speed region and a high-speed region. **TOO LOW** appears with aural alerts as defined in Table 8-8:

Mode	Alerting Criteria Met in:	Aural Alert
Mode 4A	Low-speed region	“Too Low Gear”
Mode 4B	Low-speed region	“Too Low Gear” (Landing gear UP) “Too Low Flaps” (Landing gear DOWN)
Mode 4	High-speed region	“Too Low Terrain”

Mode	Region	Speed (KIAS)	AGL Altitude (ft.)
4A	Low-Speed	< 182.5	500
	High-Speed	≥ 182.5	Lesser of: 800 or $8 \times (\text{KIAS} - 120)$
4B	Low-Speed	< 138.75	150
	High-Speed	≥ 138.75	Lesser of: 800 or $8 \times (\text{KIAS} - 120)$




Figure 8-12: Fixed Wing GPWS Mode 4

8.9. Excessive Downward Deviation from an ILS Glideslope (GPWS Mode 5)

GPWS Mode 5 function uses ILS glideslope deviation information and AGL altitude to alert when excessive downward glideslope deviation is detected on the final approach segment of an ILS approach. GPWS Mode 5 is armed when a valid glideslope signal is being received, AND the aircraft is below **1000' AGL**.

GPWS Mode 5 has a caution and a warning threshold. When below a threshold, a GPWS Mode 5 warning is generated. The curve compares glideslope deviation to AGL altitude as follows. (Reference: RTCA/DO-161A Mode 5 for TAWS)

Table 8-10: GPWS Mode 5 Envelopes	
Caution Threshold	Warning Threshold
Greater of: $\left[(150 - \text{AGL Altitude}) \times 1.3 + 1.4\% \times \right] \text{ Dots}$ or 1.3 Dots	Greater of: $\left[(150 - \text{AGL Altitude}) \times 2 + 1\% \times \right] \text{ Dots}$ or 2 Dots




Figure 8-13: Fixed Wing GPWS Mode 5

8.10. 500-Foot Wake-Up Call

This function is present in all TAWS classes. The **500-foot** function includes an arming deadband of **500 feet** to prevent nuisance warnings during low altitude operations. Thus, the aircraft must climb above **1000 feet** AGL to arm the **500-foot** function and generate a **500-foot** annunciation.

8.11. External Sensors and Switches

The EFIS TAWS requires a variety of inputs from external sensors and switches to perform its functions. Inputs are as follows:

- 1) **GPS/SBAS Receiver:** Source of aircraft position, geodetic height, horizontal figure of merit (HFOM), vertical figure of merit (VFOM), loss of integrity (LOI), and loss of navigation (LON) inputs. Connects directly to the IDU.
- 2) **Air Data Computer (ADC):** Source of barometric altitude, outside air temperature, and vertical speed. Connects directly to the IDU.
- 3) **ILS Receiver:** Glideslope receiver is the source of glideslope deviation for the TAWS.
- 4) **Radar Altimeter (RA):** Source for radar altitude.
- 5) **Gear Position Sensors:** As configured in the system limits, landing gear position discrettes are the source.
- 6) **Flap Position Sensor:** As configured in the system limits, flap position discrete is the source.
- 7) **TAWS Inhibit Switch:** As configured in the system limits, used for manual inhibiting of TAWS alerting functions. Gives an indication of actuation (e.g., toggle/rocker or pushbutton with indicator light and **XFILL INHBT** in lower left corner of PFD).
- 8) **Audio Mute Switch:** Momentarily activated to silence active aural alerts. It is connected directly to the EFIS IDU.
- 9) **Glideslope Deactivate Switch:** As configured in the system limits, momentarily activated to inhibit GPWS Mode 5 function.

Table 8-11: TAWS External Sensors and Switches

TAWS Class Configuration	A				B or C
	RG + F	RG	FG + F	FG	
GPS/SBAS	✓	✓	✓	✓	✓
ADC	✓	✓	✓	✓	✓
Gear Position Sensor	✓	✓			
TAWS Inhibit Switch	✓	✓	✓	✓	✓
Audio Cancel Switch	✓	✓	✓	✓	✓
ILS	✓	✓	✓	✓	
Radar Altimeter	✓	✓	✓	✓	
Flap Position Sensor	✓	✓	✓	✓	
Glideslope Deactivate Switch	✓	✓	✓	✓	

8.12. TAWS Basic Parameter Determination

Fundamental parameters used for TAWS functions are as follows.

Table 8-12: Airplane TAWS Basic Parameters Determination

Parameter	Source	Notes
Aircraft position, groundspeed, and track	GPS/SBAS	HFOM must be less than or equal to the greater of 0.3 NM or the Horizontal alert limit (HAL) for the mode of flight.
MSL Altitude	GPS/SBAS	Geodetic Height converted to MSL with the current EGM (Earth Gravity Model) database. To be considered valid for use as MSL altitude, the VFOM must be less than or equal to 106 feet. Secondary source of MSL altitude is barometric altitude from an air data computer. Barometric altitude is based upon a barometric setting in the following order of preference:

Table 8-12: Airplane TAWS Basic Parameters Determination

Parameter	Source	Notes
		<p>1) If either the pilot or co-pilot system is operating in QNH mode, the QNH barometric setting is used (on-side barometric setting preferred); or</p> <p>2) If GPS/SBAS geodetic height has been valid within the last 30 minutes, a barometric setting derived from the GPS/SBAS geodetic height is used.</p> <p>If neither of the above conditions are met, MSL altitude is marked as invalid.</p> <p>When a reporting station elevation is determined and outside air temperature is valid, a temperature correction is applied.</p> <p>TAWS uses the lower of the barometric altitude or the temperature-corrected altitude. In the case of QNH-mode barometric setting, reporting station elevation is derived from waypoint or active runway elevations in the active flight plan using the following logic:</p> <p>1) If the aircraft is in TERMINAL, DEPARTURE, IFR APPROACH, or VFR APPROACH mode and an active runway exists,</p>

Table 8-12: Airplane TAWS Basic Parameters Determination

Parameter	Source	Notes
		<p>reporting station elevation is the elevation of the active runway threshold.</p> <p>2) Otherwise, if the aircraft is in TERMINAL mode, reporting station elevation is the elevation of the airport causing TERMINAL mode.</p> <p>3) In ENROUTE mode, no reporting station elevation is determined.</p> <p>In the case of GPS/SBAS geodetic height-based barometric setting, reporting station elevation is the GPS MSL altitude reported at the time the barometric setting was determined (see Section 3 Display Symbology).</p>
Terrain Data	Terrain Database	<p>To be considered valid, the following must apply:</p> <ol style="list-style-type: none"> 1) Aircraft position is valid; 2) Aircraft position is within the boundaries of the terrain database; and 3) Terrain database is not corrupt as determined by CRC-32 checks at system initialization and during runtime.
Obstacle Data	Obstacle Database	<p>To be considered valid, the following must apply:</p> <ol style="list-style-type: none"> 1) Aircraft position is valid;

Table 8-12: Airplane TAWS Basic Parameters Determination

Parameter	Source	Notes
		2) Aircraft position is within the boundaries of the obstacle database; and 3) Obstacle database is not determined corrupt by CRC-32 checks at system initialization.
AGL Altitude	Radar Altitude	Secondary source is MSL altitude less terrain altitude.
Vertical Speed	Instantaneous vertical speed	IVSI values come from barometric vertical speed from an ADC “quickened” with vertical acceleration from an AHRS. Secondary source for vertical speed is barometric vertical speed from an ADC. Tertiary source for vertical speed is GPS/SBAS vertical speed providing the VFOM is less than or equal to 106 feet.
Terrain Closure Rate	Smoothed first derivative of AGL Altitude	Due to multiple sources for altitude, there are multiple sources for terrain closure rate.
Runway/ Reference point location	EFIS navigation database	To be considered valid, the following must apply: 1) Aircraft position is valid; 2) Aircraft position is within the boundaries of the navigation database; and 3) Navigation database is not determined corrupt by CRC-32 check at system initialization.

8.13. TAWS Automatic Inhibit Functions (Normal Operation)

The following automatic inhibit functions occur during normal TAWS operation to prevent nuisance warnings:

- 1) FLTA function is automatically inhibited when in the Terminal, Departure, IFR Approach, or VFR Approach modes and within 2NM and 1900' of the reference point.
- 2) PDA function is automatically inhibited when within 2NM and 1900' of the approach runway threshold.
- 3) GPWS Modes 1 through 4 are automatically inhibited when below 50 feet AGL (radar altimeter AGL altitude) or below 100 feet AGL (terrain database AGL altitude).
- 4) GPWS Mode 5 is inhibited below 200' AGL. Remains active until the aircraft climbs above 1000' AGL. Prevents nuisance alarms on missed approach when glideslope receiver detects glideslope sidelobes.

8.13.1. TAWS Automatic Inhibit Functions (Abnormal Operation)

The following automatic inhibit functions occur during the specified abnormal operations. System sensor failures, non-installation of optional sensors, database failures, and combinations thereof affect the TAWS as follows.

Sensor	Parameters Lost	Terrain Displaced	FLTA	PDA	GPWS Mode					500' Wake-Up
					1	2	3	4	5	
GPS/SBAS (H)	AC Position	Inhibit	Inhibit	Inhibit						
TD	Terrain Elev.	Inhibit	Inhibit							

Table 8-13: TAWS Automatic Inhibit Functions

Sensor	Parameters Lost	Terrain Displaced	FLTA	PDA	GPWS Mode					500' Wake-Up
					1	2	3	4	5	
ILS	Glideslope Dev.								Inhibit	
MSL	MSL Altitude	Inhibit	Inhibit	Inhibit						
GPS/SBAS (H) + RADLT	AC Position, AGL Altitude	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit
GPS/SBAS (V) + ADC	MSL Altitude, VSI	Inhibit	Inhibit	Inhibit	Inhibit		Inhibit			
TD + RADLT	Terrain Elev. AGL Altitude	Inhibit	Inhibit		Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit
MSL + RADLT	MSL Altitude, AGL Altitude	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit
GPS/SBAS (V) + ADC + RADLT	MSL Altitude, VSI, AGL ALT	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit	Inhibit

Notes:

- 1) Combinations listed give the minimum combinations with the worst consequences. Many other combinations are possible, but their effects are subsumed within the combinations listed.
- 2) GPS/SBAS (H) = HFOM > max (0.3NM, HAL). Indication is loss of terrain display on PFD and ND.
- 3) GPS/SBAS (V) = VFOM > 106'.
- 4) GPS/SBAS = GPS/SBAS (H) + GPS/SBAS (V). Indication is loss of terrain display on PFD and ND.
- 5) TD = Terrain Data invalid due to being beyond the database boundaries or database corruption.
- 6) ADC = Single Air Data Computer failure. Indication is **ADC1 FAIL** / **ADC2 FAIL** or red Xs.
- 7) RADALT = Radar Altimeter. Indication is lack of radar altimeter source indication on radar altimeter display.
- 8) ILS = ILS Glideslope Deviation. Indication is lack of glideslope needles.
- 9) MSL=MSL Altitude Invalid. Indication is **NO TAWS** in the absence of other failures.

8.13.2. TAWS Manual Inhibit Functions

The pilot may select the following manual inhibit functions:

- 1) Terrain Display function may be inhibited using EFIS soft menu declutter control.
- 2) All TAWS alerting functions (including popup functionality) are inhibited with the external TAWS Inhibit Switch, which does not affect the Terrain Display function, including display of FLTA warning (red) and caution (amber [yellow]) flags on the ND.
- 3) GPWS Mode 5 is manually inhibited with the Glideslope Cancel Switch when below 1000' AGL. GPWS Mode 5 manual inhibit automatically resets by ascending above 1000' AGL.

8.14. TAWS Selections on PFD

PFD Declutter menu includes the following possibilities for TAWS:

- 1) SVS TAWS
- 2) SVS BASIC
- 3) None

The following figures show all possible scenarios including “None” where the aircraft pierces the TAWS FLTA Terrain envelope, and SVS TAWS is enabled for the safest possible Warning Alert condition.





Figure 8-14: PFD SVS BASIC Option



TAWS FLTA Caution: Amber (Yellow)
TAWS FLTA Warning: Red

Figure 8-15: PFD SVS TAWS Option





Figure 8-16: PFD SVS TAWS Option and Obstructions




Obstruction within TAWS FLTA caution envelope.
Aural annunciation "Caution Obstruction, Caution Obstruction".
Obstruction symbols flash.

Figure 8-17: PFD Obstruction Caution



Obstruction within TAWS FLTA warning envelope.
 Aural annunciation “Warning Obstruction, Warning Obstruction”.
 Obstruction symbols flash.

Figure 8-18: PFD Obstruction Warning



If SVS TAWS and SVS BASIC were not checked and aircraft pierced TAWS FLTA Terrain envelope, EFIS automatically enables SVS TAWS. **TERRAIN** has precedence over **OBSTRUCTION**.

Figure 8-19: Automatic PFD Terrain Warning

Section 9 Appendix

9.1. Appendix

This section contains a variety of useful information not found elsewhere in the guide and includes operating tips, system specifications, and feedback forms.

9.2. Operating Tips

With the Genesys Aerosystems EFIS installed and certified in all categories of certified aircraft, numerous tips and suggestions are available for obtaining the maximum performance and benefit from this system. Additional operating tips are available with future releases of this publication.

9.3. Domestic or International Flight Planning

Due to the differences in every aircraft avionics suite installation, the pilot must determine what equipment code is applicable for domestic or international flight plans. All certifications are outlined in the Flight Manual Supplement. The aircraft operator must determine what certifications pertain to them. Visit the FAA website, www.faa.gov, for flight plan guidance for both domestic and international filers, as well as, information and documentation regarding FAA, ICAO, and Flight Services agreements and procedures.

9.4. Descent Planning

Instead of performing conventional time/speed/distance/descent-rate calculations, use the waypoint symbol for descent planning. Simply maintain the cruise altitude until the "X" at the bottom of the waypoint symbol is 2-3 degrees below the horizon (as indicated by pitch scale), and then begin a 2-3 degree descent. Maintain the correct descent angle by keeping the flight path marker positioned on the waypoint "X" symbol. Following the skyway boxes assures the VNAV descent angle is maintained.

9.5. Terrain Clearance

Use the flight path marker to evaluate climb performance in regards to terrain clearance. If climbing at the best climb speed to clear terrain and the flight path marker is overlaying terrain, which must be cleared, the climb rate is insufficient. Either the course or climb

rate must be altered to adequately clear the terrain. If the flight path marker is well clear of terrain (overlying blue sky), the climb is sufficient for the present time, and no further action is necessary until level off.

9.6. Departure Airport Information

On startup, all information for the departure airport is readily available. The altimeter is automatically set to the nearest IFR runway touchdown zone elevation. Press **NRST (R3)** to reveal the nearest airports. When highlighted, all important data such as frequencies are displayed.

9.7. Unique Names for Flight Plans

Multiple routes between the same airport pairs are numbered automatically (KCEW-KDHN) [0], (KCEW-KDHN) [1], etc.). The work-around is to apply this easily remembered differentiation. If a route is routinely flown from one airport to another but different routing is necessary due to weather, hot MOA areas, etc., two or more different flight plans may be created for the same destination.

As an example for departing Sikes on a northern routing (KCEWN) or a southern routing (KCEWS), create two different user waypoints at the departure airport named KCEWN and KCEWS followed by different routing to clear the MOA or whatever creates the necessity for specific routing.

9.8. Altimeter Settings

Use caution when setting the altimeter and inadvertently changing the transition level. If this is reset to a lower than normal altitude, **CHK BARO** may appear due to the altimeter setting not on 29.92 inHg or 1013 mbar.

9.9. Warnings, Cautions, and Advisories

Review Section 2 System Overview for the conditions precisely defining scenarios for various warnings, cautions, and advisory flags as they appear including the time delay when applicable.

9.10. Magnetic vs. True North Modes of Operation

There are two modes for the ADAHRS:

- 1) Slaved mode (i.e., compass rose stabilized by Earth's magnetic flux horizontal field) is the normal mode. It works well over most of the surface of the earth (i.e., areas with a horizontal field of 5000nT or above, which includes about 2/3rds of Canadian NDA). ADAHRS senses magnetic flux with a 3D magnetometer. Performance in small horizontal fields is installation dependent as variable magnetic disturbances from the aircraft may begin to predominate.
- 2) Free or "DG" mode (i.e., compass rose not stabilized by the Earth's magnetic flux horizontal field and subject to drift) is used in areas of magnetic disturbances (oilrigs, MRI machines, etc.) or in areas where the horizontal field is too weak. In Free/"DG" mode, heading no longer corrects towards Earth's magnetic flux horizontal field, and the pilot may "slew" the heading solution.




Figure 9-1: US/UK World Magnetic Model

There are two modes for the EFIS:

- 1) Magnetic North mode: Heading from the AHRS (whether slaved or Free/"DG") is used as-is and is expected to reflect Magnetic North. GPS Track is converted from True North-referenced to Magnetic North-referenced using a magnetic variation database. PFD scenes and compass rose symbols are aligned with Magnetic North, and wind is displayed referenced to Magnetic North.
- 2) True North mode: GPS Track is used as-is and reflects True North. When AHRS is in Slaved mode, heading from the AHRS is converted from Magnetic North-referenced to True North-

referenced using a magnetic variation database. When AHRS is in Free/DG mode, heading from the AHRS is used as-is and is expected to reflect True North. PFD scenes and compass rose symbols are aligned with True North, and wind is displayed referenced to True North.

NOTE:

Designating Magnetic North vs. True North mode is critical since it determines how inputs are used – i.e., the relationship between GPS Track and ADAHRS Heading. Mixing things up in Free/DG mode (i.e., slewing the compass rose to match Magnetic North when in True North mode and vice-versa) may result in large errors in wind calculations and GPS track/flight path marker displays.

9.11. Altitude Miscompare Threshold

The altitude miscompare threshold is based upon allowable altitude error. There are two components to allowable altitude error, instrument error and installed system error. Allowable instrument error is based upon the values of SAE AS8002A Table 1 as follows.

Table 9-1: Allowable Instrument Error	
Altitude	Allowed Error
Sea Level	25'
1,000'	25'
2,000'	25'
3,000'	25'
4,000'	25'
5,000'	25'
8,000'	30'
11,000'	35'
14,000'	40'
17,000'	45'
20,000'	50'
30,000'	75'
40,000'	100'
50,000'	125'

Allowable installed system error is added on top of instrument error and these values are derived from the regulations as follows.

Table 9-2: Regulatory Reference

Regulation	Allowed Error
14 CFR § 23.1325	At sea level, the greater of 30' or 30% of the calibrated airspeed in knots. This increases proportionally to SAE AS8002A Table 1 at higher altitudes.
14 CFR § 25.1325	
14 CFR § 27.1325	
14 CFR § 29.1325	

An allowable altitude error is computed for each compared value and added together to create the altitude miscompare threshold. This accommodates for the values deviating in different directions.

Worked example for a calibrated airspeed of 100 knots and comparing a first altitude of 3,490' with a second altitude of 3,510':

- 1) Calculate allowable instrument error based upon altitudes:
 Allowable Instrument Error #1 = 50'
 Allowable Instrument Error #2 = 50'
- 2) Calculate allowable installed system error based upon altitudes and calibrated airspeed:
 Allowable Installed System Error #1 = 30'
 Allowable Installed System Error #2 = 30'
- 3) Calculate altitude miscompare threshold based upon sum of above allowable errors:
 Altitude Miscompare Threshold = 160'

9.12. Airspeed Miscompare Threshold

Airspeed miscompare threshold is based upon allowable airspeed error. There are two components to allowable airspeed error, instrument error and installed system error. Allowable instrument error is based on values of SAE AS8002A Table 3 as follows.

Table 9-3: Airspeed Error	
Calibrated Airspeed	Allowed Error
50 knots	5 knots
80 knots	3 knots
100 knots	2 knots
120 knots	2 knots
150 knots	2 knots
200 knots	2 knots
250 knots	2.4 knots

Table 9-3: Airspeed Error	
Calibrated Airspeed	Allowed Error
300 knots	2.8 knots
350 knots	3.2 knots
400 knots	3.6 knots
450 knots	4 knots

Allowable installed system error is added on top of instrument as these values are derived from the regulations as follows.

Table 9-4: Airspeed Regulatory Reference	
Regulation	Allowed Error
14 CFR § 23.1323	Starting from $(1.3 \times V_{S1})$: Greater of 5 knots or 3%. Do not perform a comparison if either value is below $(1.3 \times V_{S1})$.
14 CFR § 25.1323	Starting from $(1.23 \times V_{SR1})$: Greater of 5 knots or 3%. Do not perform a comparison if either value is below $(1.23 \times V_{SR1})$. System uses V_{S1} as a substitute for V_{SR1} .
14 CFR § 27.1323	Starting from $(0.8 \times V_{CLIMB})$: Greater of 5 knots or 3%. Do not perform a comparison if either value is below $(0.8 \times V_{CLIMB})$.
14 CFR § 29.1323	For Climbing Flight ($VSI > 250$ feet per minute): Starting from $(V_{TOS} - 10)$: 10 knots Do not perform a comparison if either value is below $(V_{TOS} - 10)$ For Other Flight Regimes: Starting from $(0.8 \times V_{TOS})$: Greater of 5 knots or 3%. Do not perform a comparison if either value is below $(0.8 \times V_{TOS})$. System uses V_{CLIMB} as a substitute for V_{TOS} .

An allowable airspeed error is computed for each compared value and added together to create the airspeed miscompare threshold and accommodates for the values deviating in different directions.

9.13. Jeppesen NavData Chart Compatibility

As GPS navigation, flight management systems, computer flight maps, and computer flight planning systems have gained acceptance, avionics companies and software developers have added more features. Even with the many systems available today, paper enroute, departure, arrival, and approach charts are still required and necessary for flight. Avionics systems, flight planning, computer mapping systems, and associated databases *do not* provide all of the navigation information needed to conduct a legal and safe flight. They are not a substitute for current aeronautical charts.

See www.Jeppesen.com for the latest information on coding instrument procedures, naming conventions, altitudes within the database, and aeronautical information compatibility.

9.14. ARINC-424 Path Terminator Leg Types

For information, definitions, and examples, visit the FAA website, www.faa.gov, to view the Instrument Procedures Handbook (FAA-H-8083-16A).

9.15. Data Logging and Retrieval

The EFIS logs all data associated with a flight, including all flight instrument and navigation data, which may be downloaded for review after flight. Data from the last 5 flights or 20 hours are logged at a one-second interval.

Data logging files contain recordings of flight and engine parameters of up to five hours each from the previous five system operations. During system operation, flight and engine parameters are recorded every one second. Each time the parameters are recorded, a Zulu time stamp followed by three lines of comma delimited ASCII text data are written where the first line contains flight parameters and, the second line contains engine parameters.

With IDU powered off, open USB door, and insert USB memory device. Select “Download LOG Files” to create a “log” directory on the USB and copy the data logging files into the directory.

CAUTION:

Always install a valid USB memory device in the IDU prior to activating any Ground Maintenance Function to avoid erroneous failure indications or corruption of the IDU.

9.15.1. Delete LOG Files

- 1) If there are problems updating a navigation database or application software due to an excessively large log file, select “Delete LOG Files” to delete all log files in the log directory.

Files named “LOG00.dat” thru “LOG04.DAT” and “MSGLOG.DAT” are deleted. This does not affect operations of the EFIS, as the EFIS generates new “LOG00.DAT” and “MSGLOG.DAT” files once a flight has started.

- 2) Press any button on the IDU or push **1** to return to the Ground Maintenance menu.

9.15.2. Logged Flags and Custom CAS Messages

Flags and custom CAS messages are logged in memory to a file named “caslog00.csv” (*.csv files may be opened in Microsoft Excel or similar spreadsheet software). In addition, data from the previous four flights are saved in files “caslog01.csv” through “caslog04.csv.” Upon system start, the existing “caslog00.csv” through “caslog03.csv” files are renamed “caslog01.csv” through “caslog04.csv,” and “caslog00.csv” is opened for active logging.

The first line of the log files contains column headings related to the flag’s text (for standard warning functions) or the “CAS Log File Text” parameter (for custom CAS messages). All standard warning functions are logged. Only custom CAS messages with valid “CAS Log File Text” parameters (i.e., not an empty string) are logged. Within the data fields of the log file, values are written as follows.

Table 9-5: Log File Values

Category	Value
NORMAL	0
ADVISORY	1
CAUTION	2
WARNING	3

9.15.3. Screen Capture from Ground Maintenance Pages

- 1) With IDU powered off, open USB door, and insert USB.
- 2) Power up IDU and gain access to GMF desired page.
- 3) Press **(R4)** to capture view of the page. Files named either "GROUNDdd.BMP" or "LIMEDTdd.BMP" are written to the user\log\ subdirectory.
- 4) Press any button or push **1** to exit copied page and return to Ground Maintenance menu.
- 5) Scroll **1** to **Download Log Files** and push to enter.
- 6) Power down IDU, remove USB, and lower USB door.
- 7) Insert USB into computer and view list (20 maximum) of files including "GROUNDdd.BMP" or "LIMEDTdd.BMP."

9.16. Routes and Waypoints

9.16.1. VFR Flight Planning

The navigation database includes VFR waypoints, which consist of five digits beginning with "VP." These may be found on VFR charts and should be loaded in the FMS prior to flight to ensure they are available in the database, and INFO checked for proper location.




Figure 9-2: VFR Waypoint

9.16.2. EFIS Training Tool (ETT)

See the Installation and User Guide distributed with the ETT install files for directions to install and use the EFIS Training Tool.

Use the ETT to create routes and user waypoints to save and upload into the aircraft mounted IDUs. The ETT has a bezel with simulated buttons and encoders responsive to mouse and keyboard messages. Bezel graphics are derived from actual bezel design data, and the ETT presents an active display with 1:1 pixel correspondence to an actual IDU display. The audio output capability for the ETT matches the audio functionality in the actual IDU. This training tool simulates the functionalities of the IDU, which begins flight in Reno, Nevada at approximately 7900' MSL. If different ETT startup conditions are required, they may be edited.

Flight plans may be created (on the PFD or MFD), stored, and activated in the same manner as on the EFIS displays installed in the aircraft. This allows for moving the start point to anywhere in the world where loaded NavData is present for practicing published procedures. As with the demonstrator program, the aircraft begins flying at approximately 7900' MSL (unless the simulate.ini program is loaded) intercepting the first leg at a 45° angle.

9.16.3. Download Routes and User Waypoints

To download all routes and user waypoints stored in the IDU to USB memory, select "Download Routes and User Waypoints" from the Ground Maintenance Page. Routes are stored on the USB as NAME1-NAME2.RTE where NAME1 is the 1- to 5-character designation of the origin waypoint and NAME2 is the 1- to 5-character designation of the destination waypoint. User waypoints are stored on the USB as USER.DAT. This option is useful for fleet operations where multiple aircraft fly the same routes.

9.16.4. Upload Routes and User Waypoints

To copy all routes and user waypoints from a USB to the IDU, select "Upload Routes and User Waypoints" on the Ground Maintenance page. This option used in conjunction with the "Download Routes and User Waypoints" option enables the same routes and user waypoints to be stored in multiple aircraft.

9.16.5. Delete Routes/User Waypoints

When corrupted routes cause the IDU to continually reboot, select "Delete Routes" on the Ground Maintenance page to remove all routes and the user waypoint file (USER.DAT) from the IDU.

9.17. USB External Drive Memory Limitations

When powering up the IDU with a USB inserted and “Error: No updater files found on USB drive” displays, the USB is likely not acceptable for loading or transferring data.

- 1) Ensure the USB with required files is properly connected.
- 2) Try again after reboot.
- 3) Press any button to continue.
- 4) Try a different USB external drive.

NOTE:

Maximum USB memory is not a factor, but the following should be considered:

USB must be formatted as FAT.

FAT-16 for USB Drives 2 GB or smaller

FAT-32 for any larger sized drive.

If the drive is not recognized, try another source.

9.18. Service Difficulty Report

Print, complete, then fax to 940-325-3904

Name:	Phone:
Flight No:	Date:
Aircraft:	Registration#:
Software Version:	Error Code:
Route:	Duration of Flight:
Conditions:	
Remarks: (Include time, altimeter Setting, OAT, ALT, TAS, GS, Heading, track, position, flight segment, pilot action, system response, is problem repeatable?).	

9.19. Certification Basis

The following TSOs are considered applicable to the IDU-450 (depending upon the features of the installed software).

Document Number	Document Title	
ARINC 429-16	Mark 33 Digital Information Transfer System (DITS)	
ARINC 735A-1	Traffic Alert and Collision Avoidance System	
EIA-232D	Interface between Data Terminal Equipment and Data	
EIA-422A	Electrical Characteristics of Balanced Voltage Digital Interface Circuits	
FAA AC 23.1311-1B	Installation of Electronic Display in Part 23 Airplanes	
RTCA/DO-155	Minimum Performance Standards - Airborne Low-Range Radio Altimeters	
RTCA/DO-229D	Minimum Operational Performance Standards for Global Positioning System/Wide Area Augmentation System Airborne Equipment	
RTCA/DO-283A	Minimum Operational Performance Standards for Required Navigation Performance for Area Navigation	
SAE AS396B	Bank and Pitch Instruments (Indicating Stabilized Type)	
SAE AS8002A	Air Data Computer - Minimum Performance Standard	
TSO-C4c	Bank and Pitch Instruments	
TSO-C87	Airborne Low-Range Radio Altimeter	
TSO-C106	Air Data Computer	
TSO-C194	Terrain Awareness and Warning System	
TSO-C113	Airborne Multipurpose Electronic Displays	SAE AS8034
TSO-C52b	Flight Director Equipment	SAE AS8008
TSO-C146a	Stand-Alone airborne navigation equipment using the Global Positioning System (GPS) Augmented by the Wide Area Augmentation System (WAAS)	
N/A	Airplane Aerodynamics and Performance, Lan and Roskam, 1981.	

9.20. Environmental Requirements

While the IDU-450 meets the following requirements of RTCA/DO-160F, Genesys Aerosystems claims the following:

- 1) The coldest storage temperature is -55°C.
- 2) Coldest condition in which the units can be powered up is -40°C and will take at least 4 minutes to warm up with the internal heater circuit operating.

Sec.	Condition	Cat.	Test Category Description	Notes
4.0	Temperature and Altitude	F2	Equipment intended for installation in non-pressurized and non-controlled temperature location in an aircraft that is operated at altitudes up to 55,000 ft. (16,800 m) MSL. Operating Low Temp: -55 deg C Operating High temp: +70 deg C Ground Survival Low Temp: -55 deg C Ground Survival High Temp: +85 deg C Altitude: +55,000 feet	+75°C for Short-Time Operating High Temp. Cat. V (30 minutes) for loss of cooling.
5.0	Temperature Variation	B	Equipment in a non-temperature-controlled or partially temperature controlled internal section of the aircraft.	
6.0	Humidity	B	Equipment intended for installation in civil aircraft, non-civil transport aircraft and other classes, installed under conditions in which a more severe humidity environment than standard conditions may be encountered.	

Sec.	Condition	Cat.	Test Category Description	Notes
7.0	Operational Shocks & Crash Safety	B	Equipment generally installed in fixed-wing aircraft or helicopters and tested for standard operational shock and crash safety.	Aircraft Type 5, Test Type R for Crash Safety Sustained Test
8.0	Vibration	H + R + U	<p>H – Demonstrates performance at high-level, short duration transient vibration levels</p> <p>R - (Fixed-Wing) Demonstrates performance at higher, robust vibration levels and after long term vibration exposure.</p> <p>U - (Helicopter w/Unknown Frequencies) Demonstrates performance at higher vibration levels and after long-term vibration exposure for fuselage and instrument panel equipment when the specific rotor frequencies are unknown.</p>	<p>Cat. H, curve R</p> <p>Cat. R, curves B, B1</p> <p>Cat. U, curve G</p>
9.0	Explosive Atmosphere	X	Not Applicable	
10.0	Waterproofness	W	Equipment is installed in locations where it may be subjected to falling water, such as condensation.	Drip proof test
11.0	Fluids Susceptibility	X	Not Applicable	
12.0	Sand and Dust	S	Equipment is installed in locations subject to blowing sand and dust.	

Sec.	Condition	Cat.	Test Category Description	Notes
13.0	Fungus Resistance	F	Demonstrate whether equipment material is adversely affected by fungi growth.	By Analysis
14.0	Salt Fog	S	Equipment is subjected to a corrosive atmosphere	
15.0	Magnetic Effect	Z	Magnetic deflection distance less than 0.3m.	
16.0	Power Input	Z	Equipment intended for use on aircraft DC electrical systems where the DC supply has a battery whose capacity is small compared with the capacity of the DC generators.	200 ms power interruption capacity
17.0	Voltage Spike	A	Equipment intended primarily for installation where a high degree of protection against damage by voltage spikes is required.	
18.0	Audio Frequency Conducted Susceptibility-Power Inputs	Z	Equipment intended for use on aircraft DC electrical systems where the DC supply may not have a battery of significant capacity floating on the dc bus at all times.	
19.0	Induced Signal Susceptibility	ZC	Equipment intended primarily for operation in systems where interference-free operation is required on aircraft whose primary power is constant frequency or DC.	
20.0	Radio Frequency Susceptibility	Y	Equipment and interconnecting wiring installed in severe	Radiated: K

Sec.	Condition	Cat.	Test Category Description	Notes
	(Radiated and Conducted)		electromagnetic environments and to show compliance with the interim HIRF rules.	Minimum level at all frequencies to be 100V/m
21.0	Emission of Radio Frequency Energy	M	Equipment in areas where apertures are EM significant but not in direct view of aircraft antennas, such as passenger cabin or cockpit.	
22.0	Lightning Induced Transient Susceptibility	A3J 33	Equipment interconnected with wiring installed within any airframe or airframe section when structural resistance is also a significant source of induced transients, (i.e., carbon fiber composite structures). Level 3 designates equipment and interconnecting wiring installed in a moderately exposed environment.	Level 4 for MSU and OAT Probe pins.
23.0	Lightning Direct Effects	X	Not Applicable	
24.0	Icing	X	Not Applicable	
25.0	Electrostatic Discharge (ESD)	A	Electronic equipment that is installed, repaired, or operated in an aerospace environment.	
26.0	Fire, Flammability	C	Non-metallic equipment, component parts, sub-assemblies installed in pressurized or non-pressurized zones and non-fire zones with largest dimension greater than 50 mm.	By Analysis

Traffic

T 1. Traffic Symbology



Figure T-1: Traffic Symbology



When selected from declutter options, the traffic thumbnail has clock face markings fixed at the 6 NM scale. The traffic thumbnail is automatically enabled while there is an active traffic warning (TA or RA) and the aircraft is above 500' AGL. During a traffic warning, the traffic thumbnail scale automatically adjusts in multiples of two NM (2 NM, 4NM, or 6NM) to optimally display the traffic. The traffic thumbnail is mutually exclusive with the Mini-map, so it too disappears in the Unusual Attitude Mode.

The traffic thumbnail is mutually exclusive with the Mini-map, so it too disappears in the Unusual Attitude Mode.

Figure T-2: Traffic Thumbnail

T 1.1. Traffic Display Definitions

- 1) Resolution Advisory (RA): Traffic with a dangerous closest point of approach and generates climb or descent commands as defined by internal TCAS-II sensor logic.
- 2) Traffic Advisory (TA): Traffic with a dangerous closest point of approach as defined by internal traffic sensor logic.

- 3) Proximate Advisory (**PA**): Traffic within 6 NM and ± 1200 feet from ownship that is not an RA or TA.
- 4) Other Traffic (**OT**): Traffic beyond 6 NM or ± 1200 feet from ownship that is not an RA or TA.

T 1.2. Traffic Rendering Rules

Traffic thumbnail and PFD traffic are rendered as follows.

Table T-1: Traffic Rendering Rules

Type Traffic	Distance	Results
OT and PA Traffic	Beyond 6 NM	Not displayed
TCAS-I, TCAS-II, TAS, or TIS-A Sensor	Within 200' of ground	Not displayed

Table T-2: Traffic Symbology







Type Traffic	Symbology
TCAS-I, TCAS-II, and TIS-A	   
	Other Traffic Proximate Advisory Traffic Advisory (Flashing) Resolution Advisory (Flashing)
Ownship Symbol	Airplane w/o M_{Mo} Airplane with M_{Mo}
	 

Table T-3: Pilot Selected OT and PA Traffic Altitude-Filter

Mode	Parameter
AUTO	If aircraft VSI is less than -500FPM, traffic within +2,700 and -9,900 feet of aircraft altitude is displayed. If aircraft VSI is more than +500FPM, traffic within -2,700 and +9,900 feet of aircraft altitude is displayed. Otherwise, traffic within -2,700 and +2,700 feet of aircraft altitude is displayed.


Table T-3: Pilot Selected OT and PA Traffic Altitude-Filter

Mode	Parameter
ABOVE	Traffic within -2,700 and +9,900 feet of aircraft altitude is displayed.
BELOW	Traffic within +2,700 and -9,900 feet of aircraft altitude is displayed.
NORMAL	Traffic within -2,700 and +2,700 feet of aircraft altitude is displayed.
ALL	All received traffic is displayed, no altitude filtering is performed.

T 2. Dedicated Traffic Screen

When selected, a traffic screen is available based roughly on the appearance of a TCAS display and has the following elements.

T 2.1. Traffic Display Format

**Figure T-3: Traffic Display Format**

The traffic display uses a centered display format with the ownship symbol centered in the traffic screen with data displayed out to an equal distance in all directions. The compass rose is aligned with either magnetic North or True North depending upon the status of the True North discrete input. When the AHRS is in DG Mode, “DG” appears to the right of the ownship symbol.

T 2.2. Traffic Screen Range

The following traffic screen selected ranges are available (all distances represent the distance from the ownship symbol to the compass rose): 5NM, 10NM, and 20NM.

A TCAS range ring is centered on the ownship symbol to help judge range, has a 3NM radius in 5NM and 10NM ranges, and has a radius of half the range in 20NM, 50NM, and 100NM ranges. Range indication corresponding to the radius of the TCAS range ring is presented on the TCAS range ring (e.g., 3NM, 10NM, 25NM, or 50NM).

T 2.3. Compass Rose Symbols




Figure T-4: Traffic Screen Range Compass Rose Symbols

A digital heading readout and pointer aligned with the longitudinal axis of the ownship symbol appears on the compass rose boundary circle. Compass rose symbols are as specified in Section 3 Display Symbolology. A green dashed lubber line connects the center of the aircraft symbol and the track pointer.

If a target altitude is set and not captured, an altitude capture predictor arc is displayed on the lubber line at a point corresponding with predicted climb or descent distance (based upon current VSI). A top of descent symbol is shown at the point where a VNAV descent is predicted to commence. The track pointer, lubber line, altitude capture predictor arc, and top of descent symbol are not displayed when groundspeed is less than 30 knots. A pilot-settable heading bug geometrically interacting with the heading pointer appears on the compass rose. A magenta, star-shaped waypoint pointer is displayed on the heading scale at a point corresponding with the active waypoint and turns amber (yellow) in the event of GPS Loss of Navigation caution.

T 2.4. Active Flight Plan Path/Manual Course/Runways

When there is an active flight plan and the GPS/SBAS OBS setting is automatic, the flight plan path, when selected, is shown on the traffic screen in correct relationship to the ownship symbol. The active flight plan path depiction meets all the requirements of GPS/SBAS path definition and matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in automatic OBS mode, skyway boxes, and mini-map). Active flight plan path waypoint symbols for fly-over waypoints are distinct from fly-by waypoints and consist of the waypoint symbol within a circle. When there is a parallel offset, the active flight plan path depicts the parallel offset path, and the original flight plan path is shown with haloed gray dashed lines.

When there is an active waypoint and the GPS/SBAS OBS setting is manual, the manual course through the waypoint is shown as a pointer centered on the waypoint and matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in manual OBS mode, skyway boxes, and mini-map).

The active flight plan path's active leg/manual course and active waypoint are magenta but turn amber (yellow) in the event of a GPS Loss of Navigation caution.

The traffic screen displays airport runways in correct relationship and scale to the ownship symbol.

When the source of traffic is ADS-B, traffic vectors, and aircraft identification data are shown. The traffic vector is a line connecting the traffic's current position with the traffic's predicted position based upon the traffic's current track and groundspeed. The prediction time period, in minutes, is pilot-selectable. Aircraft identification is simple text located near the traffic symbol. The color of the aircraft identification data matches the color of the traffic symbol. Traffic identification data usually reflects aircraft registration number or scheduled airline flight number.

Table T-4: ADS-B and TIS-B Traffic Symbols













	Other Traffic	Proximate Advisory	Traffic Advisory (Flashing)
High-integrity traffic with track information			

Table T-4: ADS-B and TIS-B Traffic Symbols

	Other Traffic	Proximate Advisory	Traffic Advisory (Flashing)
High-integrity traffic without track information			
Degraded position traffic with track information			
Degraded position traffic without track information			

T 2.5. Clock and Options

The following are displayed in the upper right corner of traffic screen.


Figure T-5: Clock and Options
Table T-5: Clock/Options

Feature	Options	Notes
Zulu Time or Local Offset	Zulu or Local	Shown in hh:mm:ss
Traffic Status	Enabled or Disabled	If traffic is disabled, overlying red "X". When selected and enabled, traffic altitude filtering is as follows (see Table T-3.) AUTO = "TRFC AUTO" ABOVE = "TRFC ABV" BELOW = "TRFC BLW" NORMAL = "TRFC NORM" ALL = "TRFC ALL"

T 2.6. Fuel Totalizer/Waypoint Bearing and Distance Functions





Figure T-6: Fuel Totalizer/Waypoint Bearing and Distance Functions

T 3. MFD Page First-Level Option Descriptions

FORMAT  (R4): Activates appropriate page format menu.

T 3.1. MFD Traffic Format (FORMAT) Menu




Figure T-7: MFD Traffic Format (FORMAT) Menu

Upon selecting the MFD format menu, the following option list appears:

- 1) **ROUTE ON/ROUTE OFF:** Toggles showing the active flight plan route.
- 2) **IDENT OFF/IDENT ON:** When TCAS flag is TIS-B, toggles between traffic identifier and squawk information.

- 3) **ALT FILTER:** Sets traffic altitude filter to AUTO, ABOVE, BELOW, NORMAL, or ALL.
- 4) **TCAD TEST:** When TCAS flag is Ryan/Avidyne TCAD, activates TCAD test function.
- 5) **TREND VECTOR:** When TCAS flag is TIS-B, sets traffic trend vector length in minutes. **OFF (R4)** turns off traffic trend vector.

T 4. PFD Declutter (DCLTR) Menu

Upon activating the PFD declutter menu, an option list of declutter items is shown.

Table T-6: PFD Declutter Options and Features		
Declutter Options	Configuration	
	Tapes	Basic
PFD Traffic Thumbnail	✓	✓
Perspective Traffic Depiction	✓	

T 5. MFD Fault Display (FAULTS) Menu

If the traffic option is enabled, loss of communications with the traffic sensor (TRFC).

T 6. Menu Synchronization

Table T-7: Menu Synchronization	
Menu Parameter	Notes
<i>The following menu parameters are only synchronized onside. These parameters are usually sensor selections or PFD options used to keep the appearance of any pilot's PFD consistent in the case of PFD reversion. The onside characteristic means that individual pilots can still adjust their PFD settings to their preference.</i>	
PFD Traffic Thumbnail Show Flag	
<i>The following menu parameters are independent between displays. These are used to support non-PFD display options to give the pilot maximum MFD operating flexibility.</i>	
MFD Map Function Declutter Settings	
MFD Traffic Page Settings	

Remote Bugs Panel (RBP)

RBP 1. Remote BUGs Panel




Figure RBP-1: Remote Bugs Panel

The Remote Bugs Panel (RBP) provides dedicated controls for frequently needed bugs and additional controls for setting IDU parameters such as defined in Table RBP-1.

To access the internal light sensor control for brightness, press the two arrow buttons and simultaneously rotate the multifunction encoder to make adjustments. Press the Option button to exit the brightness control program and return the RBP to normal operation.

The RBP promotes ease of operation while minimizing pilot workload complexity. The HDG and ALT encoders behave as the encoders on the IDU. During initialization, the RBP begins with “GENESYS RBP” on the main and option display screens.

Table RBP-1: Remote Bugs Panel (RBP)

Button/Encoder	Function	Scroll	Press
Heading Encoder	Heading Bug	Increment or decrement	Synchronize to current heading
Altitude Encoder	Altitude Bug	Increment or decrement target altitude	Synchronize to current altitude

Table RBP-1: Remote Bugs Panel (RBP)

Button/Encoder	Function	Scroll	Press
Multifunction Encoder	GPS Course	Increment or decrement	Synchronize to current bearing to active waypoint
Multifunction Encoder	VOR 1 Course	Increment or decrement	Synchronize to current bearing to the station
	VOR 2 Course	Increment or decrement	Synchronize to current bearing to the station
	Airspeed Bug	Increment or decrement	Synchronize to current airspeed
	Vertical Speed Bug	Increment or decrement	Synchronize to current VSI
	Climb Angle Set	Increment or decrement	Set to 3 degrees
	Descent Angle Set	Increment or decrement	Set to 3 degrees
	Decision Height Bug	Increment or decrement	Set to 200' AGL
	Minimum Altitude Bug	Increment or decrement	Set to current altitude
Option “---“ Button	GPS Course	N/A	Change OBS mode (manual or automatic)
	VOR 1 Course	N/A	No function
	VOR 2 Course	N/A	No function
	Airspeed Bug	N/A	Toggle on or off
	Vertical Speed Bug	N/A	Toggle on or off

Table RBP-1: Remote Bugs Panel (RBP)

Button/Encoder	Function	Scroll	Press
	Climb Angle Setting	N/A	No function
	Descent Angle Setting	N/A	No function
	Decision Height Bug	N/A	Toggle on or off
	Minimum Altitude Bug	N/A	Toggle on or off
Arrow Buttons	Function Scroll	N/A	Scroll through "Set" options. Press both arrow buttons simultaneously to place into dimming mode.
VNAV Button	VNAV	N/A	Switch EFIS autopilot pitch steering and commanded VSI between VNAV sub-mode and target altitude sub-mode
LNAV Button	LNAV	N/A	Switch EFIS autopilot roll steering between LNAV sub-mode and heading sub-mode

RBP 2. Menu Synchronization

Table RBP-2: Menu Synchronization	
Menu Parameter	Notes
<i>The following menu parameters are synchronized across all displays at all times. These are bugs and fundamental aircraft values that should never have independence.</i>	
AHRS 1 and 2 mode and slewing values	
VNAV Climb Angle	
VNAV Descent Angle	
Decision Height Setting	Used when “Dual Decision Height Flag” is false.
Heading Bug	
Minimum Altitude Bug Value	
VLOC OBS Settings	
Airspeed Bug Setting	
Target Altitude Bug Setting	
Settable V-Speeds	
VSI Bug Setting	
Crosslink Synchronization Status	
<i>For menu synchronization. The following menu parameters are synchronized across all displays when crosslink is enabled. Otherwise, they are only synchronized onside. These parameters are FMS parameters and allow the pilot and co-pilot FMSs to be operated independently when crosslink is inhibited.</i>	
Active Flight Plan Parameters	
<i>The following menu parameters are only synchronized onside. These parameters are usually sensor selections or PFD options used to keep the appearance of any pilot's PFD consistent in the case of PFD reversion. The onside characteristic means that individual pilots can still adjust their PFD settings to their preference.</i>	
Sensor Selections	
Transition Altitude	
Barometric Setting Units	
Barometric Setting Value	
Barometric Setting Mode	
Decision Height Setting	Used when “Dual Decision Height Flag” is true.

Table RBP-2: Menu Synchronization

Menu Parameter	Notes
Navigation Source	
PFD Analog AGL	
PFD Altitude (meters) Show Flag	
<i>The following menu parameters are independent between displays. These are used to support non-PFD display options to give the pilot maximum MFD operating flexibility.</i>	
MFD Selected Page	This parameter is transmitted to all other IDUs to support weather radar vertical profile mode selection.
MFD Map Page Settings	Map scale is transmitted onside to support weather radar range selection.
MFD Map and HSI Page Pointer Settings	
MFD Map Function Declutter Settings	
MFD Show ETA Flag	
MFD Map NavData Symbol Declutter Settings	

WX-500 Lightning Strikes


S 1. WX-500 Data

When selected, the ND displays Cell Mode lightning strikes in correct relationship to the ownship symbol with the following limits.

Table S-1: Lightning Strikes	
View	Time or Distance Limit
Strikes not shown	Display scale less than 25 NM
Strikes not shown	More than 3 minutes old
Strikes less than 20 seconds old	Shown with lightning symbol
Strikes between 20 seconds and 2 minutes old	Shown with large cross symbol
Strikes between 2 minutes and 3 minutes old	Shown with small cross symbol



ND Lightning Display



Strike Screen Display

Figure S-1: Lightning Symbols

The pilot may select either an arced or centered display format.

Arced: Ownship displaced toward the bottom of the screen. Strike data are displayed in a larger scale while displaying all data within range ahead of the aircraft.

Centered: Ownship symbol is in the center of the ND with navigation data is displayed out to an equal distance in all directions.

The strike screen has “Strikefinder” markings aligned with either magnetic North or True North depending on the status of the True North discrete input. When the AHRS is in DG mode, “DG” appears to the right of the ownship symbol.

S 1.1. Strike Screen Range


The following strike screen ranges (distance from the ownship symbol to the “Strikefinder” markings) may be selected: 12.5 NM, 25 NM, 50 NM, 100 NM, and 200 NM. The range ring is centered upon the ownship symbol to judge range to displayed symbols. The range ring has half the radius of the “Strikefinder” markings displayed indicating the range corresponding to the radius of the range ring such as (1.5 NM, 25 NM, 50 NM, and 10 NM.) The range ring is completely visible in arced display format to ascertain the current strike screen setting.

S 1.2. Air Data and Groundspeed




Figure S-2: Air Data and Groundspeed in Upper Left Corner

S 1.3. Clock and Options



Clock with Local Offset Time



Clock with Zulu Time

Figure S-3: Clock and Options

The following are displayed in the upper right corner of traffic screen:

- 1) **Zulu Time or LCL Time:** As specified in Section 3 Display Symbology.

- 2) **WX-500 Status:** When selected, displays Cell Mode lightning strikes in correct relationship to the ownship symbol with the limits found in Table S-2.

A new strike rate value is calculated every five seconds during normal operation, based upon strikes within the selected display range. The number of fresh strikes (less than 20 seconds old) is used to generate a strike rate representing strikes per minute. Strike rate increases are displayed immediately upon calculation, while decreases in strike rate are damped. Activating the strike clear function resets the strike rate to zero.

Table S-2: WX-500 Status	
Condition	Annunciation
System Normal, Strikes Selected	RATE ### depicts current strike rate Strike symbols shown
System Normal, Strikes deselected with "Show Full Sensor Status Flag" enabled in EFIS Limits.	STRIKES overlaid with green "X" Strike symbols removed
System Failed with "Show Full Sensor Status Flag" enabled in EFIS Limits.	STRIKES overlaid with red "X" Strike symbols removed
System in Test Mode	STRK TST shown Strike symbols removed

S 1.4. Fuel Totalizer/Waypoint Bearing and Distance Functions




Figure S-4: Fuel Totalizer, Waypoint Bearing/Distance in Lower Right Corner

S 1.5. Active Flight Plan Path/Manual Course/Runways

When there is an active flight plan and the GPS/SBAS OBS setting is automatic, the flight plan path is shown on the strike screen in correct relationship to the ownship symbol.

When there is an active waypoint and the GPS/SBAS OBS setting is manual, the manual course through the waypoint is shown as a pointer centered on the waypoint. The pointer matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in manual OBS mode, skyway boxes, and mini-map).




The active flight plan path's active leg/manual course and active waypoint are magenta but turn amber (yellow) in the event of a GPS Loss of Navigation caution.

The strike screen displays airport runways in correct relationship and scale to the ownship symbol.

Figure S-5: Active Flight Plan Path/Manual Course/Runways

S 2. MFD Page First-Level Option Descriptions

FORMAT  (R4): Activates appropriate page format menu.

CLR STRKS (ACTV) (L2): With WX-500 option enabled, activates strike clear option for the Goodrich/L-3 WX-500.

S 2.1. MFD Strike Format (FORMAT) Menu

The following options appear in MFD Strike Format menu:

- 1) **CENTER/ARC**: Toggles between centered and arced Strike page display format.
- 2) **ROUTE ON/ROUTE OFF**: Toggles showing the active flight plan route.
- 3) **STRK MODE/CELL MODE**: Toggles between strike mode strikes and cell mode strikes.
- 4) **STRK TEST**: Activates the WX-500 test function.




Figure S-6: MFD Strike Format (FORMAT) Menu

S 3. MFD Page (PAGE) Menu

PAGE menu allows the pilot to select which MFD page to display:

STRIKES: Shows the Strike page.

S 4. MFD Fault Display (FAULTS) Menu

If the WX-500 option is enabled, loss of communications with the WX-500.

S 5. Menu Synchronization

Table S-3: Menu Synchronization

Menu Parameter	Notes
<i>The following menu parameters are only synchronized onside. These parameters are usually sensor selections or PFD options used to keep the appearance of any pilot's PFD consistent in the case of PFD reversion. The onside characteristic means that individual pilots can still adjust their PFD settings to their preference.</i>	
MFD Strike (WX-500) Page Settings	

Datalink

D 1. Datalink Symbolology




Figure D-1: Datalink Symbolology

When individually selected, the ND displays and indicates status for Temporary Flight Restriction, NEXRAD radar, graphical METAR, and lightning ground strike data. Only the following products received are supported and displayed.

Temporary Flight Restriction Data	Available if included in user subscription
NEXRAD Radar Data	
Lightning Ground Strike Data	
Graphical METAR Data	Available if textual METAR data is included in user subscription. Derived from textual METAR data using EFIS algorithm.

Temporary Flight Restrictions (TFRs) are displayed on the ND in correct relationship to the ownship symbol.

NOTE:

Up to 300 Temporary Flight Restrictions may be displayed.

NEXRAD Radar Data are displayed on the ND in correct relationship as colored regions of precipitation using the following convention.

Table D-2: Datalink NEXRAD Radar Data

Color	Meaning
Gray Shading	Areas beyond the limits of radar coverage or areas with missing data
Magenta	Rain \geq 50dBZ
Red	Rain \geq 45dBZ and $<$ 50dBZ
Light Red	Rain \geq 40dBZ and $<$ 45dBZ
Amber (Yellow)	Rain \geq 30dBZ and $<$ 40dBZ
Green	Rain \geq 20dBZ and $<$ 30dBZ
Cyan	Snow \geq 20dBZ
Light Cyan	Snow \geq 5dBZ and $<$ 20dBZ
Magenta	Mixed precipitation \geq 20dBZ (Area is distinguishable from rain \geq 50dBZ by graphical context)
Light Magenta	Mixed precipitation \geq 5dBZ and $<$ 20dBZ

Echo tops (vertical height of NEXRAD Radar Data returns) are displayed on in correct relationship to the ownship symbol and are automatically decluttered at 400NM, 800NM, and 1,600NM screen ranges. Major echo tops (i.e., group of highest returns on displayed datalink screen) are displayed as a large circle containing a textual readout of speed and a graphical arrow indicating direction of travel. Height of the major echo top, in hundreds of feet, is textually displayed to the right of the major echo top symbol, which is color-coded and presents amplifying text as follows.

Table D-3: Datalink NEXRAD Echo Tops

Severe Weather Condition	Color	Amplifying Text
Possible hail	Light Cyan	"HAIL"
Confirmed hail	Light Cyan	"HAIL+"
Mesocyclonic (Rotation Detected)	Red	"MESO"
Tornadic	Magenta	"TRNDO"

Minor echo tops are displayed as a small white circle with the height of the minor echo top, in hundreds of feet, textually displayed to the left of the minor echo top symbol. Text size for the minor echo top symbol is smaller than for the major echo top symbol.

Graphical METARs are displayed in correct relationship to the ownship symbol as a large color-filled circle as follows.

If the airport has an available datalinked METAR, the circular part of the airport symbol is colored-fill with the following coloring convention.

Table D-4: Graphical METAR Symbols		
Color		Meaning
Sky Blue		Visual Flight Rules (VFR)
Green		Marginal Visual Flight Rules (MVFR)
Amber (Yellow)		Instrument Flight Rules (IFR)
Red		Low Instrument Flight Rules (LIFR)
Magenta		Less than Category 1 Approach Minimums
Black		No Data

Table D-5: Graphical METARS (GMETARS) Screen Range	
Screen Range	Display
50 NM	All GMETARS with airport symbol and ID
100 NM	All GMETARS with airport symbol only
200 NM	All GMETARS
400 NM	VFR GMETARS decluttered
800NM and 1,600 NM	VFR and MVFR GMETARS decluttered

Graphical METARs are also displayed in the menu system “nearest airport,” “nearest weather,” and “info” functions.



Figure D-2: NRST Airport INFO

Graphical weather conditions data are displayed in the menu system “info” function as large colored squares per the following convention.

Table D-6: Datalink Graphical METAR Precipitation	
Color	Meaning
Sky blue	No significant precipitation
Green	Rain
White	Snow
Red	Hazardous weather
Right half gray	Obscuration to visibility
Small black square centered in large square	High wind
Black	No data

The following may be displayed on the datalink screen:

- 1) **Lightning ground strikes:** Amber (yellow), small cross symbols in correct relationship to the ownship symbol.
- 2) **Convective SIGMET:** Magenta line segments showing the area boundary in correct relationship to the ownship symbol. Pilot may view the text of individual convective SIGMETs. When viewing text, associated symbol flashes.
- 3) **Icing AIRMET and SIGMET:** Cyan line segments showing the area boundary in correct relationship to the ownship symbol. Pilot may view the text of individual icing AIRMETs and SIGMETs. When viewing text, associated symbol flashes.
- 4) **IFR AIRMET and SIGMET:** Red line segments showing the area boundary in correct relationship to the ownship symbol. Pilot may view the text of individual IFR AIRMETs and SIGMETs. When viewing text, associated symbol flashes.
- 5) **Turbulence AIRMET and SIGMET:** Amber (yellow) line segments showing the area boundary in correct relationship to the ownship symbol. Pilot may view the text of individual turbulence AIRMETs and SIGMETs. When viewing text, associated symbol flashes.

Winds and temperature aloft data are displayed in correct relationship to the ownship symbol as a grid of black squares with textual readouts of wind speed and temperature (units determined by Temp Units EFIS Limits setting) and a graphical arrow indicating

wind direction. When winds and temperature aloft data are displayed, soft tiles allow the pilot to change the data altitude.




Figure D-3: Datalink Winds and Temperature Aloft


Textual METAR and TAF data are displayed when appropriate in the menu system “info” function. Time of observation and forecast are contained within the text.

D 1.1. Ownship Symbol

When not panning with the AHRS in the DG mode, “DG” appears right of the ownship symbol. The datalink screen is always displayed in a North-up orientation with a boundary circle in place of the compass rose. If not in pan mode, the ownship symbol is aligned with the aircraft heading.



Airplane with V_{MO}/M_{MO}



Airplane FAR 23 with V_{NE}

Figure D-4: Datalink Symboly Ownship Symbol

D 1.2. Datalink Screen Legend

When selected, the datalink screen legend depicts symbology used for Graphical METARs, AIRMETs, SIGMETs, NEXRAD Radar with winter colors, Echo Tops, Temperatures Aloft, and Winds Aloft.




Figure D-5: WSI Datalink Screen Legend




Figure D-6: ADS-B Datalink Screen Legend

D 1.3. Air Data and Groundspeed

Air data and groundspeed are displayed in the upper left corner of the datalink screen as specified in Section 3 Display Symbology.

D 1.4. Clock/Options




Figure D-7: Clock/Options

The following are displayed in the upper right corner of the ND:

- 1) **Zulu Time or LCL Time:** As specified in Section 3 Display Symbology.
- 2) **Datalink Temporary Flight Restriction Data Status:** When Temporary Flight Restriction Data has not been completely downlinked, status annunciated as “TFR” with overlying red “X.”
- 3) **Datalink Weather Status:** Status of NEXRAD radar, graphical METARs, and lightning ground strike data displayed as follows.

Table D-7: Datalink NEXRAD Radar Status

Condition	Status Annunciation		
	*NEXRAD Radar	Graphical METAR	Lightning Ground Strike
Never completely downlinked	No Annunciation		
Downlinked within last 5 minutes and selected for display (*if installed, weather radar deselected from display). “Show Full Sensor Status Flag” enabled.	“NXRD ##” in green. ## is age in minutes. NEXRAD Radar shown.	“GMTR ##” in green. ## is age in minutes. Graphical METARs shown.	“LTNG ##” in green. ## is age in minutes. Lightning Ground Strikes shown.
Downlinked within last 5 minutes and deselected from display (*if installed, weather radar selected for display). “Show Full Sensor Status Flag” enabled.	“NXRD ##” in green. ## is age in minutes. “NXRD ##” overlaid with green “X” NEXRAD Radar not shown.	“GMTR ##” in green. ## is age in minutes. “GMTR ##” overlaid with green “X” Graphical METARs not shown.	“LTNG ##” in green. ## is age in minutes. “LTNG ##” overlaid with green “X” Lightning Ground Strikes not shown.
Not downlinked within last 5 minutes but	“NXRD ##” in amber	“GMTR ##” in amber	“LTNG ##” in amber

Table D-7: Datalink NEXRAD Radar Status

Condition	Status Annunciation		
	*NEXRAD Radar	Graphical METAR	Lightning Ground Strike
downlinked within last 10 minutes and selected for display (*if installed, weather radar deselected from display). "Show Full Sensor Status Flag" enabled.	(yellow). ## is age in minutes. NEXRAD Radar shown.	(yellow). ## is age in minutes. Graphical METARs shown.	(yellow). ## is age in minutes. Lightning Ground Strikes shown.
Not downlinked within last 5 minutes but downlinked within last 10 minutes and deselected from display (*if installed, weather radar selected for display). "Show Full Sensor Status Flag" enabled.	"NXRD ##" in amber (yellow). ## is age in minutes. "NXRD ##" overlaid with green "X" NEXRAD Radar not shown.	"GMTR ##" in amber (yellow). ## is age in minutes. "GMTR ##" overlaid with green "X" Graphical METARs not shown.	"LTNG ##" in amber (yellow). ## is age in minutes. "LTNG ##" overlaid with green "X" Lightning Ground Strikes not shown.
Not downlinked within last 10 minutes but downlinked within last 75 minutes and selected for display (*if installed, weather radar deselected from display).	"NXRD ##" in red. ## is age in minutes. NEXRAD Radar shown.	"GMTR ##" in red. ## is age in minutes. Graphical METARs shown.	"LTNG ##" in red. ## is age in minutes. Lightning Ground Strikes shown.
Not downlinked within last 10 minutes but downlinked within last 75 minutes and deselected from display (*if installed,	"NXRD ##" in red. ## is age in minutes. "NXRD ##" overlaid	"GMTR ##" in red. ## is age in minutes. "GMTR ##" overlaid	"LTNG ##" in red. ## is age in minutes. "LTNG ##" overlaid

Table D-7: Datalink NEXRAD Radar Status

Condition	Status Annunciation		
	*NEXRAD Radar	Graphical METAR	Lightning Ground Strike
weather radar selected for display). "Show Full Sensor Status Flag" enabled.	with green "X" NEXRAD Radar not shown.	with green "X" Graphical METARs not shown.	with green "X" Lightning Ground Strikes not shown.
Not downlinked within last 75 minutes (timed-out). "Show Full Sensor Status Flag" enabled.	"NXRD XX" in red "NXRD XX" overlaid with red "X" NEXRAD Radar not shown.	"GMTR XX" in red "GMTR XX" overlaid with red "X" Graphical METARs not shown.	"LTNG XX" in red "LTNG XX" overlaid with red "X" Lightning Ground Strikes not shown.

D 1.5. Datalink Screen Orientation




Figure D-8: Datalink Screen Orientation

The datalink screen is always displayed in North-up orientation and has a boundary circle instead of a compass rose. “DATALINK” appears above the boundary circle, and, if not in pan mode, the ownship symbol aligns with aircraft heading. When selected, the following datalink screen ranges are available.

Table D-8: Datalink Screen Range Values	
Distance from Ownship to Boundary Circle	Radius Range Values
50 NM	25 NM
100 NM	50 NM
200 NM	100 NM
400 NM	200 NM
800 NM	400 NM
1,600 NM	800 NM




Figure D-9: Datalink Screen Range

D 1.6. Boundary Circle Symbols

A white triangular heading pointer aligned with the longitudinal axis of the ownship symbol appears on the boundary circle with a green diamond-shaped track pointer aligned with the aircraft’s track across the earth. A green dashed lubber line connects the center of the aircraft symbol and the track pointer.



Figure D-10: Boundary Circle Symbol

If a target or VNAV altitude is set and not captured, an altitude capture predictor arc is displayed on the lubber line at a point corresponding with predicted climb or descent distance (based upon current VSI). A top of descent symbol is shown except when groundspeed is less than 30 knots. A pilot-settable heading bug geometrically interacting with the heading pointer appears on the boundary circle. A magenta, star-shaped waypoint pointer is displayed on the boundary circle at a point corresponding with the active waypoint. The waypoint pointer turns amber (yellow) in the event of GPS Loss of Navigation caution. Boundary circle symbols are not drawn if the datalink screen is in pan mode.

D 1.7. Active Flight Plan Path/Manual Course/Runways

When there is an active flight plan and the GPS/SBAS OBS setting is automatic, the flight plan path, if selected, shows on the datalink screen in correct relationship to the ownship symbol. The active flight plan path depiction meets all the requirements of GPS/SBAS path definition and matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in automatic OBS mode, skyway boxes, and mini-map). Active flight plan path waypoint symbols for fly-over waypoints are distinct from fly-by waypoints and consist of the waypoint symbol within a circle. When there is a parallel offset, the active flight plan path depicts the parallel offset path and the original flight plan path with haloed gray dashed lines.

When there is an active waypoint and the GPS/SBAS OBS setting is manual, the manual course through the waypoint is shown as a pointer centered on the waypoint. The pointer matches the lateral navigation guidance given on the PFD (GPS/SBAS CDI in manual OBS mode, skyway boxes, and mini-map).

The active flight plan path's active leg/manual course and active waypoint are magenta and turn amber (yellow) in the event of a GPS Loss of Navigation caution.

The datalink screen displays airport runways in correct relationship and scale to the ownship symbol.

D 1.8. Borders

National and United States state borders are drawn in white in correct relationship to the ownship symbol.

D 1.9. Pan Mode


Use the pan mode to change the location of the center of the screen away from current location and view weather conditions along the route of flight, at intended destination, or at alternate destination (see Table D-9). When pan mode is active, a line from the map center to the aircraft's current position is drawn. Bearing and distance to the map center are always displayed above the ownship symbol when the aircraft is more than 0.5 NM away. If referenced to magnetic North when panning, the nearest displayed graphical METAR symbol within the inner range ring is highlighted with a flashing circle. When such a point is highlighted, dedicated buttons are present to view and hide waypoint information (including datalink weather information) associated with that point

D 2. Top-Level Menu Automatic Pop-Up Function Descriptions


Table D-9: Top-Level Auto Pop-Up Function Descriptions in Order of Preference

FPL (L1)	With Pan Mode, PN OFF appears. Press to disable Pan Mode. RESET has precedence over PN OFF .
ACTV (L2)	<ol style="list-style-type: none"> 1) With Winds and Temperatures Aloft enabled, UP appears. Press to increase Winds and Temperatures Aloft grid level. UP does not appear when the highest grid level is displayed. 2) When showing ND Page with: (a) pan mode enabled; (b) information for the nearest highlighted waypoint shown; and (c) airport weather information present in the information block; WX allows display of textual METAR and TAF data for the airport.
INFO (L3)	With Pan Mode, NORTH appears. Press to shift the center of Datalink Page in the specified direction.
OBS (L4)	With Pan Mode, SOUTH appears. Press to shift the center of Datalink Page in the specified direction.
BARO (R2)	<ol style="list-style-type: none"> 1) With Winds and Temperatures Aloft enabled, DOWN appears. Press to decrease Winds and Temperatures Aloft grid level. DOWN does not appear when the lowest grid level is displayed.

Table D-9: Top-Level Auto Pop-Up Function Descriptions in Order of Preference

	2) With Pan Mode enabled, INFO or HIDE appears. Press to toggle display of information for the nearest highlighted waypoint. Refer to INFO Menu requirements for the amount and type of information presented.
NRST (R3)	With Pan Mode, EAST appears. Press to shift the center of the Datalink Page in the specified direction.
 (R4)	With Pan Mode, WEST appears. Press to shift the center of the Datalink Page in the specified direction.

D 3. MFD Page First-Level Option Descriptions

- 1) **WX LGND (ACTV) (L2)**: Activates datalink weather legend.
- 2) **FORMAT**  **(R4)**: Activates appropriate page format menu.

D 4. MFD Datalink Format (FORMAT) Menu

Upon selecting the MFD format menu, a list appears with the following options:

- 1) **ROUTE ON/ROUTE OFF**: Toggles showing the active flight plan route on the Datalink page.
- 2) **PAN ON/PAN OFF**: Toggles Datalink page Pan Mode.
- 3) **AMET-SMET**: Only available when an AIRMET or SIGMET is within the Datalink page viewable area. Allows the pilot to view text for the displayed AIRMETS and SIGMETs. While viewing text, border associated with the AIRMET or SIGMET flashes.
- 4) **DCLTR**: Only available when datalink weather products are available for display. Allows the pilot to select individual datalink weather products available for display.




Figure D-11: MFD Datalink Format (FORMAT) Menu

D 4.1. MFD Datalink Format (Step-By-Step)



- 1) Push **1** and scroll to **DATALINK**. Push to enter.



- 2) Example shows MFD with DATALINK.



3) Press **MENU (R1)** then **FORMAT.. (R4)** to format Datalink page.



4) Scroll **1** to **ROUTE ON, PAN ON, AMET-SMET.., or DCLTR..** Push to enter.

D 5. Active Flight Plan (ACTV) Menu Options

ACTV (L2): With optional datalink, **WX LGND** and **EXPND WX** tiles are available to show a weather symbol legend and highlighted result METAR and TAF text respectively.

Identifier Entry Box: Highlighted result information includes datalinked weather information when available.

D 6. MFD Fault Display Menu

If WSI datalink is enabled, the datalink item indicates either loss of communications with the datalink receiver (DLNK X), loss of satellite lock (DLNK NO LOCK), or the current bit error rate or the datalink (DLNK BER ###). WSI datalink is mutually exclusive with ADS-B datalink.

If ADS-B datalink is enabled, an indication of ADS-B position validity (ADSB POSN), an indication of whether maintenance of the ADS-B receiver is required (ADSB MAINT) and an indication of whether the Conflict Situational Awareness algorithm is working (ADSB CSA). ADS-B datalink is mutually exclusive with WSI datalink.

D 7. MFD Page (PAGE) Menu

DATALINK: Shows the Datalink page.

D 8. Menu Synchronization

Table D-10: Menu Synchronization

Menu Parameter	Notes
<i>The following menu parameters are synchronized across all displays at all times. These are bugs and fundamental aircraft values that should never have independence.</i>	

Table D-10: Menu Synchronization

Menu Parameter	Notes
Heading Bug	
True North Mode	
UTC Offset	
<p><i>The following menu parameters are synchronized across all displays when crosslink is enabled. Otherwise, they are only synchronized onside. These parameters are FMS parameters and allow the pilot and co-pilot FMSs to be operated independently when crosslink is inhibited.</i></p>	
Active Flight Plan Parameters	
Runway Display Parameters	
<p><i>The following menu parameters are only synchronized onside. These parameters are usually sensor selections or PFD options used to keep the appearance of any pilot's PFD consistent in the case of PFD reversion. The onside characteristic means that individual pilots can still adjust their PFD settings to their preference.</i></p>	
Barometric Setting Units	
Barometric Setting Value	
Barometric Setting Mode	
PFD Zoom Mode	
<p><i>The following menu parameters are independent between displays. These are used to support non-PFD display options to give the pilot maximum MFD operating flexibility.</i></p>	
MFD Selected Page	This parameter is transmitted to all other IDUs to support weather radar vertical profile mode selection.
MFD Datalink Page Settings	
MFD Map Page Settings	Map scale is transmitted onside to support weather radar range selection.

Weather Radar

WX 1. Weather Radar



Figure WX-1: Weather Radar Image on ND

Weather Radar automatically declutters when weather radar returns are selected for display on the ND map screen in correct relationship to the ownship symbol unless inhibited during active FLTA alerts. When Weather Radar is selected, datalink NEXRAD is automatically deselected. Table WX-1 defines all inhibited factors with display.

Table WX-1: Weather Radar Inhibited Conditions
During Active FLTA alerts
ND Moving Map Panning Mode
When North Up orientation is selected
When RDR-2100 is in vertical profile mode
When screen range is too small to effectively show the weather returns (defined as when the length of the weather radar scan line is longer than 512 pixels given current weather radar scale setting, screen range, and screen mode)

WX 1.1. Weather Radar Screen

In horizontal depiction, the weather screen uses an arced format with the ownship symbol centered in the bottom of the display with the weather area depicted as an arc ahead of the ownship symbol.




Figure WX-2: Radar Image in Horizontal Depiction

In profile depiction, the weather screen uses an arced format with the ownship symbol centered on the left side of the display and the weather area depicted as an arc to the right of the ownship symbol.




Figure WX-3: Radar Image in Profile Depiction

To select profile depiction, use the Weather Radar Control Panel connected to the IDU. The IDU ensures at least one weather radar-enabled screen is showing the weather radar page prior to entering into profile depiction and disables profile depiction if the pilot sets the screens for no weather radar page on any weather radar-enabled screen. The purpose is to maximize the availability of weather radar information on the ND screen. The ND screen only

shows a horizontal depiction and disables profile depiction if the weather radar mode is set to off or standby via Radar Control Panel.

WX 1.2. Weather Screen Range

Weather screen range is pilot-selectable with either ① (RDR-2000 and RDR-2100 weather radar types) or a control panel directly attached to the weather radar receiver-transmitter. Weather screen range is displayed as a series of equidistant dashed arcs centered upon the ownship symbol to help judge range to the displayed weather radar returns. All distances represent the distance from the ownship symbol to the outer dashed arc: 5NM, 10NM, 20NM, 40NM, 80NM, 160NM, 240NM, and 320NM.

For most screen ranges, there are four equidistant dashed arcs. When in 2.5NM range, there are five equidistant dashed arcs. Each arc is labeled with distance in nautical miles at its right-most point (horizontal depiction) or bottom-most point (profile depiction). In profile depiction, there are also three horizontal altitude lines drawn relative to the aircraft's altitude to help judge the vertical distance to the displayed weather radar returns. The center line is level with the ownship symbol to represent the aircraft's altitude. The other two lines are equally spaced above and below the center line to represent altitude differences above and below the aircraft. The number of feet above and below the aircraft varies with the selected range to compensate for the radar scan width at the different ranges.

WX 1.3. Track Line




Figure WX-4: Radar Track Line

When weather radar type is RDR-2000 or RDR-2100 and in horizontal depiction, a dashed track line emanates from the ownship symbol to the outer dashed arc. The value of the track line in whole degrees left or right of aircraft heading is displayed adjacent to the outer end of the track line.

WX 1.4. Active Flight Plan Path/Manual Course/Runways




Figure WX-5: Radar Active Flight Plan

The active flight plan path (when selected), waypoints, and manual course appear when the weather radar screen is in horizontal depiction. The weather radar screen displays airport runways, when the weather radar screen is in horizontal depiction.

WX 1.5. Weather Radar Return Data

Weather radar return data are displayed in correct relationship to the ownship symbol as colored regions according to the value of the ARINC 453 3-bit range bins (Table WX-2).

Table WX-2: Weather Radar Return Data

ARINC 453 3-Bit Range Bin	Color	Meaning
000b	Black	No returns
001b	Green	Low-Level Weather or Low-Level Ground Returns

Table WX-2: Weather Radar Return Data		
ARINC 453 3-Bit Range Bin	Color	Meaning
010b	Amber (Yellow)	Mid-Level Weather or Mid-Level Ground Returns
011b	Red	Third-Level Weather Returns. Color is black when in MAP mode.
100b	Magenta	Fourth-Level Weather or Third-Level Ground Returns. With RDR-2000 or RDR-2100 weather radar type, color alternates between magenta and black at 1Hz when internal submode is WXA.
101b	Cyan	Automatic Range Limit Returns. Indicates areas of unreliable returns due to radar power absorption.
110b	Light Gray	Moderate Turbulence Returns
111b	White	Severe Turbulence Returns




Figure WX-6: Radar Return Data

The following weather radar-specific warnings appear in a conspicuous area adjacent to weather radar return data, so they do not conflict with weather radar return data. Only one warning appears at a time, with the following order of precedence:

- 1) **WX ALERT:** Weather alert condition is active.
- 2) **TURB ALERT:** Turbulence alert condition is active.
- 3) **STAB LIMIT:** Aircraft attitude has moved to a point where the weather radar antenna can no longer be effectively stabilized.
- 4) **ANT FAULT:** Weather radar antenna is temporarily dislodged by turbulence.

WX 1.6. Air Data and Groundspeed

Air data and groundspeed are displayed in upper left corner of the weather radar screen as specified in Section 3 Display Symbology.

WX 1.7. Clock/Options

The following are displayed in the upper right corner of the ND:



Figure WX-7: Radar Clock/Options

- 1) **Zulu Time or LCL Time:** As in Section 3 Display Symbology;
- 2) **Weather Radar Mode Annunciation:** As in Table WX-3 and Table WX-4.

Table WX-3: RDR 2100 Applicability	
Mode	Annunciation
Off	WXR:OFF
Standby	WXR:STBY
Weather only	WXR:WX
Weather alert	WXR:WXA
Ground map	WXR:GMAP
Contour	WXR:CONT
Test	WXR:TEST
Not defined	WXR:----

Table WX-4: RDR 2100 Mode Annunciation

Annunciation	Conditions
Overlaid with Red X	<p>Weather radar mode is off or not defined.</p> <p>Cooling fault condition exists.</p> <p>Attitude or range fault condition exists.</p> <p>T/R fault condition exists.</p>
STAB OFF (Stabilization)	<p>Weather radar mode annunciation is not overlaid with a red “X”;</p> <p>Weather radar mode is not standby or forced standby; and</p> <p>Weather radar indicates stabilization is off.</p>
TGT ALERT (Target Alert)	<p>Weather radar mode annunciation is not overlaid with a red “X”;</p> <p>Weather radar mode is not standby or forced standby;</p> <p>Weather radar is in horizontal depiction.</p>
“TLT:UXX.X” or “TLT:AUTO” (TILT)	<p>U = Up or Down (either U or D, but not both, may appear – use “U” for 0°);</p> <p>XX.X represents absolute value of the tilt angle in degrees truncated to the nearest tenth;</p> <p>“TLT:AUTO” is used where weather radar reports a value of -16°, representing automatic tilt.</p> <p>Weather radar tilt annunciation only appears when all following conditions are true:</p> <ol style="list-style-type: none"> 1) Mode annunciation is not overlaid with a red “X”; 2) Mode is not standby or forced standby; and 3) Radar is not in vertical profile submode.
TRK:LXX (TRACK)	<p>L = Left or Right (either L or R, but not both, may appear – use “R” for 0°); and</p>

Table WX-4: RDR 2100 Mode Annunciation

Annunciation	Conditions
	<p>XX represents absolute value of the track angle in degrees.</p> <p>Weather radar track annunciation only appears when all following conditions are true:</p> <ol style="list-style-type: none"> 1) Mode annunciation is not overlaid with a red "X"; 2) Mode is not standby or forced standby; and 3) Radar is in vertical profile submode (profile depiction).
<p>"GN:SXXDB," "GN:CAL," or "GN:MAX" (GAIN)</p>	<p>S = Sign (either "+" or "-", but not both, may appear – use "+" for 0°); and</p> <p>XXDB represents the manual gain setting in decibels.</p> <p>"GN:CAL" represents the calibrated condition</p> <p>"GN:MAX" represents maximum manual gain</p> <p>Weather radar manual gain annunciation only appears when all following weather radar mode conditions are true:</p> <ol style="list-style-type: none"> 1) Mode annunciation is not overlaid with a red "X"; 2) Mode is not standby or forced standby; and 3) Mode is ground map.

WX 1.8. Fuel Totalizer/Waypoint Bearing and Distance Functions

Fuel totalizer, waypoint bearing, and waypoint distance are displayed in the lower right corner of the weather radar screen as specified in Section 3 Display Symbology.

WX 2.MFD WX RDR Format (FORMAT) Menu




Figure WX-8: MFD WX RDR Format Menu

Upon selecting the MFD format menu in the WX RDR page when weather radar type is RDR-2000 or RDR-2100 without an external RCP installed, a list appears with the following options:

- 1) **MODE:** Sets weather radar mode to OFF, STBY, TEST, ON: WX, ON: WXA, ON: MAP, or VERT PROF. Modes are mutually exclusive, therefore selecting one turns off other modes with exception of vertical profile option, which only appears when the selected weather radar mode is not OFF or STBY.
- 2) **CTRL:** Activates a list to control live parameters as follows:
 - a) **GAIN:** Changes gain in increments of 1dB.
 - b) **TILT:** Changes tilt in units of 0.25 degrees if tilt mode is manual for both weather radar type RDR-2000 and RDR-2100. **TILT:AUTO** is set when tilt is automatic (only RDR-2100 only). When weather radar type is RDR-2100, toggles **AUTO/MAN** tilt mode.

- c) **TRACK**: Changes track in increments of 1 degree.
- d) **ROLL TRIM**: Changes roll trim in increments of 4 degrees.
- 3) **OPITIONS**: Select or deselect available options to **ANTI-CLTR**, **ARL** (RDR-2100 only), **SCTR SCN** (RDR-2100 only), or **STAB**.
- 4) **ROUTE ON/ROUTE OFF**: Toggles showing active flight plan route on the WX RDR page.

WX 3. MFD Fault Display (FAULTS) Menu

Upon selecting the MFD faults menu, the status of the following system parameters are displayed:

- 1) If WX-500 option is enabled, loss of communications with the WX-500 (WX-500).
- 2) If weather radar is enabled, indication is weather radar power/communication status (WXR PWR X or WXR PWR OK). Weather radar power/communication status failed (WXR PWR X) reflects any one of the following conditions is true:
 - a) Loss of weather radar communication.
 - b) Weather radar mode is OFF.
- 3) If weather radar is enabled, indication of weather radar fault status (WXR FAULT –, WXR FAULT X, or WXR FAULT OK). When weather radar power/communication status is failed, status indicates determination of weather radar faults is not possible (WXR FAULT –). Weather radar fault status failed (WXR FAULT X) reflects any of the following conditions is true:
 - a) A Cooling Fault Condition exists.
 - b) For weather radar types ARINC 708-6 or Collins 800/840, a Display or Control Bus Fault Condition exists.
 - c) For weather radar types ARINC 708-6, Collins 800/840 or Honeywell PRIMUS, a Calibration or Air Data Fault Condition exists.
 - d) An Attitude or Range Fault Condition exists.
 - e) A Control Fault Condition exists.
 - f) A T/R Fault Condition exists.

- 4) If weather radar is enabled and the weather radar type is RDR-2000 or RDR-2100, an indication of radar control panel status (WXR RCP X or WXR RCP OK). Radar control panel status failed (WXR RCP X) indicates either loss of communication or a failure status using the same test as invalid data SSM for output labels 270, 271, 273, or 275.

WX 4. Menu Synchronization

Table WX-5: Menu Synchronization	
Menu Parameter	Notes
<i>The following menu parameters are only synchronized onside. These parameters are usually sensor selections or PFD options used to keep the appearance of any pilot's PFD consistent in the case of PFD reversion. The onside characteristic means that individual pilots can still adjust their PFD settings to their preference.</i>	
Weather Radar Scale	Onside because range is controlled by weather radar.
<i>The following menu parameters are independent between displays. These are used to support non-PFD display options to give the pilot maximum MFD operating flexibility.</i>	
MFD Selected Page	This parameter transmitted to all other IDUs to support weather radar vertical profile mode selection.
MFD Map Page Settings	Map scale is transmitted onside to support weather radar range selection.
MFD Map Function Declutter Settings	

Video

V 1. Video Input Screen

The video input screen is 640 by 480 pixels and accepts video input signals in RS-170 composite format. The system is configurable to NTSC, PAL (including the PAL-m and PAL-nc variants), or SECAM versions of RS-170 separately for each video input. In addition, an auto-detection mode, which programs the video input chip to process most standard RS-170 formats, is configurable for each video input.

When no video signal is detected, the video input screen is black and **NO VIDEO IMAGE AVAILABLE** is displayed in white on the center of the screen. To aid in diagnosing problems with undetected video signals, the following annunciations are also displayed:

- 1) **NO INTERLACED SIGNAL:** No interlaced signal detected.
- 2) **NO HORIZ OR VERT SYNC:** No horizontal or vertical synchronization detected.
- 3) **NO COLOR SIGNAL:** No video chroma signal detected.
- 4) **LOAD ERROR DETECTED:** Video chip reports a load error.
- 5) **TRIGGER ERROR DETECTED:** Video chip reports a trigger error.
- 6) **PROGRAMMING ERROR DETECTED:** Video chip reports a programming error.


V 1.1. ZOOM Level

Scroll **1** CW to increase or CCW to decrease zoom levels from 1 (no pixel replication) to 10 in increments of 1.



Figure V-1: Encoder Functions for MFD Video Page

V 1.2. Pan Mode



When the zoom level is greater than 1, the Video Input screen has a pan mode to select the portion of the video image displayed. When pan mode is active, controls are present to move the portion displayed up, down, left, and right (Table V-1).

Figure V-2: Video Pan View

A mini-map of the displayed image's position in the full video image is displayed for 10 seconds after:

- 1) Entering Pan Mode;
- 2) Changing the zoom level to a value greater than 1;
- 3) Panning the zoomed image.

Exiting Pan Mode removes pan mode controls and mini-map, if any.

V 2. Top-Level Menu Automatic Pop-Up Functions

Table V-1: Top-Level Auto Pop-Up Function Descriptions

ACTV (L2)	With pan mode, UP appears. Press to shift the section of the video image displayed in the specified direction.
INFO (L3)	With pan mode, DOWN appears. Press to shift the section of the video image displayed in the specified direction.
BARO (R2)	With pan mode, LEFT appears. Press to shift the section of the video image displayed in the specified direction.
NRST (R3)	With pan mode, RIGHT appears. Press to shift the section of the video image displayed in the specified direction.

V 3. Video Input Status Display

When selected, the following are optionally displayed in the upper right corner of the Video Input display:




Figure V-3: Video Status

- 1) **Label:** Identifies video input source and is configurable to one of a set of predefined labels. If no label is configured, the label is **VIDEO-n** where **n** is the video input source number.
- 2) **ZOOM:** Amount of pixel expansion is displayed as **ZOOM nnX** where **nn** is the zoom level.
- 3) **Brightness:** Displayed as **BRT nnn%** where **nnn** is the brightness setting as a percentage of the maximum value.
- 4) **Contrast:** Displayed as **CTRST nnn%** where **nnn** is the contrast setting as a percentage of the maximum value.
- 5) **Saturation:** Chroma saturation is displayed as **SAT nnn%** where **nnn** is the saturation setting as a percentage of the maximum value.
- 6) **Hue:** Chroma hue is displayed as **HUE nnn%** where **nnn** is the hue setting as a percentage of the maximum value.

V 4. MFD Page First-Level Option Descriptions



FORMAT (R4): Activates appropriate page format menu.

V 4.1. MFD Video Input Format (FORMAT) Menu

Upon selecting the MFD format menu, the following options appear.




Figure V-4: MFD Video Input Format (FORMAT) Menu

Table V-2: Video Input Controls

Controls Settings	Definition	Notes
BRT	Adjust brightness setting	DFLT (R4) resets to nominal default (50%) value.
CTRST	Adjust contrast setting	DFLT (R4) resets to nominal default (50%) value.
SAT	Adjust chroma saturation (color intensity) setting	DFLT (R4) resets to nominal default (50%) value.
HUE	Adjust chroma hue (red-green balance) settings	DFLT (R4) resets to nominal default value (50%) value.
SOURCE	Select optional video source	Displays selected video input, only if more than one video input is enabled.
DCLTR	Activate option list to select video input status settings	Video input status settings as in V 3.

V 5. Menu Synchronization

Table V-3: Menu Synchronization

Menu Parameter	Notes
<i>The following menu parameters are independent between displays. These are used to support non-PFD display options to give the pilot maximum MFD operating flexibility.</i>	
MFD Map Function Declutter Settings	
MFD Video Page Settings	Video hardware settings: <ul style="list-style-type: none"> • Selected Input • Brightness • Contrast • Saturation • Hue

Round Dials

RD 1. Display Symbology

This following details display symbology used on the PFD and MFD IDU-450 in Normal and Essential modes for round dials. Not all combinations of possible views are represented.

RD 1.1. IDU-450 PFD Display Basic Mode



Figure RD-1: PFD in Basic Mode

When round dial instruments are enabled, the following are no longer present when Basic Mode is displayed:

- | | |
|----------------------------|--------------------------|
| 1) Atmospheric perspective | 7) Highway in the Sky |
| 2) Airspeed trend | 8) Mini MAP |
| 3) Terrain rendering | 9) Mini TRFC |
| 4) Obstruction rendering | 10) Turn IND |
| 5) Flight Path Marker | 11) Bank Scale Declutter |
| 6) Airport runways | |

RD 1.2. Selecting BARO


See Section 3 Display Symbology for further information.



Figure RD-2: Selecting BARO



QNH



QFE

Figure RD-3: Altimeter Setting

RD 1.3. Selected Altitude Sub-Mode (Target Altitude)

See Section 3 Display Symbology for further information.



Altitude Hold Mode



Climb or Descent Mode

Figure RD-4: Target Altitude Bug (Vertically Integrated)



Figure RD-5: Target Altitude Bug (Not Vertically Integrated)

RD 1.4. VNAV Sub-Mode

See Section 3 Display Symbology for further information.




Not Vertically Integrated



Vertically Integrated

Figure RD-6: VNAV Sub-Mode



Round Dial users must view the Active Waypoint Identifier.

Figure RD-7: VNAV Sub-Mode (Not Vertically Integrated)

RD 1.5. Altitude Display



The PFD has an altitude readout, dial, and pointer on which digitally displays barometric altitude to the nearest ten feet as adjusted by an altimeter setting. The altitude dial shows a 1000-foot range with labels and graduations every 100 feet. CW rotation of the pointer and corresponds to increasing altitude. Target altitude in this example is 9000'.



When the altitude is negative, display of pointer, labels, bugs, and graduations are omitted.



When the ADC sensor fails, a black circle with red "X" is shown instead of the altitude readout, dial, and pointer.

Figure RD-8: Altitude Display

When in selected altitude sub-mode, the altitude dial has a pilot-settable triangular target altitude bug, which is removed when more than 500' away from current altitude. The target altitude bug (with a resolution of 100 feet) setting is limited to -1000' at the low end and 50,000' at the high end. Use the target altitude bug as either a visual reference or, when vertically integrated with an autopilot, either fully-integrated (Intelliflight 1950) or partially integrated through use of the vertical mode discrete input as a control parameter for climbs or descents.

When vertically integrated with an autopilot, the target altitude bug color and behavior are identical to the altitude display as defined in Section 3 Display Symbology. When not vertically integrated with an autopilot, the target altitude bug setting annunciation is white, and the target altitude bug is filled-white at all times.

When in VNAV sub-mode, the altitude dial shows the active waypoint VNAV altitude (if it exists) with a triangular VNAV altitude bug with a resolution of 100 feet. The VNAV altitude bug is removed when more than 500' away from current altitude. The VNAV altitude bug can be used either as a visual reference or, when vertically integrated with an autopilot, either fully-integrated (Intelliflight 1950) or partially integrated through use of the vertical mode discrete input, as a control parameter for climbs or descents.

When vertically integrated with an autopilot, the VNAV altitude bug coloring and behavior is identical to the altitude display in Section 3 Display Symbology. When not vertically integrated with an autopilot, the VNAV altitude bug setting annunciation is white, and the VNAV altitude bug is filled-magenta at all times. The minimum altitude bug settings annunciation and behavior is identical to the altitude display as defined in Section 3 Display Symbology.



Metric altitude is pilot-selectable above the altitude ring. The resolution is one meter like the target altitude bug setting. The altimeter setting displays exactly as described in Section 3 Display Symbology.

Figure RD-9: Metric Altitude

RD 1.6. PFD Symbology

See Section 3 Display Symbology for further information.



Figure RD-10: PFD Symbology

RD 1.7. Minimum Altitude



See Section 3 Display Symbology for further information. For Round Dials PFD, minimum altitude is set as stated above but turns yellow and flashes when the aircraft descends below the minimum altitude setting.

Figure RD-11: Minimum Altitude

RD 1.8. Vertical Speed Indicator



A vertical speed indicator (VSI) with a scale of the VSI limits as described in Table RD-1. Readout digitally displays vertical speed rounded to the nearest 100 feet per minute. CW rotation of the pointer corresponds to increasing vertical speed. When TCAS-II is enabled, background of the VSI dial functions as an RA display with green and red regions to provide maneuver guidance. The VSI has a pilot-settable triangular vertical speed bug, which is limited to $\pm 3,000$ feet per minute. The vertical speed bug setting is as described in Section 3 Display Symbology.

Figure RD-12: Vertical Speed Indicator

Table RD-1: Scale Graduations and Display

Type Traffic Installed	Scale Limit	Scale Graduations and Display
With TCAS-II	$\pm 6,000$ FPM	$\pm 500, \pm 1,000, \pm 2,000, \pm 4,000,$ and $\pm 6,000$ FPM Background of the VSI functions as an RA display with green and red regions to provide RA maneuver guidance.
Without TCAS-II	$\pm 3,000$ FPM	$\pm 500, \pm 1,000, \pm 2,000,$ and $\pm 3,000$ FPM

RD 1.9. Normal AGL Indication

See Section 3 Display Symbolology for further information.




Figure RD-13: Normal AGL Indication

RD 1.10. Decision Height

See Section 3 Display Symbolology for further information.



Figure RD-14: Decision Height

RD 1.11. Airspeed Display



The PFD has an airspeed readout, dial, and pointer on the left side of the display. The airspeed readout digitally displays indicated airspeed in knots, miles per hour, or kilometers per hour depending upon the setting of the “Speed Units” system limits. The airspeed dial is scaled to show the entire operating range of the aircraft with CW pointer movement corresponding to increasing speed.

Figure RD-15: Airspeed Display



When the ADC sensor fails, a black circle with red “X” is shown instead of the airspeed readout, dial and pointer.

Figure RD-16: ADC Sensor Failed

Airspeed markings airspeed bug setting are as described in Section 3 Display Symbology.


The airspeed dial has a pilot-settable triangular airspeed bug, which is limited to the higher of $1.2 \times V_s$ or 60KIAS at the low end and red-line airspeed (V_{NE} , V_{MO} , or M_{MO}) at the high end.

If the Mach indicator flag is enabled, Mach number is displayed above the airspeed readout with a resolution of .01 Mach.

In airplanes, V_1 , V_R , V_2 , V_{ENR} , V_{REF} , and V_{APP} also are shown on the airspeed dial when set. The V_1 , V_R , and V_2 symbols automatically declutter when the respective value is exceeded by 40 knots or when above 2000 feet AGL.

RD 1.12. Heading Display

In round dial mode, heading display appears at the bottom to emulate a “Basic-T” and automatically declutters when a compass rose is detected in the bottom area.



Heading detected
in bottom area

No heading detected
in bottom area

Figure RD-17: Heading in Bottom Area



When AHRS is in DG mode, heading indicator appears as shown.

Figure RD-18: Heading Indicator when AHRS in DG Mode

RD 1.13. G-Force Indicator

The G-Force indicator display has a readout, dial, pointer and scale sufficient to accommodate any G-Force with a minimum scale of +6G/-4G. The dial is centered on 1G with labeled indices at even values (i.e., -2G, 0G, +2G, etc.).



The readout digitally displays G-Force to the nearest tenth. CCW (upward) rotation of the pointer corresponds to increasing G-Force. The G-Force telltale indication and behavior are as described in Section 3 Display Symbolology.

Figure RD-19: G-Force Indicator

RD 1.14. Unusual Attitude Mode


See Section 3 Display Symbolology for further information.



Figure RD-20: Unusual Attitude Mode

RD 1.15. Turn Rate Indicator


A turn rate indicator is displayed below the airspeed display and to the right of the G-Force indicator. The turn rate indicator is a standard “turn needle” display with marks representing a standard rate turn. The full scale for the turn needle is beyond the standard rate turn mark for the pilot to fly a standard rate turn and incorporates a standard “balance ball” display.

Figure RD-21: Turn Rate Indicator
RD 1.16. Bank Angle Scale


See Section 3 Display Symbolology for further information. In Round Dial configuration, bank scale cannot be decluttered.

Figure RD-22: Bank Angle
RD 1.17. Marker Beacon Symbolology

See Section 3 Display Symbolology for further information.



**Basic Mode
and Round
Dials**


Figure RD-23: Marker Beacons
RD 1.18. Course Deviation Indicator

See Section 3 Display Symbolology for further information.


Figure RD-24: Course Deviation Indicator

RD 1.19. Flight Director Symbology

See Section 3 Display Symbology for further information.



FDI Single Cue

FD2 Dual Cue

Figure RD-25: Flight Director

RD 1.20. Landing Gear Indication

See Section 3 Display Symbology for further information.




Figure RD-26: Landing Gear Indication

RD 2. Reversionary Modes

Review the tables and notes in Section 4 Reversionary Modes for more information.

RD 2.1. PFD (Round Dials) Failure Mode 0



**Figure RD-27: PFD (Round Dials) Failure Mode 0
GPS, ADC, and AHRS Normal**

RD 2.2. PFD (Round Dials) Failure Mode 1



**Figure RD-28: PFD (Round Dials) Failure Mode 1
GPS/SBAS Failed; ADC and AHRS Normal**

RD 2.3. PFD (Round Dials) Failure Mode 2 (Normal Mode)





Figure RD-29: PFD (Round Dials) Failure Mode 2 (Normal Mode) ADC Failed; GPS/SBAS and AHRS Normal

RD 2.4. PFD (Round Dials) Failure Mode 3



Figure RD-30: PFD (Round Dials) Failure Mode 3 AHRS Failed; GPS/SBAS and ADC Normal

RD 2.5. PFD (Round Dials) Failure Mode 4




**Figure RD-31: PFD (Round Dials) Failure Mode 4
GPS/SBAS and ADC Failed; AHRS Normal**

RD 2.6. PFD (Round Dials) Failure Mode 5




**Figure RD-32: PFD (Round Dials) Failure Mode 5
GPS/SBAS and AHRS Failed; ADC Normal**

RD 2.7. PFD (Round Dials) Failure Mode 6



**Figure RD-33: PFD (Round Dials) Failure Mode 6
ADC and AHRs Failed; GPS/SBAS Normal**

RD 2.8. PFD (Round Dials) Failure Mode 7



**Figure RD-34: PFD (Round Dials) Failure Mode 7
GPS/SBAS, ADC, and AHRs Failed**

RD 3. PFD Declutter (DCLTR) Menu

PFD declutter menu items are as shown in Table RD-2. For additional information on PFD declutter options and features, see Section 5 Menu Functions and Procedures.

Table RD-2: PFD Declutter Options and Features	
Declutter Options	Round Dials Configuration
Single Cue Flight Director	✓
Dual Cue Flight Director	✓
METERS	✓


RD 4. Quick Reference

PFD



Press **BARO (R2)** and scroll **1** to desired QNH and push to enter.

Scroll **1** to proper setting and push to enter value.




Active waypoint information, including waypoint type and identifier; elevation or crossing altitude; and bearing and distance are displayed below the analog AGL indicator as configured.



Indicated airspeed on the left, altitude on the right, and heading on the bottom if there is no heading detected on the ND. A G-Meter is located below the airspeed indicator. FMS/VLOC CDI is located on the bottom. The VSI is located below the altimeter.

RD 4.1. XFILL SYNC Operation

- 1) During crossfill inhibited operation, **XFILL INHBT** appears on the PFD in the lower left corner.
- 2) When the pilot and co-pilot systems are not synchronized, **XFILL ARM** appears in lower left corner of the PFD.
- 3) When the pilot and co-pilot systems are not synchronized, press **MENU (R1)** then **XFILL SYNC (L1)** to synchronize the pilot and co-pilot active flight plan parameters to the other system from where the button press occurred.



INDEX

5

500 Foot Wake-Up Call 8-1, 8-16

A

Abbreviations and Acronyms.....2-1

About This Guide1-2

ADAHRS..... 2-1, 2-18, 2-21, 3-59, 5-38, 9-2 to 4

AGL Indication 3-8 to 9, RD-7

Air Data...2-1, 3-44, 3-59, 8-17, 8-24, 9-13, D-6, S-2, WX-6, WX-10

Aircraft Referenced.....7-9

Airport 1-4, 2-1, 3-1, 3-46, 8-3, 9-2, D-3, RD-1

Airspace.....2-8, 2-12, 4-3, 7-5

 Depiction 3-45 to 47

Airspeed

 Bug.....3-11 to 12, 5-2, RBP-2 to 4

 Display3-11, 3-15, RD-7

 Miscompare Threshold9-5

 True..... 2-7, 2-12, 3-45, 4-3, 7-11 to 12

Altimeter

 Menu 5-46 to 47

 Setting3-4, 9-2, RD-2

Altitude

 Aircraft Selected (ASEL)2-2

 Capture Predictor3-52

 Display 3-6, RD-4

 Minimum..... 3-7, 5-2, RD-6, RBP-2 to 4

 Miscompare Threshold 9-4 to 5

 Select Menu (ALT SEL)2-1

 Target..... 3-4, 5-2, RBP-4, RD-2 to 3

Analog AGL

 Indication.....3-9

 Indicator (ANLG AGL).....5-45

Analog Navigation Symbology	3-47, 3-51
Appendix	1-4, 2-48, 3-41, 3-60, 5-9, 5-51, 7-13, 7-19, 9-1
Approach	2-1 to 9, 2-31, 2-46, 3-31, 3-42, 3-62, 5-5, 7-1, 7-4 to 5, 7-10 to 13, 7-22 to 30, 7-36 to 40, 7-44, 7-47, 7-50, 7-53, 8-1 to 7, 8-13, 8-22, D-3
APPR	2-1, 6-5 to 6, 7-22, 7-27
APV.....	2-1, 7-5
ARM	3-32, 5-5, 7-6, 7-42, 7-46 to 48, 7-51
Atmospheric Perspective	3-1, 3-21, RD-1
B	
BACK.....	2-22, 3-3, 5-3, 5-13 to 15, 5-18
Bank Scale (BANK SCL).....	3-1, 3-28, 4-2, 5-3, 5-44 to 45, RD-1
BARO	2-2, 2-19, 3-3, 5-4 to 9, 5-40, 5-46 to 47, 6-1, 7-6, D-12, RD-1 to 2, RD-16, V-2
BARO-VNAV	7-5
Basic Mode....	3-1 to 2, 3-18 to 22, 3-27 to 30, 5-3, 5-44, 7-7, RD-1, RD-10
Blue	2-24, 3-47, 3-50, D-3
Borders.....	3-48 to 49, D-11
Brown	2-24, 3-49
BUGS	2-52, 5-8, 5-40 to 42, 7-4, 7-37
Button/Menu Functions	3-2 to 3, 5-1 to 3, 8-3, RD-16
C	
CENTER/ARC	5-52, S-4
Clock/Timers	
COUNT DN.....	5-38
STORE	5-37
Timer Indication	3-29
Zulu Time.....	3-45, 3-60 to 62, 5-37, 9-7, D-7, S-2, T-6, WX-6
Color Conventions.....	2-22
Compass Rose.....	3-43, 3-58, 4-3, T-4
CONT	2-2, 5-5, 7-6, 7-43, WX-6
Course Deviation Indicator (CDI)	2-2, 3-8, 3-31, RD-10
Scale.....	3-56 to 57, 7-24

CRS SYNC	5-29, 5-33
D	
Data Logging and Retrieval	9-7
Database	
Jeppesen.....	1-4, 2-7, 2-49, 2-52, 3-25, 9-7
NavData	2-19, 2-49 to 52, 3-37, 5-3, 7-2 to 4, 7-12, 7-30, 9-7, 9-10, RBP-5
Obstruction.....	2-21, 2-49 to 53
Terrain.....	2-52, 8-20
Datalink...2-19, 2-28, 3-2, 3-41, 3-47, 3-60, 5-1, 5-4, 5-51, D-1 to 16	
DCLTR.....	2-3, 3-45, 5-8, 5-43 to 45, 5-53 to 55, D-13 to 15, T-8, RD-16
DCND	2-3, 5-43
Dead Reckoning	2-3, 2-43, 4-7, 7-20
Decision Height (DEC HT).....	2-3, 2-42, 3-10, 5-2 to 3, 5-43, 7-49, RBP-2 to 4
DELETE	5-15, 5-18, 5-25, 6-4
Demonstrator	2-52
Density Altitude.....	3-44, 4-3
Departure.....	2-3, 2-9 to 11, 2-31, 3-32, 3-63, 7-4, 7-22 to 31, 8-3 to 7, 8-22, 9-2
DESIG.....	2-3, 5-8 to 11, 6-3
DG Mode	3-16, 5-40, RD-9, T-3
Direct	2-3, 5-4, 5-25 to 27, 6-2, 7-37, 9-17
Menu	5-35 to 36
Direct-To.....	3-52, 7-13, 7-18 to 22
Discontinuity	3-64, 5-25, 5-35, 7-13 to 14, 7-18 to 22, 7-27 to 29
DISCONT	3-63
Display Symbology ..3-1, 3-41, 8-3, 8-20, D-6 to 7, RD-1 to 11, S-2, T-4, WX-6 to 8	
DME.....	2-2 to 4, 2-13, 3-46, 3-55, 3-58, 7-12 to 15, 7-50, 9-7 to 9, 9-12
DONE	5-39, 5-45, 5-55
DP .2-3, 3-40, 3-53, 3-63, 7-2 to 4, 7-12 to 14, 7-20, 7-29, 7-32, 8-4	

E

EFIS Training Tool (ETT)	1-4, 2-4, 2-53, 9-9 to 10
EFIS/FMS Description	1-1
Encoder Functions	3-3, V-1
Enroute	2-31, 3-31, 3-47, 7-22 to 24, 8-4 to 6
Estimated Time Enroute (ETE)	2-4, 3-64
Estimated Time of Arrival (ETA).....	2-4, 3-64
EXIT	2-20 to 22, 3-3, 5-3, 5-13 to 20, 5-27, 5-32, 5-43 to 45,5-55, 6-3
EXPAND CAS	2-44

F

FAF....	2-4, 3-62 to 63, 7-2, 7-14, 7-28, 7-38, 7-42, 7-46 to 48, 7-51,8-9
FAULTS.....	2-28, 4-7, 5-9, 5-19, 5-48 to 50, 7-29, S-5, T-8, WX-10
FAWP	2-4, 2-46, 2-50, 3-31, 4-8, 7-2, 7-14, 7-23 to 29
Field of View	2-5
FOV Indication	3-54
Zoom Mode.....	5-3, D-16
ZOOM ON/ZOOM OFF	5-8
Flight Path Marker... ..	2-5, 2-44, 3-1, 3-18 to 21, 3-26 to 27, 4-2 to 4,RD-1
Flight Plan	
Activate	5-13, 6-3
Active (ACTV)	2-1, 3-53, 4-3, 5-2 to 5, 5-8, 5-21 to 27, 6-4 to 6,7-1, 7-8, 7-32 to 37, 7-41, 7-45, 7-51, D-11 to 16, RBP-4,S-3 to 4, T-5, V-2, WX-4
Create	6-3
CREATE-EDIT	5-12 to 19, 6-3
Delete	5-15
Edit.....	5-14
FPL	2-5, 5-4 to 19, 6-3, D-12
Reverse	5-14
Flight Planning.....	9-1, 9-9
FLT TIME	5-38

FLTA 2-4, 2-25, 2-34, 2-40, 2-44, 2-48, 3-23, 3-49, 8-1 to 8,
 8-22 to 27, WX-1

FMS ...2-4, 2-16 to 18, 3-30 to 34, 3-55 to 58, 3-63, 5-2, 5-30 to 31,
 5-51, 6-2 to 4, 7-3, 7-7, 7-39, 7-49, 7-53, 9-9, D-16, RBP-4,
 RD-16

FORMAT..... 5-52, 5-55, D-13 to 15, S-4 to 5, T-7, V-3 to 4, WX-9

Fuel Remaining 3-62, 3-65

G

General Arrangement2-21

Geodesic Path7-20

Geo-Referenced Backward/Forward7-9

Glideslope...2-5, 2-24, 2-30, 2-35, 3-34 to 36, 3-56, 8-1, 8-16 to 18,
8-24

GPS ...2-5, 2-20 to 22, 2-30 to 32, 2-35, 2-38 to 39, 2-42 to 46, 3-8,
3-17, 3-28, 3-31 to 39, 3-45, 3-50, 3-53 to 55, 3-59 to 62, 4-1,
 ..4-4 to 16, 5-19 to 20, 5-48 to 50, 7-1, 7-5 to 7, 7-12, 7-20 to 27,
 ... 7-30, 7-44, 7-53, 8-3 to 9, 8-13, 8-17 to 24, 9-3 to 4, 9-7, 9-13,
D-11, RBP-2, RD-12 to 15, S-3 to 4, T-4 to 5

ALMANAC.....5-49

Altitude 3-34, 7-19

FDE5-49

HPL5-49

LOI5-49

PWR.....5-48

SATLT5-49

VPL5-49

GPS/SBAS 2-21, 2-30 to 32, 2-35, 2-38 to 39, 2-42 to 46, 3-8,
 3-31 to 33, 3-36, 3-39, 3-45, 3-50, 3-53 to 55, 4-1, 4-4, 4-9 to 16,
5-19 to 20, 5-48 to 49, 7-5 to 7, 7-12, 7-19 to 24, 7-27, 7-30,
 8-3 to 9, 8-13, 8-17 to 24, D-11, RD-12 to 15, S-3 to 4, T-5

Default GPS/SBAS Navigation Modes7-22

GPWS.....2-5, 2-24 to 25, 2-30, 2-39 to 40, 2-45, 2-48, 8-1 to 2,
 8-10 to 17, 8-22 to 24

Gray2-23, D-2, WX-5

Groundspeed 2-31, 2-35, 3-44 to 45, 3-59, 3-62, 4-3, 8-6, D-6,
 S-2, WX-6

H

Heading		
Display	3-15, RD-8	
HDG UP/N UP	5-52	
North Up	WX-1	
Up	3-43	
Heading Bug.....	3-16, 3-33, 5-2, 7-49, D-16, RBP-1, RBP-4, (HDG) Menu	5-31 to 32
Hidden Surface Removal Technique	3-22, 3-38 to 40, 7-7	
Highway in the Sky (HITS)	1-1, 2-6, 3-21, 3-36 to 37, 4-2 to 4,	7-6 to 11, RD-1
HOLD	3-58, 7-2	
Holding Pattern.....	7-12 to 13, 7-17	

I

IAP	2-6, 7-12, 7-27	
IAS.....	2-6, 2-52, 3-11, 4-3, 5-40 to 43, 7-38	
IFR		
APPR	6-5, 7-3, 7-37, 7-41, 7-45, 7-51	
Procedures	3-36, 3-59, 5-21, 7-1, 7-4	
ILS	2-6, 5-29, 5-33 to 34, 7-5, 7-27, 7-30, 7-36 to 37, 7-48 to 49,	8-1, 8-16 to 18, 8-23 to 24
CONFIRM ACTIVATE	5-33	
INFO.....	2-6, 5-4 to 11, 5-17, 5-20, 5-23 to 30, 5-34 to 36, 9-9,	D-3, D-12 to 13, V-2
inHg/mbar	2-6 to 8, 2-43, 3-3 to 4, 5-46, 9-2	
Initialization.....	2-17, 2-52	
International Standard Atmosphere	2-6, 3-44	
Introduction.....	1-1, 3-1	

L

Latitude/Longitude.....	2-7, 2-35, 3-23, 3-42, 5-15, 5-28	
LNAV	2-7, 2-50, 3-32 to 34, 3-63, 4-7 to 8, 5-5, 7-5 to 7,	7-23 to 27, 7-53
Approach	2-44, 7-22	
LNAV/VNAV	2-50, 3-34, 4-7 to 8, 7-5 to 6, 7-23 to 26, RBP-3	

Approach..... 2-44, 7-22

Log Files9-9

LON 2-7, 3-23, 3-36, 3-39, 3-57, 4-7, 5-16, 5-55, 8-17

LP 2-7, 2-50, 3-34, 7-5, 7-23 to 26, 7-53

 Approach..... 2-44, 7-22

LPV2-7, 2-50, 3-34 to 35, 7-5 to 6, 7-23 to 26, 7-30, 7-44 to 46

 Approach..... 2-44, 7-22

M

Magnetic Course7-18

Map.....3-39, 4-2, 5-3, 5-44, T-8, V-5

 Basic Moving.....3-41

 Mini..... 3-21, 3-38 to 39

 Moving..... 3-41 to 42, WX-1

 Page..... D-16, RBP-5, WX-11

Marker Beacon 2-22, 3-29, 3-58 to 59, RD-10

Menu

 Function Types5-3

 Synchronization 5-1, D-15, RBP-4, S-5, T-8, V-5, WX-11

MENU 1-3, 5-4, 5-7, 5-11, 5-38 to 39, 5-42, 5-45, 5-50 to 52,
 5-55, 6-3, 6-6, 7-38, 7-42, D-15, RD-17

Metric Display METERS 5-45, RD-16

MFD1-3, 2-8, 2-15 to 20, 2-24, 2-33, 3-1 to 3, 3-24, 4-5 to 16,
 5-1 to 5, 5-9 to 18, 5-26, 6-2 to 6, 7-38, 7-52, 8-3,
 9-10, D-14 to 16, RBP-5, RD-1, T-7 to 9, V-1 to 5, WX-9 to 11

 Fault Display 5-48 to 50, D-15, S-5, T-8, WX-10

 ND Page Format 5-52 to 55

 Page..... 5-11, 5-50 to 51, D-13 to 15, S-4 to 5, T-7, V-3

Minima 7-30, 7-44

Minimums (MINS).....2-42, 3-7, 5-40 to 43, 7-46, 7-52, D-3

MISS 5-5, 7-6

Modes

 Mode 04-1, 4-9, RD-12

 Mode 1 ... 2-25, 2-39, 2-48, 4-1, 4-10, 8-1 to 2, 8-10 to 11, RD-12

Mode 2	2-25, 2-31, 2-48, 4-1, 4-11, 8-1 to 2, 8-11 to 13, RD-13
Mode 3	2-40, 2-48, 4-1, 4-12, 8-1 to 2, 8-13 to 14, RD-13
Mode 4	2-31, 2-40, 2-48, 4-1, 4-13, 8-1 to 2, 8-14 to 15, RD-14
Mode 5	2-24, 2-30, 2-45, 2-48, 4-1, 4-14, 8-1 to 2, 8-16 to 17, 8-22 to 24, RD-14
Mode 6	4-1, 4-15, RD-15
Mode 7	4-1, 4-16, RD-15
Mute	8-17

N

Navigation Data	2-50, 3-45
Navigation Log	3-41, 3-62, 5-51 to 52
Distance Column	3-64
Estimated Time Enroute Column	3-64
Estimated Time of Arrival Column	3-64
ETE/ETA	3-61
Fuel Remaining Column	3-65
Path Column	3-63
VNAV Offset Column	3-63
Waypoint Identifier Column	3-62
NDBs	2-23, 2-49, 3-46, 5-24, 5-32, 5-52
Nearest (NRST) Menu	2-9, 3-52, 5-4 to 12, 5-23 to 24, 5-27, 5-32 to 34, 6-3 to 4, 7-30, 7-47 to 49, 9-2, D-3, D-13, V-2
NIMA GEOMAG	7-19
NO RESULTS	5-24, 5-32
Normal/Essential	9-8, T-3, T-6 to 8
NRST ILS	5-33, 7-30, 7-47 to 49

O

Obstruction	2-3, 2-25, 2-34, 2-48 to 50, 3-23 to 25, 8-3, 8-26 to 27, RD-1
OFF	5-5 to 8, 5-16, 5-23, 5-33, 5-37 to 38, 5-43, 7-42, D-12 to 13, S-4, T-7 to 8, WX-6 to 10
Olive	2-23, 3-49

Omnibearing Selector (OBS).....	2-9, 2-18, 2-45, 3-33, 3-36, 3-53 to 55, 5-2 to 9, 5-30 to 34, 7-6 to 7, 7-42, 7-49, D-11 to 12, RBP-2 to 4, S-3 to 4, T-5, T-8
AUTO	5-31
Manual	6-4
Menu	5-30 to 31
SYNC	5-30, 6-4
Operation - FROM	7-11
Outside Air Temperature	2-9, 3-44
Ownship Symbol.....	3-39 to 41, D-5, T-2

P

PAGE.....	5-9, 5-51 to 52, 5-55, 7-38, D-15, S-5
Pan Mode	3-51, 5-5 to 6, 5-11, D-12, V-2
PAN ON/PAN OFF.....	5-52, D-13
Parallel Offsets	7-20
PDA	2-9, 2-40, 8-1 to 2, 8-9 to 10, 8-22
PFD.....	1-3, 2-9, 2-15 to 24, 2-33, 3-1 to 3, 3-6 to 9, 3-15 to 25, 3-28 to 30, 3-36 to 40, 3-52 to 58, 4-2, 4-5 to 16, 5-2 to 13, 5-26,5-32, 5-38 to 47, 6-1 to 6, 7-4, 7-7, 7-27, 7-37 to 38, 7-42, 8-1 to 3, 8-8, 8-17, 8-24 to 27, 9-3 to 4, 9-10, D-11, D-16, RBP-4 to 5, RD-1, RD-4 to 7, RD-12 to 17, S-4 to 5, T-2, T-5, T-8 to 9, V-5, WX-11
Background.....	3-21
Declutter.....	5-43 to 45, 8-25, RD-16, T-8
Symbology	3-6, RD-5
Pitch Scale.....	3-17, 4-2
Nadir Symbol	3-18
Zenith Symbol	3-18
Popup	8-8 to 9
Procedure Turn.....	2-9, 7-16, 9-10
Projected Path	3-52 to 53, 4-3
PTK.....	2-10, 3-63, 5-23, 7-21

Q

QFE	2-10, 2-43, 3-3 to 4, 5-46
-----------	----------------------------

QNE.....	2-10, 3-4, 5-46 to 47
QNH	2-10, 3-3 to 4, 5-46 to 47, 6-1, 8-19, RD-16
Quick Start Tutorial	6-1

R

RAIM	2-10, 5-10
CALC	2-2, 5-20
Prediction.....	5-19 to 20
Range.....	2-29, 2-48, 3-23, 3-54, 3-61, 4-3, 5-49, 8-5, 9-13, D-3, D-10, S-2, T-4, WX-3 to 5, WX-10
Remote Bugs Panel (RBP)	2-10, 5-1, 7-37, RBP-1, RBP-4
Required Navigation Performance (RNP).....	2-10, 2-45, 2-49 to 50, 3-34, 5-49, 7-14, 7-24 to 27, 9-13
Automatic (AUTO)	5-31, 7-29
Manual (MAN).....	2-19, 5-31, 7-29
Reversionary Modes	4-1 to 2, RD-11
RNAV	2-10, 7-4 to 5, 7-13, 7-27, 7-30, 7-44
DPs	2-49
Runway (RW).....	2-11, 2-50, 3-40, 4-2, 5-2, 5-28, 6-5 to 6, 7-34, 8-21, D-16

S

SAVE.....	5-12 to 18, 5-22, 5-27, 6-3
SBAS.....	2-11, 2-31 to 32, 2-38 to 39, 2-42, 2-45, 3-53, 4-6 to 8, . 5-19 to 20, 7-5, 7-20, 7-25 to 26, 8-4, 8-19, 8-24, D-11, S-4, T-5
HLTH	5-49
MSG.....	5-49
Search Envelope.....	8-5
Skyway	2-23, 3-36, 5-3, 5-44, 7-7
STAR.....	2-12, 3-40, 3-53, 3-63, 7-2 to 4, 7-12, 7-30, 7-33 to 34, 8-4
Start Point.....	3-52
STD	5-47
Strikes	2-12, 3-41, 5-1, 5-51 to 53, D-7 to 9, S-1 to 3
SYMB DCLTR	5-52
SYNC	2-12, 5-32, 5-43, V-1
System Overview	2-1, 2-15, 9-2

T

Terminal..	2-12 to 13, 2-31, 2-46, 3-31 to 32, 3-46, 3-63, 7-22 to 24,	7-33, 8-4 to 6, 8-22, 9-13
Terrain	2-4, 2-12, 2-25, 2-40, 2-52, 3-1, 3-21 to 24, 3-45,	3-49 to 51, 4-2 to 3, 5-3, 5-53, 8-1 to 3, 8-6 to 8, 8-11 to 15, 8-20 to 27, 9-1, 9-13, RD-1
Terrain and Obstruction Rendering	3-21 to 24, 3-38 to 40,	3-50, 7-7, 8-8
Too Low		2-40, 8-15
Top of Descent (TOD)		2-12, 3-35, 3-52
Top-Level Menu		5-4 to 5
Automatic Pop-Up		D-12, V-2
Traffic	2-2, 2-9 to 13, 2-16, 2-26, 2-39, 2-48, 3-2, 3-8, 3-21, ..3-39 to 41, 3-60, 4-2 to 3, 5-1, 5-4, 5-51 to 53, 9-13, RD-6, S-5,	T-1 to 9
TRANS ALT		5-47
Transmit Enabled		2-16, 4-3
TSO		2-13, 3-33, 7-5 to 7, 8-1 to 3, 9-13

U

Unusual Attitude Mode	3-18 to 22, 3-27 to 29, 3-34, 3-38 to 39,	7-7, RD-9, T-1
Upload		9-10
USB		1-2, 2-13, 2-51 to 52, 9-7 to 11

V

Vertical Deviation Indicator (VDI) ..	2-13, 3-21, 3-34 to 36, 3-56, 7-6	
Vertical Speed Indicator (VSI) .	2-6, 2-14, 2-22, 2-26, 2-47, 3-7 to 8,	4-2, 5-2, 5-40 to 42, 6-2, 8-8, 8-23, 9-6, D-11, RBP-2 to 4, RD-6, RD-16, T-2 to 4
VFR.....	1-1, 2-14, 2-23, 2-31, 2-46, 3-40, 3-46, 3-53, 3-63, 5-16, . 5-52 to 53, 6-5, 7-1 to 4, 7-10 to 12, 7-20 to 23, 7-27 to 28, 8-4,	8-19, 8-22, 9-9, D-3
Video.....		1-4, 2-21, 3-41, 5-1, 5-51, V-1 to 5
VNAV	2-14, 2-23, 2-42, 2-46 to 47, 2-50, 3-5 to 7, 3-34 to 38,3-52 to 53, 3-56, 3-63 to 65, 5-2, 5-5, 5-26, 7-1 to 2, 7-7 to 11,	7-26, 7-35, 9-1, D-11, RD-5, RBP-3 to 4, T-4
CDA.....		5-40 to 43

Sub-Mode	3-5, RD-3
VOR.....	2-14, 2-18, 2-23, 2-49, 3-38 to 39, 3-46, 3-51, 3-57, 4-5, 5-10 to 12, 5-24, 5-27, 5-31 to 33, 5-53 to 55, 6-3 to 4, 7-19,7-50, 9-9, 9-12, RBP-2
DME.....	7-30
VTF.....	2-14, 3-31, 7-23 to 24, 7-27 to 28
W	
WAAS.....	2-14, 7-5, 7-45, 9-13
Warnings, Cautions, and Advisories	1-3, 2-24, 9-2
Water.....	3-50
Waypoint	2-4 to 8, 2-13 to 14, 3-46, 3-60 to 65, 5-20, 6-3 to 4, 7-1, 7-10 to 15, 7-21, 9-9, S-3, T-7, WX-8
Active	3-21, 3-37, RD-3
ADD	5-12, 5-23, 6-3
APP.....	2-1, 3-63, 7-3
Create User	5-15 to 16
Create User (LAT-LON).....	5-15
Create User (RAD-DST).....	5-16
Delete User.....	5-18
Edit User	5-17
Fly-By.....	7-13 to 14
Fly-Over	7-12
Identifier	3-37, 3-62 to 65
INSERT.....	5-23, 5-27, 5-34, 6-4
MA	2-7, 3-63
MAHWP	2-7, 2-50
MAWP.....	2-8, 2-50, 7-23, 7-28, 7-39, 7-42, 7-49
NO RADIUS.....	7-3
OFLY/AUTO	7-2
OVERFLY	7-3
Overfly User.....	5-11 to 12
Phantom	7-13
Pointer	4-2 to 3

Routes and User	9-10
Sequencing	7-11
USER WPT	5-11, 5-16 to 18, 6-3
WGS-84	2-49, 7-15 to 19
Wind.....	3-44, 4-3
WX-RDR	5-51
X	
XFILL SYNC	5-7 to 8, 6-6, RD-17

Glossary

AGL Indication (Rad Alt, GPS Alt, Baro Alt) – Display of altitude above the ground, with designation of the altitude source as R (radio altitude), G (GPS WAAS geodetic altitude less local ground elevation), or B (barometric altitude less local ground elevation).

Air Data and Groundspeed – Display of density altitude, outside air temperature, ISA temperature deviation, true airspeed, and ground speed.

Airspeed Information – Display of airspeed is the indicated airspeed tape and airspeed readout with associated data. The airspeed function includes color-coded caution bands for minimum and maximum speeds based on V-speeds set in the EFIS limits.

Altitude Information – Display of altitude information is the altitude tape and altitude readout.

Approach Mode Signal Output – Conventional autopilot approach mode signals are course error output, the left/right deviation signal (localizer output) and the up/down deviation signal (glideslope output). Signals are based on the selected ILS source.

Attitude Information – Display of attitude information includes pitch and roll. The bank angle scale may be set to auto-declutter by the pilot when the bank angle is less than 2.8°. The pitch ladder is limited to $\pm 10^\circ$ from the flight path marker or aircraft waterline, whichever is greater. The unusual attitude display appears when the aircraft pitch exceeds $\pm 30^\circ$ or bank angle exceeds 65° (fixed wing) or 50° (rotorcraft).

Autoset – Automatically selects features or settings.

Azimuth – Angle between the north vector and the perpendicular projection of the star down onto the horizon. Usually measured in degrees ($^\circ$).

Barometric Altimetry – Measurement of altitude based on the atmosphere (pressure and temperature).

Barometric Correction – Display and altitude correction for local barometric pressure.

Bezel – Faceplate of the IDU comprised of pushbuttons along the pushbuttons along the sides and rotary encoders along the bottom.

Chroma – Colorfulness relative to the brightness.

Conformally – Angle-preserving. Example: Traffic appears conformally on the PFD.

Course Deviation Indicator – Display of course deviation from selected course, including a To-From indicator.

Critical Flight Phase – Phase(s) of flight where the failure mode would result in a hazard condition using flight phases. For example, failure of ILS would only be a hazard condition during approach and landing.

Crossfill – Transfer of data and information between IDUs in a dual system with two PFDs configured.

Cross-linked – Synchronized across both EFIS systems.

Datalinked – Display of received data such as weather or traffic from peripheral systems such as WSI or ADS-B.

dBZ – Decibel relative to radar reflectivity (Z). Composite reflectivity shows the highest dBZ (strongest reflected energy) at all elevations. Unlike base reflectivity, which only shows reflected energy at a single elevation scan of the radar, composite reflectivity displays the highest reflectivity of ALL elevations scans. If there is heavier precipitation in the atmosphere over an area of lighter precipitation (i.e. rain has yet to reach the ground), the composite reflectivity displays the stronger dBZ level.

Deadband – Neutral zone where no action or changes are made.

Directional Scale (Compass Rose or Arc) and Ownship Symbol – Display of general directional information. All MFD pages include a form of the compass rose with current heading pointer and aircraft “ownship” symbol.

Discrete – A logic input or output that identifies a condition or status of or for an ancillary system. Discrettes are defined by the operating software or settings programmed specifically for the aircraft.

Display of ADF – Display of single ADF bearing information in the form of an RMI needle.

Display of Glideslope – Display of Glideslope 1 or Glideslope 2 in the form of vertical deviation dots and deviation on PFD or MFD HSI page.

Display of Lightning Cell Information – Display of lightning information from a WX-500 system and shown in the form of lightning cells. The pilot may show individual lightning strike data by selecting the dedicated WX-500 page.

Display of Localizer – Display of Localizer 1 or Localizer 2 in the form of horizontal deviation dots and deviation.

Display of Marker Beacon – Display of outer, middle, and inner marker beacons in the form of a color-coded circle with the corresponding letter (O, M, I).

Display of Traffic Information – When integrated with an appropriate traffic system, the PFD and MFD display traffic information in two formats. One format is via traffic symbols as shown on the PFD and MFD Map page and Traffic page. The second format is with the traffic pop-up thumbnail display showing traffic position in a full 360° format on the PFD.

Display of VOR RMI – Display of VOR1 and VOR2 bearing in the form of RMI needles.

Dot – (CDI scale referenced) represents an additional 2° for VOR and 1.25° for Localizer.

EFIS-Coupled – The EFIS is coupled to an autopilot and controls the lateral and vertical modes of the autopilot.

Failure Condition Hazard Description – A description of the failure mode to be analyzed.

Flight Director (Selectable Function) – Display of flight director in a single or dual cue format when selected for display on the PFD.

Flight Path Marker (Velocity Vector) – Display of aircraft's actual flight path, showing where the aircraft is going as opposed to where the aircraft is pointed.

Flight Plan and Navigation Display – Display of the active GPS WAAS/SBAS-based flight plan, including course line, waypoints, ground track, glide range, projected path, altitude capture predictor, approach procedure, missed approach procedure, and the aircraft present position on the active leg.

Geodetic – Set of reference points used to locate places on the earth.

Geoid – Global mean sea level.

G-Force and Fast/Slow Indicator – Indications to show the G-force on the aircraft or, for aircraft equipped with a compatible angle of attack computer, the deviation from the reference speed while in the landing configuration.

Glideslope Sidelobes – False glideslope signals.

GPS WAAS Course Deviation Indicator (CDI) – Display of CDI relative to selected course, either automatic based on active flight plan or manual based on pilot-selected OBS.

GPS WAAS Functions – The EFIS meets the GPS WAAS navigation and flight planning/management requirements of TSO-C146a (RTCA/DO-229D) for Class Gamma 3 equipment. These functions include navigation, flight planning (function select, flight plan generation and editing, selected waypoints, user waypoints, etc.), path definition including approach and departure paths, GPS altitude, dead reckoning, navigation modes with automatic mode switching, loss of navigation monitoring, loss of integrity monitoring, etc. The database used with the GPS WAAS functions meets the integrity requirements of RTCA/DO-200A.

Heading Bug – Display and control of selected heading using a bug. May be used to drive heading bug output to autopilot for HSI-based heading mode.

Heading Display – Display of heading with directional scale is provided at the top of the PFD. This is the same heading information provided on the MFD.

Heading Mode Signal Output – Conventional autopilot heading mode signal is a heading error output based on the difference between the EFIS desired heading and the actual aircraft heading. The EFIS desired heading is either the pilot-selected

heading bug or a heading designed to achieve and maintain the active GPS-based flight plan.

Hectopascal (hPa) – International System of Units (SI) unit measure of pressure, equals one millibar (mbar).

HeliSAS – Genesys Aerosystems' helicopter autopilot and stability augmentation system.

Horizontal Situation Indicator (Selectable Function) – Display of VOR or localizer and glideslope deviation when selected for display on the PFD.

Hover Vector Display (Rotorcraft Only) – Display of hover drift in a rotorcraft installation when the helicopter is traveling less than 30 knots airspeed.

Inches of Mercury (inHg) – Unit of atmospheric pressure used in the United States. Named for the use of mercurial barometers which equate height of a column of mercury with air pressure.



Inhibit – Prevention of activity or occurrence. Examples are:

XFILL INHBT, **TAWS INHBT**, and **TAS INHBT**.

Integrated Peripherals – Internal devices of the essential unit.

Intelliflight – Genesys Aerosystems' digital autopilot.

Ionosphere – Region of the atmosphere between the stratosphere and exosphere, 50 to 250 miles (80 to 400 km) above the surface of the earth.

International Standard Atmosphere (ISA) – Standard model of the change of pressure, temperature, density, and viscosity over a wide range of altitudes or elevations.

Landing Gear Indication – When enabled on retractable landing gear aircraft, PFD shows indication of landing gear extended.

Lubber Line – Line marked on the compass showing the direction straight ahead.

Mach Display – Display of Mach number when the aircraft is traveling at or above 0.35 Mach. This function may be deselected by a setting in the IDU configuration (limits) file.

Magnetic Declination (MAGVAR) – Sometimes called magnetic variation; the angle between magnetic north and true north.

Map Data – Display of map data, including airspace, VFR/IFR airports, VHF nav aids such as VOR/NDB/DME, jet/victor airways, and display range rings.

Menu Functions – The EFIS includes menus to access functions on both the PFD and the MFD.

Mesocyclonic – Contains a vortex of air within a convective; air rises and rotates around a vertical axis, often in the same direction as low pressure systems.

Millibar (mbar) – Metric (not SI) unit of pressure, one thousandth of a bar (which is about equal to the atmospheric pressure on Earth at sea level - 1013 millibars).



Miscompare – Disparity of data or information. Examples are:

ALT MISCOMP,	ATT MISCOMP,	GPS MISCOMP,
GS MISCOMP,	HDG MISCOMP,	IAS MISCOMP,
LOC MISCOMP,	PLT MISCOMP,	RALT MISCOMP,
	CPLT MISCOMP,	and BARO MISCOMP.

NavData – Jeppesen's aeronautical database to navigate the global airspace system.

Navigation Data Display – Display of active waypoint, bearing to waypoint, and ground track based on active flight plan. The pilot may also select flight plan information as a mini-map (thumbnail map). These functions are analyzed as part of the GPS WAAS functions not the PFD functions.

Navigation Log – Display of navigation information based on active flight plan, including next waypoint, destination, estimated time remaining, and fuel totalizer-based range and endurance. This function may be deselected by a setting in the IDU configuration (limits) file. These functions are analyzed as part of the GPS WAAS functions not the MFD functions.

Navigation Mode Signal Output – Conventional autopilot Navigation mode signals are the course error output and the left-right deviation signals. Course error output is based on the difference between the EFIS selected course (OBS) and the

actual aircraft heading. These signals are based on the selected navigation signal (VOR, GPS).

Nondirectional – Functions in all directions.

Noodle – Navigation Display (ND) Projected path; curving path based upon the aircraft bank angle and ground speed used effectively to assist in course interception and making small adjustments to bank angle for proper roll out.

Nanoteslas (nT) – A unit of measurement of the strength of the magnetic field. Earth's strongest magnetic field is located at the poles, and the weakest field is near the equator.

Obstructions Display – Display of obstructions identified in the embedded obstruction database which are within 8.5 NM of the aircraft present position. Non-threatening obstructions are displayed by color to identify altitude relative to the aircraft's current altitude (amber [yellow] < 2000' below, light red < 500' below, bright red = at or above aircraft). Threatening obstructions, defined as those that pierce the TAWS envelope, are identified by highlight when producing a caution and identified by flashing highlight when producing a warning. The database used with the obstruction functions meets the integrity requirements of RTCA/DO-200A.

Omnibearing – Magnetic bearing of an omni-range station.

Ownship – Principal eye-point; referring to icon of aircraft represented on display.

Pitch Limit Indicator – Appears when the aircraft (fixed wing only) is within 10 knots of stall speed, based on the VSI setting in the EFIS limits. The intent is to notify the pilot of a possible stall condition so corrective action is taken before the stall occurs. This function may be deselected by a setting in the IDU configuration (limits) file.

Q-Routes – Published RNAV routes, including Q-Routes and T-Routes, can be flight planned for use by the Genesys EFIS, subject to any limitations or requirements noted on enroute charts, in applicable Advisory Circulars, or by NOTAM. RNAV routes are depicted in blue on aeronautical charts and are identified by the letter "Q" or "T" followed by the airway number. E.g., Q35, T-205. Published RNAV routes are RNAV-2 except when specifically charted as RNAV-1.

QFE – Barometric setting that results in the altimeter displaying height above a reference elevation (e.g., airport or runway threshold).

QNE – Standard barometric setting (29.92 inHg or 1013 mbar) used to display pressure attitude for flight above the transition attitude.

QNH – Barometric setting that results in the altimeter displaying altitude above mean sea level at the reporting station.

Recency – State of occurrence, appearance, or origin.

Selection and Display of Selected Course – Omni-Bearing Select (OBS) function for the pilot to select the course for navigation. Selected course is displayed for reference.

Settable V-Speeds, Targets – The pilot may set certain V-speeds for reference during flight. In addition, the pilot may set certain information at any time for reference during flight, including target airspeed (with corresponding bug) and target altitude (with corresponding bug).

Side in Command – Side of aircraft control responsible for its operation.

Skipped Waypoint – A skipped waypoint is a waypoint associated with a dynamic termination leg with a zero length. These are either:

- 1) An altitude termination leg when current aircraft altitude is above the termination altitude; or
- 2) System-created (i.e., not NavData specified) intercept to a “Course to a Fix” leg where there is insufficient distance to calculate an intercept heading.

Skyway VNAV/LNAV Guidance (Synthetic Vision) – Display of GPS-based active navigation route, flight plan, procedure, or OBS course in a three-dimensional series of skyway boxes. Also known as Highway in the Sky and HITS.

Slip Indicator – Display of aircraft lateral accelerations via an integral slip/skid indicator function. The slip indicator is a rectangle just below the heading pointer that moves left and right to indicate the lateral acceleration sensed by the AHRS in the same manner as the ball in a mechanical slip indicator.

Strikefinder – Lightning detector system (WX-500) connected to EFIS and enabled through Factory Program settings.

Suppressed Waypoint – A suppressed waypoint (designated by brackets) is an airport associated with an IFR or VFR approach procedure.

Symbology – Use of symbols.

T-Routes – T-Routes are available for use by GPS or GPS/SBAS equipped aircraft from 1,200 feet above the surface (or in some instances higher) up to but not including 18,000 feet MSL. T-Routes are depicted on Enroute Low Altitude Charts and considered to include the same attributes of Low Altitude Airways in the Genesys Aerosystems EFIS Declutter menus.

Talker – IDU providing data to external sensors and generating aural alerts. IDUs depend upon intra-system communications to determine which IDU on a side takes over “Talker” responsibilities. Only one talker (transmit enabled) per side, two talkers in a two sided system, and a master talker PFD when considering aircraft limits. Any IDU may become a talker through auto reversionary means in the event of the PFD failing.

Terrain Display (PFD Artificial Horizon) – Conformal display of surrounding terrain presented with the artificial horizon, shown in the correct scale and perspective for the aircraft’s current position and altitude. Includes conformal display of known runway locations, direction, scale, and perspective based on aircraft’s current position and altitude.

Terrain Display and TAWS/HTAWS – Display of terrain, including identification and annunciation of threatening terrain in accordance with Terrain Awareness Warning System (TAWS) requirements. Coloring scheme for SVS-TAWS PFD and MAP has been simplified as follows:

Non-alerting Terrain below aircraft – Olive Shades

Non-alerting terrain above aircraft – Brown Shades

TAWS FLTA Caution Terrain – Amber (Yellow)

TAWS FLTA Warning Terrain – Red

Obstacles Below aircraft – Amber (Yellow)

Obstacles above aircraft – Red

When over water – Deep Blue

Threatening terrain is determined by the requirements of TAWS TSO-C151b (fixed wing) and TSO-C194 HTAWS (rotorcraft). Threatening terrain is shaded amber (yellow) for caution situations or shaded red for warning situations per TSO-C151b and TSO-C194. TAWS cautions and warnings are accompanied by an amber (yellow) or red flag and an aural annunciation. TAWS Class A, TAWS Class B, TAWS Class C, Enhanced HTAWS, or HTAWS functions may be activated in the system prior to installation. The database used with the TAWS functions meets the integrity requirements of RTCA/DO-200A.

Timer Indication – Pilot-selected function for a count-up or count-down timer.

Traffic Display – When integrated with an appropriate traffic system, traffic is shown using standard TCAS symbology showing relative position, altitude, climb/decent, and color. The pilot may also show traffic information by selecting the dedicated traffic display page.

Vertical Speed Display – Display of altitude rate of change (vertical speed or climb rate).

V_{PROC} (Procedure Speed) – The aircraft's normal speed (in Airspeed Units and configured in EFIS Limits) for flying instrument approaches (DPs, IAPs, STARs). This value is used for calculating the turn radius used for instrument procedure legs. This speed is not seen on the airspeed tape and only found in the aircraft speed settings inside the limits.

Warning, Caution, and Advisory Flags – Display of, warning, caution, and advisory indications accompanied by aural indications. The flags are stacked in the lower left corner of the PFD. Warnings are always shown at the top of the flag stack, followed by cautions and then advisories. These flags remain in view for as long as the situation exists.

Waterline – Indication of the aircraft's longitudinal axis or waterline (attitude).

Wide Area Augmentation System (WAAS) – Developed by Federal Aviation Administration to provide accurate positioning part of the Satellite Based Augmentation System (SBAS). Other

countries have similar systems: Europe: European Geostationary Overlay System (EGNOS); Japan: MTSAT Satellite-based Augmentation System (MSAS); India: GPS Aided GEO Augmented Navigation system (GAGAN).

Wind Information – Display of wind direction, wind speed, and cross wind component.

Zulu Clock, Timers – Display of Zulu time (based on GPS data) and pilot-selected timer.



IDU-450 Version 8.0E Pilot Guide (Fixed Wing)